

Cisco IOS Asynchronous Transfer Mode Command Reference

November 2010

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at www.cisco.com/go/trademarks. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

Cisco IOS Asynchronous Transfer Mode Command Reference
© 2009–2010 Cisco Systems, Inc. All rights reserved.

About Cisco IOS Software Documentation **xi**

Documentation Objectives	xi
Audience	xi
Documentation Conventions	xi
Typographic Conventions	xii
Command Syntax Conventions	xii
Software Conventions	xiii
Reader Alert Conventions	xiii
Documentation Organization	xiii
Cisco IOS Documentation Set	xiv
Cisco IOS Documentation on Cisco.com	xiv
Configuration Guides, Command References, and Supplementary Resources	xv
Additional Resources and Documentation Feedback	xxii

Using the Command-Line Interface in Cisco IOS Software **xxv**

Initially Configuring a Device	xxv
Using the CLI	xxvi
Understanding Command Modes	xxvi
Using the Interactive Help Feature	xxix
Understanding Command Syntax	xxx
Understanding Enable and Enable Secret Passwords	xxxi
Using the Command History Feature	xxxii
Abbreviating Commands	xxxiii
Using Aliases for CLI Commands	xxxiii
Using the no and default Forms of Commands	xxxiv
Using the debug Command	xxxiv
Filtering Output Using Output Modifiers	xxxiv
Understanding CLI Error Messages	xxxv
Saving Changes to a Configuration	xxxv
Additional Information	xxxvi

Introduction **ATM-1****Asynchronous Transfer Mode Commands** **ATM-3**

aaa authentication arap	ATM-4
abr	ATM-6
atm aal aal3/4	ATM-8
atm abr rate-factor	ATM-10
atm address-registration	ATM-11

atm arp-server	ATM-12
atm autovc retry	ATM-14
atm bandwidth dynamic	ATM-15
atm classic-ip-extensions	ATM-17
atm clock internal	ATM-19
atm compression	ATM-20
atm ds3-scrumble	ATM-21
atm e164 auto-conversion	ATM-22
atm e3-scrumble	ATM-23
atm enable-ilmi-trap	ATM-24
atm ether-mac-address	ATM-25
atm esi-address	ATM-27
atm exception-queue	ATM-29
atm framing (DS3)	ATM-30
atm framing (E3)	ATM-31
atm ilmi-keepalive	ATM-32
atm ilmi-pvc-discovery	ATM-33
atm lbo	ATM-34
atm max-channels	ATM-35
atm maxvc	ATM-37
atm mid-per-vc	ATM-38
atm multicast	ATM-39
atm multipoint-interval	ATM-40
atm multipoint-signalling	ATM-41
atm nsap-address	ATM-43
atm oam ais alarm	ATM-45
atm oam flush	ATM-46
atm oversubscribe	ATM-47
atm oversubscribe factor	ATM-50
atm over-subscription-factor	ATM-53
atm pppatm passive	ATM-55
atm pvp	ATM-57
atm rate-queue	ATM-60
atm rawq-size	ATM-62
atm rxbuff	ATM-63

atm sig-traffic-shaping strict	ATM-64
atm smds-address	ATM-65
atm sonet report	ATM-66
atm sonet stm-1	ATM-69
atm sonet threshold	ATM-70
atm svc-upc-intent	ATM-73
atm txbuff	ATM-75
atm tx-latency	ATM-76
atm uni-version	ATM-78
atm vc-per-vp	ATM-79
atm vp-filter	ATM-81
atm-address	ATM-83
atmsig close atm	ATM-84
bre-connect	ATM-86
bridge-domain	ATM-88
bridge-dot1q encap	ATM-92
broadcast	ATM-94
cbr	ATM-96
ces	ATM-98
ces aal1 clock	ATM-99
ces aal1 service	ATM-101
ces circuit	ATM-103
ces dsx1 clock source	ATM-106
ces dsx1 framing	ATM-107
ces dsx1 lbo	ATM-109
ces dsx1 linecode	ATM-110
ces dsx1 loopback	ATM-112
ces dsx1 signalmode robbedbit	ATM-113
ces partial-fill	ATM-115
ces pvc	ATM-117
ces-cdv	ATM-119
class-int	ATM-120
class-vc	ATM-122
clear atm arp	ATM-126
clear atm atm-vc	ATM-127

clear atm signalling statistics **ATM-128**
clear atm vc **ATM-129**
clear lane le-arp **ATM-130**
clear lane server **ATM-132**
clear mpoa client cache **ATM-134**
clear mpoa server cache **ATM-135**
clear pppatm interface atm **ATM-136**
client-atm-address name **ATM-137**
create on-demand **ATM-139**
dbs enable **ATM-141**
default-name **ATM-143**
dxi map **ATM-145**
dxi pvc **ATM-147**
encapsulation (ATM) **ATM-149**
encapsulation (Layer 2 local switching) **ATM-155**
encapsulation atm-dxi **ATM-157**
encapsulation untagged dot1q second-dot1q **ATM-158**
framer-type **ATM-159**
holding-time **ATM-160**
idle-timeout **ATM-161**
ilmi manage **ATM-163**
ima active-links-minimum **ATM-165**
ima autorestart **ATM-167**
ima clock-mode **ATM-169**
ima differential-delay-maximum **ATM-171**
ima frame-length **ATM-173**
ima-group **ATM-175**
ima restart **ATM-178**
ima test **ATM-179**
ima version **ATM-181**
inarp **ATM-182**
inarp-vc **ATM-184**
interface atm **ATM-186**
interface atm ima **ATM-188**
interface cbr **ATM-190**

keepalive-lifetime	ATM-191
keepalive-time	ATM-192
lane auto-config-atm-address	ATM-193
lane bus-atm-address	ATM-195
lane client	ATM-197
lane client flush	ATM-199
lane client mpoa client name	ATM-201
lane client mpoa server name	ATM-202
lane client-atm-address	ATM-203
lane config database	ATM-205
lane config-atm-address	ATM-207
lane database	ATM-210
lane fixed-config-atm-address	ATM-212
lane fssrp	ATM-214
lane global-lecs-address	ATM-215
lane le-arp	ATM-216
lane server-atm-address	ATM-218
lane server-bus	ATM-220
logging event atm pvc state	ATM-222
loopback	ATM-223
loopback (ATM)	ATM-225
mac-address (ATM)	ATM-226
map-class atm	ATM-228
mid	ATM-229
mpoa client config name	ATM-230
mpoa client name	ATM-231
mpoa server config name	ATM-232
mpoa server name	ATM-233
mpoa server name trigger ip-address	ATM-234
multiqueue	ATM-235
name elan-id	ATM-237
name local-seg-id	ATM-238
name preempt	ATM-240
name server-atm-address	ATM-241
network-clock-select (ATM)	ATM-243

network-id	ATM-245
oam-ac segment endpoint	ATM-246
oam ais-rdi	ATM-247
oam retry	ATM-249
oam retry cc	ATM-252
oam-bundle	ATM-254
oam-pvc	ATM-256
oam-pvc manage cc	ATM-259
oam-pvc manage cc deny	ATM-262
oam queue	ATM-264
oam-range	ATM-265
oam-svc	ATM-267
partial-fill	ATM-269
ping atm interface atm	ATM-270
pos flag s1-byte rx-communicate	ATM-273
pos flag s1-byte tx	ATM-274
protect	ATM-275
protocol (ATM)	ATM-278
pvc	ATM-282
pvc-bundle	ATM-286
qos-group (ATM VC bundle member)	ATM-289
retry (SVC)	ATM-291
scrambling cell-payload	ATM-293
scrambling-payload	ATM-294
selection-method	ATM-295
shortcut-frame-count	ATM-297
shortcut-frame-time	ATM-298
show aal2 xgcpspi	ATM-299
show atm arp-server	ATM-300
show atm class-links	ATM-302
show atm ilmi-configuration	ATM-303
show atm ilmi-status	ATM-304
show atm interface atm	ATM-306
show atm map	ATM-309
show atm pvc	ATM-313

[show atm pvc dbs](#) **ATM-324**
[show atm signalling statistics](#) **ATM-326**
[show atm svc](#) **ATM-328**
[show atm traffic](#) **ATM-334**
[show atm vc](#) **ATM-336**
[show atm vp](#) **ATM-345**
[show ces](#) **ATM-347**
[show ces circuit](#) **ATM-349**
[show ces interface cbr](#) **ATM-352**
[show ces status](#) **ATM-355**
[show controllers atm](#) **ATM-356**
[show dxi map](#) **ATM-360**
[show dxi pvc](#) **ATM-362**
[show dxi pvc interface](#) **ATM-364**
[show ima interface atm](#) **ATM-365**
[show interface cbr](#) **ATM-369**
[show interfaces atm](#) **ATM-373**
[show lane](#) **ATM-378**
[show lane bus](#) **ATM-382**
[show ima interface atm](#) **ATM-384**
[show lane client](#) **ATM-389**
[show lane config](#) **ATM-393**
[show lane database](#) **ATM-395**
[show lane default-atm-addresses](#) **ATM-397**
[show lane le-arp](#) **ATM-399**
[show lane neighbor](#) **ATM-401**
[show lane server](#) **ATM-403**
[show mpoa client](#) **ATM-406**
[show mpoa client cache](#) **ATM-408**
[show mpoa client statistics](#) **ATM-410**
[show mpoa default-atm-addresses](#) **ATM-411**
[show mpoa server](#) **ATM-413**
[show mpoa server cache](#) **ATM-415**
[show mpoa server statistics](#) **ATM-417**
[show network-clocks](#) **ATM-419**

show sscop	ATM-421
show svc	ATM-423
snmp-server enable traps atm pvc	ATM-425
snmp-server enable traps atm pvc extension	ATM-427
snmp-server enable traps atm pvc extension mibversion	ATM-431
sscop cc-timer	ATM-433
sscop keepalive-timer	ATM-434
sscop max-cc	ATM-435
sscop poll-timer	ATM-436
sscop receive-window	ATM-437
sscop send-window	ATM-438
svc	ATM-439
transmit-priority	ATM-441
tx-limit	ATM-444
ubr	ATM-446
ubr+	ATM-449
ubr+ cos	ATM-452
vbr-nrt	ATM-454
vbr-rt	ATM-458
vc-class atm	ATM-460

About Cisco IOS Software Documentation

Last Updated: November 20, 2009

This document describes the objectives, audience, conventions, and organization used in Cisco IOS software documentation. Also included are resources for obtaining technical assistance, additional documentation, and other information from Cisco. This document is organized into the following sections:

- [Documentation Objectives, page xi](#)
- [Audience, page xi](#)
- [Documentation Conventions, page xi](#)
- [Documentation Organization, page xiii](#)
- [Additional Resources and Documentation Feedback, page xxii](#)

Documentation Objectives

Cisco IOS documentation describes the tasks and commands available to configure and maintain Cisco networking devices.

Audience

The Cisco IOS documentation set is intended for users who configure and maintain Cisco networking devices (such as routers and switches) but who may not be familiar with the configuration and maintenance tasks, the relationship among tasks, or the Cisco IOS commands necessary to perform particular tasks. The Cisco IOS documentation set is also intended for those users experienced with Cisco IOS software who need to know about new features, new configuration options, and new software characteristics in the current Cisco IOS release.

Documentation Conventions

In Cisco IOS documentation, the term *router* may be used to refer to various Cisco products; for example, routers, access servers, and switches. These and other networking devices that support Cisco IOS software are shown interchangeably in examples and are used only for illustrative purposes. An example that shows one product does not necessarily mean that other products are not supported.

This section contains the following topics:

- [Typographic Conventions, page xii](#)
- [Command Syntax Conventions, page xii](#)
- [Software Conventions, page xiii](#)
- [Reader Alert Conventions, page xiii](#)

Typographic Conventions

Cisco IOS documentation uses the following typographic conventions:

Convention	Description
^ or Ctrl	Both the ^ symbol and Ctrl represent the Control (Ctrl) key on a keyboard. For example, the key combination ^D or Ctrl-D means that you hold down the Control key while you press the D key. (Keys are indicated in capital letters but are not case sensitive.)
<i>string</i>	A string is a nonquoted set of characters shown in italics. For example, when setting a Simple Network Management Protocol (SNMP) community string to <i>public</i> , do not use quotation marks around the string; otherwise, the string will include the quotation marks.

Command Syntax Conventions

Cisco IOS documentation uses the following command syntax conventions:

Convention	Description
bold	Bold text indicates commands and keywords that you enter as shown.
<i>italic</i>	Italic text indicates arguments for which you supply values.
[x]	Square brackets enclose an optional keyword or argument.
...	An ellipsis (three consecutive nonbolded periods without spaces) after a syntax element indicates that the element can be repeated.
	A vertical line, called a pipe, that is enclosed within braces or square brackets indicates a choice within a set of keywords or arguments.
[x y]	Square brackets enclosing keywords or arguments separated by a pipe indicate an optional choice.
{x y}	Braces enclosing keywords or arguments separated by a pipe indicate a required choice.
[x {y z}]	Braces and a pipe within square brackets indicate a required choice within an optional element.

Software Conventions

Cisco IOS software uses the following program code conventions:

Convention	Description
Courier font	Courier font is used for information that is displayed on a PC or terminal screen.
Bold Courier font	Bold Courier font indicates text that the user must enter.
< >	Angle brackets enclose text that is not displayed, such as a password. Angle brackets also are used in contexts in which the italic font style is not supported; for example, ASCII text.
!	An exclamation point at the beginning of a line indicates that the text that follows is a comment, not a line of code. An exclamation point is also displayed by Cisco IOS software for certain processes.
[]	Square brackets enclose default responses to system prompts.

Reader Alert Conventions

Cisco IOS documentation uses the following conventions for reader alerts:



Caution

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.



Note

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.



Timesaver

Means *the described action saves time*. You can save time by performing the action described in the paragraph.

Documentation Organization

This section describes the Cisco IOS documentation set, how it is organized, and how to access it on Cisco.com. It also lists the configuration guides, command references, and supplementary references and resources that comprise the documentation set. It contains the following topics:

- [Cisco IOS Documentation Set, page xiv](#)
- [Cisco IOS Documentation on Cisco.com, page xiv](#)
- [Configuration Guides, Command References, and Supplementary Resources, page xv](#)

Cisco IOS Documentation Set

The Cisco IOS documentation set consists of the following:

- Release notes and caveats provide information about platform, technology, and feature support for a release and describe severity 1 (catastrophic), severity 2 (severe), and select severity 3 (moderate) defects in released Cisco IOS software. Review release notes before other documents to learn whether updates have been made to a feature.
- Sets of configuration guides and command references organized by technology and published for each standard Cisco IOS release.
 - Configuration guides—Compilations of documents that provide conceptual and task-oriented descriptions of Cisco IOS features.
 - Command references—Compilations of command pages in alphabetical order that provide detailed information about the commands used in the Cisco IOS features and the processes that comprise the related configuration guides. For each technology, there is a single command reference that supports all Cisco IOS releases and that is updated at each standard release.
- Lists of all the commands in a specific release and all commands that are new, modified, removed, or replaced in the release.
- Command reference book for **debug** commands. Command pages are listed in alphabetical order.
- Reference book for system messages for all Cisco IOS releases.

Cisco IOS Documentation on Cisco.com

The following sections describe the organization of the Cisco IOS documentation set and how to access various document types.

Use Cisco Feature Navigator to find information about platform support and Cisco IOS and Catalyst OS software image support. To access Cisco Feature Navigator, go to <http://www.cisco.com/go/cfn>. An account on Cisco.com is not required.

New Features List

The New Features List for each release provides a list of all features in the release with hyperlinks to the feature guides in which they are documented.

Feature Guides

Cisco IOS features are documented in feature guides. Feature guides describe one feature or a group of related features that are supported on many different software releases and platforms. Your Cisco IOS software release or platform may not support all the features documented in a feature guide. See the Feature Information table at the end of the feature guide for information about which features in that guide are supported in your software release.

Configuration Guides

Configuration guides are provided by technology and release and comprise a set of individual feature guides relevant to the release and technology.

Command References

Command reference books contain descriptions of Cisco IOS commands that are supported in many different software releases and on many different platforms. The books are organized by technology. For information about all Cisco IOS commands, use the Command Lookup Tool at <http://tools.cisco.com/Support/CLILookup> or the *Cisco IOS Master Command List, All Releases*, at http://www.cisco.com/en/US/docs/ios/mcl/allreleasemcl/all_book.html.

Cisco IOS Supplementary Documents and Resources

Supplementary documents and resources are listed in [Table 2 on page xxi](#).

Configuration Guides, Command References, and Supplementary Resources

[Table 1](#) lists, in alphabetical order, Cisco IOS software configuration guides and command references, including brief descriptions of the contents of the documents. The Cisco IOS command references contain commands for Cisco IOS software for all releases. The configuration guides and command references support many different software releases and platforms. Your Cisco IOS software release or platform may not support all these technologies.

[Table 2](#) lists documents and resources that supplement the Cisco IOS software configuration guides and command references. These supplementary resources include release notes and caveats; master command lists; new, modified, removed, and replaced command lists; system messages; and the debug command reference.

For additional information about configuring and operating specific networking devices, and to access Cisco IOS documentation, go to the Product/Technologies Support area of Cisco.com at the following location:

<http://www.cisco.com/go/techdocs>

Table 1 Cisco IOS Configuration Guides and Command References

Configuration Guide and Command Reference Titles	Features/Protocols/Technologies
<i>Cisco IOS AppleTalk Configuration Guide</i> <i>Cisco IOS AppleTalk Command Reference</i>	AppleTalk protocol.
<i>Cisco IOS Asynchronous Transfer Mode Configuration Guide</i> <i>Cisco IOS Asynchronous Transfer Mode Command Reference</i>	LAN ATM, multiprotocol over ATM (MPoA), and WAN ATM.

Table 1 Cisco IOS Configuration Guides and Command References (continued)

Configuration Guide and Command Reference Titles	Features/Protocols/Technologies
• <i>Cisco IOS Bridging and IBM Networking Configuration Guide</i> • <i>Cisco IOS Bridging Command Reference</i> • <i>Cisco IOS IBM Networking Command Reference</i>	Transparent and source-route transparent (SRT) bridging, source-route bridging (SRB), Token Ring Inter-Switch Link (TRISL), and token ring route switch module (TRRSM). Data-link switching plus (DLSw+), serial tunnel (STUN), block serial tunnel (BSTUN); logical link control, type 2 (LLC2), synchronous data link control (SDLC); IBM Network Media Translation, including Synchronous Data Logical Link Control (SDLLC) and qualified LLC (QLLC); downstream physical unit (DSPU), Systems Network Architecture (SNA) service point, SNA frame relay access, advanced peer-to-peer networking (APPN), native client interface architecture (NCIA) client/server topologies, and IBM Channel Attach.
• <i>Cisco IOS Broadband Access Aggregation and DSL Configuration Guide</i> • <i>Cisco IOS Broadband Access Aggregation and DSL Command Reference</i>	PPP over ATM (PPPoA) and PPP over Ethernet (PPPoE).
• <i>Cisco IOS Carrier Ethernet Configuration Guide</i> • <i>Cisco IOS Carrier Ethernet Command Reference</i>	Operations, Administration, and Maintenance (OAM); Ethernet connectivity fault management (CFM); ITU-T Y.1731 fault management functions; Ethernet Local Management Interface (ELMI); MAC address support on service instances, bridge domains, and pseudowire; IEEE 802.3ad Link Bundling; Link Aggregation Control Protocol (LACP) support for Ethernet and Gigabit Ethernet links and EtherChannel bundles; LACP support for stateful switchover (SSO), in service software upgrade (ISSU), Cisco nonstop forwarding (NSF), and nonstop routing (NSR) on Gigabit EtherChannel bundles; and Link Layer Discovery Protocol (LLDP) and media endpoint discovery (MED).
• <i>Cisco IOS Configuration Fundamentals Configuration Guide</i> • <i>Cisco IOS Configuration Fundamentals Command Reference</i>	Autoinstall, Setup, Cisco IOS command-line interface (CLI), Cisco IOS file system (IFS), Cisco IOS web browser user interface (UI), basic file transfer services, and file management.
• <i>Cisco IOS DECnet Configuration Guide</i> • <i>Cisco IOS DECnet Command Reference</i>	DECnet protocol.
• <i>Cisco IOS Dial Technologies Configuration Guide</i> • <i>Cisco IOS Dial Technologies Command Reference</i>	Asynchronous communications, dial backup, dialer technology, dial-in terminal services and AppleTalk remote access (ARA), dial-on-demand routing, dial-out, ISDN, large scale dial-out, modem and resource pooling, Multilink PPP (MLP), PPP, and virtual private dialup network (VPDN).
• <i>Cisco IOS Flexible NetFlow Configuration Guide</i> • <i>Cisco IOS Flexible NetFlow Command Reference</i>	Flexible NetFlow.

Table 1 Cisco IOS Configuration Guides and Command References (continued)

Configuration Guide and Command Reference Titles	Features/Protocols/Technologies
<i>Cisco IOS High Availability Configuration Guide</i> <i>Cisco IOS High Availability Command Reference</i>	A variety of high availability (HA) features and technologies that are available for different network segments (from enterprise access to service provider core) to facilitate creation of end-to-end highly available networks. Cisco IOS HA features and technologies can be categorized in three key areas: system-level resiliency, network-level resiliency, and embedded management for resiliency.
<i>Cisco IOS Integrated Session Border Controller Command Reference</i>	A VoIP-enabled device that is deployed at the edge of networks. An SBC is a toolkit of functions, such as signaling interworking, network hiding, security, and quality of service (QoS).
<i>Cisco IOS Intelligent Services Gateway Configuration Guide</i> <i>Cisco IOS Intelligent Services Gateway Command Reference</i>	Subscriber identification, service and policy determination, session creation, session policy enforcement, session life-cycle management, accounting for access and service usage, and session state monitoring.
<i>Cisco IOS Interface and Hardware Component Configuration Guide</i> <i>Cisco IOS Interface and Hardware Component Command Reference</i>	LAN interfaces, logical interfaces, serial interfaces, virtual interfaces, and interface configuration.
<i>Cisco IOS IP Addressing Services Configuration Guide</i> <i>Cisco IOS IP Addressing Services Command Reference</i>	Address Resolution Protocol (ARP), Network Address Translation (NAT), Domain Name System (DNS), Dynamic Host Configuration Protocol (DHCP), and Next Hop Address Resolution Protocol (NHRP).
<i>Cisco IOS IP Application Services Configuration Guide</i> <i>Cisco IOS IP Application Services Command Reference</i>	Enhanced Object Tracking (EOT), Gateway Load Balancing Protocol (GLBP), Hot Standby Router Protocol (HSRP), IP Services, Server Load Balancing (SLB), Stream Control Transmission Protocol (SCTP), TCP, Web Cache Communication Protocol (WCCP), User Datagram Protocol (UDP), and Virtual Router Redundancy Protocol (VRRP).
<i>Cisco IOS IP Mobility Configuration Guide</i> <i>Cisco IOS IP Mobility Command Reference</i>	Mobile ad hoc networks (MANet) and Cisco mobile networks.
<i>Cisco IOS IP Multicast Configuration Guide</i> <i>Cisco IOS IP Multicast Command Reference</i>	Protocol Independent Multicast (PIM) sparse mode (PIM-SM), bidirectional PIM (bidir-PIM), Source Specific Multicast (SSM), Multicast Source Discovery Protocol (MSDP), Internet Group Management Protocol (IGMP), and Multicast VPN (MVPN).
<i>Cisco IOS IP Routing: BFD Configuration Guide</i>	Bidirectional forwarding detection (BFD).
<i>Cisco IOS IP Routing: BGP Configuration Guide</i> <i>Cisco IOS IP Routing: BGP Command Reference</i>	Border Gateway Protocol (BGP), multiprotocol BGP, multiprotocol BGP extensions for IP multicast.
<i>Cisco IOS IP Routing: EIGRP Configuration Guide</i> <i>Cisco IOS IP Routing: EIGRP Command Reference</i>	Enhanced Interior Gateway Routing Protocol (EIGRP).
<i>Cisco IOS IP Routing: ISIS Configuration Guide</i> <i>Cisco IOS IP Routing: ISIS Command Reference</i>	Intermediate System-to-Intermediate System (IS-IS).

Table 1 Cisco IOS Configuration Guides and Command References (continued)

Configuration Guide and Command Reference Titles	Features/Protocols/Technologies
• <i>Cisco IOS IP Routing: ODR Configuration Guide</i> • <i>Cisco IOS IP Routing: ODR Command Reference</i>	On-Demand Routing (ODR).
• <i>Cisco IOS IP Routing: OSPF Configuration Guide</i> • <i>Cisco IOS IP Routing: OSPF Command Reference</i>	Open Shortest Path First (OSPF).
• <i>Cisco IOS IP Routing: Protocol-Independent Configuration Guide</i> • <i>Cisco IOS IP Routing: Protocol-Independent Command Reference</i>	IP routing protocol-independent features and commands. Generic policy-based routing (PBR) features and commands are included.
• <i>Cisco IOS IP Routing: RIP Configuration Guide</i> • <i>Cisco IOS IP Routing: RIP Command Reference</i>	Routing Information Protocol (RIP).
• <i>Cisco IOS IP SLAs Configuration Guide</i> • <i>Cisco IOS IP SLAs Command Reference</i>	Cisco IOS IP Service Level Agreements (IP SLAs).
• <i>Cisco IOS IP Switching Configuration Guide</i> • <i>Cisco IOS IP Switching Command Reference</i>	Cisco Express Forwarding, fast switching, and Multicast Distributed Switching (MDS).
• <i>Cisco IOS IPv6 Configuration Guide</i> • <i>Cisco IOS IPv6 Command Reference</i>	For IPv6 features, protocols, and technologies, go to the IPv6 “Start Here” document.
• <i>Cisco IOS ISO CLNS Configuration Guide</i> • <i>Cisco IOS ISO CLNS Command Reference</i>	ISO Connectionless Network Service (CLNS).
• <i>Cisco IOS LAN Switching Configuration Guide</i> • <i>Cisco IOS LAN Switching Command Reference</i>	VLANs, Inter-Switch Link (ISL) encapsulation, IEEE 802.10 encapsulation, IEEE 802.1Q encapsulation, and multilayer switching (MLS).
• <i>Cisco IOS Mobile Wireless Gateway GPRS Support Node Configuration Guide</i> • <i>Cisco IOS Mobile Wireless Gateway GPRS Support Node Command Reference</i>	Cisco IOS Gateway GPRS Support Node (GGSN) in a 2.5-generation general packet radio service (GPRS) and 3-generation universal mobile telecommunication system (UMTS) network.
• <i>Cisco IOS Mobile Wireless Home Agent Configuration Guide</i> • <i>Cisco IOS Mobile Wireless Home Agent Command Reference</i>	Cisco Mobile Wireless Home Agent, an anchor point for mobile terminals for which mobile IP or proxy mobile IP services are provided.
• <i>Cisco IOS Mobile Wireless Packet Data Serving Node Configuration Guide</i> • <i>Cisco IOS Mobile Wireless Packet Data Serving Node Command Reference</i>	Cisco Packet Data Serving Node (PDSN), a wireless gateway that is between the mobile infrastructure and standard IP networks and that enables packet data services in a code division multiple access (CDMA) environment.
• <i>Cisco IOS Mobile Wireless Radio Access Networking Configuration Guide</i> • <i>Cisco IOS Mobile Wireless Radio Access Networking Command Reference</i>	Cisco IOS radio access network products.

Table 1 Cisco IOS Configuration Guides and Command References (continued)

Configuration Guide and Command Reference Titles	Features/Protocols/Technologies
<i>Cisco IOS Multiprotocol Label Switching Configuration Guide</i> <i>Cisco IOS Multiprotocol Label Switching Command Reference</i>	MPLS Label Distribution Protocol (LDP), MPLS Layer 2 VPNs, MPLS Layer 3 VPNs, MPLS traffic engineering (TE), and MPLS Embedded Management (EM) and MIBs.
<i>Cisco IOS Multi-Topology Routing Configuration Guide</i> <i>Cisco IOS Multi-Topology Routing Command Reference</i>	Unicast and multicast topology configurations, traffic classification, routing protocol support, and network management support.
<i>Cisco IOS NetFlow Configuration Guide</i> <i>Cisco IOS NetFlow Command Reference</i>	Network traffic data analysis, aggregation caches, and export features.
<i>Cisco IOS Network Management Configuration Guide</i> <i>Cisco IOS Network Management Command Reference</i>	Basic system management; system monitoring and logging; troubleshooting, logging, and fault management; Cisco Discovery Protocol; Cisco IOS Scripting with Tool Control Language (Tcl); Cisco networking services (CNS); DistributedDirector; Embedded Event Manager (EEM); Embedded Resource Manager (ERM); Embedded Syslog Manager (ESM); HTTP; Remote Monitoring (RMON); SNMP; and VPN Device Manager Client for Cisco IOS software (XSM Configuration).
<i>Cisco IOS Novell IPX Configuration Guide</i> <i>Cisco IOS Novell IPX Command Reference</i>	Novell Internetwork Packet Exchange (IPX) protocol.
<i>Cisco IOS Optimized Edge Routing Configuration Guide</i> <i>Cisco IOS Optimized Edge Routing Command Reference</i>	Optimized edge routing (OER) monitoring; Performance Routing (PfR); and automatic route optimization and load distribution for multiple connections between networks.
<i>Cisco IOS Quality of Service Solutions Configuration Guide</i> <i>Cisco IOS Quality of Service Solutions Command Reference</i>	Traffic queueing, traffic policing, traffic shaping, Modular QoS CLI (MQC), Network-Based Application Recognition (NBAR), Multilink PPP (MLP) for QoS, header compression, AutoQoS, Resource Reservation Protocol (RSVP), and weighted random early detection (WRED).
<i>Cisco IOS Security Command Reference</i>	Access control lists (ACLs); authentication, authorization, and accounting (AAA); firewalls; IP security and encryption; neighbor router authentication; network access security; network data encryption with router authentication; public key infrastructure (PKI); RADIUS; TACACS+; terminal access security; and traffic filters.
<i>Cisco IOS Security Configuration Guide: Securing the Data Plane</i>	Access Control Lists (ACLs); Firewalls: Context-Based Access Control (CBAC) and Zone-Based Firewall; Cisco IOS Intrusion Prevention System (IPS); Flexible Packet Matching; Unicast Reverse Path Forwarding (uRPF); Threat Information Distribution Protocol (TIDP) and TMS.
<i>Cisco IOS Security Configuration Guide: Securing the Control Plane</i>	Control Plane Policing, Neighborhood Router Authentication.

Table 1 Cisco IOS Configuration Guides and Command References (continued)

Configuration Guide and Command Reference Titles	Features/Protocols/Technologies
<i>Cisco IOS Security Configuration Guide: Securing User Services</i>	AAA (includes 802.1x authentication and Network Admission Control [NAC]); Security Server Protocols (RADIUS and TACACS+); Secure Shell (SSH); Secure Access for Networking Devices (includes Autosecure and Role-Based CLI access); Lawful Intercept.
<i>Cisco IOS Security Configuration Guide: Secure Connectivity</i>	Internet Key Exchange (IKE) for IPsec VPNs; IPsec Data Plane features; IPsec Management features; Public Key Infrastructure (PKI); Dynamic Multipoint VPN (DMVPN); Easy VPN; Cisco Group Encrypted Transport VPN (GETVPN); SSL VPN.
<i>Cisco IOS Service Advertisement Framework Configuration Guide</i> <i>Cisco IOS Service Advertisement Framework Command Reference</i>	Cisco Service Advertisement Framework.
<i>Cisco IOS Service Selection Gateway Configuration Guide</i> <i>Cisco IOS Service Selection Gateway Command Reference</i>	Subscriber authentication, service access, and accounting.
<i>Cisco IOS Software Activation Configuration Guide</i> <i>Cisco IOS Software Activation Command Reference</i>	An orchestrated collection of processes and components to activate Cisco IOS software feature sets by obtaining and validating Cisco software licenses.
<i>Cisco IOS Software Modularity Installation and Configuration Guide</i> <i>Cisco IOS Software Modularity Command Reference</i>	Installation and basic configuration of software modularity images, including installations on single and dual route processors, installation rollbacks, software modularity binding, software modularity processes, and patches.
<i>Cisco IOS Terminal Services Configuration Guide</i> <i>Cisco IOS Terminal Services Command Reference</i>	DEC, local-area transport (LAT), and X.25 packet assembler/disassembler (PAD).
<i>Cisco IOS Virtual Switch Command Reference</i>	Virtual switch redundancy, high availability, and packet handling; converting between standalone and virtual switch modes; virtual switch link (VSL); Virtual Switch Link Protocol (VSLP). Note For information about virtual switch configuration, see the product-specific software configuration information for the Cisco Catalyst 6500 series switch or for the Metro Ethernet 6500 series switch.
<i>Cisco IOS Voice Configuration Library</i> <i>Cisco IOS Voice Command Reference</i>	Cisco IOS support for voice call control protocols, interoperability, physical and virtual interface management, and troubleshooting. The library includes documentation for IP telephony applications.
<i>Cisco IOS VPDN Configuration Guide</i> <i>Cisco IOS VPDN Command Reference</i>	Layer 2 Tunneling Protocol (L2TP) dial-out load balancing and redundancy; L2TP extended failover; L2TP security VPDN; multihop by Dialed Number Identification Service (DNIS); timer and retry enhancements for L2TP and Layer 2 Forwarding (L2F); RADIUS Attribute 82 (tunnel assignment ID); shell-based authentication of VPDN users; tunnel authentication via RADIUS on tunnel terminator.

Table 1 Cisco IOS Configuration Guides and Command References (continued)

Configuration Guide and Command Reference Titles	Features/Protocols/Technologies
<i>Cisco IOS Wide-Area Networking Configuration Guide</i> <i>Cisco IOS Wide-Area Networking Command Reference</i>	Frame Relay; Layer 2 Tunnel Protocol Version 3 (L2TPv3); L2VPN Pseudowire Redundancy; L2VPN Interworking; Layer 2 Local Switching; Link Access Procedure, Balanced (LAPB); and X.25.
<i>Cisco IOS Wireless LAN Configuration Guide</i> <i>Cisco IOS Wireless LAN Command Reference</i>	Broadcast key rotation, IEEE 802.11x support, IEEE 802.1x authenticator, IEEE 802.1x local authentication service for Extensible Authentication Protocol-Flexible Authentication via Secure Tunneling (EAP-FAST), Multiple Basic Service Set ID (BSSID), Wi-Fi Multimedia (WMM) required elements, and Wi-Fi Protected Access (WPA).

Table 2 lists documents and resources that supplement the Cisco IOS software configuration guides and command references.

Table 2 Cisco IOS Supplementary Documents and Resources

Document Title or Resource	Description
<i>Cisco IOS Master Command List, All Releases</i>	Alphabetical list of all the commands documented in all Cisco IOS releases.
<i>Cisco IOS New, Modified, Removed, and Replaced Commands</i>	List of all the new, modified, removed, and replaced commands for a Cisco IOS release.
<i>Cisco IOS System Message Guide</i>	List of Cisco IOS system messages and descriptions. System messages may indicate problems with your system, may be informational only, or may help diagnose problems with communications lines, internal hardware, or system software.
<i>Cisco IOS Debug Command Reference</i>	Alphabetical list of debug commands including brief descriptions of use, command syntax, and usage guidelines.
Release Notes and Caveats	Information about new and changed features, system requirements, and other useful information about specific software releases; information about defects in specific Cisco IOS software releases.
MIBs	Files used for network monitoring. To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator .
RFCs	Standards documents maintained by the Internet Engineering Task Force (IETF) that Cisco IOS documentation references where applicable. The full text of referenced RFCs may be obtained at the following URL: http://www.rfc-editor.org/

Additional Resources and Documentation Feedback

What's New in Cisco Product Documentation is released monthly and describes all new and revised Cisco technical documentation. The *What's New in Cisco Product Documentation* publication also provides information about obtaining the following resources:

- Technical documentation
- Cisco product security overview
- Product alerts and field notices
- Technical assistance

Cisco IOS technical documentation includes embedded feedback forms where you can rate documents and provide suggestions for improvement. Your feedback helps us improve our documentation.

CCDE, CCENT, CCSI, Cisco Eos, Cisco HealthPresence, Cisco IronPort, the Cisco logo, Cisco Nurse Connect, Cisco Pulse, Cisco SensorBase, Cisco StackPower, Cisco StadiumVision, Cisco TelePresence, Cisco Unified Computing System, Cisco WebEx, DCE, Flip Channels, Flip for Good, Flip Mino, Flipshare (Design), Flip Ultra, Flip Video, Flip Video (Design), Instant Broadband, and Welcome to the Human Network are trademarks; Changing the Way We Work, Live, Play, and Learn, Cisco Capital, Cisco Capital (Design), Cisco:Financed (Stylized), Cisco Store, Flip Gift Card, and One Million Acts of Green are service marks; and Access Registrar, Aironet, AllTouch, AsyncOS, Bringing the Meeting To You, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, CCVP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Lumin, Cisco Nexus, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Collaboration Without Limitation, Continuum, EtherFast, EtherSwitch, Event Center, Explorer, Follow Me Browsing, GainMaker, iLynx, IOS, iPhone, IronPort, the IronPort logo, Laser Link, LightStream, Linksys, MeetingPlace, MeetingPlace Chime Sound, MGX, Networkers, Networking Academy, PCNow, PIX, PowerKEY, PowerPanels, PowerTV, PowerTV (Design), PowerVu, Prisma, ProConnect, ROSA, SenderBase, SMARTnet, Spectrum Expert, StackWise, WebEx, and the WebEx logo are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0910R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2008–2009 Cisco Systems, Inc. All rights reserved.

Using the Command-Line Interface in Cisco IOS Software

Last Updated: October 14, 2009

This document provides basic information about the command-line interface (CLI) in Cisco IOS software and how you can use some of the CLI features. This document contains the following sections:

- [Initially Configuring a Device, page xxv](#)
- [Using the CLI, page xxvi](#)
- [Saving Changes to a Configuration, page xxxv](#)
- [Additional Information, page xxxvi](#)

For more information about using the CLI, see the “[Using the Cisco IOS Command-Line Interface](#)” section of the *Cisco IOS Configuration Fundamentals Configuration Guide*.

For information about the software documentation set, see the “[About Cisco IOS Software Documentation](#)” document.

Initially Configuring a Device

Initially configuring a device varies by platform. For information about performing an initial configuration, see the hardware installation documentation that is provided with the original packaging of the product or go to the Product/Technologies Support area of Cisco.com at <http://www.cisco.com/go/techdocs>.

After you have performed the initial configuration and connected the device to your network, you can configure the device by using the console port or a remote access method, such as Telnet or Secure Shell (SSH), to access the CLI or by using the configuration method provided on the device, such as Security Device Manager.

Changing the Default Settings for a Console or AUX Port

There are only two changes that you can make to a console port and an AUX port:

- Change the port speed with the **config-register 0x** command. Changing the port speed is not recommended. The well-known default speed is 9600.
- Change the behavior of the port; for example, by adding a password or changing the timeout value.



Note

The AUX port on the Route Processor (RP) installed in a Cisco ASR 1000 series router does not serve any useful customer purpose and should be accessed only under the advisement of a customer support representative.

Using the CLI

This section describes the following topics:

- [Understanding Command Modes, page xxvi](#)
- [Using the Interactive Help Feature, page xxix](#)
- [Understanding Command Syntax, page xxx](#)
- [Understanding Enable and Enable Secret Passwords, page xxxi](#)
- [Using the Command History Feature, page xxxii](#)
- [Abbreviating Commands, page xxxiii](#)
- [Using Aliases for CLI Commands, page xxxiii](#)
- [Using the no and default Forms of Commands, page xxxiv](#)
- [Using the debug Command, page xxxiv](#)
- [Filtering Output Using Output Modifiers, page xxxiv](#)
- [Understanding CLI Error Messages, page xxxv](#)

Understanding Command Modes

The CLI command mode structure is hierarchical, and each mode supports a set of specific commands. This section describes the most common of the many modes that exist.

[Table 3](#) lists common command modes with associated CLI prompts, access and exit methods, and a brief description of how each mode is used.

Table 3 *CLI Command Modes*

Command Mode	Access Method	Prompt	Exit Method	Mode Usage
User EXEC	Log in.	Router>	Issue the logout or exit command.	• Change terminal settings. • Perform basic tests. • Display device status.
Privileged EXEC	From user EXEC mode, issue the enable command.	Router#	Issue the disable command or the exit command to return to user EXEC mode.	• Issue show and debug commands. • Copy images to the device. • Reload the device. • Manage device configuration files. • Manage device file systems.
Global configuration	From privileged EXEC mode, issue the configure terminal command.	Router(config)#	Issue the exit command or the end command to return to privileged EXEC mode.	Configure the device.

Table 3 *CLI Command Modes (continued)*

Command Mode	Access Method	Prompt	Exit Method	Mode Usage
Interface configuration	From global configuration mode, issue the interface command.	Router(config-if)#	Issue the exit command to return to global configuration mode or the end command to return to privileged EXEC mode.	Configure individual interfaces.
Line configuration	From global configuration mode, issue the line vty or line console command.	Router(config-line)#	Issue the exit command to return to global configuration mode or the end command to return to privileged EXEC mode.	Configure individual terminal lines.

Table 3 CLI Command Modes (continued)

Command Mode	Access Method	Prompt	Exit Method	Mode Usage
ROM monitor	From privileged EXEC mode, issue the reload command. Press the Break key during the first 60 seconds while the system is booting.	rommon # > The # symbol represents the line number and increments at each prompt.	Issue the continue command.	- Run as the default operating mode when a valid image cannot be loaded. - Access the fall-back procedure for loading an image when the device lacks a valid image and cannot be booted. - Perform password recovery when a Ctrl-Break sequence is issued within 60 seconds of a power-on or reload event.
Diagnostic (available only on Cisco ASR 1000 series routers)	The router boots or enters diagnostic mode in the following scenarios. When a Cisco IOS process or processes fail, in most scenarios the router will reload. - A user-configured access policy was configured using the transport-map command, which directed the user into diagnostic mode. - The router was accessed using an RP auxiliary port. - A break signal (Ctrl-C, Ctrl-Shift-6, or the send break command) was entered, and the router was configured to enter diagnostic mode when the break signal was received.	Router(diag) #	If a Cisco IOS process failure is the reason for entering diagnostic mode, the failure must be resolved and the router must be rebooted to exit diagnostic mode. If the router is in diagnostic mode because of a transport-map configuration, access the router through another port or use a method that is configured to connect to the Cisco IOS CLI. If the RP auxiliary port was used to access the router, use another port for access. Accessing the router through the auxiliary port is not useful for customer purposes.	- Inspect various states on the router, including the Cisco IOS state. - Replace or roll back the configuration. - Provide methods of restarting the Cisco IOS software or other processes. - Reboot hardware (such as the entire router, an RP, an ESP, a SIP, a SPA) or other hardware components. - Transfer files into or off of the router using remote access methods such as FTP, TFTP, and SCP.

EXEC commands are not saved when the software reboots. Commands that you issue in a configuration mode can be saved to the startup configuration. If you save the running configuration to the startup configuration, these commands will execute when the software is rebooted. Global configuration mode is the highest level of configuration mode. From global configuration mode, you can enter a variety of other configuration modes, including protocol-specific modes.

ROM monitor mode is a separate mode that is used when the software cannot load properly. If a valid software image is not found when the software boots or if the configuration file is corrupted at startup, the software might enter ROM monitor mode. Use the question symbol (?) to view the commands that you can use while the device is in ROM monitor mode.

```
rommon 1 > ?
alias                set and display aliases command
boot                 boot up an external process
confreg              configuration register utility
cont                 continue executing a downloaded image
context              display the context of a loaded image
cookie               display contents of cookie PROM in hex
.
.
.
rommon 2 >
```

The following example shows how the command prompt changes to indicate a different command mode:

```
Router> enable
Router# configure terminal
Router(config)# interface ethernet 1/1
Router(config-if)# ethernet
Router(config-line)# exit
Router(config)# end
Router#
```



Note

A keyboard alternative to the **end** command is Ctrl-Z.

Using the Interactive Help Feature

The CLI includes an interactive Help feature. [Table 4](#) describes the purpose of the CLI interactive Help commands.

Table 4 CLI Interactive Help Commands

Command	Purpose
help	Provides a brief description of the Help feature in any command mode.
?	Lists all commands available for a particular command mode.
<i>partial command?</i>	Provides a list of commands that begin with the character string (no space between the command and the question mark).
<i>partial command</i> <Tab>	Completes a partial command name (no space between the command and <Tab>).
<i>command ?</i>	Lists the keywords, arguments, or both associated with the command (space between the command and the question mark).
<i>command keyword ?</i>	Lists the arguments that are associated with the keyword (space between the keyword and the question mark).

The following examples show how to use the help commands:

help

```
Router> help
```

Help may be requested at any point in a command by entering a question mark '?'. If nothing matches, the help list will be empty and you must backup until entering a '?' shows the available options.

Two styles of help are provided:

1. Full help is available when you are ready to enter a command argument (e.g. 'show ?') and describes each possible argument.
2. Partial help is provided when an abbreviated argument is entered and you want to know what arguments match the input (e.g. 'show pr?'.)

?

```
Router# ?
```

Exec commands:

access-enable	Create a temporary access-List entry
access-profile	Apply user-profile to interface
access-template	Create a temporary access-List entry
alps	ALPS exec commands
archive	manage archive files

<snip>

partial command?

```
Router(config)# zo?
zone zone-pair
```

partial command<Tab>

```
Router(config)# we<Tab> webvpn
```

command?

```
Router(config-if)# pppoe ?
enable Enable pppoe
max-sessions Maximum PPPOE sessions
```

command keyword?

```
Router(config-if)# pppoe enable ?
group attach a BBA group
<cr>
```

Understanding Command Syntax

Command syntax is the format in which a command should be entered in the CLI. Commands include the name of the command, keywords, and arguments. Keywords are alphanumeric strings that are used literally. Arguments are placeholders for values that a user must supply. Keywords and arguments may be required or optional.

Specific conventions convey information about syntax and command elements. [Table 5](#) describes these conventions.

Table 5 **CLI Syntax Conventions**

Symbol/Text	Function	Notes
< > (angle brackets)	Indicate that the option is an argument.	Sometimes arguments are displayed without angle brackets.
A.B.C.D.	Indicates that you must enter a dotted decimal IP address.	Angle brackets (< >) are not always used to indicate that an IP address is an argument.
WORD (all capital letters)	Indicates that you must enter one word.	Angle brackets (< >) are not always used to indicate that a WORD is an argument.
LINE (all capital letters)	Indicates that you must enter more than one word.	Angle brackets (< >) are not always used to indicate that a LINE is an argument.
<cr> (carriage return)	Indicates the end of the list of available keywords and arguments, and also indicates when keywords and arguments are optional. When <cr> is the only option, you have reached the end of the branch or the end of the command if the command has only one branch.	—

The following examples show syntax conventions:

```
Router(config)# ethernet cfm domain ?
WORD domain name
Router(config)# ethernet cfm domain dname ?
level
Router(config)# ethernet cfm domain dname level ?
<0-7> maintenance level number
Router(config)# ethernet cfm domain dname level 7 ?
<cr>

Router(config)# snmp-server file-transfer access-group 10 ?
protocol protocol options
<cr>

Router(config)# logging host ?
Hostname or A.B.C.D IP address of the syslog server
ipv6 Configure IPv6 syslog server
```

Understanding Enable and Enable Secret Passwords

Some privileged EXEC commands are used for actions that impact the system, and it is recommended that you set a password for these commands to prevent unauthorized use. Two types of passwords, enable (not encrypted) and enable secret (encrypted), can be set. The following commands set these passwords and are issued in global configuration mode:

- **enable** *password*
- **enable secret** *password*

Using an enable secret password is recommended because it is encrypted and more secure than the enable password. When you use an enable secret password, text is encrypted (unreadable) before it is written to the config.text file. When you use an enable password, the text is written as entered (readable) to the config.text file.

Each type of password is case sensitive, can contain from 1 to 25 uppercase and lowercase alphanumeric characters, and can start with a numeral. Spaces are also valid password characters; for example, “two words” is a valid password. Leading spaces are ignored, but trailing spaces are recognized.

**Note**

Both password commands have numeric keywords that are single integer values. If you choose a numeral for the first character of your password followed by a space, the system will read the number as if it were the numeric keyword and not as part of your password.

When both passwords are set, the enable secret password takes precedence over the enable password.

To remove a password, use the **no** form of the commands: **no enable password** or **no enable secret password**.

For more information about password recovery procedures for Cisco products, see http://www.cisco.com/en/US/products/sw/iosswrel/ps1831/products_tech_note09186a00801746e6.shtml.

Using the Command History Feature

The command history feature saves, in a command history buffer, the commands that you enter during a session. The default number of saved commands is 10, but the number is configurable within the range of 0 to 256. This command history feature is particularly useful for recalling long or complex commands.

To change the number of commands saved in the history buffer for a terminal session, issue the **terminal history size** command:

```
Router# terminal history size num
```

A command history buffer is also available in line configuration mode with the same default and configuration options. To set the command history buffer size for a terminal session in line configuration mode, issue the **history** command:

```
Router(config-line)# history [size num]
```

To recall commands from the history buffer, use the following methods:

- Press Ctrl-P or the Up Arrow key—Recalls commands beginning with the most recent command. Repeat the key sequence to recall successively older commands.
- Press Ctrl-N or the Down Arrow key—Recalls the most recent commands in the history buffer after they have been recalled using Ctrl-P or the Up Arrow key. Repeat the key sequence to recall successively more recent commands.

**Note**

The arrow keys function only on ANSI-compatible terminals such as the VT100.

- Issue the **show history** command in user EXEC or privileged EXEC mode—Lists the most recent commands that you entered. The number of commands that are displayed is determined by the setting of the **terminal history size** and **history** commands.

The command history feature is enabled by default. To disable this feature for a terminal session, issue the **terminal no history** command in user EXEC or privileged EXEC mode or the **no history** command in line configuration mode.

Abbreviating Commands

Typing a complete command name is not always required for the command to execute. The CLI recognizes an abbreviated command when the abbreviation contains enough characters to uniquely identify the command. For example, the **show version** command can be abbreviated as **sh ver**. It cannot be abbreviated as **s ver** because **s** could mean **show**, **set**, or **systat**. The **sh v** abbreviation also is not valid because the **show** command has **vrp** as a keyword in addition to **version**. (Command and keyword examples are from Cisco IOS Release 12.4(13)T.)

Using Aliases for CLI Commands

To save time and the repetition of entering the same command multiple times, you can use a command alias. An alias can be configured to do anything that can be done at the command line, but an alias cannot move between modes, type in passwords, or perform any interactive functions.

Table 6 shows the default command aliases.

Table 6 *Default Command Aliases*

Command Alias	Original Command
h	help
lo	logout
p	ping
s	show
u or un	undebg
w	where

To create a command alias, issue the **alias** command in global configuration mode. The syntax of the command is **alias mode command-alias original-command**. Following are some examples:

- Router(config)# **alias exec prt partition**—privileged EXEC mode
- Router(config)# **alias configure sb source-bridge**—global configuration mode
- Router(config)# **alias interface rl rate-limit**—interface configuration mode

To view both default and user-created aliases, issue the **show alias** command.

For more information about the **alias** command, see

http://www.cisco.com/en/US/docs/ios/fundamentals/command/reference/cf_a1.html.

Using the no and default Forms of Commands

Most configuration commands have a **no** form that is used to reset a command to its default value or disable a feature or function. For example, the **ip routing** command is enabled by default. To disable this command, you would issue the **no ip routing** command. To re-enable IP routing, you would issue the **ip routing** command.

Configuration commands may also have a **default** form, which returns the command settings to their default values. For commands that are disabled by default, using the **default** form has the same effect as using the **no** form of the command. For commands that are enabled by default and have default settings, the **default** form enables the command and returns the settings to their default values.

The **no** form is documented in the command pages of command references. The **default** form is generally documented in the command pages only when the **default** form performs a different function than the plain and **no** forms of the command. To see what **default** commands are available on your system, enter **default ?** in the appropriate command mode.

Using the debug Command

A **debug** command produces extensive output that helps you troubleshoot problems in your network. These commands are available for many features and functions within Cisco IOS software. Some **debug** commands are **debug all**, **debug aaa accounting**, and **debug mpls packets**. To use **debug** commands during a Telnet session with a device, you must first enter the **terminal monitor** command. To turn off debugging completely, you must enter the **undebug all** command.

For more information about **debug** commands, see the *Cisco IOS Debug Command Reference* at http://www.cisco.com/en/US/docs/ios/debug/command/reference/db_book.html.



Caution

Debugging is a high priority and high CPU utilization process that can render your device unusable. Use **debug** commands only to troubleshoot specific problems. The best times to run debugging are during periods of low network traffic and when few users are interacting with the network. Debugging during these periods decreases the likelihood that the **debug** command processing overhead will affect network performance or user access or response times.

Filtering Output Using Output Modifiers

Many commands produce lengthy output that may use several screens to display. Using output modifiers, you can filter this output to show only the information that you want to see.

The following three output modifiers are available:

- **begin** *regular-expression*—Displays the first line in which a match of the regular expression is found and all lines that follow.
- **include** *regular-expression*—Displays all lines in which a match of the regular expression is found.
- **exclude** *regular-expression*—Displays all lines except those in which a match of the regular expression is found.

To use one of these output modifiers, type the command followed by the pipe symbol (**|**), the modifier, and the regular expression that you want to search for or filter. A regular expression is a case-sensitive alphanumeric pattern. It can be a single character or number, a phrase, or a more complex string.

The following example illustrates how to filter output of the **show interface** command to display only lines that include the expression “protocol.”

```
Router# show interface | include protocol

FastEthernet0/0 is up, line protocol is up
Serial4/0 is up, line protocol is up
Serial4/1 is up, line protocol is up
Serial4/2 is administratively down, line protocol is down
Serial4/3 is administratively down, line protocol is down
```

Understanding CLI Error Messages

You may encounter some error messages while using the CLI. [Table 7](#) shows the common CLI error messages.

Table 7 Common CLI Error Messages

Error Message	Meaning	How to Get Help
% Ambiguous command: “show con”	You did not enter enough characters for the command to be recognized.	Reenter the command followed by a space and a question mark (?). The keywords that you are allowed to enter for the command appear.
% Incomplete command.	You did not enter all the keywords or values required by the command.	Reenter the command followed by a space and a question mark (?). The keywords that you are allowed to enter for the command appear.
% Invalid input detected at “^” marker.	You entered the command incorrectly. The caret (^) marks the point of the error.	Enter a question mark (?) to display all the commands that are available in this command mode. The keywords that you are allowed to enter for the command appear.

For more system error messages, see the following document:

- [Cisco IOS Release 12.4T System Message Guide](#)

Saving Changes to a Configuration

To save changes that you made to the configuration of a device, you must issue the **copy running-config startup-config** command or the **copy system:running-config nvram:startup-config** command. When you issue these commands, the configuration changes that you made are saved to the startup configuration and saved when the software reloads or power to the device is turned off or interrupted. The following example shows the syntax of the **copy running-config startup-config** command:

```
Router# copy running-config startup-config
Destination filename [startup-config]?
```

You press Enter to accept the startup-config filename (the default), or type a new filename and then press Enter to accept that name. The following output is displayed indicating that the configuration was saved.

```
Building configuration...
[OK]
Router#
```

On most platforms, the configuration is saved to NVRAM. On platforms with a Class A flash file system, the configuration is saved to the location specified by the CONFIG_FILE environment variable. The CONFIG_FILE variable defaults to NVRAM.

Additional Information

- “Using the Cisco IOS Command-Line Interface” section of the *Cisco IOS Configuration Fundamentals Configuration Guide*
http://www.cisco.com/en/US/docs/ios/fundamentals/configuration/guide/cf_cli-basics.html
- Cisco Product/Technology Support
<http://www.cisco.com/go/techdocs>
- Support area on Cisco.com (also search for documentation by task or product)
<http://www.cisco.com/en/US/support/index.html>
- Software Download Center (downloads; tools; licensing, registration, advisory, and general information) (requires Cisco.com user ID and password)
<http://www.cisco.com/kobayashi/sw-center/>
- Error Message Decoder, a tool to help you research and resolve error messages for Cisco IOS software
<http://www.cisco.com/cgi-bin/Support/Errordecoder/index.cgi>
- Command Lookup Tool, a tool to help you find detailed descriptions of Cisco IOS commands (requires Cisco.com user ID and password)
<http://tools.cisco.com/Support/CLILookup>
- Output Interpreter, a troubleshooting tool that analyzes command output of supported **show** commands
<https://www.cisco.com/cgi-bin/Support/OutputInterpreter/home.pl>

CCDE, CCENT, CCSI, Cisco Eos, Cisco HealthPresence, Cisco IronPort, the Cisco logo, Cisco Nurse Connect, Cisco Pulse, Cisco SensorBase, Cisco StackPower, Cisco StadiumVision, Cisco TelePresence, Cisco Unified Computing System, Cisco WebEx, DCE, Flip Channels, Flip for Good, Flip Mino, Flipshare (Design), Flip Ultra, Flip Video, Flip Video (Design), Instant Broadband, and Welcome to the Human Network are trademarks; Changing the Way We Work, Live, Play, and Learn, Cisco Capital, Cisco Capital (Design), Cisco:Financed (Stylized), Cisco Store, Flip Gift Card, and One Million Acts of Green are service marks; and Access Registrar, Aironet, AllTouch, AsyncOS, Bringing the Meeting To You, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, CCVP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Lumin, Cisco Nexus, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Collaboration Without Limitation, Continuum, EtherFast, EtherSwitch, Event Center, Explorer, Follow Me Browsing, GainMaker, iLNNX, IOS, iPhone, IronPort, the IronPort logo, Laser Link, LightStream, Linksys, MeetingPlace, MeetingPlace Chime Sound, MGX, Networkers, Networking Academy, PCNow, PIX, PowerKEY, PowerPanels, PowerTV, PowerTV (Design), PowerVu, Prisma, ProConnect, ROSA, SenderBase, SMARTnet, Spectrum Expert, StackWise, WebEx, and the WebEx logo are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0910R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2008–2009 Cisco Systems, Inc. All rights reserved.

Introduction

This document describes the commands used to configure ATM features with Cisco IOS software. ATM commands are used to configure ATM interfaces and to configure serial interfaces for ATM access. For ATM configuration information and examples, refer to the *Cisco IOS Asynchronous Transfer Mode Configuration Guide*.

Asynchronous Transfer Mode Commands

aaa authentication arap

To enable an authentication, authorization, and accounting (AAA) authentication method for AppleTalk Remote Access (ARA), use the **aaa authentication arap** command in global configuration mode. To disable this authentication, use the **no** form of this command.

aaa authentication arap {**default** | *list-name*} *method1* [*method2*...]

no aaa authentication arap {**default** | *list-name*} *method1* [*method2*...]

Syntax Description

default	Uses the listed methods that follow this argument as the default list of methods when a user logs in.
<i>list-name</i>	Character string used to name the following list of authentication methods tried when a user logs in.
<i>method1</i> [<i>method2</i> ...]	At least one of the keywords described in Table 8 .

Command Default

If the **default** list is not set, only the local user database is checked. This has the same effect as the following command:

```
aaa authentication arap default local
```

Command Modes

Global configuration

Command History

Release	Modification
10.3	This command was introduced.
12.0(5)T	Group server and local-case support were added as method keywords for this command.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

The list names and default that you set with the **aaa authentication arap** command are used with the **arap authentication** command. Note that ARAP guest logins are disabled by default when you enable AAA. To allow guest logins, you must use either the **guest** or **auth-guest** method listed in [Table 8](#). You can only use one of these methods; they are mutually exclusive.

Create a list by entering the **aaa authentication arap list-name method** command, where *list-name* is any character string used to name this list (such as *MIS-access*). The *method* argument identifies the list of methods the authentication algorithm tries in the given sequence. See [Table 8](#) for descriptions of method keywords.

To create a default list that is used if no list is specified in the **arap authentication** command, use the **default** keyword followed by the methods you want to be used in default situations.

The additional methods of authentication are used only if the previous method returns an error, not if it fails.

Use the **more system:running-config** command to view currently configured lists of authentication methods.

**Note**

In [Table 8](#), the **group radius**, **group tacacs+**, and **group group-name** methods refer to a set of previously defined RADIUS or TACACS+ servers. Use the **radius-server host** and **tacacs+-server host** commands to configure the host servers. Use the **aaa group server radius** and **aaa group server tacacs+** commands to create a named group of servers.

Table 8 *aaa authentication arap Methods*

Keyword	Description
guest	Allows guest logins. This method must be the first method listed, but it can be followed by other methods if it does not succeed.
auth-guest	Allows guest logins only if the user has already logged in to EXEC. This method must be the first method listed, but can be followed by other methods if it does not succeed.
line	Uses the line password for authentication.
local	Uses the local username database for authentication.
local-case	Uses case-sensitive local username authentication.
group radius	Uses the list of all RADIUS servers for authentication.
group tacacs+	Uses the list of all TACACS+ servers for authentication.
group group-name	Uses a subset of RADIUS or TACACS+ servers for authentication as defined by the aaa group server radius or aaa group server tacacs+ command.

Examples

The following example creates a list called *MIS-access*, which first tries TACACS+ authentication and then none:

```
aaa authentication arap MIS-access group tacacs+ none
```

The following example creates the same list, but sets it as the default list that is used for all ARA protocol authentications if no other list is specified:

```
aaa authentication arap default group tacacs+ none
```

Related Commands

Command	Description
aaa new-model	Enables the AAA access control model.

abr

To select available bit rate (ABR) quality of service (QoS) and configure the output peak cell rate and output minimum guaranteed cell rate for an ATM permanent virtual circuit (PVC) or virtual circuit (VC) class, use the **abr** command in the appropriate command mode. To remove the ABR parameters, use the **no** form of this command.

abr *output-pcr output-mcr*

no abr *output-pcr output-mcr*

Syntax Description

<i>output-pcr</i>	The output peak cell rate, in kilobits per second.
<i>output-mcr</i>	The output minimum guaranteed cell rate, in kilobits per second.

Command Default

ABR QoS at the maximum line rate of the physical interface.

Command Modes

Interface-ATM-VC configuration (for an ATM PVC)
 VC-class configuration (for a VC class)
 PVC range configuration (for an ATM PVC range)
 PVC-in-range configuration (for an individual PVC within a PVC range)

Command History

Release	Modification
11.1	This command was introduced.
12.1(5)T	This command was modified to be available in PVC range and PVC-in-range configuration modes.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

If the **abr** command is not explicitly configured on an ATM PVC, the VC inherits the following default configuration (listed in order of precedence):

- Configuration of any QoS command (**abr**, **ubr**, **ubr+**, or **vbr-nrt**) in a VC class assigned to the PVC itself.
- Configuration of any QoS command (**abr**, **ubr**, **ubr+**, or **vbr-nrt**) in a VC class assigned to the PVC's ATM subinterface.
- Configuration of any QoS command (**abr**, **ubr**, **ubr+**, or **vbr-nrt**) in a VC class assigned to the PVC's ATM main interface.
- Global default value: ABR QoS at the maximum line rate of the PVC.

ABR is a quality of service class defined by the ATM Forum for ATM networks. ABR is used for connections that do not require timing relationships between source and destination. ABR provides no guarantees in terms of cell loss or delay, providing only best-effort service. Traffic sources adjust their transmission rate in response to information they receive describing the status of the network and its capability to successfully deliver data.

In ABR transmission, the peak cell rate (PCR) specifies the maximum value of the allowed cell rate (ACR), and minimum cell rate (MCR) specifies the minimum value for the ACR. ACR varies between the MCR and the PCR and is dynamically controlled using congestion control mechanisms.

Examples

The following example specifies the *output-pcr* argument to be 100,000 kbps and the *output-mcr* argument to be 3000 kbps for an ATM PVC:

```
pvc 1/32
abr 100000 3000
```

Related Commands

Command	Description
ubr	Configures UBR QoS and specifies the output peak cell rate for an ATM PVC, SVC, VC class, or VC bundle member.
ubr+	Configures UBR QoS and specifies the output peak cell rate and output minimum guaranteed cell rate for an ATM PVC, SVC, VC class or VC bundle member.
vbr-nrt	Configures the VBR-NRT QoS and specifies output peak cell rate, output sustainable cell rate, and output maximum burst cell size for an ATM PVC, SVC, or VC class.

atm aal aal3/4

To enable support for ATM adaptation layer 3/4 (AAL3/4) on an ATM interface, use the **atm aal aal3/4** command in interface configuration mode. To disable support for AAL3/4 on an ATM interface, use the **no** form of this command.

atm aal aal3/4

no atm aal aal3/4

Syntax Description

This command has no arguments or keywords.

Command Default

Support for AAL3/4 is disabled.

Command Modes

Interface configuration

Command History

Release	Modification
10.3	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command is supported on Cisco 7500 series routers with ATM Interface Processor (AIP). This command is not supported on the ATM port adapter. Because Cisco 4500 and Cisco 4700 routers always support both AAL3/4 and AAL5, this command is not required on Cisco 4500 and Cisco 4700 routers.

Only one virtual circuit can exist on a subinterface that is being used for AAL3/4 processing, and that virtual circuit must be an AAL3/4 virtual circuit.

The AAL3/4 support feature requires static mapping of all protocols except IP.

Examples

The following example enables AAL3/4 on ATM interface 2/0:

```
interface atm2/0
 ip address 172.21.177.178 255.255.255.0
 atm aal aal3/4
```

Related Commands

Command	Description
atm mid-per-vc	Limits the number of MID numbers allowed on each VC.
atm multicast	Assigns an SMDS E.164 multicast address to the ATM subinterface that supports AAL3/4 and SMDS encapsulation.
atm smds-address	Assigns a unicast E.164 address to the ATM subinterface that supports AAL3/4 and SMDS encapsulation.
pvc	Creates or assigns a name to an ATM PVC, specifies the encapsulation type on an ATM PVC, or enters interface-ATM-VC configuration mode.

atm abr rate-factor

To configure the amount by which the cell transmission rate increases or decreases in response to flow control information from the network or destination for available bit rate (ABR) virtual circuits (VCs), use the **atm abr rate-factor** command in interface configuration mode. To return to the default, use the **no** form of this command.

atm abr rate-factor [*rate-increase-factor*] [*rate-decrease-factor*]

no atm abr rate-factor [*rate-increase-factor*] [*rate-decrease-factor*]

Syntax Description

<i>rate-increase-factor</i>	(Optional) Factor by which to increase the data rate. The rate increase factor is specified in powers of 2 from 1 to 32768.
<i>rate-decrease-factor</i>	(Optional) Factor by which to decrease the data rate. The rate decrease factor is specified in powers of 2 from 1 to 32768.

Command Default

The ABR rate increase and decrease factor is 16.

Command Modes

Interface configuration

Command History

Release	Modification
11.1	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

To configure an ABR VC, use the **pvc** command with the **abr** keyword.

To verify the ABR rate factor, use the **show atm interface atm EXEC** command.

Examples

The following example sets the ABR rate factor to 32 for the next cell transferred on ATM interface 4/0:

```
interface atm 4/0
 atm abr rate-factor 32 32
```

Related Commands

Command	Description
pvc	Configures the PVC interface.
show atm interface atm	Displays ATM-specific information about an ATM interface.

atm address-registration

To enable the router to engage in address registration and callback functions with the Interim Local Management Interface (ILMI), use the **atm address-registration** command in interface configuration mode. To disable ILMI address registration functions, use the **no** form of this command.

atm address-registration

no atm address-registration

Syntax Description This command has no arguments or keywords.

Command Default Enabled

Command Modes Interface configuration

Command History	Release	Modification
	11.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines This command enables a router to register its address with the ILMI for callback when specific events occur, such as incoming Simple Network Management Protocol (SNMP) traps or incoming new network prefixes.

Examples The following example enables ATM interface 1/0 to register its address:

```
interface atm 1/0
 atm address-registration
```

Related Commands	Command	Description
	atm ilmi-keepalive	Enables ILMI keepalives.

atm arp-server

To identify an ATM Address Resolution Protocol (ARP) server for the IP network or set time-to-live (TTL) values for entries in the ATM ARP table, use the **atm arp-server** command in interface configuration mode. To remove the definition of an ATM ARP server, use the **no** form of this command.

atm arp-server [**self** | **nsap** *nsap-address*] [**time-out** *minutes*]

no atm arp-server [**self** [**time-out** *minutes*] | [**nsap** *nsap-address*]]

Syntax Description

self	(Optional) Specifies the current router as the ATM ARP server.
time-out <i>minutes</i>	(Optional) Number of minutes for which a destination entry listed in the ATM ARP server's ARP table will be kept before the server takes any action to verify or time out the entry. The default timeout value is 20 minutes.
nsap <i>nsap-address</i>	(Optional) Network service access point (NSAP) address of an ATM ARP server.

Command Default

The ARP server process is disabled.

Command Modes

Interface configuration

Command History

Release	Modification
11.1	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

If an NSAP address is specified, the ARP client on this interface uses the specified host as an ARP server. You can specify multiple ATM ARP servers by repeating the command. If **self** is specified, this interface acts as the ARP server for the logical IP network.

The ATM ARP server takes one of the following actions if a destination listed in the server's ARP table expires:

- If a virtual circuit still exists to that destination, the server sends an Inverse ARP request. If no response arrives, the entry times out.
- If a virtual circuit does not exist to the destination, the entry times out immediately.

This implementation follows RFC 1577, *Classical IP over ATM*.

To configure redundant ARP servers, you must first enable redundant ARP server support by entering the **atm classic-ip-extensions** command with the **BFI** keyword.

Examples

The following example configures ATM on an interface and configures the interface to function as the ATM ARP server for the IP subnetwork:

```
interface atm 0/0
 ip address 10.0.0.1.255.0.0.0
 atm nsap-address ac.1533.66.020000.0000.0000.0000.0000.0000.00
 atm rate-queue 1 100
 atm maxvc 1024
 atm pvc 1 0 5 qsaal
 atm arp-server self
```

Related Commands

Command	Description
atm classic-ip-extensions	Enables support for redundant ATM ARP servers on a single LIS.

atm autovc retry

To configure retry frequency of create-on-demand permanent virtual circuits (PVC), use the **atm autovc retry** command in interface configuration mode. To set the retry frequency of create-on-demand PVCs to their default value, use the **no** form of this command.

atm autovc retry *timeout-value*

no atm autovc retry *timeout-value*

Syntax Description

<i>timeout-value</i>	Specifies the retry timeout value, in minutes. Range is from 1 to 60.
----------------------	---

Command Default

The retry timeout value is set to 1 minute.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
12.2(15)B	This command was introduced.
15.0(1)M	This command was integrated into Cisco IOS Release 15.0(1)M.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.

Usage Guidelines

Use this command to configure retry frequency of create-on-demand PVCs, when the initial VC creation fails due to reasons such as temporary shortage of resource.

Examples

The following example shows how to configure retry frequency of 12 minutes for create-on-demand PVCs:

```
Router> enable
Router# configure terminal
Router(config)# interface atm 2/0
Router(config-if)# atm autovc retry 12
```

Related Commands

Command	Description
create on-demand	Configures ATM PVC auto provisioning, which enables a PVC or range of PVCs to be created automatically on demand.

atm bandwidth dynamic

To enable the automatic management of changes in the total bandwidth of an Asynchronous Transfer Mode (ATM) interface configured with an Inverse Multiplexing over ATM (IMA) group, use the **atm bandwidth dynamic** command in interface configuration mode. To disable automatic management of changes in total IMA group bandwidth, use the **no** form of this command.

atm bandwidth dynamic

no atm bandwidth dynamic

Syntax Description This command has no arguments or keywords.

Command Default Changes in total IMA group bandwidth are not automatically managed.

Command Modes Interface configuration (config-if)

Command History	Release	Modification
	12.0(30)S1	This command was introduced.
	12.0(31)S	This command was integrated into Cisco IOS Release 12.0(31)S.

Usage Guidelines

When the **atm bandwidth dynamic** command is enabled, all of the permanent virtual circuits (PVCs) configured on an IMA group interface are created again if the total available IMA group bandwidth changes.

There must be at least one active link on the IMA group interface for dynamic bandwidth changes to take effect.

Automatic bandwidth management is supported only for the following quality of service (QoS) classes:

- UBR—unspecified bit rate
- ABR—available bit rate
- VBR-NRT—variable bit rate nonreal-time

If necessary and applicable for a particular PVC based on its QoS class, new values are applied for the following parameters when PVCs are re-created:

- peak cell rate (PCR)—all supported QoS classes
- minimum cell rate (MCR)—ABR QoS
- sustainable cell rate (SCR)—VBR-NRT QoS

The algorithm used to implement automatic bandwidth management is applied only when dynamic changes to an IMA group interface occur. It is not applied at virtual circuit creation on router bootup.

**Note**

PVCs may have incorrect QoS parameters if the **atm bandwidth dynamic** command is disabled after changing the total bandwidth, and enabled again after changing the total bandwidth once more.

Examples

The following example shows how to create IMA group 1, enable automatic bandwidth management, and assign a physical ATM interface to the IMA group:

```
interface atm3/ima 1
  atm bandwidth dynamic
!
interface atm0/1
  ima-group 1
```

Related Commands

Command	Description
ima-group	Defines physical links as IMA group members.
interface atm	Configures an ATM interface and enters interface configuration mode.
interface atm ima	Configures an IMA group.

atm classic-ip-extensions

To enable support for redundant ATM Address Resolution Protocol (ARP) servers on a single logical IP subnetwork (LIS), use the **atm classic-ip-extensions** command in interface configuration mode. To remove support for redundant ATM ARP servers, use the **no** form of this command.

atm classic-ip-extensions {BFI | none}

no atm classic-ip-extensions

Syntax Description	BFI	Enables simple redundant ARP server support. BFI as an acronym is undefined.
	none	Enables standard RFC 1577 behavior (no redundant ARP server support).

Command Default	Redundant ATM ARP server support is not enabled.
-----------------	--

Command Modes	Interface configuration
---------------	-------------------------

Command History	Release	Modification
	11.2	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	Cisco's implementation of the ATM ARP server supports redundant ATM ARP servers on a single logical IP subnetwork (LIS). In order for redundant ATM ARP server support to work, all of the devices on the LIS must be Cisco devices and must have the atm classic-ip-extensions BFI command configured.
------------------	---

The **none** keyword enables behavior that complies with RFC 1577, *Classical IP over ATM*. RFC 1577 does not support redundant ARP servers.

Examples	The following example shows how to configure redundant ARP servers on an ATM interface:
----------	---

```
Router(config)# interface atm 1/0
Router(config-if)# atm classic-ip-extensions BFI
Router(config-if)# atm arp-server nsap 47.000580FFE1000000F21A3167.666666666666.00
Router(config-if)# atm arp-server nsap 47.000580FFE1000000F21A3167.555555555555.00
```

Related Commands

Command	Description
atm arp-server	Identifies an ATM Address Resolution Protocol (ARP) server for the IP network or sets TTL values for entries in the ATM ARP table.

atm clock internal

To cause the ATM interface to generate the transmit clock internally, use the **atm clock internal** command in interface configuration mode. To restore the default value, use the **no** form of this command.

atm clock internal

no atm clock internal

Syntax Description This command has no arguments or keywords.

Command Default The ATM interface uses the transmit clock signal from the remote connection (the line).

Command Modes Interface configuration

Command History	Release	Modification
	10.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines When the ATM interface uses the transmit clock signal from the remote connection (the line), the switch provides the clocking.

This command is meaningless on a 4B/5B physical layer interface module (PLIM).

For SONET interfaces, use the **atm clock internal** command to configure an ATM port adapter to supply its internal clock to the line.

Examples The following example causes the ATM interface to generate the transmit clock internally:

```
interface atm 4/0
 atm clock internal
```

atm compression

To specify the software compression mode on an interface, use the **atm compression** command in interface configuration mode. To remove the compression mode setting, use the **no** form of this command.

atm compression {per-packet | per-interface | per-vc}

no atm compression {per-packet | per-interface | per-vc}

Syntax Description

per-packet	Specifies packet-by-packet compression mode (no history).
per-interface	Specifies one context per interface (with history).
per-vc	Specifies one context for every virtual circuit (with history).

Command Default

Packet-by-packet compression mode (no history) is used.

Command Modes

Interface configuration

Command History

Release	Modification
11.3(1)MA	This command was introduced on the Cisco MC3810 multiservice concentrator.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command applies to ATM configuration on the Cisco MC3810 multiservice concentrator.

Examples

The following example configures per-packet ATM compression:

```
interface atm0
 atm compression per-packet
```


atm ds3-scramble

To enable scrambling of the ATM cell payload for the DS3 physical layer interface module (PLIM) on an ATM interface, use the **atm ds3-scramble** command in interface configuration mode. To disable scrambling of the ATM cell payload for the DS3 PLIM, use the **no** form of this command.

atm ds3-scramble

no atm ds3-scramble

Syntax Description This command has no arguments or keywords.

Command Default DS3 scrambling is not enabled.

Command Modes Interface configuration

Command History	Release	Modification
	11.0	This command was introduced.
	11.1	Command syntax was changed from ds3 scramble to atm ds3-scramble .
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines DS3 scrambling is used to assist clock recovery on the receiving end.

Examples The following example disables DS3 scrambling on the interface:

```
interface atm 4/0
 no atm ds3-scramble
```

atm e164 auto-conversion

To enable ATM E164 autoconversion, use the **atm e164 auto-conversion** command in interface configuration mode. To disable autoconversion, use the **no** form of this command.

atm e164 auto-conversion

no atm e164 auto-conversion

Syntax Description

This command has no arguments or keywords.

Command Default

E.164 auto conversion is not enabled.

Command Modes

Interface configuration

Command History

Release	Modification
11.3	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

You must enable the ATM interface before using the **atm e164 auto-conversion** command.

When an interface is configured for E.164 auto conversion, ATM E.164 format addresses are converted to the corresponding native E.164 address for outgoing calls. For incoming calls, native E.164 addresses are converted to the corresponding ATM E.164 format.

Examples

The following example enables E.164 auto conversion on ATM interface 0/0/1:

```
interface atm 0/0/1
 atm e164 auto-conversion
```

atm e3-scramble

To enable scrambling of the ATM cell payload for the E3 physical layer interface module (PLIM) on an ATM interface, use the **atm e3-scramble** command in interface configuration mode. To disable scrambling of the ATM cell payload for the E3 PLIM, use the **no** form of this command.

atm e3-scramble

no atm e3-scramble

Syntax Description This command has no arguments or keywords.

Command Default E3 scrambling is enabled.

Command Modes Interface configuration

Command History	Release	Modification
	11.1	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines E3 scrambling is used to assist clock recovery on the receiving end.

Examples The following example disables E3 scrambling on the interface:

```
interface atm 2/0
no atm e3-scramble
```

atm enable-ilmi-trap

To generate an Integrated Local Management Interface (ILMI) atmVccChange trap when an ATM interface or subinterface is enabled or shut down, use the **atm enable-ilmi-trap** command in subinterface configuration mode. To disable ILMI traps, use the **no** form of this command.

atm enable-ilmi-trap

no atm enable-ilmi-trap

Syntax Description

This command has no arguments or keywords.

Command Default

An atmVccChange trap is not generated when an ATM interface or subinterface is enabled or shut down.

Command Modes

Subinterface configuration (config-subif)

Command History

Release	Modification
12.0(28)S	This command was introduced.
12.2SB	This command was integrated into Cisco IOS Release 12.2SB.

Usage Guidelines

ILMI permanent virtual circuit (PVC) should have been created under the ATM main interface. The **atm enable-ilmi-trap** command is supported only on Cisco 12000 routers.

Examples

The following example allows atmVccChange traps to be generated when an ATM interface or subinterface has a status of shut or no shut:

```
atm enable-ilmi-trap
```

Related Commands

Command	Description
atm ilmi-keepalive	Enables ILMI keepalives.
pvc	Creates or assigns a name to an ATM PVC, specifies the encapsulation type on an ATM PVC, and enters ATM virtual circuit configuration mode.

atm ether-mac-address

To configure the ATM point-to-point subinterface to use a user-defined MAC address or a MAC address of any other physical interface, use the **atm ether-mac-address** command in ATM point-to-point subinterface configuration mode. To disable any configured functionality, use the **no** form of this command.

atm ether-mac-address {*MAC-address* | **interface** *interface-name*}

no atm ether-mac-address

Syntax Description

<i>MAC-address</i>	The specific or user-defined MAC address.
interface <i>interface-name</i>	Name of the physical interface whose MAC address can be used.

Command Default

The functionality is disabled if the **atm ether-mac-address** command is not used in conjunction with the Route Bridge Encapsulation (RBE) feature.

Command Modes

ATM point-to-point subinterface configuration (config-subif)

Command History

Release	Modification
15.0(1)M2	This command was introduced.

Usage Guidelines

You can use the MAC address of any other physical interface as the MAC address of a subinterface, in conjunction with the Dynamic Host Configuration Protocol (DHCP) client. You can also configure an explicit MAC address for an ATM point-to-point subinterface.

Examples

The following example shows how the ATM point-to-point subinterface can be configured to use the MAC address of any other physical interface:

```
Router# config t
Router(config)# interface atm3/0.100 point-to-point
Router(config-subif)# atm ether-mac-address interface fastEthernet 0/0
Router(config-subif)# interface ATM3/0.100 point-to-point
Router(config-subif)# atm ether-mac-address interface FastEthernet0/0
Router(config-subif)# no atm enable-ilmi-trap
Router(config-subif)# end
```



Note

For RBE, the client interface is restricted to ethernet interfaces only.

The following example shows how the ATM point-to-point subinterface can be configured with the user-defined MAC address:

```
Router(config-subif)# atm ether-mac-address 0a0a.0b0b.0c0c
```

```
Router(config-subif)# interface ATM3/0.100 point-to-point
Router(config-subif)# no atm enable-ilmi-trap
end
```

**Note**

A valid nonzero MAC address is essential for a successful configuration.

```
Router(config-subif)# atm ether-mac-address 0000.0000.0000
% Malformed hex mac address
```

Related Commands

Command	Description
show run	Displays the configured interface name.

atm esi-address

To enter the end station ID (ESI) and selector byte fields of the ATM network service access point (NSAP) address, use the **atm esi-address** command in interface configuration mode. The NSAP address prefix is filled in via Integrated Local Management Interface (ILMI) from the ATM switch. To delete the end station address, use the **no** form of this command.

atm esi-address *esi.selector*

no atm esi-address *esi.selector*

Syntax Description	<i>esi</i>	End station ID field value in hexadecimal; 6 bytes long.
	<i>.selector</i>	Selector field value in hexadecimal; 1 byte long. Dot is required as a separator.

Command Default	No ESI is defined.
-----------------	--------------------

Command Modes	Interface configuration
---------------	-------------------------

Command History	Release	Modification
	11.1	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	The atm esi-address command allows you to configure the ATM address by entering the ESI (12 hexadecimal characters) and the selector byte (2 hexadecimal characters). The ATM prefix (26 hexadecimal characters) will be provided by the ATM switch. To get the prefix from the ATM switch, the ILMI permanent virtual circuit (PVC) must be configured on the router and the ATM switch must be able to supply a prefix via ILMI. A period must be used to separate the <i>esi</i> from the <i>selector</i> arguments.
------------------	--

**Note**

When ILMI is configured, use the **atm esi-address** command instead of the **atm nsap-address** command. The **atm esi-address** and **atm nsap-address** commands are mutually exclusive. Configuring the router with the **atm esi-address** command negates the **atm nsap-address** setting, and vice versa.

The ILMI PVC must be configured in order to get an NSAP address prefix from the switch.

Examples

The following example sets up the ILMI PVC and assigns the ESI and selector field values on the ATM interface 4/0:

```
interface atm 4/0
 atm pvc 2 0 16 ilmi
 atm esi-address 345678901234.12
```

Related Commands

Command	Description
atm nsap-address	Sets the NSAP address for an ATM interface using SVC mode.
ilmi manage	Enables ILMI management on an ATM PVC.
pvc	Configures the PVC interface.

atm exception-queue

To set the exception queue length, use the **atm exception-queue** command in interface configuration mode. To restore the default value, use the **no** form of this command.

atm exception-queue *number*

no atm exception-queue

Syntax Description	<i>number</i> Number of entries. Range is from 8 to 256. Default is 32.								
Defaults	32 entries								
Command Modes	Interface configuration								
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>10.0</td><td>This command was introduced.</td></tr><tr><td>12.2(33)SRA</td><td>This command was integrated into Cisco IOS Release 12.2(33)SRA.</td></tr><tr><td>12.2SX</td><td>This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.</td></tr></table>	Release	Modification	10.0	This command was introduced.	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Release	Modification								
10.0	This command was introduced.								
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.								
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.								
Usage Guidelines	This command is supported on ATM interface processor (AIP) for Cisco 7500 series routers. This command is not supported on the ATM port adapter for Cisco 7200 and 7500 series routers, nor is it supported on Cisco 4500 and Cisco 4700 routers. The exception queue is used for reporting ATM events, such as cycle redundancy check (CRC) errors.								
Examples	The following example sets the exception queue to 50 entries: <pre>atm exception-queue 50</pre>								

atm framing (DS3)

To specify digital signal level 3 (DS3) line framing on an ATM interface, use the **atm framing** command in interface configuration mode. To return to the default C-bit with Physical Layer Convergence Protocol (PLCP) framing, use the **no** form of this command.

atm framing [**cbitadm** | **cbitplcp** | **m23adm** | **m23plcp**]

no atm framing [**cbitadm** | **cbitplcp** | **m23adm** | **m23plcp**]

Syntax Description

cbitadm	(Optional) Specifies C-bit with ATM direct mapping (ADM).
cbitplcp	(Optional) Specifies C-bit with PLCP framing.
m23adm	(Optional) Specifies M23 ATM direct mapping.
m23plcp	(Optional) Specifies M23 with PLCP framing.

Defaults

C-bit with PLCP framing is used.

Command Modes

Interface configuration

Command History

Release	Modification
11.0	This command was introduced.
11.1	This command was modified to include the Cisco 7200 series routers with the ATM-CES port adapter.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command is available on Cisco 4500 and 4700 routers with DS3 access speeds, Cisco 7200 series routers, and Cisco 7500 series routers.

Framing on the interface must match that on the switch for this ATM link.

Examples

The following example specifies M23 ADM framing on a router that has been set up with DS3 access to an ATM network:

```
interface atm 4/0
 atm framing m23adm
```

atm framing (E3)

To specify E3 line framing, use the **atm framing** command in interface configuration mode. To return to the default G.751 Physical Layer Convergence Protocol (PLCP) framing, use the **no** form of this command.

atm framing [**g751adm** | **g832adm** | **g751plcp**]

no atm framing [**g751adm** | **g832adm** | **g751plcp**]

Syntax Description

g751adm	(Optional) Specifies G.751 ATM direct mapping (ADM).
g832adm	(Optional) Specifies G.832 ATM direct mapping.
g751plcp	(Optional) Specifies G.751 PLCP encapsulation.

Defaults

G.751 ATM direct mapping (ADM) is used.

Command Modes

Interface configuration

Command History

Release	Modification
11.0	This command was introduced.
11.1	The g751plcp keyword was added, together with information on the Cisco 7200 series router with the ATM-CES port adapter.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

The default framing is described in the ITU-T Recommendation G.751.

Framing on the interface must match that on the switch for this ATM link.

Examples

The following example specifies G.832 ADM framing on a router that has been set up with E3 access to an ATM network:

```
interface atm 4/0
 atm framing g832adm
```

atm ilmi-keepalive

To enable Interim Local Management Interface (ILMI) keepalives, use the **atm ilmi-keepalive** command in interface configuration mode. To disable ILMI keepalives, use the **no** form of this command.

atm ilmi-keepalive [*seconds*]

no atm ilmi-keepalive [*seconds*]

Syntax Description

seconds (Optional) Number of seconds between keepalives. Values less than 3 seconds are rounded up to 3 seconds, and there is no upper limit.

Defaults

3 seconds

Command Modes

Interface configuration

Command History

Release	Modification
11.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following example enables ILMI keepalives for the ATM interface 1/0:

```
interface atm 1/0
 atm address-registration
 atm ilmi-keepalive
```

Related Commands

Command	Description
atm address-registration	Enables the router to engage in address registration and callback functions with the ILMI.

atm ilmi-pvc-discovery

To enable ATM permanent virtual circuit (PVC) discovery, use the **atm ilmi-pvc-discovery** command in interface configuration mode. To disable PVC discovery, use the **no** form of this command.

atm ilmi-pvc-discovery [**subinterface**]

no atm ilmi-pvc-discovery [**subinterface**]

Syntax Description	subinterface (Optional) Causes discovered PVCs to be assigned to the ATM subinterface whose number matches the discovered PVC's VPI number.
---------------------------	--

Command Default	PVC discovery is not enabled.
------------------------	-------------------------------

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	11.3	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples	The following example enables PVC discovery on the ATM main interface 2/0. The subinterface keyword is used so that all discovered PVCs with a VPI value of 1 will be assigned to the subinterface 2/0.1:
-----------------	--

```
interface atm 2/0
 pvc RouterA 0/16 ilmi
 exit
 atm ilmi-pvc-discovery subinterface
 exit

interface atm 2/0.1 multipoint
 ip address 172.21.51.5 255.255.255.0
```

atm lbo

To specify the cable length (line build-out) for the ATM interface, use the **atm lbo** command in interface configuration mode. To return to the default, use the **no** form of this command.

atm lbo {long | short}

no atm lbo

Syntax Description

long	Specifies a cable length greater than 50 feet.
short	Specifies a cable length up to 50 feet.

Defaults

A cable length greater than 50 feet is specified.

Command Modes

Interface configuration

Command History

Release	Modification
11.1	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following example specifies that the ATM interface uses a cable of up to 50 feet in length:

```
interface atm 4/0
 atm lbo short
```

Related Commands

Command	Description
ces	Configures cable length for the CBR interface.

atm max-channels

To configure the number of transmit channels for the interface, use the **atm max-channels** command in interface configuration mode. To return to the default, use the **no** form of this command.

atm max-channels *number*

no atm max-channels

Syntax Description	<i>number</i>	Maximum number of transmit channels for the interface. The range is from 64 to 2048 channels. The default is 64 channels.
Defaults	64 channels	
Command Modes	Interface configuration	
Command History	Release	Modification
	11.1	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines The **atm max-channels** command replaces the **atm tx-channels** command.

Transmit Descriptors

The **atm max-channels** command can be used to divide the available number (fixed) of transmit descriptors across the configured number of transmit channels. Typically, you think of a one-to-one association between a transmit channel and a VC; however, the ATM-CES port adapter supports other types of VCs than data VCs (for example CES VCs). Also, the ATM-CES port adapter can multiplex one or more VCs over a single virtual path (VP) that is shaped, and the VP only requires a single transmit channel. Therefore, the term *transmit channel* is used rather than *virtual circuit*.

Maximum Burst

The maximum burst of packets that are allowed per VC is limited by the number of transmit descriptors allocated per VC. Because the total number of transmit descriptors available is limited by the available SRAM space, configuration of the number of transmit channels for the interface determines the number of transmit descriptors for each transmit channel. Hence the burst size for each transmit channel is determined by the **atm max-channels** command. For example, for 64 (the default) transmit channels for the interface, 255 transmit descriptors are associated per channel, and for 512 transmit channels for the interface, 31 transmit descriptors are associated per channel.

To display information about the transmit descriptors, use the **show atm interface atm** command.

Examples

The following example sets the number of transmit descriptors for the interface to 120.

```
interface atm 2/0
 atm max-channels 120
```

Related Commands

Command	Description
show atm interface atm	Displays ATM-specific information about an ATM interface.

atm maxvc

To set the ceiling value of the virtual circuit descriptor (VCD) on the ATM interface, use the **atm maxvc** command in interface configuration mode. To restore the default value, use the **no** form of this command.

atm maxvc *number*

no atm maxvc

Syntax Description	<i>number</i> Maximum number of supported virtual circuits. Valid values are 256, 512, 1024, and 2048.
---------------------------	--

Defaults	2048 virtual circuits
-----------------	-----------------------

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	10.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	This command is supported on Cisco 7500 series routers; it is not supported on the Cisco 4500 and Cisco 4700 routers, which have a fixed maximum of 1024 VCs.
	This command sets the maximum value supported for the <i>vcd</i> argument in the atm pvc command. It also determines the maximum number of virtual circuits on which the AIP allows segmentation and reassembly (SAR) to occur. However, if you set a maxvc limit and then enter the atm pvc command with a larger value for the <i>vcd</i> argument, the software does not generate an error message.
	This command does not affect the virtual path identifier (VPI)-virtual channel identifier (VCI) pair of each virtual circuit.

Examples	The following example sets a ceiling VCD value of 1024 and restricts the AIP to supporting no more than 1024 virtual circuits:
	<pre>atm maxvc 1024</pre>

Related Commands	Command	Description
	pvc	Configures an ATM PVC.

atm mid-per-vc

To limit the number of message identifier (MID) numbers allowed on each virtual circuit, use the **atm mid-per-vc** command in interface configuration mode.

atm mid-per-vc *maximum*

Syntax Description

<i>maximum</i>	Number of MIDs allowed per virtual circuit on this interface. The values allowed are 16, 32, 64, 128, 256, 512, and 1024.
----------------	---

Defaults

16 MIDs per virtual circuit

Command Modes

Interface configuration

Command History

Release	Modification
10.3	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command is supported on Cisco 7200 and 7500 series routers.

MID numbers are used by receiving devices to reassemble cells from multiple sources into packets.

This command limits the number of discrete messages allowed on the PVC at the same time. It does not limit the number of cells associated with each message.

The *maximum* set by the **atm mid-per-vc** command overrides the range between the *midhigh* and *midlow* values set by the **atm pvc** command. If you set a *maximum* of 16 but a *midlow* of 0 and a *midhigh* of 255, only 16 MIDs (not 256) are allowed on the virtual circuit.

Examples

The following example allows 64 MIDs per ATM virtual circuit:

```
atm mid-per-vc 64
```

Related Commands

Command	Description
pvc	Configures the PVC interface.

atm multicast

To assign a Switched Multimegabit Data Service (SMDS) E.164 multicast address to the ATM subinterface that supports ATM adaptation layer 3/4 (AAL3/4) and SMDS encapsulation, use the **atm multicast** command in interface configuration mode.

atm multicast *address*

Syntax Description	<i>address</i> Multicast E.164 address assigned to the subinterface.
---------------------------	--

Command Default	No multicast E.164 address is defined.
------------------------	--

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	10.3	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	This command is supported on Cisco 7500 series, Cisco 4500, and Cisco 4700 routers. This command is not supported on the ATM port adapter.
	Each AAL3/4 subinterface is allowed only one multicast E.164 address. This multicast address is used for all protocol broadcast operations.

Examples	The following example assigns a multicast E.164 address to the ATM subinterface that is being configured:
-----------------	---

```
atm multicast e180.0999.000
```

Related Commands	Command	Description
	abr	Selects ABR QoS and configures output peak cell rate and output minimum guaranteed cell rate for an ATM PVC or VC class.
	atm smds-address	Assigns a unicast E.164 address to the ATM subinterface that supports AAL3/4 and SMDS encapsulation.
	pvc	Configures the PVC interface.

atm multipoint-interval

To specify how often new destinations can be added to multipoint calls to an ATM switch in the network, use the **atm multipoint-interval** command in interface configuration mode. To return to the default interval, use the **no** form of this command.

atm multipoint-interval *interval*

no atm multipoint-interval *interval*

Syntax Description	<i>interval</i> Interval length, in seconds. Range is from 0 to 4294967. Default is 30.									
Defaults	30 seconds									
Command Modes	Interface configuration									
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>11.0</td><td>This command was introduced.</td></tr><tr><td>12.2(33)SRA</td><td>This command was integrated into Cisco IOS Release 12.2(33)SRA.</td></tr><tr><td>12.2SX</td><td>This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.</td></tr></table>		Release	Modification	11.0	This command was introduced.	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Release	Modification									
11.0	This command was introduced.									
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.									
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.									
Usage Guidelines	This command applies to switched virtual circuits (SVCs) only, not to permanent virtual circuits (PVCs). This command has no effect unless ATM multipoint signaling is enabled on the interface.									
Examples	The following example enables point-to-multipoint signaling on the ATM interface 2/0. It also specifies that new destinations can be added to multipoint calls every 60 seconds: <pre>interface atm 2/0 atm multipoint-signalling atm multipoint-interval 60</pre>									
Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>atm multipoint-signalling</td><td>Enables point-to-multipoint signaling to the ATM switch.</td></tr></table>		Command	Description	atm multipoint-signalling	Enables point-to-multipoint signaling to the ATM switch.				
Command	Description									
atm multipoint-signalling	Enables point-to-multipoint signaling to the ATM switch.									

atm multipoint-signalling

To enable point-to-multipoint signaling to the ATM switch, use the **atm multipoint-signalling** command in interface configuration mode. To disable point-to-multipoint signalling to the ATM switch, use the **no** form of this command.

atm multipoint-signalling

no atm multipoint-signalling

Syntax Description This command has no arguments or keywords.

Command Default Point-to-multipoint signaling is not enabled.

Command Modes Interface configuration

Command History	Release	Modification
	11.0	This command was introduced.
	11.1	Functionality was changed to allow this command on all subinterfaces, not just the main interface.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines If multipoint signaling is enabled, the router uses existing static map entries that have the **broadcast** keyword set to establish multipoint calls. One call is established for each logical subnet of each protocol. All destinations are added to the call. One multicast packet is sent to the ATM switch for each multipoint call. The ATM switch replicates the packet to all destinations.

The **atm multipoint-interval** command determines how often new destinations can be added to a multipoint call.



Note

Prior to Cisco IOS Release 11.1, when this command was used on the main interface, it also affected all subinterfaces. For Release 11.1 and later, explicit configuration on each subinterface is required to obtain the same functionality.

Examples The following example enables point-to-multipoint signalling on the ATM interface 2/0:

```
interface atm 2/0
 atm multipoint-signalling
```

Related Commands

Command	Description
atm multipoint-interval	Specifies how often new destinations can be added to multipoint calls to an ATM switch in the network.

atm nsap-address

To set the network service access point (NSAP) address for an ATM interface using switched virtual circuit (SVC) mode, use the **atm nsap-address** command in interface configuration mode. To remove any configured address for the interface, use the **no** form of this command.

atm nsap-address *nsap-address*

no atm nsap-address

Syntax Description

nsap-address The 40-digit hexadecimal NSAP address of this interface (the source address).

Command Default

No NSAP address is defined for this interface.

Command Modes

Interface configuration

Command History

Release	Modification
10.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

When configuring an SVC, you must use the **atm nsap-address** command to define the source NSAP address. It identifies a particular port on the ATM network and must be unique across the network.



Note

When the Integrated Local Management Interface (ILMI) is configured, use the **atm esi-address** command instead of the **atm nsap-address** command. The **atm esi-address** and **atm nsap-address** commands are mutually exclusive. Configuring the router with the **atm esi-address** command negates the **atm nsap-address** setting, and vice versa.

Configuring a new address on the interface overwrites the previous address. The router considers the address as a string of bytes and will not prefix or suffix the address with any other strings or digits. The complete NSAP address must be specified, because this value is used in the Calling Party Address Information Element in the SETUP message to establish a virtual circuit.

ATM NSAP addresses have a fixed length of 40 hexadecimal digits. You must configure the complete address in the following dotted format:

xx . xxxx . xx . xxxxxx . xxxx . xxxx . xxxx . xxxx . xxxx . xxxx . xx

**Note**

All ATM NSAP addresses should be entered in the dotted hexadecimal format shown above, which conforms to the User-Network Interface (UNI) specification. The dotted method provides some validation that the address is a legal value. If you know your address format is correct, the dots may be omitted.

Examples

In the following example, the source NSAP address for the interface is AB.CDEF.01.234567.890A.BCDE.F012.3456.7890.1234.12:

```
atm nsap-address AB.CDEF.01.234567.890A.BCDE.F012.3456.7890.1234.12
```


atm oam ais alarm

To enable the generation of Operation, Administration, and Maintenance (OAM) Alarm Indication Signal (AIS) alarms, use the **atm oam ais alarm** command in interface configuration mode. To disable the generation of OAM AIS alarms, use the **no** form of this command.

atm oam ais alarm

no atm oam ais alarm

Syntax Description This command has no arguments or keywords.

Command Default OAM AIS alarms are generated.

Command Modes Interface configuration (config-if)

Release	Modification
12.0(32)SY4	This command was introduced.

Usage Guidelines Use the **show interfaces atm** command to determine whether generation of OAM AIS alarms is enabled.

Examples The following example shows how to enable the generation of OAM AIS alarms:

```
Router> enable
Password:
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# interface atm 0/0
Router(config-if)# atm oam ais alarm
Router(config-if)# end
```

Command	Description
show interfaces atm	Displays information about ATM interfaces.

atm oam flush

To drop all current and future Operation, Administration, and Maintenance (OAM) cells received on an ATM interface, use the **atm oam flush** command in interface configuration mode. To receive OAM cells on an ATM interface, use the **no** form of this command.

atm oam flush

no atm oam flush

Syntax Description

This command has no arguments or keywords.

Command Default

Dropping of OAM cells is disabled.

Command Modes

Interface configuration

Command History

Release	Modification
11.3	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following example drops all current and future OAM cells received on the ATM main interface with slot 0 and port 0:

```
interface atm 0/0
 atm oam flush
```

atm oversubscribe

To enable infinite bandwidth oversubscription for service categories other than constant bit rate (CBR), use the **atm oversubscribe** command in interface configuration mode. To disable bandwidth oversubscription for service categories other than CBR, use the **no** form of this command.

atm oversubscribe

no atm oversubscribe

Syntax Description This command has no arguments or keywords.

Command Default Infinite bandwidth oversubscription is enabled.

Command Modes Interface configuration

Command History	Release	Modification
	12.0(3)T	This command was introduced.
	12.2(16)BX3	This command was integrated into Cisco IOS Release 12.2(16)BX3.
	12.3(7)XI1	This command was integrated into Cisco IOS Release 12.3(7)XI1.
	12.4(6)T	Support for this command was added to DSL ATM interfaces.
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines This command disables bandwidth management for service categories other than CBR.

When infinite bandwidth oversubscription is enabled, the interface allows as much bandwidth as possible with no upper limits (except on digital subscriber line (DSL) ATM interfaces, in which oversubscription is not infinite, but is a factor of 2). The system determines if the ATM link is already oversubscribed. If so, the command is rejected. Otherwise, the total bandwidth available on the link is recorded, and all future connection setup requests are monitored to ensure that the link is not oversubscribed.

The bandwidth allocated for each service category appears in the output of the **show atm interface atm** command.

The ATM bandwidth manager tracks the bandwidth used by virtual circuits (VCs) on a per-interface basis. Because many services require guaranteed bandwidth (for example, for variable bit rate-real time (VBR-RT), available bit rate (ABR), and CBR), bandwidth management is required. The purpose of the bandwidth manager is to reserve resources for connections that require guaranteed services. Bandwidth

management for CBR is turned on automatically for all interfaces supporting CBR. Bandwidth management for other service categories must be turned on by the user. All service categories outside CBR are monitored only if specifically requested.

**Note**

Because unspecified bit rate (UBR) does not provide guaranteed bandwidth, the bandwidth specified for a UBR connection is not used in any calculations.

Bandwidth checking for a permanent virtual circuit (PVC) is done when that PVC is configured. Bandwidth checking for a switched virtual circuit (SVC) is done when a signaling call is placed or received.

When you use the **atm pvp** command, the system checks if the specified bandwidth is available on the interface. If the bandwidth available is greater than or equal to the peak rate specified for the Permanent Virtual Path (PVP), the command is accepted; otherwise, the command is rejected.

Within the VC mode, the available bandwidth check will determine whether the bandwidth is already used by the VC to fulfill the request. If the VC being configured is a PVC and belongs to a PVP, the bandwidth available on the PVP is used for the check; otherwise, the bandwidth available on the interface is used for the check.

When services within a VC class are being configured, the check determines whether the new bandwidth requirement can be fulfilled for all VCs using the class (on a per-interface basis) by comparing it with the bandwidth available on the corresponding interface.

Bandwidth checking for an SVC occurs before a SETUP message is sent for an outbound call. If the bandwidth check fails, the SETUP message is not sent. If the bandwidth check passes, the traffic class from which the service category is inherited is updated with the requirements for the new SVC.

When an SVC setup is requested for remotely initiated calls, a bandwidth check occurs as soon as the SETUP message is received. This bandwidth check has two components:

- Match the bandwidth requested by the remote end with the bandwidth configured locally.
- Check if bandwidth configured locally can be satisfied currently.

If the bandwidth check fails, a RELEASE message is sent out, and the call is rejected. If the bandwidth check passes, resources are reserved for the VC, and the call is accepted.

Cisco 10000 Series Router

Oversubscription of the ATM interfaces is off by default. Oversubscription of the tunnels (the number and bandwidth of VCs that can be in a tunnel) is on by default and is not subject to any oversubscription factor. Oversubscription of the tunnels cannot be adjusted or turned off. On the Cisco 10000 Series router, to enable the oversubscription feature for a particular interface or tunnel, use the **atm over-subscription-factor** command (but not the **atm oversubscribe** command, which can cause undesirable results). To prevent oversubscription of the interface, use the **no atm oversubscribe** command.

With variable bit rate-nonreal time (VBR-NRT) oversubscription, because of congestion on the physical interface, the accuracy of priority queueing (PQ) and class-based weighted fair queueing (CBWFQ) on individual VCs degrades. For example, if you configure each of three queues at a distribution of 50, 30, and 20 percent, respectively, the actual distribution might be 45, 40, and 15 percent, respectively. The distribution of bandwidth for each VC might be less than expected based on the speed of the VC. Typically, low-speed VCs are allocated the expected bandwidth, and high-speed VCs share the remaining bandwidth equally. The amount of bandwidth allocated for the PQ or latency might be less than expected.

Examples

The following example enables the oversubscription feature:

```
Router(config)# interface atm 4/0/0
Router(config-if)# atm oversubscribe
Router(config-if)# exit
```

The following example displays the available bandwidth in kbps after the router enters VC mode. In this example, the available bandwidth is 139,000 kbps:

```
Router# show atm interface atm 2/0

Interface ATM2/0:
AAL enabled: AAL5, Maximum VCs:1024, Current VCCs:5

Maximum Transmit Channels:64
Max. Datagram Size:4496
PLIM Type:SONET - 155Mbps, TX clocking:LINE
Cell-payload scrambling:OFF
sts-stream scrambling:ON
877 input, 120843834 output, 0 IN fast, 20 OUT fast
ABR parameters, rif:16 rdf:16, 0 out drop
Bandwidth distribution :CBR :16000 Avail bw = 139000
Config. is ACTIVE
```

Cisco 10000 Series Router

The following example enables the oversubscription feature (using the **atm over-subscription-factor** command rather than the **atm oversubscribe** command) and configures the interface with an oversubscription factor of 50:

```
Router(config)# interface atm 4/0/0
Router(config-if)# atm over-subscription-factor 50
Router(config-if)# exit
```

The following example disables oversubscription of the ATM 4/0/0 interface. The previously configured factor 50 is configured on the interface, but the router does not allow the oversubscription:

```
Router(config)# interface atm 4/0/0
Router(config-if)# no atm oversubscribe
Router(config-if)# exit
```

Related Commands

Command	Description
atm oversubscribe factor	Enables finite line bandwidth oversubscription for DSL.
atm over-subscription-factor	Oversubscribes ATM VCs.
atm pvp	Creates a PVP used to multiplex (or bundle) one or more VCs.
show atm interface atm	Displays ATM-specific information about an ATM interface.
show controllers	Displays the total subscribed rate of all VCs on the port.
show running-config	Displays the contents of the running configuration file.
ubr+	Configures unspecified bit rate plus for an ATM PVC.
vbr-nrt	Configures variable bit rate-nonreal-time for an ATM PVC.
vbr-rt	Configures variable bit rate real-time for VoATM voice connections.

atm oversubscribe factor

To set up finite line bandwidth oversubscription for digital subscriber line (DSL), use the **atm oversubscribe factor** command in interface configuration mode. To disable finite line bandwidth oversubscription for DSL, use the **no** form of this command.

atm oversubscribe factor *factor*

no atm oversubscribe factor *factor*

Syntax Description

<i>factor</i>	Oversubscription factor in the range from 2 to 14000000000.
---------------	---

Command Default

Finite line bandwidth oversubscription for DSL is disabled.

Command Modes

Interface configuration

Command History

Release	Modification
12.4(2)XA	This command was introduced.
12.4(6)T	This command was integrated into Cisco IOS Release 12.4(6)T.

Usage Guidelines

Resource limitations on Cisco xDSL interfaces require a way to configure bandwidth oversubscription up to a defined bandwidth (a *finite* oversubscription of bandwidth). For this requirement, the **atm oversubscribe factor** command is used. A DSL ATM interface supports only an oversubscribe factor of 2.

Oversubscription is allowed on variable bit rate real time class (VBR-rt), variable bit rate non-real time class (VBR-nrt), and unspecified bit rate plus (UBR+) permanent virtual circuits (PVCs). With oversubscription enabled, multiple VBR-rt, VBR-nrt, and UBR+ PVCs can be configured even when the sum of their sustainable cell rates (SCRs) exceeds the actual bandwidth available over the physical line. For example, if oversubscription is enabled and an oversubscription factor of 2 is set for a line rate of 2304 kbps, the sum of SCRs and minimum desired cell rates of VBR-rt, VBR-nrt, and UBR+ PVCs must be less than or equal to 4608 kbps, excluding the constant bit rate (CBR) PVC bandwidth.

An oversubscription factor of 2 is used internally; that is, VBR and UBR+ PVCs with a sum of SCRs up to twice the current line rate are valid. If you configure VBR-rt, VBR-nrt, or UBR+ for more than the configured oversubscription factor, the PVCs will be configured when bandwidth is available. But when no oversubscription bandwidth is available, a PVC is downgraded to an unspecified bit rate (UBR) (CBR PVCs are not affected, however); in this state, if you try to configure VBR or UBR+ PVCs beyond the line rate, the new PVCs will be downgraded to UBR state. If you have no oversubscription configured, each virtual circuit (VC) receives up to its configured SCR value of traffic, and VCs with higher SCR values receive more bandwidth. For example, if VC1 is a VBR-rt PVC configured with peak cell rate (PCR) and SCR line rates of 2304 kbps (command **vbr-rt 2304 2304**), VC2 is a VBR-nrt PVC configured with PCR and SCR line rates of 2000 kbps (command **vbr-nrt 2000 2000**), and VC3 has PCR

and SCR line rates of 496 kbps (command **vbr-rt 496 496**), then when no oversubscription bandwidth is available, VC1 and VC 2 are configured with the specified PCR and SCR line rates, but VC3 is downgraded to UBR class.

If the DSL line rate goes down and comes back up with less than the trained rate (based on the trained bandwidth PVCs) and no bandwidth is left, some PVCs might be downgraded to UBR class.

The value of the oversubscription factor determines the maximum bandwidth that is configured, which is the sum of SCRs for all VBR-rt, VBR-nrt, and UBR+. PVCs. To disable oversubscription, the total configured bandwidth of CBR, VBR-rt, VBR-nrt, and UBR+ must not exceed actual trained bandwidth. The CBR bandwidth is counted when disabling oversubscription.

With oversubscription disabled, a PVC can be configured only up to the line rate. For example, if the line rate is 2304 kbps, the SCR or PCR of a VBR PVC cannot be more than 2304 kbps (assuming there are no other PVCs). If there is another PVC, such as a CBR PVC with a PCR of 500 kbps, that line rate is subtracted, and the maximum SCR or PCR allowed on the VBR PVC is 1804 kbps.

The first time VBR-rt, VBR-nrt, or UBR+ PVCs are configured with the oversubscription factor enabled, the available bandwidth is checked. If the required bandwidth is available, the service class commands (**vbr-rt**, **vbr-nrt**, and **ubr+**) are accepted. If there is not enough requested bandwidth, the service class commands are rejected, and the PVC state will be UP with service class set to UBR.

After VBR-rt, VBR-nrt, or UBR+ PVCs are configured, a dynamic line rate modification occurs when the **atm oversubscribe factor** command is enabled. The available bandwidth is checked, and if the required amount is available, the PVC state will be UP with the configured service class. If there is not enough bandwidth, the PVC state will be UP with service class UBR.

DSL ATM interfaces do not support switched virtual circuits (SVCs).

Examples

The following example shows how to set oversubscription on the link by a factor of 2.

```
interface ATM0/0
  no ip address
  atm oversubscribe factor 2
  no atm ilmi-keepalive
  pvc 2/100
    vbr-nrt 2304 2304 1
  !
  pvc 3/100
    cbr 2304
  !
  pvc 4/100
    ubr+ 2304 2304
  !
  pvc 5/100
  !
```

The oversubscription configuration can be verified by using the **show atm interface EXEC** command. The report from the command indicates that the link is oversubscribed by 4608 kbps.

```
Router# show atm interface atm 0/0
```

```
Interface ATM0/0:
AAL enabled: AAL5 , Maximum VCs: 23, Current VCCs: 4

VCIs per VPI: 256,
Max. Datagram Size: 4528
PLIM Type: GSHDSL - 2304Kbps, Framing is Unknown,, TX clocking: LINE
0 input, 0 output, 0 IN fast, 0 OUT fastCBR : 2304 UBR+ : 2304 VBR-NRT : 2304
Link oversubscribed by 4608 kbps
Config. is ACTIVE
```

Related Commands

Command	Description
atm oversubscribe	Disables bandwidth management for service categories other than CBR.
show atm interface atm	Displays ATM-specific information about an ATM interface.
ubr+	Configures unspecified bit rate plus for an ATM PVC.
vbr-nrt	Configures variable bit rate-nonreal time for an ATM PVC.
vbr-rt	Configures variable bit rate real-time for VoATM voice connections.

atm over-subscription-factor

To oversubscribe ATM virtual circuits (VCs), use the **atm over-subscription-factor** command in interface configuration mode. To disable oversubscription of ATM VCs, use the **no** form of this command.

atm over-subscription-factor *value*

no atm over-subscription-factor

Syntax Description	value	Oversubscription factor. The range is from 1 to 500.
---------------------------	--------------	--

Command Default	The default factor is 1 (no oversubscription).
------------------------	--

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	12.2(16)BX	This command was introduced. on the Cisco 10000 series Performance Routing Engine (PRE-2).
	12.3(7)XI3	This command was integrated into Cisco IOS Release 12.3(7)XI3, and the maximum oversubscription factor was increased from 50 to 500.
	12.2(31)SB	This command was integrated into Cisco IOS Release 12.2(31)SB.

Usage Guidelines

Restrictions and Limitations for Interface Oversubscription

Because of a mismatch of rates between the packet scheduler and the network, interface oversubscription can degrade system performance during congestion.

With oversubscription, network congestion can occur if all of the network capacity is used concurrently. However, the risk is low if you avoid oversubscribing a network that is likely to congest and if you do not oversubscribe a service excessively.

The router uses the **atm over-subscription-factor** command in conjunction with the **atm oversubscribe** command to enable or disable oversubscription for a particular interface. When enabling ATM oversubscription for a particular interface, specify the **atm over-subscription-factor** command. Do not use the **atm oversubscribe** command to enable oversubscription, because this can cause undesirable results.

An ATM variable bit rate (VBR) VC uses the sustained cell rate (SCR) to define the VC's average transmission rate. Therefore, use the **atm over-subscription-factor** command, but not the **service-policy** command, to specify the ATM VC oversubscription.

Because the oversubscription of VBR-nrt VCs requires resources from the entire line card, apply the **atm over-subscription-factor** command on all ports of the ATM interface (for example, the 4-port OC-3 ATM line card). If you enable oversubscription on only one port, the other ports might use more resources than they were configured to use. As a result, some ports might not receive adequate resources, which would cause VC creation failures.

Examples

The following example shows how to configure an ATM interface with an oversubscription factor of 500:

```
Router(config)# interface atm 4/0/0
Router(config-if)# atm oversubscribe
Router(config-if)# atm over-subscription-factor 500
```

The following example shows how to disable oversubscription of the ATM 4/0/0 interface to prevent oversubscription of the interface:

```
Router(config)# interface atm 4/0/0
Router(config-if)# no atm oversubscribe
```

Related Commands

Command	Description
atm oversubscribe	Disables bandwidth management for service categories other than CBR.
service-policy	Attaches a policy map to an input interface or virtual circuit (VC), or an output interface or VC, to be used as the service policy for that interface or VC
show atm interface atm	Displays ATM interface information.

atm pppatm passive

To place an ATM subinterface in passive mode, use the **atm pppatm passive** command in ATM subinterface configuration mode. To change the configuration back to the default (active) mode, use the **no** form of this command.

atm pppatm passive

no atm pppatm passive

Syntax Description This command has no arguments or keywords.

Defaults Active mode

Command Modes ATM subinterface configuration

Command History	Release	Modification
	12.2(13)T	This command was introduced.
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.

Usage Guidelines The **atm pppatm passive** command places PPP over ATM (PPPoA) sessions on an ATM subinterface in “listening” mode. Rather than trying to establish the sessions actively by sending out Link Control Protocol (LCP) packets, these sessions listen to the incoming LCP packets and become active only after they have received their first LCP packet. This feature is useful for L2TP access concentrators (LACs) in the broadband access deployments where thousands of PPPoA sessions are configured on LACs. When PPPoA is in the passive mode, the LAC brings up the sessions only when the subscribers become active and not use its processing power on polling all sessions.

For better scalability and faster convergence of PPP sessions, you should set the PPPoA sessions to passive mode at the LAC.

Cisco 10000 Series Router

For better scalability and faster convergence of PPPoA, PPP over Ethernet over ATM (PPPoEoA), or LAC sessions, set the sessions to passive mode.

You must use the **atm pppatm passive** command for large-scale PPP terminated aggregation (PPPoA and PPPoEoA) and Layer 2 Tunnel Protocol (L2TP) access concentrator (LAC). Instead of sending out LCP packets to establish the sessions actively, the sessions listen to the incoming LCP packets and become active only after they receive their first LCP packet. When PPPoX is in the passive mode, the LAC brings up the sessions only when the subscribers become active and does not use processing power polling all sessions.

Examples

The following example configures the passive mode for the PPPoA sessions on an ATM subinterface:

```
Router(config)# interface atm 1/0.1 multipoint
Router(config-subif)# atm pppatm passive
Router(config-subif)# range range-pppoa-1 pvc 100 199
Router(config-subif-atm-range)# protocol ppp virtual-template 1
```

Cisco 10000 Series Router

The following example configures passive mode for the PPPoA sessions on an ATM multipoint subinterface:

```
Router(config)# interface atm 1/0.1 multipoint
Router(config-subif)# atm pppatm passive
Router(config-subif)# range range-pppoa-1 pvc 100 199
Router(config-subif-atm-range)# encapsulation aal5mux ppp virtual-template 1
```

atm pvp

To create a permanent virtual path (PVP) used to multiplex (or bundle) one or more virtual circuits (VCs), use the **atm pvp** command in interface configuration mode. To remove a PVP, use the **no** form of this command.

atm pvp *vpi* [*peak-rate*] [**l2transport**]

no atm pvp *vpi*

Cisco 10000 Series Router

atm pvp *vpi* [*peak-rate*] [*cdvt* [**no-f4-oam**] | **no-f4-oam**]

no atm pvp *vpi*

Syntax Description		
<i>vpi</i>		ATM network virtual path identifier (VPI) of the VC to multiplex on the permanent virtual path. The range is 0 to 255. The VPI is an 8-bit field in the header of the ATM cell. Because it has local significance only, the VPI value is unique only on a single link, not throughout the ATM network. The VPI value must match that of the switch. The number specified for the <i>vpi</i> argument must not already exist in a VC. If the number specified for the <i>vpi</i> is already used by an existing VC, this command is rejected.
<i>peak-rate</i>		(Optional) Maximum rate in kbps at which the PVP can transmit data. The range is 84 kbps to line rate. The default is the line rate.
l2transport		(Optional) Specifies that the PVP is for the Any Transport over MPLS (AToM) ATM cell relay feature or the ATM Cell Relay over L2TPv3 feature.
<i>cdvt</i>		(Optional) Cell delay variation tolerance (CDVT) in tenths of a microsecond. The range is 1 to 7140.
no-f4-oam		(Optional) Inhibits the creation of F4 (virtual path connection [VPC] level) Operation, Administration, and Maintenance (OAM) VCs.

Command Default A PVP is not configured.

Command Modes Interface configuration

Command History

Release	Modification
11.1	This command was introduced.
12.0(17)SL	This command was integrated into Cisco IOS Release 12.0(17)SL.
12.0(25)S	This command was integrated into Cisco IOS Release 12.0(25)S, and the l2transport keyword was added.
12.2(16)BX	This command was integrated into Cisco IOS Release 12.2(16)BX.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.
12.2(27)SBC	This command was integrated into Cisco IOS Release 12.2(27)SBC.
12.2(31)SB	This command was integrated into Cisco IOS Release 12.2(31)SB.

Usage Guidelines

This command is commonly used to create a PVP that is used to multiplex circuit emulation service (CES) and data VCs.

The ATM-CES port adapter supports multiplexing of one or more VCs over a virtual path that is shaped at a constant bandwidth. For example, you can buy a virtual path service from an ATM service provider and multiplex both the CES and data traffic over the virtual path.

All subsequently created VCs with a *vpi* argument matching the *vpi* specified with the **atm pvp** command are multiplexed onto this PVP. This PVP connection is an ATM connection where switching is performed on the VPI field of the cell only.

A PVP is created and left up indefinitely. All VCs that are multiplexed over a PVP share and are controlled by the traffic parameters associated with the PVP.

Changing the *peak-rate* value causes the ATM-CES port adapter to go down and then back up.

When you create a PVP, two VCs are created (VCI 3 and 4) by default. These VCs are created for VP end-to-end loopback and segment loopback OAM support.

When you use the **l2transport** keyword with the **atm pvp** command, the router enters l2transport PVP configuration mode. You must issue the **l2transport** keyword to configure the ATM cell relay over multiprotocol label switching (MPLS) feature in port mode or to configure the ATM cell relay over L2TPv3 feature.

To verify the configuration of a PVP, use the **show atm vp** command.

Examples

The following example creates a PVP with a peak rate of 2000 kbps. The subsequent VCs created are multiplexed onto this virtual path.

```
interface atm 6/0
  atm pvp 1 2000
  atm pvc 13 1 13 aal5snap
  exit
interface cbr 6/1
  ces circuit 0
  ces pvc 9 interface atm6/0 vpi 1 vci 100
  exit
```

The following example configures ATM cell relay over MPLS in port mode:

```
interface atm5/0
  atm pvp 1 l2transport
  xconnect 10.0.0.1 123 encapsulation mpls
```

The following example configures ATM cell relay over L2TPv3:

```
pw-class atm-xconnect
 encapsulation l2tpv3

interface atm 4/1/0
 atm pvp 5 l2transport
 xconnect 10.0.3.201 888 pw-class atm-xconnect
```

Related Commands

Command	Description
show atm vp	Displays the statistics for all VPs on an interface or for a specific VP.

atm rate-queue

To create a permanent rate queue or specify a rate queue tolerance, use the **atm rate-queue** command in interface configuration mode. To remove a rate queue or rate queue tolerance, use the **no** form of this command.

atm rate-queue {*queue-number speed* | **tolerance svc** [**pvc**] *tolerance-value* [**strict**]}

no atm rate-queue {*queue-number speed* | **tolerance svc** [**pvc**] *tolerance-value* [**strict**]}

Syntax Description

<i>queue-number</i>	Queue number in the range 0 through 7 on the ATM Interface Processor (AIP) for Cisco 7500 series routers, and in the range 0 through 3 on the network processing module (NPM) for Cisco 4500 and Cisco 4700 routers. On the AIP, queues 0 through 3 are in the high-priority bank, and queues 4 through 7 are in the low-priority bank. Queues in the same priority bank have the same priority; for example, queues 0 and 3 have the same priority. On the NPM, all 4 queues have the same priority.
<i>speed</i>	Speed in megabits per second (Mbps) in the range from 1 through 155. The maximum speed is determined by the detected physical layer interface module (PLIM) type on the AIP or NPM: • 34 Mbps for E3 • 45 Mbps for DS-3 • 100 Mbps for Transparent Asynchronous Transmitter/Receiver Interface (TAXI) • 155 Mbps for Synchronous Optical Network (SONET)
tolerance	Specifies that you want to use a rate queue tolerance value.
svc	Specifies that the <i>tolerance-value</i> will be applied to SVCs.
pvc	(Optional) If specified, the <i>tolerance-value</i> will be applied to PVCs.
<i>tolerance-value</i>	A tolerance level expressed as a percentage used for assigning rate queues for each virtual circuit (VC) with a requested peak rate. This value is applied to switched virtual circuits (SVCs), discovered VCs, and permanent virtual circuits (PVCs) (when the pvc keyword is used). This value can be 0 or 5 through 99. For SVCs and discovered VCs, the default value is 10. For PVCs, the default value is 0.
strict	(Optional) Indicates whether SVC traffic-shaping parameters are altered beyond the SVC tolerance or rejects the incoming call.

Command Default

No rate queue is defined.

Command Modes

Interface configuration

Command History

Release	Modification
10.0	This command was introduced.
11.3	The following keywords were added: • tolerance • svc
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Cisco IOS XE Release 2.3	This command was integrated into Cisco IOS XE Release 2.3.

Usage Guidelines

If a PVC or SVC is created, and its rate queue does not match a permanent rate queue that was created using the **atm-rate queue queue-number speed** command, one of the following will occur:

- The PVC or SVC will use an existing rate queue if the PVC's or SVC's rate queue falls within the *tolerance-value* specified.
- The software will dynamically create a new and unique rate queue if the PVC or SVC does not fall within a previously configured rate-queue tolerance.

If you do not create permanent rate queues or if you create PVCs with peak or average rates that are not matched by the rate queues you configure, the software dynamically creates rate queues as necessary to satisfy the requests of the **atm pvc** commands.

You can create multiple rate queues. A warning message appears if all rate queues are deconfigured or if the combined rate queues exceed the PLIM rate.

Examples

The following example configures a permanent rate queue with a *queue-number* of 1 and a *speed* of 100 Mbps:

```
atm rate-queue 1 100
```

The following example configures a rate queue with a *tolerance-value* of 20, which will apply to SVCs, discovered VCs, and PVCs.

```
interface atm 2/0
 atm rate-queue tolerance svc pvc 20
```

Related Commands

Command	Description
pvc	Configures the PVC interface.
svc	Creates an ATM SVC and specifies the destination NSAP address on a main interface or subinterface.

atm rawq-size

To define the ATM Interface Processor (AIP) raw-queue size, use the **atm rawq-size** command in interface configuration mode. To restore the default value, use the **no** form of this command.

atm rawq-size *number*

no atm rawq-size

Syntax Description

number Maximum number of cells in the raw queue simultaneously. Range is from 8 to 256. Default is 32.

Defaults

32 cells

Command Modes

Interface configuration

Command History

Release	Modification
10.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command is supported on the Cisco 7200 and 7500 series routers, but not on the Cisco 4500 and Cisco 4700 routers.

The raw queue is used for raw ATM cells, which include Operation, Administration, and Maintenance (OAM) (F4 and F5) and Interim Local Management Interface (ILMI) cells.

Examples

The following example allows a maximum of 48 cells in the raw queue:

```
atm rawq-size 48
```

atm rxbuff

To set the maximum number of receive buffers for simultaneous packet reassembly, use the **atm rxbuff** command in interface configuration mode. To restore the default value, use the **no** form of this command.

atm rxbuff *number*

no atm rxbuff

Syntax Description

<i>number</i>	Maximum number of packet reassemblies that the ATM Interface Processor (AIP) can perform simultaneously. Range is from 0 to 512. Default is 256.
---------------	--

Defaults

256 packet reassemblies

Command Modes

Interface configuration

Command History

Release	Modification
10.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command is supported on AIP for Cisco 7500 series routers. This command is not supported on the ATM port adapter for Cisco 7200 and 7500 series routers, nor is it supported on Cisco 4500 and Cisco 4700 routers.

Examples

The following example allows the AIP to perform a maximum of 300 packet reassemblies simultaneously:

```
atm rxbuff 300
```

atm sig-traffic-shaping strict

To specify that a switched virtual circuit (SVC) should be established on an ATM interface only if shaping can be done in accordance with the signaled traffic parameters, use the **atm sig-traffic-shaping strict** command in interface configuration mode. To disable strict traffic shaping, use the **no** form of this command.

atm sig-traffic-shaping strict

no atm sig-traffic-shaping strict

Syntax Description

This command has no arguments or keywords.

Command Default

The default value is lenient (not strict) traffic shaping for SVCs.

Command Modes

Interface configuration

Command History

Release	Modification
10.3	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command is supported on the Cisco 7500 series routers, Cisco 4500 routers, and Cisco 4700 routers. This command is not supported on the ATM port adapter.

If strict traffic shaping is configured on the router ATM interface, then an SVC is established only if traffic shaping can be provided for the transmit cell flow according to the signaled traffic parameters. If such shaping cannot be provided, the SVC is released.

If strict traffic shaping is not configured on the router ATM interface, an attempt is made to establish an SVC with traffic shaping for the transmit cell flow according to the signaled traffic parameters. If such shaping cannot be provided, the SVC is installed with default shaping parameters (it behaves as though a permanent virtual circuit (PVC) were created without specifying traffic parameters).

The signalling SETUP message carries the forward and backward traffic parameters. For connections initiated by the source router, traffic is shaped to the SETUP message forward parameters. For connections initiated by another router or host, traffic is shaped to the backward parameters.

Examples

The following example allows an SVC to be established on an ATM interface using only signaled traffic parameters:

```
atm sig-traffic-shaping strict
```

atm smds-address

To assign a unicast E.164 address to the ATM subinterface that supports ATM adaptation layer 3/4 (AAL3/4) and Switched Multimegabit Data Service (SMDS) encapsulation, use the **atm smds-address** command in interface configuration mode.

atm smds-address *address*

Syntax Description	<i>address</i> Unicast E.164 address assigned to the subinterface.
---------------------------	--

Command Default	No E.164 address is assigned.
------------------------	-------------------------------

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	10.3	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	This command is supported on Cisco 7500 series routers, Cisco 4500 routers, and Cisco 4700 routers. This command is not supported on the ATM port adapter.
	Each AAL3/4 subinterface is allowed only one unicast E.164 address.

Examples	The following example assigns a unicast E.164 address to the ATM subinterface that is being configured: <pre>atm smds-address c141.555.1212</pre>
-----------------	--

Related Commands	Command	Description
	abr	Selects ABR QoS and configures output peak cell rate and output minimum guaranteed cell rate for an ATM PVC or VC class.
	atm aal aal3/4	Enables support for AAL3/4 on an ATM interface.
	atm multicast	Assigns an SMDS E.164 multicast address to the ATM subinterface that supports AAL3/4 and SMDS encapsulation.
	pvc	Configures the PVC interface.

atm sonet report

To enable the reporting of some or all ATM Synchronous Optical Network (SONET) alarms, use the **atm sonet report** command in interface or subinterface configuration mode. To disable the reporting of some or all ATM SONET alarms, use the **no** form of this command.

atm sonet report { **all** | **b1-tca** | **b2-tca** | **b3-tca** | **lais** | **lrldi** | **none** [**ignore**] | **pais** | **plop** | **pplm** | **prdi** | **ptim** | **puneq** | **sd-ber** | **sf-ber** | **slof** | **slos** }

no atm sonet report { **all** | **b1-tca** | **b2-tca** | **b3-tca** | **lais** | **lrldi** | **none** [**ignore**] | **pais** | **plop** | **pplm** | **prdi** | **ptim** | **puneq** | **sd-ber** | **sf-ber** | **slof** | **slos** }

Syntax Description

all	Enables the reporting of all ATM SONET alarms.
b1-tca	Enables the reporting of B1 threshold crossing alarms (B1-TCA).
b2-tca	Enables the reporting of B2 threshold crossing alarms (B2-TCA).
b3-tca	Enables the reporting of B3 threshold crossing alarms (B3-TCA).
lais	Enables the reporting of line alarm indication signal (LAIS) alarms.
lrldi	Enables the reporting of line remote defect indication (LRDI) alarms.
none [ignore]	Disables the reporting of all ATM SONET alarms. The optional ignore keyword supports only OSM and SPA ATM interfaces, and instructs the ATM interface to ignore any ATM SONET alarms and to remain up and continue operation. This option allows the ATM interface to be used in a “transmit-only” mode, without a receive fiber being connected, so as to support one-way applications, such as video-on-demand. Note You must remove all IP (layer 3) configuration (such as the IP address) from the interface before you can use the none [ignore] option. Also, the none [ignore] option cannot be used with any of the other atm sonet report options.
pais	Enables the reporting of path alarm indication signal (PAIS) alarms.
plop	Enables the reporting of path loss of pointer (PLOP) alarms.
pplm	Enables the reporting of path payload mismatch (PPLM) alarms.
prdi	Enables the reporting of path remote defect indication (PRDI) alarms.
ptim	Enables the reporting of path trace identifier mismatch (PTIM) alarms.
puneq	Enables the reporting of path label equivalent to zero (path unequal, PUNEQ) alarms.
sd-ber	Enables the reporting of signal degrade bit error rate (SD-BER) alarms.
sf-ber	Enables the reporting of signal failure bit error rate (SF-BER) alarms.
slof	Enables the reporting of signal loss of frame (SLOF) alarms.
slos	Enables the reporting of signal loss of signal (SLOS) alarms.

Defaults

PLOP, SLOF, and SLOS alarms are enabled. All other alarms are not enabled.

Command Modes

Interface or subinterface configuration

Command History

Release	Modification
12.1(7)E	This command was introduced.
12.2(14)SX	This command was integrated into Cisco IOS Release 12.2(14)SX to support OSM ATM interfaces.
12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE to support ATM shared port adapters (SPAs) on the Cisco 7600 series routers and Catalyst 6500 series switches. The none [ignore] option was also added to support one-way applications.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.

Usage Guidelines

The **atm sonet report** command enables one or more of the possible SONET alarms that can be generated by the ATM interface. By default, only the PLOP, SLOF, and SLOS alarms are enabled, but you can enable the other alarms or all alarms, as well. You can also disable one or all of the alarms using the **no** form of the command.

Examples

The following example shows how to enable the alarm for B1 threshold crossings:

```
Router# configure terminal
Router(config)# interface atm 3/1/1
Router(config-if)# atm sonet report b1-tca
Router(config-if)# end
Router#
```

The following example shows multiple SONET alarms being enabled for an ATM interface:

```
Router# configure terminal
Router(config)# interface atm 5/0/1
Router(config-if)# atm sonet report b1-tca
Router(config-if)# atm sonet report b2-tca
Router(config-if)# atm sonet report b3-tca
Router(config-if)# atm sonet report plop
Router(config-if)# atm sonet report sf-ber
Router(config-if)# atm sonet report slof
Router(config-if)# atm sonet report slos
Router(config-if)# end
Router#
```

The following example shows an ATM interface being configured to ignore all ATM SONET alarms, so as to allow transmit-only operation. This example shows the error message that appears if you attempt to give this command when an IP address is configured on the interface. To resolve the problem, you must first remove the IP address and then repeat the command.

```
Router# configure terminal
Router(config)# interface atm 3/1/1
Router(config-if)# ip address 192.168.100.12 255.255.255.0
Router(config-if)# atm sonet report none ignore

%Configuration is not allowed: IP address is already configured on ATM3/1/1

Router(config-if)# no ip address 192.168.100.12 255.255.255.0
Router(config-if)# atm sonet report none ignore
Router(config-if)#
```

**Note**

When an ATM interface is configured to ignore ATM SONET alarms, you cannot then configure any IP (Layer 3) parameters on the interface. If you attempt to do so, the CLI displays the following error message:

```
%Configuration is not allowed: <interface> is already configured to ignore alarms
```

Related Commands

Command	Description
set mpls experimental imposition	Configures a policy map class with the value of the Multiprotocol Label Switching (MPLS) experimental (EXP) field to be set on all imposed label entries.
set mpls experimental topmost	Configures a policy map class to set the topmost MPLS label on outgoing packets with one or more specified experimental values.
show class-map	Displays information about the configured traffic classes.
show policy-map	Displays information about the configured policy maps and the interfaces on which they are applied.

atm sonet stm-1

To set the mode of operation and thus control type of ATM cell used for cell-rate decoupling on the SONET physical layer interface module (PLIM), use the **atm sonet stm-1** command in interface configuration mode. To restore the default Synchronous Transport Signal level 3, concatenated (STS-3c) operation, use the **no** form of this command.

atm sonet stm-1

no atm sonet stm-1

Syntax Description This command has no arguments or keywords.

Command Default STS-3c is used.

Command Modes Interface configuration

Command History	Release	Modification
	10.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines Use STM-1 in applications where the ATM switch requires “idle cells” for rate adaptation. An idle cell contains 31 zeros followed by a one. STM-1 is defined as a Synchronous Digital Hierarchy/Synchronous Transport Signal level 1 (SDH/STM-1) operation (ITU-T specification).

Use the default (STS-3c) in applications where the ATM switch requires “unassigned cells” for rate adaptation. An unassigned cell contains 32 zeros.

Examples The following example specifies ATM SONET STM-1:

```
atm sonet stm-1
```

atm sonet threshold

To configure the bit error rate (BER) threshold values for an ATM interface, use the **atm sonet threshold** command in interface configuration mode. To reset a threshold value to its default value, use the **no** form of this command.

atm sonet threshold { **b1-tca** *value* | **b2-tca** *value* | **b3-tca** *value* | **sd-ber** *value* | **sf-ber** *value* }

no atm sonet threshold { **b1-tca** | **b2-tca** | **b3-tca** | **sd-ber** | **sf-ber** }

Syntax Description

b1-tca <i>value</i>	Sets the threshold for B1 threshold crossing (B1-TCA) alarms. The <i>value</i> specifies a negative exponent to the power of 10 (10 to the power of minus <i>value</i>) for the threshold value, with a default value of 6 (10e-6).
b2-tca <i>value</i>	Sets the threshold for B2 threshold crossing (B2-TCA) alarms. The <i>value</i> specifies a negative exponent to the power of 10 (10 to the power of minus <i>value</i>) for the threshold value, with a default value of 6 (10e-6).
b3-tca <i>value</i>	Sets the threshold for B3 threshold crossing (B3-TCA) alarms. The <i>value</i> specifies a negative exponent to the power of 10 (10 to the power of minus <i>value</i>) for the threshold value, with a default value of 6 (10e-6).
sd-ber <i>value</i>	Sets the threshold for signal degrade bit error rate (SD-BER) alarms. The <i>value</i> specifies a negative exponent to the power of 10 (10 to the power of minus <i>value</i>) for the threshold value, with a default value of 6 (10e-6).
sf-ber <i>value</i>	Sets the threshold for signal failure bit error rate (SF-BER) alarms. The <i>value</i> specifies a negative exponent to the power of 10 (10 to the power of minus <i>value</i>) for the threshold value, with a default value of 3 (10e-3).

Defaults

The default values are 6 (10e-6) for **b1-tca**, **b2-tca**, **b3-tca**, and **sd-ber**. The default value is 3 (10e-3) for **sf-ber**.

Command Modes

Interface configuration

Command History

Release	Modification
12.1(7)E	This command was introduced.
12.2(14)SX	This command was integrated into Cisco IOS Release 12.2(14)SX.
12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE to support ATM shared port adapters (SPAs) on the Cisco 7600 series router and Catalyst 6500 series switch.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.

Usage Guidelines

The **atm sonet threshold** command configures the allowable threshold for errors before a Synchronous Optical Network (SONET) alarm is reported. The different SONET alarms report on errors at different points in the SONET network, allowing for the source of a problem to be more easily identified.

Use the **atm sonet threshold** command to increase or decrease the sensitivity of the ATM interface to these SONET alarms, depending on the nature of your network and application needs. In particular, if a particular problem seems to be occurring, you can increase the sensitivity of the related alarm to help you more quickly troubleshoot and diagnose the problem.

Examples

The following example shows how to configure the threshold for B1 threshold crossings:

```
Router# configure terminal
Router(config)# interface atm 3/1/1
Router(config-if)# atm sonet threshold b1-tca 9
Router(config-if)# end
Router#
```

Use the **show controllers atm** command to display the currently configured BER threshold values:

```
Router# show controllers atm 5/1/0

Interface ATM5/1/0 is up
  Framing mode: SONET OC3 STS-3c Clock source: Line
ATM framing errors:
  HCS (correctable): 0
  HCS (uncorrectable): 0

SONET Subblock:
APS
  COAPS = 0          PSBF = 0
  State: PSBF_state = false
  Rx(K1/K2): 0 /0    Tx(K1/K2): 0 /0
SECTION
  LOF = 0            LOS = 0          BIP(B1) = 603
LINE
  AIS = 0            RDI = 2          FEBE = 2332      BIP(B2) = 1018
PATH
  AIS = 0            RDI = 1          FEBE = 28         BIP(B3) = 228
  LOP = 0            NEWPTR = 0       PSE = 1         NSE = 2

Active Defects: None
Active Alarms: None
Alarm reporting enabled for: SF SLOS SLOF B1-TCA B2-TCA PLOP B3-TCA

BER thresholds: SF = 10e-3, SD = 10e-6
TCA thresholds: B1 = 10e-6, B2 = 10e-6, B3 = 10e-6

Rx S1S0 = 00, Rx C2 = 13

PATH TRACE BUFFER : STABLE

Router#
```



Note

The actual display from the **show controllers atm** command varies slightly, depending on the type of line card.

Related Commands

Command	Description
set mpls experimental imposition	Configures a policy map class with the value of the Multiprotocol Label Switching (MPLS) experimental (EXP) field to be set on all imposed label entries.
set mpls experimental topmost	Configures a policy map class to set the topmost MPLS label on outgoing packets with one or more specified experimental values.
show class-map	Displays information about the configured traffic classes.
show policy-map	Displays information about the configured policy maps and the interfaces on which they are applied.

atm svc-upc-intent

To change the intended usage parameter control (UPC) mode that is to be used on the cell flow received into the switch fabric for switched virtual circuits (SVCs) or destination legs of soft permanent virtual circuits (PVCs) on an interface, use the **atm svc-upc-intent** command in interface configuration mode. Any change in this parameter is applied to SVCs or soft PVCs subsequently established on the interface. To assign the default value to the parameter, use the **no** form of this command.

atm svc-upc-intent [**abr** | **cbr** | **vbr-rt** | **vbr-nrt** | **ubr**] {**tag** | **pass** | **drop**}

no atm svc-upc-intent

Syntax Description	abr cbr vbr-rt vbr-nrt ubr	(Optional) Specifies the service category: • abr—available bit rate • cbr—constant bit rate • vbr-rt—variable bit rate, real time • vbr-nrt—variable bit rate, nonreal time • ubr—unspecified bit rate
	tag	Specifies that cells that are received on the interface and that violate the traffic contract have their CLP bit set prior to entering the switching fabric.
	pass	Specifies that cells received on the interface are passed to the switching fabric with no change, regardless of their conformance to the traffic contract.
	drop	Specifies that cells that are received on the interface and that violate the traffic contract are dropped.

Command Default Cells received on the interface are passed to the switching fabric with no change, regardless of their conformance to the traffic contract.

Command Modes Interface configuration

Command History	Release	Modification
	11.1(4)	This command was introduced on the LS1010.
	12.2(4)B	This command was modified for the Cisco 6400 NSP.
	12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This configuration parameter determines the UPC to use for SVCs and for the destination leg of soft VC and VP. If policing is desired, it should be applied once for traffic entering a network.

Examples

In the following example, the intended UPC for SVCs on an interface is set to tagging:

```
Router(config-if)# atm svc-upc-intent tag
```

In the following example, the UBR traffic on an interface is passed while all other traffic is policed:

```
Router(config-if)# atm svc-upc-intent ubr pass
Router(config-if)# atm svc-upc-intent cbr tag
Router(config-if)# atm svc-upc-intent vbr-rt tag
Router(config-if)# atm svc-upc-intent vbr-nrt tag
Router(config-if)# atm svc-upc-intent abr drop
```

Related Commands

Command	Description
show atm interface	Displays ATM-specific information about an ATM interface.

atm txbuff

To set the maximum number of transmit buffers for simultaneous packet fragmentation, use the **atm txbuff** command in interface configuration mode. To restore the default value, use the **no** form of this command.

atm txbuff *number*

no atm txbuff

Syntax Description

<i>number</i>	Maximum number of packet fragmentations that the ATM Interface Processor (AIP) can perform simultaneously. Range is from 0 to 512. Default is 256.
---------------	--

Defaults

256

Command Modes

Interface configuration

Command History

Release	Modification
10.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command is supported on the AIP for Cisco 7500 series routers. This command is not supported on the ATM port adapter for Cisco 7200 and 7500 series routers, nor is it supported on Cisco 4500 and Cisco 4700 routers.

Examples

The following example configures the AIP to perform up to 300 packet fragmentations simultaneously:

```
atm txbuff 300
```

atm tx-latency

To specify the default transmit latency for an ATM Shared Port Adapter (SPA) interface, use the **atm tx-latency** command in interface configuration mode. To reset the default transmit latency to its default value, use the **no** form of this command.

atm tx-latency *milliseconds*

no atm tx-latency

Syntax Description

<i>milliseconds</i>	The default transmit latency for the interface, in milliseconds. The valid range is from 1 to 200, with a default of 100 milliseconds.
---------------------	--

Defaults

100 milliseconds

Command Modes

Interface configuration (ATM interface only)

Command History

Release	Modification
12.2(18)SXE	This command was introduced for the ATM Shared Port Adapters (SPA) on the Cisco 7600 series router and Catalyst 6500 series switch.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.

Usage Guidelines

The **atm tx-latency** command specifies the default maximum latency for all virtual circuits (VC) on a particular ATM SPA interface. This value is used, together with the value of the **tx-limit** command, to configure the interface and its VCs for the maximum number of transmit buffers for each VC, so that each VC can maintain the desired latency at the VC's configured line rate.



Caution

When the **atm tx-latency** command is configured on an interface, all VCs on that interface are torn down and then set up again, so that the VCs are using the correct latency and buffer values. If you have a large number of VCs configured on the interface, we recommend using this command only during scheduled maintenance times, or at other times where disruption to customer traffic can be minimized.



Tip

Use the **atm tx-latency** command to specify the default latency value for all VCs on the interface, and then use the **tx-limit** command to fine-tune the configuration for a particular VC, as needed.

Examples

The following example shows the default transmit latency for a particular ATM SPA interface being set to 20 milliseconds:

```
Router# configure terminal
Router(config)# interface atm 3/1/1
Router(config-if)# atm tx-latency 20
Router(config-if)#
```

Related Commands

Command	Description
tx-limit	Specifies the maximum number of transmit buffers for an ATM virtual circuit (VC).

atm uni-version

To specify the User-Network Interface (UNI) version (3.0 or 3.1) the router should use when Interim Local Management Interface (ILMI) link autodetermination is unsuccessful or ILMI is disabled, use the **atm uni-version** command in interface configuration mode. To restore the default value to 3.0, use the **no** form of this command.

atm uni-version *version-number*

no atm uni-version *version-number*

Syntax Description

version-number UNI version selected on an interface. Valid values are 3.0 and 3.1.

Defaults

Version 3.0

Command Modes

Interface configuration

Command History

Release	Modification
11.2	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Normally, when the ILMI link autodetermination is enabled on the interface and is successful, the router accepts the UNI version returned by ILMI. If the ILMI link autodetermination is unsuccessful or ILMI is disabled, the UNI version defaults to 3.0. You can override the default UNI version by using this command to enable UNI 3.1 signalling support. The **no** form of the command sets the UNI version to one returned by ILMI if ILMI is enabled and the link autodetermination process is successful. Otherwise, the UNI version reverts to 3.0.

Examples

The following example specifies UNI version 3.1 signaling port on the ATM interface 2/0:

```
interface atm 2/0
 atm uni-version 3.1
```

atm vc-per-vp

To set the maximum number of virtual channel identifier (VCIs) to support per virtual path identifier (VPI), use the **atm vc-per-vp** interface configuration command. To restore the default value, use the **no** form of this command.

atm vc-per-vp *number*

no atm vc-per-vp

Syntax Description

<i>number</i>	Maximum number of VCIs to support per VPI. See the following list for valid values: - AIP for Cisco 7500 series—Valid values are 16, 32, 64, 128, 256, 512, and 1024. - ATM port adapter for Cisco 7200 series and 7500 series—Valid values are 16, 32, 64, 128, 256, 512, 1024, and 2048. - NPM for Cisco 4500 and Cisco 4700 routers—Valid values are 32, 64, 128, 256, 512, 1024, 2048, 4096, and 8192. - Network module with IMA for the Cisco 2600 series and 3600 series—Valid values are 256, 512, and 1024.
---------------	--

Defaults

1024

Command Modes

Interface configuration

Command History

Release	Modification
10.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command controls the memory allocation in the ATM Interface Processor (AIP), ATM port adapter, ATM network module, or network processor module (NPM) to deal with the VCI table. It defines the maximum number of VCIs to support per VPI; it does not bound the VCI numbers.

An invalid VCI causes a warning message to be displayed.

Cisco 2600 and 3600 Series with IMA



Note

For Cisco 2600 and 3600 series with IMA, changing the value of the **atm vc-per-vp** command on one interface affects all of the interfaces on that network module.

Table 9 lists the possible VCI ranges and corresponding VPI ranges for the Cisco 2600 and 3600 series with IMA.

Table 9 *VCI and VPI Ranges for Cisco 2600 and 3600 Series with IMA*

VCI Range	VPI Range
0–255	0–15, 64–79, 128–143, and 192–207
0–511	0–15, 64–79
0–1023	0–15

Examples

The following example sets the maximum number of VCIs per VPI to 512:

```
atm vc-per-vp 512
```

Related Commands

Command	Description
pvc	Configures the PVC interface.

atm vp-filter

To set the ATM Interface Processor (AIP) filter register, use the **atm vp-filter** command in interface configuration mode. To restore the default value, use the **no** form of this command.

atm vp-filter *hexvalue*

no atm vp-filter

Syntax Description	<i>hexvalue</i> Value in hexadecimal format.				
Defaults	0x7B				
Command Modes	Interface configuration				
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>10.0</td><td>This command was introduced.</td></tr></table>	Release	Modification	10.0	This command was introduced.
Release	Modification				
10.0	This command was introduced.				

Usage Guidelines

This command is supported on Cisco 7500 series routers, but not on Cisco 4500 and Cisco 4700 routers. This command is not supported on ATM port adapters.

This command allows you to specify a virtual path identifier (VPI) or range of VPIs to be used for ATM adaptation layer 3/4 (AAL3/4) processing. All other VPIs map to AAL5 processing. If only AAL5 processing is required, you can either let the virtual path filter default or set it to an arbitrary VPI so that AAL5 processing is performed on all VPIs.

This command configures the hexadecimal value used in the virtual path filter register in the reassembly operation. The virtual path filter comprises 16 bits. The virtual path filter register uses the most significant bits (bits 15 through 8, the left half of the filter) as mask bits, and uses bits 7 through 0 (the right half of the filter) as compare bits.

When a cell is received, the right half of the filter is exclusively NORed with the binary value of the incoming VPI. The result is then ORed with the left half of the filter (the mask). If the result is all ones, reassembly is done using the VCI/message identifier (MID) table (AAL3/4 processing). Otherwise, reassembly is done using the VPI-VCI pair table (AAL5 processing).

Examples

In the following example, all incoming cells are reassembled using AAL3/4 processing:

```
atm vp-filter ff00
```

In the following example, all incoming cells with the virtual path equal to 0 are reassembled using AAL3/4 processing; all other cells are reassembled using AAL5 processing:

```
atm vp-filter 0
```

In the following example, all incoming cells with the most significant bit of the virtual path set are reassembled using AAL3/4 processing; all other cells are reassembled using AAL5 processing:

```
atm vp-filter 7f80
```

atm-address

To override the control ATM address of a Multiprotocol over ATM client (MPC) or a Multiprotocol over ATM server (MPS), use the **atm-address** command in interface configuration mode. To revert to the default address, use the **no** form of this command.

atm-address *atm-address*

no atm-address

Syntax Description

atm-address Control ATM address.

Command Default

An automatically-generated ATM address is used.

Command Modes

Interface configuration

Command History

Release	Modification
11.3(3a)WA4(5)	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command specifies the control ATM address that an MPC or MPS should use when it comes up if it is associated with a hardware interface.

The **atm-address** command overrides the default operational control address of the MPC or MPS. When this address is deleted (using the **no** form of the command), the MPC or MPS uses an automatically generated address as its control address.

Examples

The following example shows how to specify the ATM address for an MPC:

```
Router(config-if)# atm-address 47.0091810000000061705b7701.00400BFF0011.00
```

The following example shows how to specify the ATM address for an MPS:

```
Router(config-if)# atm-address 47.0091810000000061705C2B01.00E034553024.00
```

atmsig close atm

To disconnect a switched virtual circuit (SVC), use the **atmsig close atm** command in EXEC mode.

AIP on Cisco 7500 series; ATM, ATM-CES, Enhanced ATM Port Adapter on Cisco 7200 Series; 1-port ATM-25 Network Module on Cisco 2600 and 3600 Series

```
atmsig close atm slotport vcd
```

ATM and Enhanced ATM Port Adapter on Cisco 7500 series

```
atmsig close atm slotport-adapterlport vcd
```

NPM on Cisco 4500 and Cisco 4700

```
atmsig close atm number vcd
```

Syntax Description		
<i>slot</i>	ATM slot number. Use this format for the following platform configurations:	- AIP on Cisco 7500 series routers. - ATM port adapter, ATM-CES port adapter, or enhanced ATM port adapter on Cisco 7200 series routers. 1-port ATM-25 network module on Cisco 2600 and 3600 series routers.
<i>lport</i>	ATM port number. Because the AIP and all ATM port adapters have a single ATM interface, the port number is always 0. The slash (/) is required.	
<i>vcd</i>	Virtual circuit descriptor of the signalling SVC to close.	
<i>slotport-adapter</i>	ATM slot number and port adapter number. Use this format for the ATM port adapter or ATM-CES port adapter on Cisco 7500 series routers.	
<i>number</i>	ATM network processor module number for the NPM on Cisco 4500 and Cisco 4700 routers.	

Command Modes	EXEC
---------------	------

Command History	Release	Modification
	10.3	This command was introduced.
	11.1	The <i>number</i> argument was added.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	Execute this command if you want to close a particular SVC. Because virtual circuits are numbered per interface, you must specify the ATM interface by its slot number.
------------------	---

Examples

The following example closes SVC 2 on ATM interface 4/0:

```
atmsig close atm4/0 2
```

bre-connect

To enable the bridging of routed encapsulations (BRE) over a permanent virtual circuit (PVC) or switched virtual circuit (SVC), use the **bre-connect** command in VC configuration mode. To disable the bridging of routed encapsulations, use the **no** form of this command.

bre-connect *vlan-id* [**mac** *mac-address*]

no bre-connect

Syntax Description

<i>vlan-id</i>	Specifies the number of the virtual LAN (VLAN) to be used in this bridging configuration. The valid range is from 2 to 4094.
mac <i>mac-address</i>	(Optional) Specifies the hardware (MAC) address of the Ethernet customer premises equipment (CPE) device at the remote end of this VLAN.

Command Default

Bridging of route encapsulations is disabled.

Command Modes

VC configuration mode

Command History

Release	Modification
12.1(12)E	This command was introduced for the 2-port OC-12 ATM WAN Optical Services Modules (OSMs) on Cisco 7600 series routers and Catalyst 6500 series switches.
12.1(19)E1	The <i>ip-address</i> keyword and argument were removed because they were not needed.
12.2(17)S	This command, as modified in Cisco IOS Release 12.1(19)E1, was integrated into Cisco IOS Release 12.2(18)S.
12.2(17a)SX	This command was integrated into Cisco IOS Release 12.2(17a)SX.
12.2(18)SXE	Support was added for the 2-Port and 4-Port OC-3c/STM-1 ATM SPAs and the 1-Port OC-12c/STM-4 ATM SPA on the Cisco 7600 series routers and Catalyst 6500 series switches.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.

Usage Guidelines

The **bre-connect** command allows the OC-12 ATM OSM or ATM SPA to receive RFC 1483 routed encapsulated packets and forward them as Layer 2 frames. When the **bre-connect** command is configured on a PVC (or SVC), the PVC (or SVC) receives routed packets, removes the RFC 1483 routed encapsulation header, and adds an Ethernet MAC header to the packet. The Layer 2 encapsulated packet is then switched to the Layer 2 interface that is determined by the VLAN number and the MAC address for the remote CPE device (if specified).



Note

The **bridge-vlan** and **bre-connect** commands are mutually exclusive. You cannot use both commands on the same PVC for concurrent RFC 1483 and BRE bridging.

**Note**

If the ATM interface is configured with only BRE VLANs, you must also use the **spanning-tree bpdupfilter enable** command on the main ATM interface, so that the interface blocks all Spanning Tree BPDUs. If RFC 1483 bridged VLANs are also configured on the same ATM interface, or on one of its subinterfaces, do not enter the **spanning-tree bpdupfilter enable** command unless you explicitly intend to block BPDUs on the interface.

Examples

The following example shows a PVC being configured for BRE bridging using a VLAN ID of 10:

```
Router# configure terminal
Router(config)# interface atm3/1.1 point-to-point
Router(config-subif)# pvc 1/101
Router(config-if-atm-vc)# bre-connect 10
Router(config-if-atm-vc)# end
```

Related Commands

Command	Description
bridge-vlan	Configures a PVC for RFC 1483 -compliant, point-to-point bridging of Layer 2 packets over an ATM interface.
show atm pvc	Displays the configuration of a particular permanent virtual circuit (PVC).

bridge-domain

To enable RFC 1483 ATM bridging or RFC 1490 Frame Relay bridging to map a bridged VLAN to an ATM permanent virtual circuit (PVC) or Frame Relay data-link connection identifier (DLCI), use the **bridge-domain** command in Frame Relay DLCI configuration, interface configuration, interface ATM VC configuration, or PVC range configuration mode. To disable bridging, use the **no** form of this command.

bridge-domain *vlan-id* [**access** | **dot1q** [*tag*] | **dot1q-tunnel**] [**broadcast**] [**ignore-bpdu-pid**] [**pvst-tlv** *CE-vlan*] [**increment**] [**lan-fcs**] [**split-horizon**]

no bridge-domain *vlan-id*

Syntax Description		
<i>vlan-id</i>		The number of the VLAN to be used in this bridging configuration. The valid range is from 2 to 4094.
access		(Optional) Enables bridging access mode, in which the bridged connection does not transmit or act upon bridge protocol data unit (BPDU) packets.
dot1q		(Optional) Enables Institute of Electrical and Electronic Engineers (IEEE) 802.1Q tagging to preserve the class of service (CoS) information from the Ethernet frames across the ATM network. If this keyword is not specified, the ingress side assumes a CoS value of 0 for quality of service (QoS) purposes.
<i>tag</i>		(Optional—ATM PVCs only) Specifies the 802.1Q value in the range 1 to 4095. You can specify up to 32 bridge-domain command entries using dot1q tag for a single PVC. The highest tag value in a group of bridge-domain commands must be greater than the first tag entered (but no more than 32 greater).
dot1q-tunnel		(Optional) Enables IEEE 802.1Q tunneling mode, so that service providers can use a single VLAN to support customers who have multiple VLANs, while preserving customer VLAN IDs and segregating traffic in different customer VLANs.
broadcast		(Optional) Enables bridging broadcast mode on this PVC. This option is not supported for multipoint bridging. Support for this option was removed in Cisco IOS Release 12.2(18)SXF2 and Cisco IOS Release 12.2(33)SRA.
ignore-bpdu-pid		(Optional for ATM interfaces only) Ignores BPDU protocol identifiers (PIDs) and treats all BPDU packets as data packets to allow interoperation with ATM customer premises equipment (CPE) devices that do not distinguish BPDU packets from data packets.
pvst-tlv		(Optional) When the router or switch is transmitting, translates Per-VLAN Spanning Tree Plus (PVST+) BPDUs into IEEE BPDUs. When the router or switch is receiving, translates IEEE BPDUs into PVST+ BPDUs.
<i>CE-vlan</i>		Customer-edge VLAN in the Shared Spanning Tree Protocol (SSTP) tag-length-value (TLV) to be inserted in an IEEE BPDU to a PVST+ BPDU conversion.
increment		(PVC range configuration mode only) (Optional) Increments the bridge domain number for each PVC in the range.

lan-fcs	(Optional) Specifies that the VLAN bridging should preserve the Ethernet LAN frame checksum (FCS) of the Ethernet frames across the ATM network. Note This option applies only to routers using a FlexWAN module. Support for this option was removed in Cisco IOS Release 12.2(18)SXF2 and Cisco IOS Release 12.2(33)SRA.
split-horizon	(Optional) Enables RFC 1483 split horizon mode to globally prevent bridging between PVCs in the same VLAN.

Command Default

Bridging is disabled.

Command Modes

Frame Relay DLCI configuration
 Interface configuration—Only the **dot1q** and **dot1q-tunnel** keywords are supported in interface configuration mode.
 Interface ATM VC configuration
 PVC range configuration

Command History

Release	Modification
12.1(13)E	This command was introduced as the bridge-vlan command for the 2-port OC-12 ATM WAN Optical Services Modules (OSMs) on Cisco 7600 series routers and Catalyst 6500 series switches.
12.1(12c)E	This command was integrated into Cisco IOS Release 12.1(12c)E.
12.1(14)E1	This command was integrated into Cisco IOS Release 12.1(14)E1. The dot1q-tunnel keyword was added.
12.2(14)SX	This command was integrated into Cisco IOS Release 12.2(14)SX. The dot1q-tunnel keyword is not supported in this release.
12.1(19)E	The split-horizon keyword was added.
12.2(18)S	This command was integrated into Cisco IOS Release 12.2(18)S. The dot1q-tunnel and split-horizon keywords are supported in this release.
12.2(17a)SX	Support was added for the dot1q-tunnel keyword in Cisco IOS Release 12.2(17a)SX.
12.2(18)SXE	This command was renamed from bridge-vlan to bridge-domain . The access , broadcast , ignore-bpdu-pid , and increment keywords were added.
12.2(18)SXF2	Support for the lan-fcs and broadcast keywords was removed. The ignore-bpdu-pid and pvst-tlv keywords were added.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.

Usage Guidelines

RFC 1483 bridging on ATM interfaces supports the point-to-point bridging of Layer 2 packet data units (PDUs) over Ethernet networks. RFC 1490 Frame Relay bridging on Packet over SONET (POS) or serial interfaces that are configured for Frame Relay encapsulation provides bridging of Frame Relay packets over Ethernet networks.

The Cisco 7600 router can transmit BPDUs with a PID of either 0x00-0E or 0x00-07. When the router connects to a device that is fully compliant with RFC 1483 Appendix B, in which the IEEE BPDUs are sent and received by the other device using a PID of 0x00-0E, you must not use the **ignore-bpdu-pid** keyword.

If you do not enter the **ignore-bpdu-pid** keyword, the PVC between the devices operates in compliance with RFC 1483 Appendix B. This is referred to as *strict mode*. Entering the **ignore-bpdu-pid** keyword creates *loose mode*. Both modes are described as follows:

- Without the **ignore-bpdu-pid** keyword, in strict mode, IEEE BPDUs are sent out using a PID of 0x00-0E, which complies with RFC 1483.
- With the **ignore-bpdu-pid** keyword, in loose mode, IEEE BPDUs are sent out using a PID of 0x00-07, which is normally reserved for RFC 1483 data.

Cisco-proprietary PVST+ BPDUs are always sent out on data frames using a PID of 0x00-07, regardless of whether you enter the **ignore-bpdu-pid** keyword.

Use the **ignore-bpdu-pid** keyword when connecting to devices such as ATM digital subscriber line (DSL) modems that send PVST (or 802.1D) BPDUs with a PID of 0x00-07.

The **pvst-tlv** keyword enables BPDU translation when the router interoperates with devices that understand only PVST or IEEE Spanning Tree Protocol. Because the Catalyst 6500 series switch ATM modules support PVST+ only, you must use the **pvst-tlv** keyword when connecting to a Catalyst 5000 family switch that understands only PVST on its ATM modules, or when connecting with other Cisco IOS routers that understand IEEE format only.

When the router or switch is transmitting, the **pvst-tlv** keyword translates PVST+ BPDUs into IEEE BPDUs.

When the router or switch is receiving, the **pvst-tlv** keyword translates IEEE BPDUs into PVST+ BPDUs.

**Note**

The **bridge-domain** and **bre-connect** commands are mutually exclusive. You cannot use both commands on the same PVC for concurrent RFC 1483 and BRE bridging.

To preserve class of service (CoS) information across the ATM network, use the **dot1q** option. This configuration uses IEEE 802.1Q tagging to preserve the VLAN ID and packet headers as they are transported across the ATM network.

To enable service providers to use a single VLAN to support customers that have multiple VLANs, while preserving customer VLAN IDs and segregating traffic in different customer VLANs, use the **dot1q-tunnel** option on the service provider router. Then use the **dot1q** option on the customer routers.

**Note**

The **access**, **dot1q**, and **dot1q-tunnel** options are mutually exclusive. If you do not specify any of these options, the connection operates in “raw” bridging access mode, which is similar to access, except that the connection does act on and transmit BPDU packets.

RFC 1483 bridging is supported on AAL5-MUX and AAL5-LLC Subnetwork Access Protocol (SNAP) encapsulated PVCs. RFC-1483 bridged PVCs must terminate on the ATM interface, and the bridged traffic must be forwarded over an Ethernet interface, unless the **split-horizon** option is used, which allows bridging of traffic across bridged PVCs.

**Note**

RFC 1483 bridging is not supported for switched virtual circuits (SVCs). It also cannot be configured for PVCs on the main interface.

In interface configuration mode, only the **dot1q** and **dot1q-tunnel** keyword options are supported.

Examples

The following example shows a PVC being configured for IEEE 802.1Q VLAN bridging using a VLAN ID of 99:

```
Router# configure terminal
Router(config)# interface ATM6/2
Router(config-if)# pvc 2/101
Router(config-if-atm-vc)# bridge-domain 99 dot1q
Router(config-if-atm-vc)# end
```

The following example shows how to enable BPDU translation when a Catalyst 6500 series switch is connected to a device that understands only IEEE BPDUs in an RFC 1483-compliant topology:

```
Router(config-if-atm-vc)# bridge-domain 100 pvst-tlv 150
```

The **ignore-bpdu-pid** keyword is not used because the device operates in an RFC 1483-compliant topology for IEEE BPDUs.

The following example shows how to enable BPDU translation when a Catalyst 5500 ATM module is a device that understands only PVST BPDUs in a non-RFC1483-compliant topology. When a Catalyst 6500 series switch is connected to a Catalyst 5500 ATM module, you must enter both keywords.

```
Router(config-if-atm-vc)# bridge-domain 100 ignore-bpdu-pid pvst-tlv 150
```

To enable BPDU translation for the Layer 2 Protocol Tunneling (L2PT) topologies, use the following command:

```
Router(config-if-atm-vc)# bridge-domain 100 dot1q-tunnel ignore-bpdu-pid pvst-tlv 150
```

The following example shows a range of PVCs being configured, with the bridge domain number being incremented for each PVC in the range:

```
Router(config)# interface atm 8/0.100
Router(config-subif)# range pvc 102/100 102/199
Router(config-if-atm-range)# bridge-domain 102 increment
```

Related Commands

Command	Description
bre-connect	Enables the BRE over a PVC or SVC.
show atm pvc	Displays the configuration of a particular PVC.

bridge-dot1q encap

To add a VLAN ID at an ATM PVC over an ATM xDSL link, use the **bridge-dot1q encap** command in PVC configuration mode. To prevent a VLAN ID from being sent across the link, use the no form of this command.

bridge-dot1q encap *outgoing_vlan_id*

no bridge-dot1q encap *outgoing_vlan_id*

Syntax Description

<i>outgoing_vlan_id</i>	The VLAN ID to be carried over ADSL. The valid value of the VLAN ID can range from 1 to 4094.
-------------------------	---

Command Default

PVC configuration mode.

Command Modes

ATM PVC configuration modes (config-if-atm-vc)

Command History

Release	Modification
15.0(1)XA	This command was introduced.

Usage Guidelines

You can configure only one bridge-dot1q encap 802.1Q VLAN tag under a PVC.

If the incoming packet at the FE port contains an ingress 802.1Q tag, then the incoming packet is replaced by the egress 802.1Q tag while forwarding the packet over ADSL.

The Transporting 802.1q tag over PVC feature is supported only for AAL5-SNAP encapsulation.

Examples

The following example of configuring one bridge-dot1q encap 802.1Q VLAN tag under a PVC:

```
Router> enable
Router# configure terminal
Router(config)# interface ATM0.100 point-to-point
Router(config-if)# pvc 1/1
Router(config-if-atm-vc)# bridge-dot1q encap 100
Router(config-if-atm-vc)# end
```


Related Commands

Command	Description
show atm pvc	Displays all ATM permanent virtual connections (PVCs) and traffic information.

broadcast

To configure broadcast packet duplication and transmission for an ATM virtual circuit (VC) class, permanent virtual circuit (PVC), switched virtual circuit (SVC), or VC bundle, use the **broadcast** command in the appropriate command mode. To disable transmission of broadcast packets for your ATM VC class, PVC, SVC, or VC bundle, use the **no** form of this command. To restore the default behavior according to the description in the “Usage Guidelines” section, use the **default** form of this command.

broadcast

no broadcast

default broadcast

Syntax Description

This command has no arguments or keywords.

Command Default

Broadcast transmission is not enabled.
For classical IP SVCs, broadcast is enabled.

Command Modes

Interface-ATM-VC configuration (for ATM PVCs and SVCs)
VC-class configuration (for a VC-class)
Bundle configuration (for a VC bundle)
PVC range configuration (for an ATM PVC range)
PVC-in-range configuration (for an individual PVC within a PVC range)

Command History

Release	Modification
11.3 T	This command was introduced.
12.0(3)T	Enhancements were added for configuration of broadcast packet duplication and transmission for an ATM VC bundle.
12.1(5)T	This command was made available in PVC range and PVC-in-range configuration modes.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

If broadcasting and multipoint signalling are enabled on an SVC, a multipoint SVC will be created to handle the SVC.



Note

If you use the **broadcast** command to configure broadcasting for an ATM PVC or SVC, VC-class, or VC bundle, this configuration takes precedence over any previous configuration using the **broadcast** command.

If the **broadcast** command is not explicitly configured on an ATM PVC, SVC, or VC bundle, the VC inherits the following default configuration (listed in order of precedence):

- Configuration of the **broadcast** command in a VC class assigned to the PVC, SVC, or VC bundle itself.
- Configuration of the **broadcast** command in a VC class assigned to the PVC's, SVC's, or VC bundle's ATM subinterface.
- Configuration of the **broadcast** command in a VC class assigned to the PVC's, SVC's, or VC bundle's ATM main interface.

**Note**

When a VC is a member of a VC bundle, configuration using the **broadcast** command in VC-class configuration mode no longer applies to the VC. Bundle configuration takes precedence.

To use the **broadcast** command in bundle configuration mode, enter the **bundle** command to enact bundle configuration mode for the bundle for which you want to enable broadcast forwarding.

Examples

The following example enables the transmission of broadcast packets on an ATM PVC named “router5”:

```
pvc router5 1/32
 broadcast
```

The following example enables the transmission of broadcast packets on an ATM PVC bundle named “bundle1”:

```
bundle bundle1
 broadcast
```

Related Commands

Command	Description
class-int	Assigns a VC class to an ATM main interface or subinterface.
class-vc	Assigns a VC class to an ATM PVC, SVC, or VC bundle member.
encapsulation	Sets the encapsulation method used by the interface.
inarp	Configures the Inverse ARP time period for an ATM PVC, VC class, or VC bundle.
oam-bundle	Enables end-to-end F5 OAM loopback cell generation and OAM management for a virtual circuit class that can be applied to a virtual circuit bundle.
oam retry	Configures parameters related to OAM management for an ATM PVC, SVC, VC class, or VC bundle.
protocol (ATM)	Configures a static map for an ATM PVC, SVC, VC class, or VC bundle. Enables Inverse ARP or Inverse ARP broadcasts on an ATM PVC by either configuring Inverse ARP directly on the PVC, on the VC bundle, or in a VC class (applies to IP and IPX protocols only).
ubr	Configures UBR QoS and specifies the output peak cell rate for an ATM PVC, SVC, VC class, or VC bundle member.
ubr+	Configures UBR QoS and specifies the output peak cell rate and output minimum guaranteed cell rate for an ATM PVC, SVC, VC class, or VC bundle member.
vbr-nrt	Configures the VBR-NRT QoS and specifies output peak cell rate, output sustainable cell rate, and output maximum burst cell size for an ATM PVC, SVC, VC class, or VC bundle member.

cbr

To configure the constant bit rate (CBR) for the ATM circuit emulation service (CES) for an ATM permanent virtual circuit (PVC) on the Cisco MC3810 or the PA-A3 port adapter for the Cisco 7200 and 7500 series routers, use the **cbr** command in the appropriate configuration mode. To restore the default, use the **no** form of this command.

cbr *rate*

no cbr *rate*

Syntax Description

<i>rate</i>	Constant bit rate (also known as the average cell rate) for ATM CES. The valid range for this command is from 56 to 10000 kbps for ATM CES on the Cisco MC3810 or from 1 to 155000 kbps for the PA-A3 port adapter on the Cisco 7200 and 7500 series routers.
-------------	---

Command Default

The CBR is not configured.

Command Modes

Interface-ATM-VC configuration (for ATM PVCs and SVCs)
PVC range configuration (for an ATM PVC range)
PVC-in-range configuration (for an individual PVC within a PVC range)
ATM PVP configuration

Command History

Release	Modification
12.0	This command was introduced for the ATM CES on the Cisco MC3810.
12.1(5)T	This command was made available in PVC range and PVC-in-range configuration modes.
12.2(5)	Support was added for the PA-A3 port adapter on the Cisco 7200 series routers.
12.2(7)	Support was added for the PA-A3 port adapter on the Cisco 7500 series routers.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Cisco IOS XE Release 2.3	This command was made available in ATM PVP configuration mode.

Usage Guidelines

This command applies to ATM configuration on the Cisco MC3810 and the PA-A3 port adapter on the Cisco 7200 and 7500 series routers.

Examples

The following example configures the constant bit rate on ATM PVC 20 on the Cisco MC3810:

```
pvc 20
 cbr 56
```

Related Commands

Command	Description
ces	Sets the CES cell-loss integration period on the Cisco MC3810 multiservice concentrator.
cell-loss-integration-period	
ces clockmode synchronous	Configures the ATM CES synchronous clock mode on the Cisco MC3810 multiservice concentrator.
ces connect	Maps the CES service to an ATM PVC on the Cisco MC3810 multiservice concentrator.
ces initial-delay	Configures the size of the receive buffer of a CES circuit on the Cisco MC3810 multiservice concentrator.
ces max-buf-size	Configures the send buffer of a CES circuit on the Cisco MC3810 multiservice concentrator.
ces partial-fill	Configures the number of user octets per cell for the ATM CES on the Cisco MC3810 multiservice concentrator.
ces service	Configures the ATM CES type on the Cisco MC3810 multiservice concentrator.
encapsulation atm-ces	Enables CES ATM encapsulation on the Cisco MC3810 multiservice concentrator.

ces

To configure circuit emulation service (CES) on a router port and enter CES configuration mode, use the **ces** command in global configuration mode.

ces *slot/port*

Syntax Description

<i>slot/port</i>	Backplane slot number and port number on the interface. The port value is always 0 because the interface configuration applies to all ports in the slot. The slash (/) is required.
------------------	---

Command Default

No CES interface is configured.

Command Modes

Global configuration

Command History

Release	Modification
12.1(2)T	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command is used on Cisco 2600 series and 3600 series routers that have OC-3/STM-1 ATM CES network modules.

The **ces** command enters CES configuration mode. Use CES configuration mode to configure CES parameters such as the CES clock.

Examples

The following example configures the CES interface in slot 2:

```
ces 2/0
```

Related Commands

Command	Description
clock-select	Allows the selection of clock sources and priority.

ces aal1 clock

To configure the ATM adaptation layer 1 (AAL1) timing recovery clock for the constant bit rate (CBR) interface, use the **ces aal1 clock** command in interface configuration mode. To return the clock to the default, use the **no** form of this command.

ces aal1 clock {adaptive | srts | synchronous}

no ces aal1 clock

Syntax Description	adaptive	Adjusts output clock on a received AAL1 on FIFO basis. Use in unstructured mode.
	srts	Sets the clocking mode to synchronous residual time stamp.
	synchronous	Configures the timing recovery to synchronous for structured mode.

Defaults	The timing recovery is set to synchronous for structured mode.
----------	--

Command Modes	Interface configuration
---------------	-------------------------

Command History	Release	Modification
	11.1	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	The clock mode must be synchronous for structured mode. In unstructured mode, use the adaptive keyword when a network-derived clock is not available. Use the srts keyword when a network-derived clock is available but devices attached to the CES port use a different clock reference. The srts keyword samples the incoming clock, subtracts from the network clock, and sends the remainder in an AAL1 header. The clock is reconstructed during output by adding the residual to the network reference. Use the synchronous keyword for all other modes.
------------------	---

Examples	The following command sets the AAL1 timing recovery clock to adaptive mode:
----------	---

```
interface cbr 4/0
ces aal1 clock adaptive
```

Related Commands

Command	Description
ces aal1 service	Configures the type of CES used on the CBR interface.
ces dsx1 clock source	Configures a transmit clock source for the CBR interface.
network-clock-select (ATM)	Establishes the sources and priorities of the requisite clocking signals for an ATM-CES port adapter.

ces aal1 service

To configure the type of circuit emulation service used on the constant bit rate (CBR) interface, use the **ces aal1 service** command in interface configuration mode. To return the type of service to unstructured, use the **no** form of this command.

ces aal1 service {structured | unstructured}

no ces aal1 service

Syntax Description

structured	Sets the type of service to structured (cross-connect).
unstructured	Sets the type of service to unstructured (clear-channel).

Defaults

The type of service is set to unstructured (clear-channel).

Command Modes

Interface configuration

Command History

Release	Modification
11.1	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

The **structured** keyword means that each time slot is an independent entity grouped into circuits, where each circuit has an independent permanent virtual circuit (PVC).

The **unstructured** keyword reduces the incoming serial data on the receiving end of the ATM network. The keyword also sets the service to single circuit, single PVC, where all time slots are carried.

Examples

The following example changes the mode for the **ces aal1 service** command to structured:

```
interface cbr 4/0
  ces aal1 service structured
```

Related Commands

Command	Description
ces aal1 clock	Configures the AAL1 timing recovery clock for the CBR interface.
ces circuit	Configures the connection attributes for the CBR interface.
ces dsx1 clock source	Configures a transmit clock source for the CBR interface.
ces dsx1 framing	Selects the frame type for the data line on the CBR interface.
ces dsx1 lbo	Configures cable length for the CBR interface.

Command	Description
ces dsx1 linecode	Selects the line code type for the CBR interface.
ces dsx1 loopback	Enables a loopback for the CBR interface.
ces dsx1 signalmode robbedbit	Enables the signal mode as robbed bit on a CBR interface.
ces pvc	Configures the destination port for the circuit on the CBR interface.
show ces circuit	Displays detailed circuit information for the CBR interface.
show ces interface cbr	Displays detailed CBR port information.
show ces status	Displays the status of the ports on the ATM-CES port adapter.
show interface cbr	Displays the information about the CBR interface on the ATM-CES port adapter.

ces circuit

To configure the connection attributes for the constant bit rate (CBR) interface, use the **ces circuit** command in interface configuration mode. To return the connection attributes to the default or to enable the circuit, use the **no** form of this command.

ces circuit *circuit-number* [**cas** | **no cas**] [**cdv** *range*] [**circuit-name** *name*] [**on-hook-detection** *hex-number*] [**partial-fill** *range*] [**shutdown** | **no shutdown**] [**timeslots** *range*]

no ces circuit *circuit-number* [[**no**] **cas**] [**cdv** *range*] [**circuit-name** *name*] [**on-hook-detection** *hex-number*] [**partial-fill** *range*] [[**no**] **shutdown**] [**timeslots** *range*]

Syntax Description		
<i>circuit-number</i>		Selects the circuit identification. For unstructured service, use 0. For T1 structured service, the range is from 1 to 24. For E1 structure service, the range is from 1 to 31.
cas		(Optional) Enables channel-associated signaling for structured service only. no cas disables channel-associated signaling. The default is no cas .
no cas		(Optional) Disables channel-associated signaling for structured service only. This is the default.
cdv <i>range</i>		(Optional) Enables the peak-to-peak cell delay variation requirement. The range for CDV is 1 through 65535 milliseconds. The default is 2000 milliseconds.
circuit-name <i>name</i>		(Optional) Sets the ASCII name for the circuit emulation service internetworking function CES-IWF circuit. The string for the circuit name ranges from 0 to 255. The default is CBRx/x:0.
on-hook-detection <i>hex-number</i>		(Optional) Enables detection of whether the circuit is on-hook. Hex values are 0 through F to indicate a 2- or 4-bit AB[CD] pattern to detect on-hook. The AB[CD] bits are determined by the manufacturer of the voice/video telephony device that is generating the CBR traffic.
partial-fill <i>range</i>		(Optional) Enables the partial AAL1 cell fill service for structured service only. The range is from 0 to 47. The default is 47.
shutdown		(Optional) Marks the CES-IWF circuit administratively down. The default is no shutdown .
no shutdown		(Optional) Returns the CES-IWF circuit to an administrative up state.
timeslots <i>range</i>		(Optional) Configures the time slots for the CES-IWF circuit for structured service only. The range is from 1 to 24 for T1. The range is from 1 to 31 for E1.

Command Default No circuit is configured.

Command Modes Interface configuration

Command History

Release	Modification
11.1	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Channel-associated signalling (CAS) provides information about the time slot (on or off the hook) and is updated once per multiframe.

With both the CAS and on-hook detection features enabled, these features work together to enable an ingress node in an ATM network to monitor on-hook and off-hook conditions for a specified 1 x 64 structured CES circuit. As implied by the notation “1 x 64,” the on-hook detection (or bandwidth-release) feature is supported only in a structured CES circuit that involves a single time slot at each end of the connection.

The time slot configured for the structured CES circuit at the ingress node (time slot 2) can be different from the DS0 time slot configured at the egress node (time slot 4). Only one such time slot can be configured at each end of the circuit when the on-hook detection feature is used.

When you invoke the on-hook feature, the ingress ATM-CES port adapter monitors the ABCD bits in the incoming CBR bit stream to detect on-hook and off-hook conditions in the circuit. In an “off-hook” condition, all the bandwidth provisioned for the specified CES circuit is used for transporting ATM AAL1 cells across the network from the ingress node to the egress node.

In an on-hook condition, the network periodically sends dummy ATM cells from the ingress node to the egress node to maintain the connection. However, these dummy cells consume only a fraction of the circuit’s reserved bandwidth, leaving the rest of the bandwidth available for use by other network traffic. This bandwidth-release feature enables the network to make more efficient use of its resources.

When the CAS feature is enabled for a CES circuit, the bandwidth of the DS0 channel is limited to 56 kbps for user data, because CAS functions consume 8 kbps of channel bandwidth for transporting the ABCD signalling bits. These signalling bits are passed transparently from the ingress node to the egress node as part of the ATM AAL1 cell stream.

In summary, when the optional CAS and on-hook detection features are enabled, the following conditions apply:

- The permanent virtual connection (PVC) provisioned for the CES circuit always exists.
- The bandwidth for the CES circuit is always reserved.
- During an on-hook state, most of the bandwidth reserved for the CES circuit is not in use. (Dummy cells are sent from the ingress node to the egress node to maintain the connection.) Therefore, this bandwidth becomes available for use by other network traffic, such as available bit rate (ABR) traffic.
- During an off-hook state, all the bandwidth reserved for the CES circuit is dedicated to that circuit.

Examples

The following example sets the structured service CDV range to 5000 milliseconds and enables the interface:

```
interface cbr 4/0
  ces circuit 3 cdv 5000
  ces circuit 3 no shutdown
```

Related Commands

Command	Description
ces aal1 service	Configures the type of CES used on the CBR interface.
show ces circuit	Displays detailed circuit information for the CBR interface.
show ces interface cbr	Displays detailed CBR port information.
show ces status	Displays the status of the ports on the ATM-CES port adapter.
show interface cbr	Displays the information about the CBR interface on the ATM-CES port adapter.

ces dsx1 clock source

To configure a transmit clock source for the constant bit rate (CBR) interface, use the **ces dsx1 clock source** command in interface configuration mode. To return the clock source to the default, use the **no** form of this command.

ces dsx1 clock source {loop-timed | network-derived}

no ces dsx1 clock source

Syntax Description

loop-timed	Configures the transmit clock to loop (RX-clock to TX-clock).
network-derived	Configures the transmit clock to be derived from the network.

Command Default

The transmit clock is derived from the network.

Command Modes

Interface configuration

Command History

Release	Modification
11.1	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following example sets the clock source to loop-timed:

```
interface cbr 4/0
ces dsx1 clock source loop-timed
```

Related Commands

Command	Description
ces aal1 clock	Configures the AAL1 timing recovery clock for the CBR interface.
ces aal1 service	Configures the type of CES used on the CBR interface.
network-clock-select (ATM)	Establishes the sources and priorities of the requisite clocking signals for an ATM-CES port adapter.
show ces circuit	Displays detailed circuit information for the CBR interface.
show ces interface cbr	Displays detailed CBR port information.
show interface cbr	Displays the information about the CBR interface on the ATM-CES port adapter.

ces dsx1 framing

To select the frame type for the data line on the constant bit rate (CBR) interface, use the **ces dsx1 framing** command in interface configuration mode. To return the frame type to the default, use the **no** form of this command.

T1

ces dsx1 framing {esf | sf}

no ces dsx1 framing

E1

ces dsx1 framing {e1_crc_mfCASlt | e1_crc_mf_lt | e1_lt | e1_mfCAS_lt}

no ces dsx1 framing

Syntax Description

esf	Configures the line type to extended super frame for T1.
sf	Configures the line type to super frame for T1.
e1_crc_mfCASlt	Configures the line type to E1 CRC with channel-associated signalling (CAS) enabled.
e1_crc_mf_lt	Configures the line type to E1 CRC with CAS disabled.
e1_lt	Configures the line type to E1 with CAS disabled.
e1_mfCAS_lt	Configures the line type to E1 with CAS enabled.

Defaults

esf (for T1)
e1_lt (for E1)

Command Modes

Interface configuration

Command History

Release	Modification
11.1	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Use this command in configurations where the router communicates with the data line. The service provider determines which framing type is required for your circuit.

Examples

The following example sets the data line type to super frame:

```
interface cbr 4/0
ces dsx1 framing sf
```

Related Commands

Command	Description
ces aal1 service	Configures the type of CES used on the CBR interface.
show ces circuit	Displays detailed circuit information for the CBR interface.
show ces interface cbr	Displays detailed CBR port information.
show ces status	Displays the status of the ports on the ATM-CES port adapter.
show interface cbr	Displays the information about the CBR interface on the ATM-CES port adapter.

ces dsx1 lbo

To configure cable length for the constant bit rate (CBR) interface, use the **ces dsx1 lbo** command in interface configuration mode. To return the cable length to the default, use the **no** form of this command.

ces dsx1 lbo *length*

no ces dsx1 lbo

Syntax Description	<i>length</i> Sets the cable length. Values (in feet) are 0_110 , 110_200 , 220_330 , 330_440 , 440_550 , 550_660 , 660_above , and square_pulse . Values represent a range in feet.
---------------------------	--

Defaults	0_110 feet
-----------------	-------------------

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	11.1	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	Set the cable length to the desired number of feet on your system.
-------------------------	--

Examples	The following example sets the cable length to 440 feet:
-----------------	--

```
interface cbr 4/0
  ces dsx1 lbo 440_550
```

Related Commands	Command	Description
	atm lbo	Specifies the cable length (line build-out) for the ATM interface.
	ces aal1 service	Configures the type of CES used on the CBR interface.
	show ces circuit	Displays detailed circuit information for the CBR interface.
	show ces interface cbr	Displays detailed CBR port information.
	show ces status	Displays the status of the ports on the ATM-CES port adapter.
	show interface cbr	Displays the information about the CBR interface on the ATM-CES port adapter.

ces dsx1 linecode

To select the line code type for the constant bit rate (CBR) interface, use the **ces dsx1 linecode** command in interface configuration mode. To return the line code to the default, use the **no** form of this command.

T1

```
ces dsx1 linecode {ami | b8zs}
```

```
no ces dsx1 linecode
```

E1

```
ces dsx1 linecode {ami | hdb3}
```

```
no ces dsx1 linecode
```

Syntax Description

ami	Specifies the alternate mark inversion (AMI) as the line code type. Valid for T1 and E1 interfaces.
b8zs	Specifies B8ZS as the line code type. Valid for T1 interfaces. This is the default for T1.
hdb3	Specifies HDB3 as the line code type. Valid for E1 interfaces. This is the default for E1.

Defaults

For T1 interfaces, B8ZS is used as the line code type. For E1 interfaces, HDB3 is used as the line code type.

Command Modes

Interface configuration

Command History

Release	Modification
11.1	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Use this command in configurations where the switch communicates with the data line. The service provider determines which line code type is required for your circuit.

Examples

The following example specifies B8ZS as the line code type:

```
interface cbr 4/0
ces dsx1 linecode b8zs
```

Related Commands

Command	Description
ces aal1 service	Configures the type of CES used on the CBR interface.
show ces circuit	Displays detailed circuit information for the CBR interface.
show ces interface cbr	Displays detailed CBR port information.
show ces status	Displays the status of the ports on the ATM-CES port adapter.
show interface cbr	Displays the information about the CBR interface on the ATM-CES port adapter.

ces dsx1 loopback

To enable a loopback for the constant bit rate (CBR) interface, use the **ces dsx1 loopback** command in interface configuration mode. To disable the loopback, use the **no** form of this command.

ces dsx1 loopback {line | noloop | payload}

no ces dsx1 loopback {line | noloop | payload}

Syntax Description

line	Sets the received signal to be looped at the line (does not penetrate the line).
noloop	Sets the interface to no loop.
payload	Sets the received signal to be looped through the device and returned.

Command Default

No loopback is enabled.

Command Modes

Interface configuration

Command History

Release	Modification
11.1	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command is useful for testing the circuit emulation port adapter module.

Examples

The following example sets a payload loopback:

```
interface cbr 4/0
  ces dsx1 loopback payload
```

Related Commands

Command	Description
ces aal1 service	Configures the type of CES used on the CBR interface.
loopback	Configures the ATM interface into loopback mode.
show ces circuit	Displays detailed circuit information for the CBR interface.
show ces interface cbr	Displays detailed CBR port information.
show ces status	Displays the status of the ports on the ATM-CES port adapter.
show interface cbr	Displays the information about the CBR interface on the ATM-CES port adapter.

ces dsx1 signalmode robbedbit

To enable the signal mode as robbed bit on a constant bit rate (CBR) interface, use the **ces dsx1 signalmode robbedbit** command in interface configuration mode. To return the signal mode to the default, use the **no** form of this command.

ces dsx1 signalmode robbedbit

no ces dsx1 signalmode robbedbit

Syntax Description This command has no arguments or keywords.

Command Default No signal mode is enabled.

Command Modes Interface configuration

Command History	Release	Modification
	11.1	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines A T1 frame consists of 24 time slots (DS0) that send at a rate of 64 kbps. T1 defines the ability to send signaling in-band on individual time slots by removing the low bit of each byte for signaling in robbedbit mode. This procedure allows 8 kbps for signalling and leaves 56 kbps for data.

In structured mode, you can send the T1 signalling information across the network. Structured mode means that after you enable **robbedbit** signalling mode on the port, and enable CAS on individual circuits that need this type of service, you are robbing bits from the DS0. The system then puts the bits in the specified format to be sent across the network and reinserts them at the passive side on the CES-IWF connection.

Examples The following example enables channel-associated signaling and robbed-bit signaling:

```
interface cbr 4/0
  ces circuit 1 cas
  ces dsx1 signalmode robbedbit
```

Related Commands

Command	Description
ces aal1 service	Configures the type of CES used on the CBR interface.
ces circuit	Configures the connection attributes for the CBR interface.
show ces circuit	Displays detailed circuit information for the CBR interface.
show ces interface cbr	Displays detailed CBR port information.
show ces status	Displays the status of the ports on the ATM-CES port adapter.
show interface cbr	Displays the information about the CBR interface on the ATM-CES port adapter.

ces partial-fill

To configure the number of user octets per cell for the ATM circuit emulation service (CES), use the **ces partial-fill** command in interface configuration mode. To delete the CES partial-fill value, use the **no** form of this command.

ces partial-fill *octets*

no ces partial-fill *octets*

Syntax Description	<i>octets</i> Number of user octets per cell for the CES. Possible values of octet range from 0 to 47. The default is 47.	
Defaults	47 octets	
Command Modes	Interface configuration	
Command History	Release	Modification
	11.3MA	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Usage Guidelines	This command applies to ATM configuration on the Cisco MC3810. Setting the value of the ces partial-fill command to zero disables partial cell fill and causes all cells to be completely filled before they are sent. This command is supported on serial ports 0 and 1 when the encapsulation atm-ces command is enabled.	
Examples	The following example sets the CES partial cell fill to 20 octets per cell for serial port 0: <pre>interface serial 0 ces partial-fill 20</pre>	
Related Commands	Command	Description
	ces cell-loss-integration-period	Sets the CES cell-loss integration period on the Cisco MC3810 multiservice concentrator.
	ces clockmode synchronous	Configures the ATM CES synchronous clock mode on the Cisco MC3810 multiservice concentrator.

Command	Description
ces connect	Maps the CES service to an ATM PVC on the Cisco MC3810 multiservice concentrator.
ces initial-delay	Configures the size of the receive buffer of a CES circuit on the Cisco MC3810 multiservice concentrator.
ces max-buf-size	Configures the send buffer of a CES circuit on the Cisco MC3810 multiservice concentrator.
ces service	Configures the ATM CES type on the Cisco MC3810 multiservice concentrator.

ces pvc

To configure the destination port for the circuit on the constant bit rate (CBR) interface, use the **ces pvc** command in interface configuration mode. To remove the destination port on the circuit, use the **no** form of this command.

ces pvc *circuit-number* **interface atm** *slot/port* **vpi** *number* **vci** *number*

no ces pvc *circuit-number* **interface atm** *slot/port* **vpi** *number* **vci** *number*

Syntax Description

<i>circuit-number</i>	Selects the circuit identification. The range is from 0 to 24. For unstructured service, use 0. For T1 structure service, the range is from 1 to 24. For E1 structure service, the range is from 1 to 31.
interface atm <i>slot/port</i>	Slot and port number of the ATM interface. The slash (/) is required. Used to create a hard permanent virtual circuit (PVC). Only a hard PVC can be configured for the CBR interfaces on the ATM-CES port adapter.
vpi <i>number</i>	Virtual path identifier of the destination PVC. Range is from 0 to 255.
vci <i>number</i>	Virtual channel identifier of the destination PVC. Range is from 1 to 16383.

Command Default

No destination port is configured.

Command Modes

Interface configuration

Command History

Release	Modification
11.1	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Use the **interface** option to create a hard PVC. Use the **dest-atm-addr** option to create a soft PVC. Soft PVCs are not supported on Cisco 7200 series routers.

You must configure both sides of the CES circuits because at the source (the active side in CES-IWF), the time slots are not recognized at the destination (the passive side).

Each CES circuit has an ATM address. When configuring the source PVC, you need the destination ATM address.

Examples

The following example shows setting a hard PVC. In this example, the destination of ATM port 0 in slot 1 is assigned to circuit 31 on CBR port 0 in slot 1.

```
interface cbr 1/0
ces pvc 31 interface atm 1/0 vpi 0 vci 512
```

Related Commands

Command	Description
ces aal1 service	Configures the type of CES used on the CBR interface.
show ces circuit	Displays detailed circuit information for the CBR interface.
show ces interface cbr	Displays detailed CBR port information.
show ces status	Displays the status of the ports on the ATM-CES port adapter.
show interface cbr	Displays the information about the CBR interface on the ATM-CES port adapter.

ces-cdv

To set the cell delay variation, use the **ces-cdv** command in interface-ATM-VC configuration mode.

ces-cdv *time*

Syntax Description	<i>time</i>	Maximum tolerable cell arrival jitter with a range from 1 to 65535 microseconds. Default is 5000.
--------------------	-------------	---

Defaults	5000 microseconds
----------	-------------------

Command Modes	Interface-ATM-VC configuration
---------------	--------------------------------

Command History	Release	Modification
	12.1(2)T	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	This command is used on Cisco 2600 series and 3600 series routers that have OC-3/STM-1 ATM CES network modules.
------------------	---

Examples	The following example configures the maximum tolerable cell arrival jitter at 7500 microseconds: <pre>interface atm1/0 pvc 0 0/41 ces ces-cdv 7500</pre>
----------	---

Related Commands	Command	Description
	interface atm	Configures the ATM interface.
	svc	Configures the SVC.

class-int

To assign a virtual circuit (VC) class to an ATM main interface or subinterface, use the **class-int** command in interface configuration mode. To remove a VC class, use the **no** form of this command.

class-int *vc-class-name*

no class-int *vc-class-name*

Syntax Description

<i>vc-class-name</i>	Name of the VC class you are assigning to your ATM main interface or subinterface.
----------------------	--

Command Default

No VC class is assigned to an ATM main interface or subinterface.

Command Modes

Interface configuration

Command History

Release	Modification
11.3(4)T	This command was introduced, replacing the class command for assigning VC classes to ATM main interfaces or subinterfaces.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Use this command to assign a previously defined set of parameters (defined in a VC class) to an ATM main interface or subinterface. To create a VC class that defines these parameters, use the **vc-class atm** command. Refer to the section “Configuring VC Classes” in the “Configuring ATM” chapter of the *Cisco IOS Wide-Area Networking Configuration Guide* for more information.

To use this command for assigning a VC class to an ATM main interface or subinterface, you must first enter the **interface atm** command to enter interface configuration mode.

When you create a VC class for an ATM main interface or subinterface, you can use the following commands to define your parameters: **abr**, **broadcast**, **bump**, **encapsulation**, **idle-timeout**, **ilmi manage**, **inarp**, **oam-bundle**, **oam-pvc**, **oam retry**, **oam-svc**, **protocol**, **ubr**, **ubr+**, and **vbr-nrt**.

Parameters applied to an individual VC supersede interface- and subinterface-level parameters. Parameters that are configured for a VC through discrete commands entered in interface-ATM-VC configuration mode supersede VC class parameters assigned to an ATM main interface or subinterface by the **class-int** command.

Examples

In the following example, a class called “classA” is first created and then applied to ATM main interface 2/0:

```
! The following commands create the class classA:
vc-class atm classA
ubr 10000
encapsulation aal5mux ip
```

```
! The following commands apply classA to ATM main interface 2/0:
interface atm 2/0
class-int classA
```

Related Commands

Command	Description
protocol (ATM)	Configures a static map for an ATM PVC, SVC, VC class, or VC bundle and enables Inverse ARP or Inverse ARP broadcasts on an ATM PVC.
show atm map	Displays the list of all configured ATM static maps to remote hosts on an ATM network.
vc-class atm	Configures a VC class for an ATM VC or interface.

class-vc

To assign a virtual circuit (VC) class to an ATM permanent virtual circuit (PVC), switched virtual circuit (SVC), or VC bundle member, use the **class-vc** command in the appropriate configuration mode. To remove a VC class, use the **no** form of this command.

class-vc *name*

no class-vc *name*

Syntax Description

<i>name</i>	Name of the VC class.
-------------	-----------------------

Command Default

No VC class is assigned.

Command Modes

Bundle-vc configuration (for VC bundle members)
 Interface-ATM-VC configuration (for ATM PVCs and SVCs)
 PVC-in-range configuration (for an individual PVC within a PVC range)

Command History

Release	Modification
11.3(4)T	This command was introduced.
12.0(3)T	This command was modified to support application of a VC class to an ATM VC bundle and an ATM VC bundle member.
12.1(5)T	This command was made available in PVC-in-range configuration mode.
12.2(16)BX	This command was integrated into Cisco IOS Release 12.2(16)BX.
12.0(26)S	This command was integrated into Cisco IOS Release 12.0(26)S.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(31)SB	This command was integrated into Cisco IOS Release 12.2(31)SB.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Use this command to assign a previously defined set of parameters (defined in a VC class) to an ATM PVC, SVC, or VC bundle member. To create a VC class that defines these parameters, use the **vc-class atm** command.

ATM PVCs and SVCs

To use this command for assigning a VC class to an ATM PVC or SVC, you must first enter the **interface atm** command in global configuration mode and then the **pvc** or **svc** command in interface configuration mode.

When you create a VC class for an ATM PVC or SVC, you can use the following commands to define your parameters: **abr**, **broadcast**, **bump**, **encapsulation**, **idle-timeout**, **ilmi manage**, **inarp**, **oam-bundle**, **oam-pvc**, **oam retry**, **oam-svc**, **protocol**, **ubr**, **ubr+**, and **vbr-nrt**.

Parameters that are configured for a PVC or SVC through discrete commands entered in interface-ATM-VC configuration mode supersede VC class parameters assigned to an ATM PVC or SVC by the **class-vc** command.

ATM VC Bundle Members

To use this command for assigning a VC class to a VC bundle member, you must first use the **pvc-bundle** command to enter bundle-vc configuration mode.

When you create a VC class for a VC bundle member, you can use the following commands to define your parameters: **bump**, **precedence**, **protect**, **ubr**, **ubr+**, and **vbr-nrt**.

You cannot use the following commands in vc-class configuration mode to configure a VC bundle member: **broadcast**, **encapsulation**, **inarp**, and **protocol**. These commands are usable only at the bundle level, not the bundle member level.

Parameters applied to an individual VC supersede bundle-level parameters. Parameters that are directly configured for a VC through discrete commands entered in bundle-vc configuration mode supersede VC class parameters assigned to a VC bundle member by the **class-vc** command.

Examples

In the following example, a class named classA is created and then applied to an ATM PVC:

```
! The following commands create the class classA:
vc-class atm classA
  ubr 10000
  encapsulation aal5mux ip

! The following commands apply classA to an ATM PVC:
interface atm 2/0
  pvc router5 1/32
  class-vc classA
```

In the following example, a class named classA is created and then applied to a bundle member named vcmember, which is a member of bundle bundle1:

```
! The following commands create the class classA:
vc-class atm classA
  precedence 6-5
  no bump traffic
  protect group
  bump explicitly 7
  vbr-nrt 20000 10000 32

! The following commands create bundle1, add vcmember to bundle1, and then applies classA
! to vcmember:
bundle bundle1
  pvc-bundle vcmember
  class-vc classA
```

In the preceding example, because of hierarchy precedence rules, the VC bundle member named vcmember has the following characteristics:

- It carries traffic whose IP Precedence level is 6 and 5.
- It does not allow other traffic to be bumped onto it. When the VC goes down, its bumped traffic will be redirected to a VC whose IP Precedence level is 7.
- It is a member of the protected group of the bundle. When all members of a protected group go down, the bundle goes down.
- It has variable bit rate-nonreal-time (VBR-NRT) quality of service traffic parameters.

Related Commands

Command	Description
abr	Selects available bit rate (ABR) quality of service (QoS) and configures the output peak cell rate and output minimum guaranteed cell rate for an ATM PVC or VC class.
broadcast	Configures broadcast packet duplication and transmission for an ATM VC class, PVC, SVC, or VC bundle.
bump	Configures the bumping rules for a VC class that can be assigned to a VC bundle.
class-bundle	Configures a VC bundle with the bundle-level commands in the specified VC class.
encapsulation	Sets the encapsulation method used by the interface.
idle-timeout	Configures the idle timeout parameter for tearing down an ATM switched virtual circuit (SVC) connection.
ilmi manage	Enables Integrated Local Management Interface (ILMI) management on an ATM PVC.
inarp	Configures the Inverse ARP time period for an ATM PVC, VC class, or VC bundle.
oam-bundle	Enables end-to-end F5 Operation, Administration, and Maintenance (OAM) loopback cell generation and OAM management for a VC class that can be applied to a VC bundle.
oam-pvc	Enables end-to-end F5 OAM loopback cell generation and OAM management for an ATM PVC or VC class.
oam retry	Configures parameters related to OAM management for an ATM PVC, SVC, VC class, or VC bundle.
oam-svc	Enables end-to-end F5 OAM loopback cell generation and OAM management for an ATM SVC or VC class.
precedence	Configures precedence levels for a VC class that can be assigned to a VC bundle and thus applied to all VC members of that bundle.
protect	Configures a VC class with protected group or protected VC status for application to a VC bundle member.
protocol	Configures a static map for an ATM PVC, SVC, or VC class or enables Inverse Address Resolution Protocol (ARP) or Inverse ARP broadcasts on an ATM PVC.
pvc	Creates or assigns a name to an ATM PVC, specifies the encapsulation type on an ATM PVC, and enters interface-ATM-VC configuration mode.
pvc-bundle	Adds a PVC to a bundle as a member of the bundle and enters bundle-vc configuration mode in order to configure that PVC bundle member.
show atm bundle	Displays the bundle attributes assigned to each bundle VC member and the current working status of the VC members.
show atm bundle statistics	Displays statistics on the specified bundle.
show atm map	Displays the list of all configured ATM static maps to remote hosts on an ATM network.
svc	Creates an ATM SVC and specifies the destination network service access point (NSAP) address on a main interface or subinterface.

Command	Description
ubr	Configures unspecified bit rate (UBR) quality of service (QoS) and specifies the output peak cell rate (PCR) for an ATM PVC, PVC range, SVC, VC class, or VC bundle member.
ubr+	Configures UBR QoS and specifies the output peak cell rate and output minimum guaranteed cell rate for an ATM PVC, SVC, VC class, or VC bundle member.
vbr-nrt	Configures the VBR-NRT QoS and specifies output peak cell rate, output sustainable cell rate, and output maximum burst cell size for an ATM PVC, SVC, VC class, or VC bundle member.
vc-class atm	Configures a VC class for an ATM VC or interface.

clear atm arp

To clear Address Resolution Protocol (ARP) entries for an ATM interface that is configured as an ARP server, use the **clear atm arp** command in privileged EXEC mode.

clear atm arp *atm-interface* [*ip-address* | *]

Syntax Description

<i>atm-interface</i>	ATM interface number (for example, 3/0).
<i>ip-address</i>	Clears the ARP entry for the specified IP address.
*	Clears all ARP entries on the interface.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
11.2	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Use this command to clear ARP entries for an ATM interface. Specify the IP address of a particular entry to be deleted, or use the asterisk (*) to delete all the ARP entries for the interface.

If an ARP entry for an existing virtual circuit (VC) is deleted, the ARP server will immediately try to get another entry for that VC.

Examples

The following example shows how to delete the ARP entry for 172.20.173.28:

```
Router# clear atm arp 3/0 172.20.173.28
```

clear atm atm-vc

To clear ATM virtual circuits on an interface, use the **clear atm atm-vc** command in privileged EXEC mode.

clear atm atm-vc interface *type number vpi vci*

Syntax Description

interface <i>type number</i>	Clears ATM virtual circuits on the specified interface.
<i>vpi</i>	Virtual path identifier (VPI). The value range is from 0 to 4095.
<i>vci</i>	Virtual circuit identifier (VCI). The value range is from 0 to 65535.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
15.0(1)M	This command was introduced in a release earlier than Cisco IOS Release 15.0(1)M.
12.2(33)SRC	This command was integrated into a release earlier than Cisco IOS Release 12.2(33)SRC.

Examples

The following example shows how to clear ATM virtual circuits on the specified interface:

```
Router# clear atm atm-vc atm 2/0 5 2
```

Related Commands

Command	Description
show atm vc	Displays all ATM PVCs, SVCs, and traffic information.

clear atm signalling statistics

To clear ATM signaling statistics for all interfaces, use the **clear atm signalling statistics** command in privileged EXEC mode.

clear atm signalling statistics [**interface** *type number*]

Syntax Description

interface *type number* (Optional) Specifies the type and number of the interface.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
15.0(1)M	This command was introduced in a release earlier than Cisco IOS Release 15.0(1)M.
12.2(33)SRC	This command was integrated into a release earlier than Cisco IOS Release 12.2(33)SRC.

Examples

The following example shows how to clear ATM signaling statistics for all interfaces:

```
Router# clear atm signalling statistics interface atm2/0/0
```

Related Commands

Command	Description
show atm signalling statistics	Displays ATM signaling statistics counters.

clear atm vc

To release a specified switched virtual circuit (SVC), use the **clear atm vc** command in privileged EXEC mode.

clear atm vc *vcd*

Syntax Description	<i>vcd</i>	Virtual channel descriptor of the channel to be released.
---------------------------	------------	---

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	11.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	For multicast or control virtual channel connections (VCCs), this command causes the LAN emulation (LANE) client to exit and rejoin an emulated LAN.
	For data VCCs, this command also removes the associated LAN Emulation Address Resolution Protocol (LE ARP) table entries.

Examples	The following example shows how to release SVC 1024:
	Router# clear atm vc 1024

clear lane le-arp

To clear the dynamic LAN Emulation Address Resolution Protocol (LE ARP) table or a single LE ARP entry of the LANE client configured on the specified subinterface or emulated LAN, use the **clear lane le-arp** command in user EXEC or privileged EXEC mode.

Cisco 7500 Series

```
clear lane le-arp [interface slot/port [.subinterface-number] | name elan-name] [mac-address
mac-address | route-desc segment segment-number bridge bridge-number]
```

Cisco 4500 and 4700 Routers

```
clear lane le-arp [interface number [.subinterface-number] | name elan-name] [mac-address
mac-address | route-desc segment segment-number bridge bridge-number]
```

Syntax Description

interface <i>slot/port</i> [<i>.subinterface-number</i>]	(Optional) Interface or subinterface for the LAN emulation (LANE) client whose LE ARP table or entry is to be cleared for the Cisco 7500 series routers. The space between the interface keyword and the <i>slot</i> argument is optional.
interface <i>number</i> [<i>.subinterface-number</i>]	(Optional) Interface or subinterface for the LANE client whose LE ARP table or entry is to be cleared for the Cisco 4500 or 4700 routers. The space between the interface keyword and the <i>number</i> argument is optional.
name <i>elan-name</i>	(Optional) Name of the emulated LAN for the LANE client whose LE ARP table or entry is to be cleared. Maximum length is 32 characters.
mac-address <i>mac-address</i>	(Optional) Keyword and MAC address of the LANE client.
route-desc segment <i>segment-number</i>	(Optional) Keywords and LANE segment number. The segment number ranges from 1 to 4095.
bridge <i>bridge-number</i>	(Optional) Keyword and bridge number that is contained in the route descriptor. The bridge number ranges from 1 to 15.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
11.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command removes dynamic LE ARP table entries only. It does not remove static LE ARP table entries.

If you do not specify an interface or an emulated LAN, this command clears all the LE ARP tables of any LANE client in the router.

If you specify a major interface (not a subinterface), this command clears all the LE ARP tables of every LANE client on all the subinterfaces of that interface.

This command also removes the fast-cache entries built from the LE ARP entries.

Examples

The following example shows how to clear all the LE ARP tables for all clients on the router:

```
Router# clear lane le-arp
```

The following example shows how to clear all the LE ARP tables for all LANE clients on all the subinterfaces of interface 1/0:

```
Router# clear lane le-arp interface 1/0
```

The following example shows how to clear the entry corresponding to MAC address 0800.aa00.0101 from the LE ARP table for the LANE client on the emulated LAN named red:

```
Router# clear lane le-arp name red 0800.aa00.0101
```

The following example shows how to clear all dynamic entries from the LE ARP table for the LANE client on the emulated LAN named red:

```
Router# clear lane le-arp name red
```

The following example shows how to clear the dynamic entry from the LE ARP table for the LANE client on segment number 1, bridge number 1 in the emulated LAN named red:

```
Router# clear lane le-arp name red route-desc segment 1 bridge 1
```

**Note**

MAC addresses are written in the same dotted notation for the **clear lane le-arp** command as they are for the global IP **arp** command.

clear lane server

To force a LAN emulation (LANE) server to drop a client and allow the LANE configuration server to assign the client to another emulated LAN (ELAN), use the **clear lane server** command in user EXEC or privileged EXEC mode.

Cisco 7500 Series

```
clear lane server { interface slot/port [.subinterface-number] | name elan-name } [mac-address
mac-address | client-atm-address atm-address | lecid lane-client-id | route-desc segment
segment-number bridge bridge-number]
```

Cisco 4500 and 4700 Routers

```
clear lane server { interface number [.subinterface-number] | name elan-name } [mac-address
mac-address | client-atm-address atm-address | lecid lecid | route-desc segment
segment-number bridge bridge-number]
```

Syntax Description

interface <i>slot/port</i> [<i>.subinterface-number</i>]	Interface or subinterface where the LANE server is configured for the Cisco 7500 series. The space between the interface keyword and the <i>slot</i> argument is optional.
interface <i>number</i> [<i>.subinterface-number</i>]	Interface or subinterface where the LANE server is configured for the Cisco 4500 or 4700 routers. The space between the interface keyword and the <i>number</i> argument is optional.
name <i>elan-name</i>	Name of the emulated LAN on which the LANE server is configured. Maximum length is 32 characters.
mac-address <i>mac-address</i>	(Optional) Keyword and MAC address of the LANE client.
client-atm-address <i>atm-address</i>	(Optional) Keyword and ATM address of the LANE client.
lecid <i>lane-client-id</i>	(Optional) Keyword and ID of the LANE client. The LANE client ID is a value from 1 to 4096.
route-desc segment <i>segment-number</i>	(Optional) Keywords and LANE segment number. The segment number ranges from 1 to 4095.
bridge <i>bridge-number</i>	(Optional) Keyword and bridge number that is contained in the route descriptor. The bridge number ranges from 1 to 15.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
11.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

After changing the bindings on the configuration server, use this command on the LANE server to force the client to leave one emulated LAN. The LANE server will drop the Control Direct and Control Distribute virtual channel connections (VCCs) to the LANE client. The client will then ask the LANE configuration server for the location of the LANE server of the emulated LAN it should join.

If no LANE client is specified, all LANE clients attached to the LANE server are dropped.

Examples

The following example shows how to force all the LANE clients on the emulated LAN named red to be dropped. The next time they try to join, they will be forced to join a different emulated LAN.

```
Router# clear lane server name red
```

Related Commands

Command	Description
client-atm-address name	Adds a LANE client address entry to the configuration database of the configuration server.
lane database	Creates a named configuration database that can be associated with a configuration server.
mac-address	Sets the MAC layer address of the Cisco Token Ring.
show lane server	Displays global information for the LANE server configured on an interface, on any of its subinterfaces, on a specified subinterface, or on an ELAN.

clear mpoa client cache

To clear the ingress and egress cache entries of one or all Multiprotocol over ATM (MPOA) clients (MPCs), use the **clear mpoa client cache** command in user EXEC or privileged EXEC mode.

clear mpoa client [*name mpc-name*] **cache** [**ingress** | **egress**] [**ip-address** *ip-address*]

Syntax Description

name <i>mpc-name</i>	(Optional) Specifies the name of the MPC with the specified name.
ingress	(Optional) Clears ingress cache entries associated with the MPC.
egress	(Optional) Clears egress cache entries associated with the MPC.
ip-address <i>ip-address</i>	(Optional) Clears matching cache entries with the specified IP address.

Defaults

The system defaults are:

- All MPC cache entries are cleared.
- Both caches are cleared.
- Entries matching only the specified destination IP address are cleared.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
11.3(3a)WA4(5)	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following example shows how to clear the ingress and egress cache entries for the MPC named ip_mpc:

```
Router# clear mpoa client name ip_mpc cache
```

Related Commands

Command	Description
show mpoa client cache	Displays the ingress or egress cache entries matching the IP addresses for the MPCs.

clear mpoa server cache

To clear the ingress and egress cache entries, use the **clear mpoa server cache** command in user EXEC or privileged EXEC mode.

clear mpoa server [*name mps-name*] **cache** [**ingress** | **egress**] [**ip-address** *ip-address*]

Syntax Description

name <i>mps-name</i>	(Optional) Specifies the name of the Multiprotocol over ATM (MPOA) server (MPS). If this keyword is omitted, this command will apply to all servers.
ingress	(Optional) Clears ingress cache entries associated with the MPS.
egress	(Optional) Clears egress cache entries associated with the MPS.
ip-address <i>ip-address</i>	(Optional) Clears matching cache entries with the specified IP address. If this keyword is omitted, this command will clear all entries.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
11.3(3a)WA4(5)	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following example shows how to clear all cache entries:

```
Router# clear mpoa server cache
```

Related Commands

Command	Description
show mpoa server cache	Displays ingress and egress cache entries associated with the MPS.

clear pppatm interface atm

To clear PPP ATM sessions on an ATM interface, use the **clear pppatm interface atm** command in privileged EXEC mode.

clear pppatm interface atm *interface-number* [*.subinterface-number*] [**vc** {[*vpi*]/*vci* | *virtual-circuit-name*}]

Syntax Description	<i>interface-number</i>	ATM interface number.
	<i>.subinterface-number</i>	(Optional) ATM subinterface number. A period must precede the number.
	vc [<i>vpi</i>]/ <i>vci</i>	(Optional) Specifies virtual circuit (VC) by virtual path identifier (VPI) and virtual channel identifier (VCI). A slash must follow the VPI.
	vc <i>virtual-circuit-name</i>	(Optional) Specifies VC by name.

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	12.2(13)T	This command was introduced.
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.

Usage Guidelines	This command clears the PPP over ATM (PPPoA) sessions in an interface, or in a VC when the VC is specified.
-------------------------	---

When the **clear pppatm interface atm** command is used to clear sessions on an interface, PPP keepalives continue to work and can be used to detect a broken link.

Examples	The following example clears a PPP ATM session on ATM interface 1/0.10:
-----------------	---

```
Router# clear pppatm interface atm 1/0.10
```

Related Commands	Command	Description
	debug pppatm	Enables reports for PPPoA events, errors, and states either globally or conditionally on an interface or VC.
	show pppatm summary	Displays PPPoA session counts.

client-atm-address name

To add a LAN emulation (LANE) client address entry to the configuration server's configuration database, use the **client-atm-address name** command in database configuration mode. To remove a client address entry from the table, use the **no** form of this command.

client-atm-address *atm-address-template* **name** *elan-name*

no client-atm-address *atm-address-template*

Syntax Description	<i>atm-address-template</i>	Template that explicitly specifies an ATM address or a specific part of an ATM address and uses wildcard characters for other parts of the ATM address, making it easy and convenient to specify multiple addresses matching the explicitly specified part. Wildcard characters can replace any nibble or group of nibbles in the prefix, the end-system identifier (ESI), or the selector fields of the ATM address.
	name <i>elan-name</i>	Name of the emulated LAN. Maximum length is 32 characters.

Command Default	No address and no emulated LAN name are provided.
-----------------	---

Command Modes	Database configuration
---------------	------------------------

Command History	Release	Modification
	11.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

The effect of this command is to bind any client whose address matches the specified template into the specified emulated LAN. When a client comes up, it consults the LANE configuration server, which responds with the ATM address of the LANE server for the emulated LAN. The client then initiates join procedures with the LANE server.

Before this command is used, the emulated LAN specified by the *elan-name* argument must have been created in the configuration server's database by use of the **name server-atm-address** command.

If an existing entry in the configuration server's database binds the LANE client ATM address to a different emulated LAN, the new command is rejected.

This command affects only the bindings in the named configuration server database. It has no effect on the LANE components themselves.

See the **lane database** command for information about creating the database, and the **name server-atm-address** command for information about binding the emulated LAN's name to the server's ATM address.

The **client-atm-address name** command is a subcommand of the global **lane database** command.

ATM Addresses

A LANE ATM address has the same syntax as a network service access point (NSAP), but it is not a network-level address. It consists of the following:

- A 13-byte prefix that includes the following fields defined by the ATM Forum:
 - AFI (Authority and Format Identifier) field (1 byte), DCC (Data Country Code) or ICD (International Code Designator) field (2 bytes), DFI (Domain Specific Part Format Identifier) field (1 byte), Administrative Authority field (3 bytes), Reserved field (2 bytes), Routing Domain field (2 bytes), and the Area field (2 bytes)
- A 6-byte ESI
- A 1-byte selector field

Address Templates

LANE ATM address templates can use two types of wildcards: an asterisk (*) to match any single character (nibble), and an ellipsis (...) to match any number of leading, middle, or trailing characters. The values of the characters replaced by wildcards come from the automatically assigned ATM address.

In LANE, a *prefix template* explicitly matches the prefix but uses wildcards for the ESI and selector fields. An *ESI template* explicitly matches the ESI field but uses wildcards for the prefix and selector.

In our implementation of LANE, the prefix corresponds to the switch, the ESI corresponds to the ATM interface, and the selector field corresponds to the specific subinterface of the interface.

Examples

The following example shows how to use an ESI template to specify the part of the ATM address corresponding to the interface. This example allows any client on any subinterface of the interface that corresponds to the displayed ESI value, no matter to which switch the router is connected, to join the emulated LAN named engineering:

```
ATM(lane-config-database)# client-atm-address ...0800.200C.1001.** name engineering
```

The following example shows how to use a prefix template to specify the part of the ATM address corresponding to the switch. This example allows any client on a subinterface of any interface connected to the switch that corresponds to the displayed prefix to join the emulated LAN named marketing:

```
ATM(lane-config-database)# client-atm-address 47.000014155551212f.00.00... name marketing
```

Related Commands

Command	Description
default-name	Provides an ELAN name in the database of the configuration server for those client MAC addresses and client ATM addresses that do not have explicit ELAN name bindings.
lane database	Creates a named configuration database that can be associated with a configuration server.
mac-address	Sets the MAC layer address of the Cisco Token Ring.
name	Specifies or replaces the ATM address of the LANE server for the ELAN
server-atm-address	in the configuration database of the configuration server.

create on-demand

To configure ATM PVC autoprovisioning, which enables a permanent virtual circuit (PVC) or range of PVCs to be created automatically on demand, use the **create on-demand** command in ATM PVC range configuration mode, Interface-ATM-VC configuration mode, PVC-in-range configuration mode or VC-class configuration mode. To disable the ATM PVC autoprovisioning configuration, use the **no** form of this command.

create on-demand [*type*]

no create on-demand [*type*]

Syntax Description	<i>type</i> (Optional) Indicates the means by which the VCs are provisioned. Two options are available: • aaa—Indicates that the VC/range are provisioned from a RADIUS AAA server. • default—Disables create on-demand under current mode but allows inheritance.
---------------------------	--

Command Default	PVCs or range of PVCs cannot be created automatically.
------------------------	--

Command Modes	ATM PVC range configuration (config-if-atm-range) Interface-ATM-VC configuration (config-if-atm-range-pvc) PVC-in-range (config-if-atm-range-pvc) VC-class configuration (config-vc-class)
----------------------	---

Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>11.3</td><td>This command was introduced.</td></tr> <tr> <td>12.2(15)B</td><td>This command was integrated into Cisco IOS Release 12.2(15)B. Support for this command was extended to be applied on create-on-demand PVCs</td></tr> <tr> <td>15.0(1)M</td><td>This command was integrated into Cisco IOS Release 15.0(1)M.</td></tr> <tr> <td>12.2(33)SRA</td><td>This command was integrated into Cisco IOS Release 12.2(33)SRA.</td></tr> <tr> <td>12.2SX</td><td>This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.</td></tr> </table>	Release	Modification	11.3	This command was introduced.	12.2(15)B	This command was integrated into Cisco IOS Release 12.2(15)B. Support for this command was extended to be applied on create-on-demand PVCs	15.0(1)M	This command was integrated into Cisco IOS Release 15.0(1)M.	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Release	Modification												
11.3	This command was introduced.												
12.2(15)B	This command was integrated into Cisco IOS Release 12.2(15)B. Support for this command was extended to be applied on create-on-demand PVCs												
15.0(1)M	This command was integrated into Cisco IOS Release 15.0(1)M.												
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.												
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.												

Usage Guidelines	Use the create on-demand command to configure ATM PVC autoprovisioning, which enables a PVC or range of PVCs to be created automatically on demand. A VC will not be created until there is an activity on that virtual path identifier (VPI)/virtual channel identifier (VCI) pair. When you use the shutdown or no shutdown on an ATM interface, all create on-demand VCs on that interface will remain in INACTIVE state until the first incoming packet triggers the VC creation. During router reload, the create-on-demand VCs will not be established until there is incoming traffic.
-------------------------	--

You can erase, modify and restore the configuration. To erase the configuration, enter the **no create on-demand aaa** command.

To erase an individual PVC configuration within a range, use the **no create on-demand aaa** command in PVC-in-range mode on the VC.

To erase the entire RADIUS configuration from the router, use the **erase** command.

To modify VC attributes from the command, you must erase the configuration and disable the create-on-demand VCs by using **no create on-demand aaa**.

To restore configuration from RADIUS, you can use the **create** command.

To provision VC Class attributes from RADIUS server, you must enable the **create on-demand aaa** in the VC class. The RADIUS user-name attribute for each VC Class is uniquely defined as **hostname {ip address / vc-class-name}**.

You can configure the password by using **radius-server** command. You can use the **create** command to manually download the configuration.

After receiving RADIUS response to a VC provisioning request, if the VC-class name is specified in the response, the VC-class will be searched for locally on the router. If the VC-class is configured as create-on-demand and not yet provisioned, VC-class RADIUS request will be sent.

Examples

The following example shows how to configure VPI/VCI from 0/50 to 0/60 via RADIUS, on subinterface ATM 5/0.1:

```
Router> enable
Router# configure terminal
Router(config)# interface atm 5/0.1 multipoint
Router(config-subif) range auto pvc 0/50 0/60
Router(config-if-atm-range)# create on-demand aaa
```

The following example shows how to configure ATM PVC autoprovisioning on VC class:

```
Router> enable
Router# configure terminal
Router(config)# interface atm 5/0 multipoint
Router(config)# vc-class atm vctest
Router(config-vc-class)# create on-demand
```

Related Commands

Command	Description
idle-timeout	Configures the idle timeout parameter for tearing down an ATM SVC connection
radius-server	Specifies the default direction of filters from RADIUS.
range pvc	Defines a range of ATM PVCs.
vc-class atm	Creates a VC class for an ATM PVC, SVC, or ATM interface.

dbns enable

To apply Dynamic Subscriber Bandwidth Selection (DBS) QoS parameters, use the **dbns enable** command in the appropriate configuration mode. To remove DBS QoS parameters, use the **no** form of this command.

dbns enable

no dbns enable

Syntax Description This command has no arguments or keywords.

Command Default DBS QoS parameters are not applied.

Command Modes

- ATM VC class configuration
- ATM VC configuration
- ATM PVC range configuration
- ATM PVC-in-range configuration

Command History	Release	Modification
	12.2(4)B	This command was introduced.
	12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

The **no dbns enable** command configured in any configuration mode overrides the **dbns enable** command configured in any configuration mode. Both the **dbns enable** and **no dbns enable** commands are saved in the running configuration and appear, when configured, in the output of the **show running-config** command. The **default dbns enable** command does not appear in the output of the **show running-config** command when configured.

When you enter the **dbns enable** or **no dbns enable** command, existing sessions are not disconnected. If you have a session that has been configured for DBS and you configure the **no dbns enable** command on a VC, additional sessions that are configured will display DBS-configured QoS values until the first new session is up. After the first session is brought up, the VC has default and locally configured values. If you configure the **dbns enable** command after multiple sessions are already up on the VC, all sessions on that VC have DBS QoS parameters.

RADIUS QoS attributes are applied to PVCs when a new PPP over Ethernet (PPPoE) session has peak cell rate (PCR) and sustainable cell rate (SCR) values that are higher than existing PPPoE sessions. If a new PPPoE session with lower PCR and SCR values is added to a PVC, the RADIUS QoS attributes are not applied to the new session. If the user of the PPPoE session that has the higher PCR and SCR values logs out, the QoS attributes are set to those of the lower bandwidth user.

RADIUS QoS attributes override attributes on a PVC configured in ATM PVC-in-range or ATM PVC range configuration mode. If the RADIUS QoS attributes cannot be applied to a PVC, PPPoE and PPPoA sessions cannot be established.

When DBS is configured, normal ATM precedences apply. PVC configurations take precedence over VC class configurations. Thus, if DBS QoS parameters are applied on a VC class and disabled on one PVC in that VC class, DBS QoS parameters are not applied on the PVC. ATM PVC-in-range configurations take precedence over PVC range configurations.

When you configure DBS on a PVC, existing sessions on that PVC remain connected.

Examples

The following example configures DBS in ATM VC class configuration mode:

```
vc-class atm pppoe
  dba enable
```

The following example configures DBS in ATM VC configuration mode:

```
interface atm0/0/0.5 point-to-point
  ip address 10.0.0.0 255.255.255.0
  pvc 0/100
    dba enable
  protocol pppoe
```

The following example configures DBS in ATM PVC range configuration mode:

```
interface atm0/0/0.1 multipoint
  ip address 10.0.0.0 255.255.255.0
  range pvc 0/50 0/70
    dba enable
```

The following example configures DBS in ATM PVC-in-range configuration mode:

```
interface atm0/0/0.1 multipoint
  range pvc 0/50 0/70
    pvc-in-range 60
    dba enable
```

Related Commands

Command	Description
pvc	Creates or assigns a name to an ATM PVC, specifies the encapsulation type on an ATM PVC, or enters interface-ATM-VC configuration mode.
pvc-in-range	Configures an individual PVC within a PVC range.
range pvc	Defines a range of ATM PVCs.
show atm pvc dba	Displays all ATM PVCs on which DBS QoS parameters are applied.
vc-class atm	Configures a VC class for an ATM VC or interface.

default-name

To provide an emulated LAN name in the configuration server's database for those client MAC addresses and client ATM addresses that do not have explicit emulated LAN name bindings, use the **default-name** command in database configuration mode. To remove the default name, use the **no** form of this command.

default-name *elan-name*

no default-name

Syntax Description	<i>elan-name</i>	Default emulated LAN name for any LAN emulation (LANE) client MAC address or LANE client ATM address not explicitly bound to any emulated LAN name. Maximum length is 32 characters.
---------------------------	------------------	--

Command Default	No name is provided.
------------------------	----------------------

Command Modes	Database configuration
----------------------	------------------------

Command History	Release	Modification
	11.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	This command affects only the bindings in the configuration server's database. It has no effect on the LANE components themselves.
	The named emulated LAN must already exist in the configuration server's database before this command is used. If the default name-to-emulated LAN name binding already exists, the new binding replaces it.
	The default-name command is a subcommand of the global lane database global configuration command.

Examples	The following example shows how to specify the emulated Token Ring LAN named man as the default emulated LAN. Because none of the emulated LANs are restricted, clients are assigned to whichever emulated LAN they request. Clients that do not request a particular emulated LAN will be assigned to the named man emulated LAN.
-----------------	--

```
lane database example2
name eng server-atm-address 39.000001415555121101020304.0800.200c.1001.02
name eng local-seg-id 1000
name man server-atm-address 39.000001415555121101020304.0800.200c.1001.01
```

■ default-name

```
name man local-seg-id 2000
name mkt server-atm-address 39.000001415555121101020304.0800.200c.4001.01
name mkt local-seg-id 3000
default-name man
```

Related Commands

Command	Description
client-atm-address name	Adds a LANE client address entry to the configuration database of the configuration server.
lane database	Creates a named configuration database that can be associated with a configuration server.
mac-address	Sets the MAC layer address of the Cisco Token Ring.
name server-atm-address	Specifies or replaces the ATM address of the LANE server for the ELAN in the configuration database of the configuration server.

dxi map

To map a protocol address to a given virtual path identifier (VPI) and virtual channel identifier (VCI), use the **dxi map** command in interface configuration mode. To remove the mapping for that protocol and protocol address, use the **no** form of this command.

dxi map *protocol protocol-address vpi vci* [**broadcast**]

no dxi map *protocol protocol-address*

Syntax Description	<i>protocol</i>	One of the following bridging or protocol keywords: appletalk , bridge , clns , decnet , ip , or novell .
	<i>protocol-address</i>	Protocol-specific address.
	<i>vpi</i>	Virtual path identifier in the range from 0 to 15.
	<i>vci</i>	Virtual circuit identifier in the range from 0 to 63.
	broadcast	(Optional) Address to which broadcasts should be forwarded.

Command Default	No map definition is established.
------------------------	-----------------------------------

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	10.3	This command was introduced.
	12.2(13)T	The apollo , vines , and xns arguments were removed because Apollo Domain, Banyan VINES, and Xerox Network Systems are no longer supported in the Cisco IOS software.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	This command is used in configurations where the router is intended to communicate with an ATM network through an ATM data service unit (ADSU). Given the circuit identifier parameters (VPI and VCI) for the ATM permanent virtual circuit (PVC), the router computes and uses the DXI frame address (DFA) that is used for communication between the router and the ADSU.
-------------------------	--

The **dxi map** command can be used only on a serial interface or HSSI configured for ATM-DXI encapsulation.

Examples

The following example converts all IP packets intended for the host with IP address 172.21.170.49 into ATM cells identified with a VPI of 2 (binary 0000 0010) and a VCI of 46 (binary 0000 0000 0010 1110) by the ADSU:

```
interface serial 0
 dxi map ip 172.21.170.49 2 46 broadcast
```

Using the mapping defined in Annex A of the ATM DXI Specification, the router uses the VPI and VCI information in this example to compute a DFA of 558 (binary 1000101110). The ADSU will use the DFA of the incoming frame to extract the VPI and VCI information when formulating ATM cells.

Related Commands

Command	Description
dxi pvc	Configures multiprotocol or single-protocol ATM-DXI encapsulation.
encapsulation atm-dxi	Enables ATM-DXI encapsulation.

dxi pvc

To configure multiprotocol or single protocol ATM-Data Exchange Interface (DXI) encapsulation, use the **dxi pvc** command in interface configuration mode. To disable multiprotocol ATM-DXI encapsulation, use the **no** form of this command.

dxi pvc *vpi vci* [**snap** | **nlpid** | **mux**]

no dxi pvc *vpi vci* [**snap** | **nlpid** | **mux**]

Syntax Description	<i>vpi</i>	ATM network virtual path identifier (VPI) of this permanent virtual circuit (PVC), in the range from 0 to 15. The VPI is a 4-bit field in the header of the ATM DXI frame. The VPI value is unique only on a single interface, not throughout the ATM network, because it has local significance only. Both <i>vpi</i> and <i>vci</i> cannot be specified as 0; if one is 0, the other cannot be 0.
	<i>vci</i>	ATM network virtual channel identifier (VCI) of this PVC, in the range from 0 to 63. The VCI is a 6-bit field in the header of the ATM DXI frame. The VCI value is unique only on a single interface, not throughout the ATM network, because it has local significance only. Both <i>vpi</i> and <i>vci</i> cannot be specified as 0; if one is 0, the other cannot be 0.
	snap	(Optional) LLC/SNAP encapsulation based on the protocol used in the packet. This keyword defines a PVC that can carry multiple network protocols. This is the default.
	nlpid	(Optional) RFC 1294/1490 encapsulation. This option is provided for backward compatibility with the default encapsulation in earlier versions of the Cisco IOS software.
	mux	(Optional) MUX encapsulation; the carried protocol is defined by the dxi map command when the PVC is set up. This keyword defines a PVC that carries only one network protocol.

Defaults LLC/SNAP encapsulation

Command Modes Interface configuration

Command History	Release	Modification
	10.3	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines This command can be used only on a serial interface or HSSI that is configured with ATM-DXI encapsulation.

Select the **nlpid** option if you are using the default encapsulation for software releases earlier than Cisco IOS Release 10.3.

Examples

The following example configures ATM-DXI MUX encapsulation on serial interface 1. The PVC identified by a VPI of 10 and a VCI of 10 can carry a single protocol. Then the protocol to be carried on this PVC is defined by the **dxi map** command.

```
interface serial 1
 dxi pvc 10 10 mux
 dxi map ip 172.21.176.45 10 10 broadcast
```

The following example configures ATM-DXI NLPID encapsulation on serial interface 1. The PVC identified by a VPI of 11 and a VCI of 12 can carry multiprotocol traffic that is encapsulated with a header described in RFC 1294/1490.

```
interface serial 1
 dxi pvc 11 12 nlpid
```

Related Commands

Command	Description
class-int	Maps a protocol address to a given VPI and VCI.
encapsulation atm-dxi	Enables ATM-DXI encapsulation.
show dxi pvc	Displays the PVC statistics for a serial interface.

encapsulation (ATM)

To configure the ATM adaptation layer (AAL) and encapsulation type for an ATM virtual circuit (VC), VC class, VC, bundle, or permanent virtual circuit (PVC) range, use the **encapsulation** command in the appropriate mode. To remove an encapsulation type, use the **no** form of this command.

```
encapsulation { aal2 | aal5auto | aal5autopp virtual-template template-number | aal5ciscoppp
virtual-template template-number | aal5mux protocol | aal5nlpid | aal5snap } [group
group-name]
```

```
no encapsulation { aal2 | aal5auto | aal5autopp virtual-template template-number |
aal5ciscoppp virtual-template template-number | aal5mux protocol | aal5nlpid | aal5snap }
[group group-name]
```

Syntax Description	
aal2	AAL and encapsulation type for PVCs dedicated to AAL2 Voice over ATM.
aal5auto	AAL and encapsulation type for PPP over ATM (PPPoA) switched virtual circuits (SVCs). Enables an ATM SVC to use either the aal5snap or aal5mux encapsulation option.
aal5autopp	Enables PPPoA/PPPoE autosense. PPPoA/PPPoE autosense enables a router to distinguish between incoming PPPoA and PPP over Ethernet (PPPoE) sessions and to create virtual access for both PPP types based on demand.
virtual-template <i>template-number</i>	Number used to identify the virtual template.
group	(Optional) Specifies that a PPPoE profile will be used by PPPoE sessions on the interface.
<i>group-name</i>	(Optional) Name of the PPPoE profile to be used by PPPoE sessions on the interface.
aal5ciscoppp	AAL and encapsulation type for Cisco PPP over ATM. Supported on ATM PVCs only.
aal5mux	AAL and encapsulation type for multiplex (MUX)-type VCs. A protocol must be specified when you use this encapsulation type.

<i>protocol</i>	Protocol type being used by the MUX-encapsulated VC. Values for the <i>protocol</i> argument are as follows: • appletalk—AppleTalk protocol. • bridge ieee8023—Ethernet LAN protocol. • decnet—DECnet protocol. • frame-relay—Frame Relay-ATM Network Interworking (FRF.5) on the Cisco MC3810. • fr-atm-srv—Frame Relay-ATM Service Interworking (FRF.8) on the Cisco MC3810. • ip—IP protocol. • ipx—Internet Packet Exchange (IPX) protocol. • ppp virtual-template <i>number</i>—Internet Engineering Task Force (IETF)-compliant PPP over ATM. Use the virtual-template <i>number</i> options to identify the virtual template. Supported on ATM PVCs only. • pppoe—PPP over Ethernet. • voice—Voice over ATM.
aal5nlpid	AAL and encapsulation type that allows ATM interfaces to interoperate with High-Speed Serial Interfaces (HSSIs) that are using an ATM data service unit (ADSU) and running ATM-Data Exchange Interface (DXI). Supported on ATM PVCs only.
aal5snap	AAL and encapsulation type that supports Inverse Address Resolution Protocol (ARP). Logical link control/Subnetwork Access Protocol (LLC/SNAP) precedes the protocol datagram.

Defaults

The global default encapsulation option is **aal5snap**. See the “Usage Guidelines” section for other default characteristics.

Command Modes

ATM VC configuration (for an ATM PVC or SVC)
 Bundle configuration (for a VC bundle)
 PVC range configuration (for an ATM PVC range)
 PVC-in-range configuration (for an individual PVC within a PVC range)
 VC-class configuration (for a VC class)

Command History

Release	Modification
11.3T	This command was introduced.
12.0(3)T	This command was enhanced to provide encapsulation configuration for ATM VC bundles. The aal5mux frame and aal5mux voice keywords were added for the Cisco MC3810 series router.
12.0(7)XK	Support for the aal5mux voice option was added to Cisco 3600 series routers.
12.0(7)T	The aal5mux fr-atm-srv option was added for the Cisco MC3810 router. The aal5mux frame option was changed to aal5mux frame-relay .

Release	Modification
12.1(1)XA	Support for the aal2 option was added to the Cisco MC3810 router.
12.1(3)T	The aal5auto option was added to provide encapsulation configuration for PPP over ATM SVCs.
12.1(5)XM	Support for the aal2 option was added to the Cisco AS5300 access server and Cisco 3600 multiservice platforms.
12.1(5)T	The aal5ciscoppp , aal5mux , and aal5snap options were made available in PVC range and PVC-in-range configuration modes.
12.2(2)T	This command was integrated into Cisco IOS Release 12.2(2)T.
12.1(1)DC1	The aal5autopp option was introduced on the Cisco 6400 universal access concentrator.
12.2(4)T	The aal5autopp option was integrated into Cisco IOS Release 12.2(4)T.
12.2(13)T	The apollo , vines , and xns values were removed as options for the <i>protocol</i> argument because Apollo Domain, Banyan VINES, and Xerox Network Systems are no longer supported in the Cisco IOS software.
12.2(15)T	The group option was added.
12.3(7)XI3	This command was integrated into Cisco IOS Release 12.3(7)XI3.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.4(11)XW	The pppoe and bridge ieee8023 options were added.

Usage Guidelines



Note

To configure Integrated Local Management Interface (ILMI), QSAAL, or Switched Multimegabit Data Service (SMDS) encapsulations for an ATM PVC, use the **pvc** command.

Use the **aal5mux** encapsulation option to dedicate the specified PVC to a single protocol; use the **aal5snap** encapsulation option to multiplex two or more protocols over the same PVC. Whether you select **aal5mux** or **aal5snap** encapsulation might depend on practical considerations, such as the type of network and the pricing offered by the network. If the pricing of the network depends on the number of PVCs set up, **aal5snap** might be the appropriate choice. If pricing depends on the number of bytes transmitted, **aal5mux** might be the appropriate choice because it has slightly less overhead. Use the **aal5mux pppoe** option to reduce SNAP encapsulation overhead associated with carrying PPPoE frames. Use the **aal5mux bridge ieee8023** option to reduce SNAP encapsulation overhead associated with carrying bridged frames.

Encapsulation for PPPoA

When configuring Cisco PPP over ATM, use the **aal5ciscoppp** keyword and specify the virtual template number.

It is possible to implicitly create a virtual template when configuring Cisco PPP over ATM. In other words, if the parameters of the virtual template are not explicitly defined before you configure the ATM PVC, the PPP interface will be brought up using default values from the virtual template identified. However, some parameters (such as an IP address) take effect only if they are specified before the PPP interface comes up. Therefore, we recommend that you explicitly create and configure the virtual template before configuring the ATM PVC to ensure that such parameters take effect.

If you specify virtual template parameters after the ATM PVC is configured, you should enter a **shutdown** command followed by a **no shutdown** command on the ATM subinterface to restart the interface, causing the newly configured parameters (such as an IP address) to take effect.

Configuring PPPoA/PPPoE Autosense

Use the **encapsulation aal5autopp virtual-template** *template-number* command to configure PPPoA/PPPoE autosense. PPPoA/PPPoE autosense enables a router to distinguish between incoming PPPoA and PPPoE sessions and create virtual access for both PPP types based on demand.

If a PPPoE profile is not specified by using the **group** *group-name* option, PPPoE sessions will be established using parameters from the global PPPoE profile. PPPoE profiles must be configured using the **bba-group pppoe** command.



Note

Do not use this command on a router that initiates PPPoA sessions.

Entering the **no encapsulation aal5autopp virtual-template** command will terminate the PPPoA or PPPoE session and detach the virtual-access interface from the PVC.

Configuring Encapsulation for VC Bundles

Before using this command to configure a VC bundle, enter the **bundle** subinterface configuration command to create a new bundle or modify an existing one and to enter bundle configuration mode.

A VC bundle can have only one encapsulation keyword configured for it: either **aal5snap** or **aal5mux**.

Encapsulation Rules of Precedence

If the **encapsulation** command is not explicitly configured on an ATM PVC, SVC, or VC bundle, the VC inherits the following default configuration (listed in order of precedence from lowest to highest):

- Configuration of the **encapsulation** command in a VC class assigned to the PVC, PVC bundle, or SVC itself.
- Configuration of the **encapsulation** command in a VC class assigned to the ATM subinterface of the PVC, SVC, or VC bundle.
- Configuration of the **encapsulation** command in a VC class assigned to the ATM main interface of the PVC, SVC, or VC bundle.
- Global encapsulation option default: **aal5snap**.



Note

When a VC is a member of a VC bundle, bundle configuration takes precedence over configuration using the **encapsulation** command in VC-class mode.

Configuring Encapsulation for a PVC Range

When a PVC range or an individual PVC within a PVC range is being configured, the following options are available:

- **encapsulation aal5ciscoppp**
- **encapsulation aal5mux**
- **encapsulation aal5snap**

Examples**MUX-Type Encapsulation on a VC Example**

The following example configures an ATM PVC with VPI 0 and VCI 33 for a MUX-type encapsulation using IP:

```
interface atm 1/0
 pvc 0/33
  encapsulation aal5mux ip
```

SNAP Encapsulation Example

The following example configures a bundle called “bundle1” for **aal5snap** encapsulation:

```
bundle bundle1
 encapsulation aal5snap
```

PPP over ATM SVCs Example

The following example configures an ATM SVC called “bundle1” with the encapsulation type **aal5auto**. Encapsulation type **aal5auto** enables the SVC to use PPP and either **aal5snap** or **aal5mux** encapsulation.

```
interface ATM 2/0/0
 svc bundle1
  encapsulation aal5auto
```

PPPoA/PPPoE Autosense Example

The following example enables PPPoA/PPPoE autosense on PVC 30/33. PPPoA sessions will use virtual template 1, and PPPoE sessions will use the global PPPoE profile.

```
interface ATM 0/0/0.33 multipoint
 pvc 30/33
  encapsulation aal5autopp virtual-template 1
!
bba-group pppoe global
 virtual-template 1
 sessions max limit 8000
 sessions per-vc limit 8
 sessions per-mac limit 2
```

AAL2 Voice over ATM Example

The following example configures a PVC to support AAL2 encapsulation for Voice over ATM:

```
interface ATM0.2 point-to-point
 pvc 2/200
  vbr-rt 760 760 100
  encapsulation aal2
```

Related Commands

Command	Description
bba-group pppoe	Creates a PPPoE profile.
broadcast	Configures broadcast packet duplication and transmission for an ATM VC class, PVC, SVC, or VC bundle.
bundle	Configures a VC bundle.
class-vc	Assigns a VC class to an ATM PVC, SVC, or VC bundle member.
debug pppoe	Displays debugging information for PPPoE sessions.
inarp	Configures the Inverse ARP time period for an ATM PVC, VC class, or VC bundle.

Command	Description
oam retry	Configures parameters related to OAM management for an ATM PVC, SVC, VC class, or VC bundle.
protocol (ATM)	Configures a static map for an ATM PVC, SVC, VC class, or VC bundle and enables Inverse ARP or Inverse ARP broadcasts on an ATM PVC.
pvc	Creates an ATM PVC.
shutdown	Deactivates an interface or ATM PVC.

encapsulation (Layer 2 local switching)

To configure the ATM adaptation layer (AAL) for a Layer 2 local switching ATM permanent virtual circuit (PVC), use the **encapsulation** command in ATM PVC L2transport configuration mode. To remove an encapsulation from a PVC, use the **no** form of this command.

encapsulation *layer-type*

no encapsulation *layer-type*

Syntax Description

<i>layer-type</i>	Adaptation layer type. The values are: • aal5 • aal0 • aal5snap • aal5mux • aal5nlpid (not available on Cisco 12000 series)
-------------------	--

Command Default

If you do not create a PVC, one is created for you. The default encapsulation types for autoprovisioned PVCs are as follows:

- For ATM-to-ATM local switching, the default encapsulation type for the PVC is AAL0.
- For ATM-to-Ethernet or ATM-to-Frame Relay local switching, the default encapsulation type for the PVC is AAL5SNAP.

Command Modes

ATM PVC L2transport configuration

Command History

Release	Modification
12.0(27)S	This command was introduced for Layer 2 local switching.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.
12.0(30)S	This command was integrated into Cisco IOS Release 12.0(30)S.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.4(11)T	This command was integrated into Cisco IOS Release 12.4(11)T.
12.2(33)SRB	This command was integrated into Cisco IOS Release 12.2(33)SRB.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.

Usage Guidelines

The **pvc** command and the **encapsulation** command work together. The use of these commands with Layer 2 local switching is slightly different from the use of these commands with other applications. The following list highlights the differences:

- For Layer 2 local switching, you must add the **l2transport** keyword to the **pvc** command. The **l2transport** keyword enables the PVC to transport Layer 2 packets.
- The Layer 2 local switching **encapsulation** command works only with the **pvc** command. You cannot create switched virtual circuits or VC bundles to transport Layer 2 packets. You can use only PVCs to transport Layer 2 packets.

Table 10 shows the encapsulation types supported for each transport type:

Table 10 *Supported Encapsulation Types*

Interworking Type	Encapsulation Type
ATM to ATM	AAL0, AAL5
ATM to Ethernet with IP interworking	AAL5SNAP, AAL5MUX
ATM to Ethernet with Ethernet interworking	AAL5SNAP
ATM to Frame-Relay	AAL5SNAP, AAL5NLPID

Examples

The following example shows how to configure a PVC to transport AAL0 packets for Layer 2 local switching:

```
pvc 1/100 l2transport
encapsulation aal0
```

Related Commands

Command	Description
pvc	Creates or assigns a name to an ATM PVC.

encapsulation atm-dxi

To enable ATM-Data Exchange Interface (DXI) encapsulation, use the **encapsulation atm-dxi** command in interface configuration mode. To disable ATM-DXI, use the **no** form of this command.

encapsulation atm-dxi

no encapsulation atm-dxi

Syntax Description This command has no arguments or keywords.

Command Default When ATM-DXI encapsulation is not configured, HDLC is the default encapsulation.

Command Modes Interface configuration

Command History	Release	Modification
	10.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples The following example configures ATM-DXI encapsulation on serial interface 1:

```
interface serial 1
 encapsulation atm-dxi
```

Related Commands	Command	Description
	class-int	Maps a protocol address to a given VPI and VCI.

encapsulation untagged dot1q second-dot1q

To define the matching criteria to map untagged dot1q ingress Ethernet frames on an interface to the appropriate service instance, use the **encapsulation untagged dot1q second-dot1q** command in the service instance mode. To delete the matching criteria to map untagged dot1q ingress Ethernet frames on an interface to the appropriate service instance, use the **no** form of this command.

encapsulation untagged dot1q {**any** | *vlan-id*[*vlan-id*[*vlan-id*]]} **second-dot1q** {**any** | *vlan-id*[*vlan-id*[*vlan-id*]]}

no encapsulation untagged dot1q

Syntax Description	<i>vlan-id</i>	VLAN ID, integer in the range 1 to 4094. Hyphen must be entered to separate the starting and ending VLAN ID values that are used to define a range of VLAN IDs. (Optional) Comma must be entered to separate each VLAN ID range from the next range.
	any	Any second tag in the range 1 to 4094.

Command Default No matching criteria are defined.

Command Modes Service instance mode (config-if-srv) #

Command History	Release	Modification
	12.2(33)SRE	This command was introduced.

Usage Guidelines Only one service instance per port is allowed to have untagged encapsulation. The reason is to be able to unambiguously map the incoming frames to the service instance. However, it is possible for a port that hosts an service instance matching untagged traffic to host other service instances that match tagged frames.

Only one encapsulation command may be configured per service instance.

Examples The following example shows how to map untagged dot1q ingress Ethernet frames to a service instance. The example contains VLAN IDs 40 and 42.

```
Router(config-if-srv)# encapsulation untagged dot1q 40 second-dot1q 42
```

Related Commands	Command	Description
	encapsulation default	Configures the default service instance on a port.
	encapsulation dot1q (service instance)	Defines the matching criteria to map 802.1Q frames ingress on an interface to the appropriate service instance.
	encapsulation dot1q second-dot1q	Defines the matching criteria to map Q-in-Q ingress frames on an interface to the appropriate service instance.

framer-type

To set the framer type of supported circuit emulation service (CES) multiservice interchange (MIX) connections to T1 or E1, use the **framer-type** command in CES configuration mode.

framer-type {**t1** | **e1**}

Syntax Description

t1	Sets the framer type of supported CES connections to T1.
e1	Sets the framer type of supported CES connections to E1.

Defaults

T1

Command Modes

CES configuration

Command History

Release	Modification
12.1(5)XM	This command was introduced for the Cisco 3660.
12.2(4)T	This command was integrated into Cisco IOS Release 12.2(4)T.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command is needed only with CES-enabled network modules (ATM OC-3 CES network modules) that do *not* contain Cisco T1/E1 multiflex voice/WAN interface cards (VWICs) on the Cisco 3660. Other network modules set their framer type automatically and therefore do not require use of this command. It is also not necessary to use this command for T1 connections, because **t1** is the default argument.

To reach CES configuration mode for a particular slot, enter **ces** and the slot number and port number while in global configuration mode. Note that the port value is always 0, as the interface configuration applies to all ports in the slot.

Examples

The following example sets the framer type of the CES card in slot 1 to E1:

```
Router(config)# ces 1/0  
Router(config-ces)# framer-type e1
```

Related Commands

Command	Description
ces	Configures CES on a router port and enters controller configuration mode.

holding-time

To specify the holding time value for the MPS-p7 variable of a Multiprotocol over ATM server (MPS), use the **holding-time** command in MPS configuration mode. To revert to the default value, use the **no** form of this command.

holding-time *seconds*

no holding-time *seconds*

Syntax Description

<i>seconds</i>	Specifies the holding time value in seconds. The default is 1200 seconds.
----------------	---

Defaults

The default holding time is 1200 seconds (20 minutes).

Command Modes

MPS configuration

Command History

Release	Modification
11.3(3a)WA4(5)	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following example shows how to set the holding time to 600 seconds (10 minutes):

```
holding-time 600
```

idle-timeout

To configure the idle timeout parameter for tearing down an ATM switched virtual circuit (SVC) connection, use the **idle-timeout** command in the VC-class configuration mode or interface-ATM-VC configuration mode. To disable the timeout parameter, use the **no** form of this command.

idle-timeout *seconds* [*minimum-traffic*]

no idle-timeout *seconds* [*minimum-traffic*]

Syntax Description	<i>seconds</i>	Number of seconds that the SVC is idle, after which the ATM SVC is disconnected. The range is from 0 to 2000000.
	<i>minimum-rate</i>	(Optional) Minimum traffic rate, in kilobits per second (kbps), required on an ATM SVC to maintain the SVC connection. The range is from 0 to 149760.

Command Default

For PVCs, the default timeout value is infinity.
For SVCs, the default timeout value is 300 seconds.

Command Modes

Interface-ATM-VC configuration (config-if-atm-range-pvc)
VC-class configuration (config-vc-class)

Command History	Release	Modification
	11.3	This command was introduced.
	12.2(15)B	This command was integrated into Cisco IOS Release 12.2(15)B. Support for this command was extended to be applied on create-on-demand PVCs
	15.0(1)M	This command was integrated into Cisco IOS Release 15.0(1)M.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

If within the idle timeout period, both the input and output traffic rates are below the *minimum-rate*, the SVC connection is torn down. The input and output traffic rates are set using the **ubr**, **ubr+**, or **vbr-nrt** command.

If the **idle-timeout** command is not explicitly configured on an ATM SVC, the SVC inherits the following default configuration (listed in order of next highest precedence):

- Configuration of the **idle-timeout** command in a VC class assigned to the SVC.
- Configuration of the **idle-timeout** command in a VC class assigned to the SVC's ATM subinterface.
- Configuration of the **idle-timeout** command in a VC class assigned to the SVC's ATM main interface.

- Global default—The global idle timeout default is the value set using the **idle-timeout** command. If the **idle-timeout** command is not configured, the default idle timeout is 300 seconds, and the *minimum-rate* is 0 kbps.

Examples

The following example configures an idle period of 300 seconds for an ATM SVC connection. The SVC connection is also configured so that it is considered inactive if the traffic rate is less than 5 kbps.

```
Router> enable
Router# configure terminal
Router(config)# interface atm 2/0
Router(config-if)# range ran1 pvc 32/45 45/56
Router(config-if-atm-range)# idle-timeout 300 5
```

Related Commands

Command	Description
create on-demand	Configures ATM PVC autoprovisioning, which enables a PVC or range of PVCs to be created automatically on demand.
ubr	Selects UBR QoS and configures the output peak cell rate for an ATM PVC, SVC, or VC class.
ubr+	Selects UBR QoS and configures the output peak cell rate and output minimum guaranteed cell rate for an ATM PVC, SVC, or VC class.
vbr-nrt	Configures the VBR-NRT QoS and specifies output peak cell rate, output sustainable cell rate, and output maximum burst cell size for an ATM PVC, SVC, or VC class.

ilmi manage

To enable Integrated Local Management Interface (ILMI) management on an ATM permanent virtual circuit (PVC), use the **ilmi manage** command in the appropriate command mode. To disable ILMI management, use the **no** form of this command.

ilmi manage

no ilmi manage

Syntax Description This command has no arguments or keywords.

Command Default ILMI management is disabled.

Command Modes

- Interface-ATM-VC configuration (for an ATM PVC)
- VC-class configuration (for a virtual circuit [VC] class)
- PVC range configuration (for an ATM PVC range)
- PVC-in-range configuration (for an individual PVC within a PVC range)

Command History	Release	Modification
	11.3 T	This command was introduced.
	12.1(5)T	This command was made available in PVC range and PVC-in-range configuration modes.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

If the **ilmi manage** command is not explicitly configured on an ATM PVC, the PVC inherits the following default configuration (listed in order of precedence):

- Configuration of the **ilmi manage** command in a VC class assigned to the PVC itself.
- Configuration of the **ilmi manage** command in a VC class assigned to the PVC's ATM subinterface.
- Configuration of the **ilmi manage** command in a VC class assigned to the PVC's ATM main interface.
- Global default: ILMI management is disabled.

Examples

The following example enables ILMI management on the ATM PVC with VPI 0 and VCI 60. The ILMI PVC is assigned the name routerA and the VPI and VCI are 0 and 16, respectively.

```
interface atm 0/0
 pvc routerA 0/16 ilmi
 exit
interface atm 0/0.1 multipoint
 pvc 0/60
 ilmi manage
```


ima active-links-minimum

To set the minimum number of links that must be operating in order for an ATM inverse multiplexing over ATM (IMA) group to remain in service, use the **ima active-links-minimum** interface configuration command. To remove the current configuration and set the value to the default, use the **no** form of this command.

ima active-links-minimum *number*

no ima active-links-minimum *number*

Syntax Description	<i>number</i>	Number of links; a value from 1 to 8.
		On Cisco 7600 series routers, <i>number</i> is a value from 1 to 16.

Defaults	Links: 1
----------	----------

Command Modes	Interface configuration
---------------	-------------------------

Command History	Release	Modification
	12.0(5)XK	This command was introduced on Cisco 2600 and 3600 series routers.
	12.0(5)T	This command was integrated into Cisco IOS Release 12.0(5)T.
	12.0(5)XE	Support for Cisco 7200 and 7500 series routers was added.
	12.0(7)XE1	Support for Cisco 7100 series routers was added.
	12.1(5)T	Support for Cisco 7100, 7200, and 7500 series routers was integrated into Cisco IOS Release 12.1(5)T.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
	12.2(33)SRB2	Support for Cisco 7600 CCoP ATM SPAs was added.

Usage Guidelines	The minimum number of links that should be active for continued group operation depends upon the applications you are using and the speeds they require. ATM frame size and the number of links in a group affect the overhead required by ATM.
------------------	---

Examples	Cisco 2600, 3600, 7100, 7200, and 7500 series routers
	The following example specifies that two links in IMA group 2 must be operational in order for the group to remain in service:

```
interface atm 0/ima2
  ima active-links-minimum 2
```

Cisco 7600 series routers

The following example shows how to specify that three links in IMA group 0 (on the SPA in chassis slot 2, SIP subslot 1) must be operational in order for the group to remain in service:

```
interface atm2/1/ima0
  ima active-links-minimum 3
```

Related Commands

Command	Description
interface atm ima	Configures an ATM IMA group.

ima autorestart

To enable the auto restart feature for an inverse multiplexing over ATM (IMA) group, use the **ima autorestart** command in interface configuration mode. Use the **no** form of the command to disable auto restart if it is enabled.

ima autorestart {**near-end-id** *near-end-group-id* [**far-end-id** *far-end-group-id*]}

no ima autorestart {**near-end-id** *near-end-group-id* [**far-end-id** *far-end-group-id*]}

Syntax Description	near-end-id <i>near-end-group-id</i>	The group number of the local IMA group. Valid values are 0 through 41.
	far-end-id <i>far-end-group-id</i>	(Optional) The remote IMA group that the local IMA group is to synchronize with. Valid values are 0 through 41.

Defaults	Disabled
-----------------	----------

Command Modes	Interface configuration (IMA interface)
----------------------	---

Command History	Release	Modification
	12.2(33)SRB2	This command was introduced on the Cisco 7600 series router.

Usage Guidelines

The IMA auto restart feature controls how IMA groups are to sync up after a restart. When an IMA group stops operating correctly (for example, due to a failure with the CEsP SPA, an IMA link, or the router), the group must be restarted. When it is restarted, the local IMA group must synchronize with an IMA group at the remote end:

- If auto restart is disabled (the default), IMA learns the ID of the remote group each time a restart occurs. In this case, the remote IMA group ID might change between restarts.
- If auto restart is enabled, you can specify which remote IMA group the local group should synchronize with. This allows you to keep an IMA group from synchronize with any group ID.

Include IMA group IDs in the command line to specify how IMA groups are to synchronize:

- If you specify **near-end-id** only, the local IMA group learns the ID of the remote group to synchronize with (which will be the first remote IMA group to become active). This learned remote group ID remains active until the SPA is reloaded.
- If you specify both **near-end-id** and **far-end-id**, the local IMA group will only synchronize with this remote IMA group. Both the near-end and far-end IDs must be the same.

To see the current settings for auto restart, issue the **show ima interface** command and view the Auto-Restart section of the command output.

Examples

The following example shows how to enable IMA auto restart for local IMA group 0 and specify that the group should synchronize with IMA group 5 on the remote end:

```
interface atm2/1/ima0
  ima autorestart far-end-id 5
```

The following example shows how to enable IMA auto restart for local IMA group 3 and specify that the group should synchronize with IMA group 3 on the remote end:

```
interface atm2/1/ima3
  ima autorestart near-end-id 3 far-end-id 3
```

Related Commands

Command	Description
ima restart	Manually restarts an IMA group that had previously stopped operating correctly.
show ima interface atm	Provides information about all configured IMA groups or a specific IMA group.

ima clock-mode

To set the transmit clock mode for an ATM inverse multiplexing over ATM (IMA) group, use the **ima clock-mode** command in interface configuration mode. To remove the current configuration, use the **no** form of this command.

ima clock-mode { **common** *port* | **independent** }

no ima clock-mode

Syntax Description

common	Sets the transmit clocks for all the links in the group to be derived from the same source.
<i>port</i>	Link that will provide clocking for the IMA group (called the command link). If the common link fails, the system automatically chooses one of the remaining active links to provide clocking. On the Cisco 7600 series router, this argument is not used.
independent	Sets the transmit clock source for at least one link in the IMA group to be different from the clock source used by the other links.

Defaults

The default value is **common**. If no port is specified, the system automatically chooses an active link to provide clocking.

Command Modes

Interface configuration

Command History

Release	Modification
12.0(5)XK	This command was introduced on Cisco 2600 and 3600 series routers.
12.0(5)T	This command was integrated into Cisco IOS Release 12.0(5)T
12.0(5)XE	This command was implemented on Cisco 7200 and 7500 series routers.
12.0(7)XE1	This command was implemented on Cisco 7100 series routers.
12.1(5)T	Support for Cisco 7100, 7200, and 7500 series routers was implemented in Cisco IOS Release 12.1(5)T.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
12.2(33)SRB2	Support for Cisco 7600 series routers was added.

Usage Guidelines

This command controls the clock for the IMA group as a whole. If all the links in the group share a clock source, use the **common** keyword. If all the links use different clock sources, use the **independent** clock source keyword.

When the **common** keyword is set, the **clock source** ATM interface configuration command for the common link determines clocking for all the links in the group. When the **independent** keyword is set, the **clock source** ATM interface configuration command is used under each interface to determine clocking individually.

Because the system automatically chooses a replacement for the common link when it fails, any link in an IMA group potentially can provide the recovered transmit clock. For this reason, even when the common keyword is set with a specific link stipulated by the port value, you should use the ATM interface configuration **clock source** command to make sure that the clock source is configured correctly on each interface in the IMA group.

Examples

Cisco 2600, 3600, 7100, 7200, and 7500 series routers

The following example specifies that the links in IMA group 2 use a common clock source on link 0:

```
interface atm0/ima2
  ima clock-mode common 0
```

Cisco 7600 series routers

The following example shows how to configure the links in IMA group 0 (on the SPA in slot 2, subslot 1) to use independent clock mode:

```
interface atm2/1/ima0
  ima clock-mode independent
```

Related Commands

Command	Description
clock source	Configures the clock source of a DS1 link.
interface atm ima	Configures an ATM IMA group.
show ima interface atm	Provides information about all configured IMA groups or a specific IMA group.

ima differential-delay-maximum

To specify the maximum differential delay among the active links in an inverse multiplexing over ATM (IMA) group, use the **ima differential-delay-maximum** command in interface configuration mode. To restore the default setting, use the **no** form of this command.

ima differential-delay-maximum *milliseconds*

no ima differential-delay-maximum *milliseconds*

Syntax Description

<i>milliseconds</i>	Specifies the differential delay in milliseconds (ms). The range of values depends on the type of card used: - PA-A3-8T1IMA—25 to 250 milliseconds - PA-A3-8E1IMA—25 to 190 milliseconds - NM-8T1-IMA—25 to 200 milliseconds On Cisco 7600 routers, valid values are as follows (depending on link type): 25 to 250 milliseconds (T1) 25 to 190 milliseconds (E1)
---------------------	--

Defaults

25 milliseconds

Command Modes

Interface configuration

Command History

Release	Modification
12.0(5)XK	This command was introduced on Cisco 2600 and 3600 series routers.
12.0(5)T	This command was integrated into Cisco IOS Release 12.0(5)T.
12.0(5)XE	This command was implemented on Cisco 7200 and 7500 series routers.
12.0(7)XE1	This command was implemented on Cisco 7100 series routers.
12.1(5)T	Support for Cisco 7100, 7200, and 7500 series routers was implemented in Cisco IOS Release 12.1(5)T.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
12.2(33)SRB2	Support for Cisco 7600 series routers was added.

Usage Guidelines

This command helps control latency in ATM-layer traffic by setting a limit on how much latency the slowest link in the group is allowed to introduce (a slower link has a longer propagation delay—for example, due to a longer path through the network or less accurate physical layer clocking—than other links). Setting a high value allows a slow link to continue operating as part of the group, although such

a setting means there is added delay to links across the group. A low setting may result in less latency for traffic across the group than a high setting, but it can mean that the system takes a slow link out of operation, reducing total bandwidth.

When a link has been removed from service, it is automatically placed back in service when it meets the delay differential standard. If a link delay exceeds the specified maximum, the link is dropped; otherwise, the IMA feature adjusts for differences in delays so that all links in a group are aligned and carry ATM-layer traffic.

Examples

Cisco 2600, 3600, 7100, 7200, and 7500 series routers

The following example specifies that the links in IMA group 2 have a maximum differential delay of 50 ms:

```
interface atm0/ima2
  ima differential-delay-maximum 50
```

Cisco 7600 series routers

The following example shows how to set the differential delay to 50 milliseconds for the links in IMA group 0 (on the SPA in chassis slot 2, SIP subslot 1):

```
interface atm2/1/ima0
  ima differential-delay-maximum 50
```

Related Commands

Command	Description
show ima interface atm	Provides information about all configured IMA groups or a specific IMA group.

ima frame-length

To specify the number of cells in inverse multiplexing over ATM (IMA) frames, use the **ima frame-length** command in interface configuration mode. To remove the current setting and restore the default value, use the **no** form of this command.

ima frame-length {32 | 64 | 128 | 256}

no ima frame-length {32 | 64 | 128 | 256}

Syntax Description

32	Specifies a value of 32 cells.
64	Specifies a value of 64 cells.
128	Specifies a value of 128 cells.
256	Specifies a value of 256 cells.

Defaults

The default value is 128 cells in a frame.

Command Modes

Interface configuration

Command History

Release	Modification
12.0(5)XE	This command was introduced.
12.0(7)XE1	Support for Cisco 7100 series routers was added.
12.1(5)T	This command was integrated into Cisco IOS Release 12.1(5)T.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
12.2(33)SRB2	Support for Cisco 7600 series routers was added.

Usage Guidelines

IMA frames are numbered sequentially, and each contains an IMA Control Protocol (ICP) cell at a specific position. This command controls how often ICP cells are sent over the links in an IMA group. For example, with a frame length of 64, 1 out of every 64 cells on the link is an ICP cell.

Frame length can affect performance because the greater the total number of frames required to communicate a given number of cells, the greater the overhead for header and other control cells. In addition, shorter frame lengths might diminish performance when translated ATM-Frame Relay interworking occurs.

Examples**Cisco 7100 and 7200 series routers**

The following example specifies that the links in IMA group 2 have a frame length of 64 cells:

```
interface atm 1/ima2
  ima frame-length 64
```

Cisco 7600 series routers

The following example shows how to specify that the links in IMA group 0 on the SPA in slot 2, subslot 1, use a frame length of 256 cells:

```
interface atm2/1/ima0
  ima frame-length 256
```

ima-group

To define inverse multiplexing over ATM (IMA) groups, use the **ima-group** command in interface configuration mode (Cisco 7100, 7200, and 7500 series routers), controller configuration mode (Cisco 7600 router), or config controller mode (Cisco HWIC-4SHDSL). To remove the group, use the **no** form of this command.

Cisco HWIC-4SHDSL

ima-group [**shutdown** | **minimum-links** *number* | **clock-mode**]

Cisco 7100, 7200, 7500, and 7600 series routers

ima-group *group-number*

no ima-group *group-number*

Syntax Description		
	clock-mode	Sets the clock mode for an IMA group
	<i>group-number</i>	Specifies an IMA group number from 0 to 3. IMA groups can span multiple ports on a port adapter or shared port adapter (SPA) but cannot span port adapters or SPAs. On the Cisco 7600 router, the group number must be unique on the SPA. Valid values for group number are: 0 to 23 on the 24-Port Channelized T1/E1 ATM CEoP SPA. 0 to 41 on the 1-Port Channelized OC-3/STM-1 ATM CEoP SPA.
	minimum-links <i>number</i>	Defines the number of minimum links that must remain in operation for an IMA group to remain in service.
	shutdown	Shuts down physical links in an IMA group.

Command Defaults No IMA groups are defined.

Command Modes

Cisco HWIC-4SHDSL
 Config controller
 Config controller DSL group

Cisco 7100, 7200, and 7500 series routers
 Interface configuration

Cisco 7600 series routers
 Controller configuration

Command History	Release	Modification
	12.0(5)XK	This command was introduced on Cisco 2600 and 3600 series routers.

12.0(5)T	This command was integrated into Cisco IOS Release 12.0(5)T.
12.0(5)XE	Support for Cisco 7200 and 7500 series routers was added.
12.0(7)XE1	Support for Cisco 7100 series routers was added.
12.1(5)T	Support for Cisco 7100, 7200, and 7500 series routers was added.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.4 (11)XJ	This command was integrated into Cisco IOS Release 12.4 (11)XJ.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
12.2(33)SRB2	Support for Cisco 7600 series routers was added.

Usage Guidelines

For usage guidelines for using the **clock-mode** keyword, see the command reference page for the **ima group clock-mode** command.

Cisco HWIC-4SHDSL

Use the **dsl-group** command with the optional keyword **ima** to create an IMA DSL group and to enter config-controller-dsl-group mode. Use the **ima group** command to define the links as IMA group members.

Cisco 7100, 7200, and 7500 series routers

When the configuration is first performed or when the group number is changed, the interface is automatically disabled, moved to the new group, and then enabled.

Examples

Cisco HWIC-4SHDSL

The following example uses the **dsl-group** command to create an IMA group and enter config-controller-dsl-group mode on the Cisco HWIC-4SHDSL in a Cisco access router:

```
Router(config-controller)# dsl-group 1 pairs 0-1 ima
Router(config-controller-dsl-group)#
```

```
Sep 26 11:43:55.798: %HWIC_SHDSL-5-DSLGROUP_UPDOWN: SHDSL 0/2/0 dsl-group(1) state changed to down.
```

```
Sep 26 11:43:57.798: %LINK-3-UPDOWN: Interface ATM0/2/IMA1, changed state to down
```

```
Sep 26 11:43:58.798: %LINEPROTO-5-UPDOWN: Line protocol on Interface ATM0/2/IMA1, changed state to down
```

```
Router (config-controller-dsl-group)# ?
```

```
dsl-group configuration sub commands:
  default  Set a command to its defaults
  exit     Exit dsl-group sub commands
  ima      IMA sub commands
  no       Negate a command or set its defaults
  shdsl    Symmetric g.shdsl configuration
  shutdown Shutdown this dsl-group
```

```
Router (config-controller-dsl-group)# ima ?
```

```
group  IMA group configuration
link   IMA link configuration
```

```
Router (config-controller-dsl-group)# ima group ?

clock-mode      IMA group clock mode configuration
minimum-links   Minimum number of active links for group UP
shutdown        IMA group shutdown
```

Cisco 7100, 7200, and 7500 series routers

The following example assigns interface 1 on the ATM module in slot 0 to a member of IMA group 2:

```
interface atm0/1
  ima-group 2
```

Cisco 7600 series routers

The following example shows how to create IMA group 0 and add T1 interfaces 2/1/0, 2/1/1, and 2/1/2 to the group. These interfaces represent the T1 links attached to ports 0, 1, and 2 of the SPA in subslot 1 of the SPA interface processor (SIP) in chassis slot 2.

```
controller t1 2/1/0
  ima-group 0
exit
controller t1 2/1/1
  ima-group 0
exit
controller t1 2/1/2
  ima-group 0
exit
```

Related Commands

Command	Description
ima group clock-mode	Sets the clock mode for an IMA group.
ima link	Defines physical links for an IMA group.
interface atm	Configures an ATM interface.
interface atm ima	Configures an ATM IMA group.
show ima interface atm	Provides information about all configured IMA groups or a specific IMA group.
shutdown (interface)	Disables an interface.

ima restart

To manually restart an IMA group, issue the **ima restart** command in interface configuration mode on the IMA interface that represents the IMA group you want to restart.

ima restart

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	No default behavior or values.
-----------------	--------------------------------

Command Modes	Interface configuration (IMA interface)
----------------------	---

Command History	Release	Modification
	12.2(33)SRB2	This command was introduced on the Cisco 7600 series router.

Usage Guidelines	If an IMA group stops operating correctly (for example, due to a link or configuration failure), you must restart the group once the problem has been corrected. This command provides a way to manually restart an IMA group. Issue the command on the IMA interface that represents the group you want to restart. When you issue this command, the IMA group attempts to re-establish the IMA protocol (synchronize) with the remote end.
-------------------------	--

Examples	The following example shows how to restart IMA for group 0 on the SPA installed in slot 2, subslot 1: <pre>interface atm2/1/ima0 ima restart</pre>
-----------------	---

Related Commands	Command	Description
	ima autorestart	Specifies how IMA groups should sync up with remote groups after a restart.

ima test

To specify an interface and test pattern for verifying connectivity of all links in an inverse multiplexing over ATM (IMA) group, use the **ima test** command in interface configuration mode. To stop the test, use the **no** form of this command.

Cisco 2600, 3600, 7100, 7200, and 7500 series router

ima test [**link** *port*] [**pattern** *pattern-id*]

no ima test [**link** *port*] [**pattern** *pattern-id*]

Cisco 7600 series router

ima test [**link** *link number*] [**pattern** *pattern*]

no ima test [**link** *link number*] [**pattern** *pattern*]

Syntax Description

link <i>port</i>	(Optional) The identifier for the interface where the physical link is located.
link <i>link number</i>	(Optional) On Cisco 7600 series routers, <i>link number</i> identifies the link to test. Specify the IMA link ID that is displayed by the show ima interface interface command. Valid values are 0 through 15.
pattern <i>pattern-id</i>	(Optional) A value from 0 to 254, specified as hexadecimal or decimal numbers, identifying a pattern to be sent to the far end of the link.

Defaults

There is no default for the *port* value. The default value for *pattern-id* is 106 (0x6A).

Command Modes

Interface configuration

Command History

Release	Modification
12.0(5)XK	This command was introduced on Cisco 2600 and 3600 series routers.
12.0(5)T	This command was integrated into Cisco IOS 12.0(5)T.
12.0(5)XE	Support for Cisco 7200 and 7500 series routers was added.
12.0(7)XE1	Support for Cisco 7100 series routers was added.
12.1(5)T	This command was integrated into Cisco IOS Release 12.1(5)T.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
12.2(33)SRB2	Support for Cisco 7600 series routers was added.

Usage Guidelines

To verify link and group connectivity, the pattern is sent from the specified link and looped back from the receiving end across all links belonging to the group as defined at the remote end. Verifying link and group connectivity can help you to troubleshoot physical link connectivity or configuration problems at the remote end. The local end verifies that the pattern is returned on all links belonging to the group at the local end, and testing is continuous. An IMA control protocol (ICP) cell in each frame identifies the pattern.

When a link is not transmitting or receiving a pattern correctly, the command reports the link number where the problem exists.

Examples**Cisco 2600, 3600, 7100, 7200, and 7500 series routers**

The following example configures link 4 to send test pattern 56:

```
interface atm 0/ima 2
  ima test link 2 pattern 56
```

Cisco 7600 series routers

The following example shows how to configure IMA to send the test pattern 255 (0xFE) over link 4 in IMA group 0:

```
interface atm2/1/ima0
  ima test link 4 pattern 0xFE
```

Related Commands

Command	Description
show ima interface atm	Provides information about all configured IMA groups or a specific IMA group.

ima version

To specify which version of inverse multiplexing over ATM (IMA) to use, issue the **ima version** command in interface configuration mode. Use the **no** form of the command to revert to the default value.

ima version { 1.0 | 1.1 }

no ima version

Syntax Description	1.0	Selects IMA version 1.0.
	1.1	Selects IMA version 1.1.

Defaults The default is version 1.1.

Command Modes Interface configuration (IMA interface)

Command History	Release	Modification
	12.2(33)SRB2	This command was introduced on the Cisco 7600 series router.

Usage Guidelines Use this command in interface configuration mode on the IMA interface that represents the IMA group that you are configuring for operation.

Examples The following example shows how to select IMA version 1.0 for IMA group 0 on the SPA installed in chassis slot 2, SIP subslot 1:

```
interface atm2/1/ima0
  ima version 1.0
```

Related Commands	Command	Description
	show ima interface atm	Provides information about all configured IMA groups or a specific IMA group.

inarp

To configure the Inverse Address Resolution Protocol (ARP) time period for an ATM permanent virtual circuit (PVC), virtual circuit (VC) class, or VC bundle, use the **inarp** command in the appropriate command mode. To restore the default Inverse ARP time period behavior, use the **no** form of this command.

inarp *minutes*

no inarp *minutes*

Syntax Description

<i>minutes</i>	Number of minutes for the Inverse ARP time period.
----------------	--

Defaults

15 minutes

Command Modes

Interface-ATM-VC configuration (for an ATM PVC)
 VC-class configuration (for a VC class)
 Bundle configuration (for a VC bundle)
 PVC range configuration (for an ATM PVC range)
 PVC-in-range configuration (for an individual PVC within a PVC range)

Command History

Release	Modification
11.3 T	This command was introduced.
12.0(3)T	This command was enhanced to provide support to configure the Inverse ARP time period for an ATM VC bundle.
12.1(5)T	This command was made available in PVC range and PVC-in-range configuration modes.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command is supported for **aal5snap** encapsulation only when Inverse ARP is enabled. Refer to the **encapsulation** command for configuring **aal5snap** encapsulation and the **protocol** command for enabling Inverse ARP.

If the **inarp** command is not explicitly configured on an ATM PVC, the PVC inherits the following default configuration (listed in order of precedence):

- Configuration of the **inarp** command in a VC class assigned to the PVC itself.
- Configuration of the **inarp** command in a VC class assigned to the PVC's ATM subinterface.
- Configuration of the **inarp** command in a VC class assigned to the PVC's ATM main interface.

- Global default for the *minutes* argument is 15 minutes; this default assumes that Inverse ARP is enabled.

**Note**

As the inheritance rules imply, when a VC is a member of a VC bundle, configuration using the **inarp** command in VC-class configuration mode no longer applies to that VC. Bundle configuration takes precedence.

For ATM VC bundle management, the Inverse ARP parameter can only be enabled at the bundle level and applied to all VC members of the bundle—that is, it cannot be enabled in bundle-vc configuration mode for individual VC bundle members. To use this command in bundle configuration mode, first enter the **bundle** command to create the bundle and enter bundle configuration mode.

Examples

The following example sets the Inverse ARP time period to 10 minutes:

```
inarp 10
```

Related Commands

Command	Description
bundle	Creates a bundle or modifies an existing bundle to enter bundle configuration mode.
broadcast	Configures broadcast packet duplication and transmission for an ATM VC class, PVC, SVC, or VC bundle.
class-int	Assigns a VC class to an ATM main interface or subinterface.
class-vc	Assigns a VC class to an ATM PVC, SVC, or VC bundle member.
encapsulation atm-dxi	Configures the AAL and encapsulation type for an ATM PVC, SVC, or VC class.
oam-bundle	Enables end-to-end F5 OAM loopback cell generation and OAM management for a virtual circuit class that can be applied to a virtual circuit bundle.
oam retry	Configures parameters related to OAM management for an ATM PVC, SVC, VC class, or VC bundle.
protocol (ATM)	Configures a static map for an ATM PVC, SVC, VC class, or VC bundle. Enables Inverse ARP or Inverse ARP broadcasts on an ATM PVC by either configuring Inverse ARP directly on the PVC, on the VC bundle, or in a VC class (applies to IP and IPX protocols only).

inarp-vc

To enable Inverse Address Resolution Protocol (InARP) for a permanent virtual circuit (PVC) bundle member, use the **inarp-vc** command in ATM VC bundle-member configuration mode. To disable InARP for a PVC bundle member, use the **no** form of this command.

inarp-vc

no inarp-vc

Syntax Description

This command has no arguments or keywords.

Command Default

InARP is disabled for the PVC bundle member.

Command Modes

ATM VC bundle-member configuration

Command History

Release	Modification
12.4(4)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.

Usage Guidelines

You can use this command only when using the quality of service (QoS) groups method for selecting the PVC bundle members. When InARP is enabled for a PVC bundle member, InARP requests are sent and are expected to be received on the PVC bundle member, and InARP replies are expected to be received on the PVC bundle member.

Examples

The following example associates QoS group 1 with a PVC bundle member and enables InARP on the PVC bundle member:

```
Router> enable
Password:
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# interface atm 2/0
Router(config-subif)# bundle cisco
Router(config-if-atm-bundle)# selection-method qos-group
Router(config-if-atm-bundle)# pvc 1/32
Router(config-if-atm-member)# qos-group 1
Router(config-if-atm-member)# inarp-vc
Router(config-if-atm-member)# end
```

Related Commands

Command	Description
qos-group (ATM VC bundle member)	Associates a QoS group or groups with a PVC bundle member.
selection-method	Specifies the method for selection of the PVC bundle member.

interface atm

To configure an ATM interface and enter interface configuration mode, use the **interface atm** command in global configuration mode.

interface atm *interface-number* [*.subinterface-number* {**mpls** | **multipoint** | **point-to-point**}]

Syntax Description

<i>interface-number</i>	Specifies a (physical) ATM interface (for example, 3/0).
<i>.subinterface-number</i>	(Optional) Specifies a subinterface number. A dot (.) must be used to separate the <i>interface-number</i> from the <i>subinterface-number</i> (for example 2/0.1).
mpls	(Optional) Specifies MPLS as the interface type for which a subinterface is to be created.
multipoint	(Optional) Specifies multipoint as the interface type for which a subinterface is to be created.
point-to-point	(Optional) Specifies point-to-point as the interface type for which a subinterface is to be created.

Defaults

None

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.
12.1(3)T	New optional subinterface types were introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

The **interface atm** command enables you to define a subinterface for a specified type of ATM interface. The subinterface for the ATM interface is created the first time this command is issued with a specified subinterface number.

For the Cisco 7600 series routers, you must specify the interface ATM slot, bay, and port for the SIP400 or SIP200.

Examples

For physical ATM interface 3/0, the following command creates an ATM MPLS subinterface having subinterface number 1:

```
Router# interface atm 3/0.1 mpls
```

For a Cisco 7600 series router where the slot is 4, the bay is 3, and the port is 0, the command is:

```
Router# interface atm 4/3/0 mpls
```

Related Commands

Command	Description
show interfaces atm	Displays information about the ATM interface.
show mpls interfaces	Displays information about one or more MPLS interfaces that have been configured for label switching.

interface atm ima

To configure an inverse multiplexing over ATM (IMA) group, use the **interface atm ima** global configuration command.

interface atm *slot/imagroup-number*

Syntax Description

<i>slot/</i>	Specifies the slot location of the ATM IMA network module. The values range from 0 to 5 depending on the router.
<i>group-number</i>	Enter an IMA group number from 0 to 3. You can create up to four groups. Do not include a space before the group number.

Command Default

There are no IMA groups (only individual ATM links).

Command Modes

Global configuration

Command History

Release	Modification
12.0(5)XK	This command was introduced on Cisco 2600 and 3600 series routers.
12.0(5)T	This command was integrated into Cisco IOS 12.0(5)T.
12.0(5)XE	Support for Cisco 7200 and 7500 series routers was added.
12.0(7)XE1	Support for Cisco 7100 series routers was added.
12.1(5)T	Support for Cisco 7100, 7200, and 7500 series routers was integrated into Cisco IOS Release 12.1(5)T.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

If the group does not exist when the command is issued, the command automatically creates the group. When a port is configured for IMA functionality, it no longer operates as an individual ATM link. Specifying ATM links as members of a group by using the **ima group** interface command does not enable the group. You must use the **interface atm ima** command to create the group.

Examples

The following example configures IMA group 0 on the module in slot 1:

```
interface atm 1/ima0
 ip address 10.18.16.121 255.255.255.192
```


Related Commands

Command	Description
ima-group	Defines IMA group members.
interface atm	Configures an ATM interface.
show ima interface atm	Provides information about all configured IMA groups or a specific IMA group.
shutdown (interface)	Disables an interface.

interface cbr

To specify the T1 or E1 constant bit rate interface on an ATM-CES port adapter, and to enter interface configuration mode, use the **interface cbr** command in global configuration mode.

interface cbr *slot/port*

Syntax Description

<i>slot/</i>	Backplane slot number. The slash (/) must be typed.
<i>port</i>	Interface port number.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
11.1	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

The ATM-CES port adapter has four T1 (1.544 Mbps) or four E1 (2.048 Mbps) ports (75- or 120-ohm) that can support both structured (N x 64 kbps) and unstructured ATM Forum-compliant circuit emulation services (CES), and one port that supports an OC-3 (155 Mbps) single-mode intermediate reach interface or a T3 (45 Mbps) or E3 (34 Mbps) standards-based ATM interface.

Examples

The following example specifies the first T1 or E1 port on the ATM-CES port adapter in slot 1:

```
interface cbr 1/0
```

Related Commands

Command	Description
show ces interface cbr	Displays detailed CBR port information.
show interface cbr	Displays the information about the CBR interface on the ATM-CES port adapter.

keepalive-lifetime

To specify the duration that a keepalive message from a Multiprotocol over ATM server (MPS) is considered valid by the Multiprotocol over ATM client (MPC), use the **keepalive-lifetime** command in global configuration mode.

keepalive-lifetime *seconds*

Syntax Description	
<i>seconds</i>	Time (in seconds) for the MPS-p2 variable of the MPS.

Defaults	
	The default is 35 seconds.

Command Modes	
	Global configuration

Command History	Release	Modification
	12.0(3)T	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	
	The keepalive lifetime (MPS-p2) must be greater than or equal to three times the value of the keepalive time (MPS-p1). MPS-p1 specifies the frequency with which a keepalive message is sent from the MPS to the MPC.

Examples	
	The following example shows how to specify a keepalive lifetime of 60 seconds:

```
Router(config)# keepalive-lifetime 60
```

Related Commands	Command	Description
	keepalive-time	Specifies the keepalive time value for the MPS-p1 variable of an MPS.

keepalive-time

To specify the keepalive time value for the Multiprotocol over ATM (MPOA) server (MPS)-p1 variable of an MPS, use the **keepalive-time** command in MPS configuration mode. To revert to the default value, use the **no** form of this command.

keepalive-time *seconds*

no keepalive-time *seconds*

Syntax Description

<i>seconds</i>	Specifies the keepalive time value (in seconds). The default value is 10 seconds.
----------------	---

Defaults

The default keepalive time is 10 seconds.

Command Modes

MPS configuration

Command History

Release	Modification
11.3(3a)WA4(5)	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following example shows how to set the keepalive time to 25 seconds:

```
Router (mpoa-server-config) # keepalive-time 25
```

lane auto-config-atm-address

To specify that the configuration server ATM address is computed by the Cisco automatic method, use the **lane auto-config-atm-address** command in interface configuration mode. To remove the previously assigned ATM address, use the **no** form of this command.

lane [**config**] **auto-config-atm-address**

no lane [**config**] **auto-config-atm-address**

Syntax Description	config	(Optional) When the config keyword is used, this command applies only to the LAN Emulation Configuration Server (LECS). This keyword indicates that the LECS should use the auto computed LECS address.
---------------------------	---------------	--

Command Default	No specific ATM address is set.
------------------------	---------------------------------

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	11.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	When the config keyword is not present, this command causes the LANE server and LANE client on the subinterface to use the automatically assigned ATM address for the configuration server.
-------------------------	--

When the **config** keyword is present, this command assigns the automatically generated ATM address to the configuration server (LECS) configured on the interface. Multiple commands that assign ATM addresses to the LANE configuration server can be issued on the same interface to assign different ATM addresses to the configuration server. Commands that assign ATM addresses to the LANE configuration server include **lane auto-config-atm-address**, **lane config-atm-address**, and **lane fixed-config-atm-address**.

For a discussion of Cisco's method of automatically assigning ATM addresses, refer to the "Configuring LAN Emulation" chapter in the *Cisco IOS Switching Services Configuration Guide*.

Examples

The following example shows how to associate the LANE configuration server with the database named network1 and specifies that the configuration server's ATM address will be assigned by the Cisco automatic method:

```
Router(config)# lane database network1
Router(lane-config-dat)# name eng server-atm-address
39.020304050607080910111213.0800.AA00.1001.02
Router(lane-config-dat)# name mkt server-atm-address
39.020304050607080910111213.0800.AA00.4001.01

Router(config)# interface atm 1/0
Router(config-if)# lane config database network1
Router(config-if)# lane config auto-config-atm-address
```

The following example shows how to cause the LANE server and LANE client on the subinterface to use the automatically assigned ATM address to communicate with the configuration server:

```
Router(config)# interface atm 2/0.1
Router(config-if)# ip address 172.16.0.4 255.255.255.0
Router(config-if)# lane client ethernet
Router(config-if)# lane server-bus ethernet eng
Router(config-if)# lane auto-config-atm-address
```

Related Commands

Command	Description
lane config-atm-address	Specifies the ATM address of the configuration server explicitly.
lane database	Creates a named configuration database that can be associated with a configuration server.
lane fixed-config-atm-address	Specifies that the fixed configuration server ATM address assigned by the ATM Forum will be used.

lane bus-atm-address

To specify an ATM address—and thus override the automatic ATM address assignment—for the broadcast and unknown server on the specified subinterface, use the **lane bus-atm-address** command in interface configuration mode. To remove the ATM address previously specified for the broadcast and unknown server on the specified subinterface and thus revert to the automatic address assignment, use the **no** form of this command.

lane bus-atm-address *atm-address-template*

no lane bus-atm-address [*atm-address-template*]

Syntax Description	<i>atm-address-template</i>	ATM address or a template in which wildcard characters are replaced by any nibble or group of nibbles of the prefix bytes, the end-system identifier (ESI) bytes, or the selector byte of the automatically assigned ATM address.
---------------------------	-----------------------------	---

Defaults	For the broadcast and unknown server, the default is automatic ATM address assignment.
-----------------	--

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	11.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	When applied to a broadcast and unknown server, this command overrides automatic ATM address assignment for the broadcast and unknown server. When applied to a LANE client, this command gives the client the ATM address of the broadcast and unknown server. The client will use this address rather than sending LAN Emulation Address Resolution Protocol (LE ARP) requests for the broadcast address. When applied to a selected interface, but with a different ATM address from what was used previously, this command replaces the broadcast and unknown server's ATM address.
-------------------------	---

ATM Addresses

A LANE ATM address has the same syntax as a network service access point (NSAP) (but it is not a network-level address). It consists of the following:

- A 13-byte prefix that includes the following fields defined by the ATM Forum:
 - AFI (Authority and Format Identifier) field (1 byte)
 - DCC (Data Country Code) or ICD (International Code Designator) field (2 bytes)
 - DFI field (Domain Specific Part Format Identifier) (1 byte)

- Administrative Authority field (3 bytes)
- Reserved field (2 bytes)
- Routing Domain field (2 bytes)
- Area field (2 bytes)
- A 6-byte ESI
- A 1-byte selector field

Address Templates

LANE ATM address templates can use two types of wildcards: an asterisk (*) to match any single character (nibble), and an ellipsis (...) to match any number of leading, middle, or trailing characters. The values of the characters replaced by wildcards come from the automatically assigned ATM address.

The values of the digits that are replaced by wildcards come from the automatic ATM assignment method.

In LANE, a *prefix template* explicitly matches the prefix but uses wildcards for the ESI and selector fields. An *ESI template* explicitly matches the ESI field but uses wildcards for the prefix and selector.

In the Cisco implementation of LANE, the prefix corresponds to the switch, the ESI corresponds to the ATM interface, and the selector field corresponds to the specific subinterface of the interface.

Examples

The following example shows how to use an ESI template to specify the part of the ATM address corresponding to the interface; the remaining values in the ATM address come from automatic assignment:

```
Router(config-if)# lane bus-atm-address ...0800.200C.1001.**
```

The following example shows how to use a prefix template to specify the part of the ATM address corresponding to the switch; the remaining values in the ATM address come from automatic assignment:

```
Router(config-if)# lane bus-atm-address 45.000014155551212f.00.00...
```

Related Commands

Command	Description
lane server-bus	Enables a LANE server and a broadcast and unknown server on the specified subinterface with the ELAN ID.

lane client

To activate a LAN Emulation (LANE) client on the specified subinterface, use the **lane client** command in interface configuration mode. To remove a previously activated LANE client on the subinterface, use the **no** form of this command.

lane client {ethernet} [elan-name]

no lane client {ethernet} [elan-name]

Syntax Description	ethernet	Identifies the emulated LAN (ELAN) attached to this subinterface as an Ethernet ELAN.
	<i>elan-name</i>	(Optional) Name of the ELAN. This argument is optional because the client obtains its ELAN name from the configuration server. The maximum length of the name is 32 characters.

Command Default	No LANE clients are enabled on the interface.
------------------------	---

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	11.0	This command was introduced.
	12.3(2)T	The tokenring keyword was removed.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	If a lane client command has already been used on the subinterface for a different ELAN, then the client initiates termination procedures for that ELAN and joins the new ELAN. If you do not provide an <i>elan-name</i> value, the client contacts the server to find which ELAN to join. If you do provide an ELAN name, the client consults the configuration server to ensure that no conflicting bindings exist.
-------------------------	---

Examples	The following example shows how to enable an Ethernet LANE client on an interface:
-----------------	--

```
Router(config-if)# lane client ethernet
```

Related Commands

Command	Description
lane client-atm-address	Specifies an ATM address—and thus overrides the automatic ATM address assignment—for the LANE client on the specified subinterface.

lane client flush

To enable the flush mechanism of a LAN Emulation Client (LEC), use the **lane client flush** command in global configuration mode. To disable the flush mechanism of a LEC, use the **no** form of this command.

lane client flush

no lane client flush

Syntax Description

This command contains no arguments or keywords.

Command Default

All the LECs perform the LANE LE_FLUSH process by default.

Command Modes

Global configuration

Command History

Release	Modification
12.1(2)T	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

In Cisco IOS Release 12.1(3)T and later releases, the **lane client flush** command will be hidden and will not be visible in the configuration.

Configuring the **no lane client flush** command on a Cisco networking device is recommended to prevent the initial packet drops during the establishment of LANE data direct virtual connection (VCC).

Use the **no lane client flush** command to keep LANE clients from sending LE_FLUSH messages to the remote LANE client. This configuration also allows the LANE clients to process the LE_FLUSH messages from the remote LANE clients.



Note

Configuring the **no lane client flush** command on a Cisco networking device does not guarantee the orderly delivery of incoming packets. There is a chance of receiving out-of-order packets at the destination during the establishment of a LANE data direct VCC.

Examples

The following example shows how to disable the flush mechanism of a LEC:

```
Router(config)# no lane client flush
```

Related Commands

Command	Description
lane client	Activates a LANE client on the specified subinterface.
lane client-atm-address	Specifies an ATM address—and thus overrides the automatic ATM address assignment—for the LANE client on the specified subinterface.

lane client mpoa client name

To bind a LAN Emulation Client (LEC) to the named Multiprotocol over ATM client (MPC), use the **lane client mpoa client name** command in interface configuration mode. To unbind the named MPC from a LEC, use the **no** form of this command.

lane client mpoa client name *mpc-name*

no lane client mpoa client name *mpc-name*

Syntax Description

mpc-name Name of the specific MPC.

Command Default

No LEC is bound to a named MPC.

Command Modes

Interface configuration

Command History

Release	Modification
11.3(3a)WA4(5)	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

When you enter this command, the named MPC is bound to a LEC. The named MPC must exist before this command is accepted. If you enter this command before a LEC is configured (not necessarily running), a warning message is issued.

Examples

The following example shows how to bind a LEC on a subinterface to the MPC:

```
Router(config-if)# lane client mpoa client name ip_mpc
```

lane client mpoa server name

To bind a LAN Emulation Client (LEC) with the named Multiprotocol over ATM server (MPS), use the **lane client mpoa server name** command in interface configuration mode. To unbind the server, use the **no** form of this command.

lane client mpoa server name *mps-name*

no lane client mpoa server name *mps-name*

Syntax Description

<i>mps-name</i>	Name of the specific MPS.
-----------------	---------------------------

Command Default

No LEC is bound to a named MPS.

Command Modes

Interface configuration

Command History

Release	Modification
11.3(3a)WA4(5)	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command binds a LEC to the named MPS. The specified MPS must exist before this command is accepted. If this command is entered when a LEC is not already configured (not necessarily running), a warning message will be issued.

Examples

The following example shows how to bind a LANE client with the MPS named MYMPS:

```
Router(config-if)# lane client mpoa server name MYMPS
```

lane client-atm-address

To specify an ATM address—and thus override the automatic ATM address assignment—for the LAN Emulation (LANE) client on the specified subinterface, use the **lane client-atm-address** command in interface configuration mode. To remove the ATM address previously specified for the LANE client on the specified subinterface and thus revert to the automatic address assignment, use the **no** form of this command.

lane client-atm-address *atm-address-template*

no lane client-atm-address [*atm-address-template*]

Syntax Description	<i>atm-address-template</i>	ATM address or a template in which wildcard characters are replaced by any nibble or group of nibbles of the prefix bytes, the end-system identifier (ESI) bytes, or the selector byte of the automatically assigned ATM address.
---------------------------	-----------------------------	---

Defaults	Automatic ATM address assignment
-----------------	----------------------------------

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	11.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	Use of this command on a selected subinterface, but with a different ATM address from what was used previously, replaces the ATM address of the LANE client.
-------------------------	--

ATM Addresses

A LANE ATM address has the same syntax as a network service access point (NSAP) (but it is not a network-level address). It consists of the following:

- A 13-byte prefix that includes the following fields defined by the ATM Forum:
 - AFI (Authority and Format Identifier) field (1 byte)
 - DCC (Data Country Code) or ICD (International Code Designator) field (2 bytes)
 - DFI field (Domain Specific Part Format Identifier) (1 byte)
 - Administrative Authority field (3 bytes)
 - Reserved field (2 bytes)
 - Routing Domain field (2 bytes)

- Area field (2 bytes)
- A 6-byte ESI
- A 1-byte selector field

Address Templates

LANE ATM address templates can use two types of wildcards: an asterisk (*) to match any single character (nibble), and an ellipsis (...) to match any number of leading, middle, or trailing characters. The values of the characters replaced by wildcards come from the automatically assigned ATM address.

In LANE, a *prefix template* explicitly matches the ATM address prefix but uses wildcards for the ESI and selector fields. An *ESI template* explicitly matches the ESI field but uses wildcards for the prefix and selector.

The Cisco implementation of LANE, the prefix corresponds to the switch, the ESI corresponds to the ATM interface, and the selector field corresponds to the specific subinterface of the interface.

For a discussion of Cisco's method of automatically assigning ATM addresses, refer to the "Configuring LAN Emulation" chapter in the *Cisco IOS Switching Services Configuration Guide*.

Examples

The following example shows how to use an ESI template to specify the part of the ATM address corresponding to the interface; the remaining parts of the ATM address come from automatic assignment:

```
Router(config-if)# lane client-atm-address...0800.200C.1001.**
```

The following example shows how to use a prefix template to specify the part of the ATM address corresponding to the switch; the remaining parts of the ATM address come from automatic assignment:

```
Router(config-if)# lane client-atm-address 47.000014155551212f.00.00...
```

Related Commands

Command	Description
lane client	Activates a LANE client on the specified subinterface.

lane config database

To associate a named configuration table (database) with the configuration server on the selected ATM interface, use the **lane config database** command in interface configuration mode. To remove the association between a named database and the configuration server on the specified interface, use the **no** form of this command.

lane config database *database-name*

no lane config database

Syntax Description

<i>database-name</i>	Name of the LAN emulation (LANE) database.
----------------------	--

Command Default

No configuration server is defined, and no database name is provided.

Command Modes

Interface configuration

Command History

Release	Modification
11.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command is valid only on a major interface, not a subinterface, because only one LANE Configuration Server (LECS) can exist per interface.

The named database must exist before the **lane config database** command is used. Refer to the **lane database** command for more information.

Multiple **lane config database** commands cannot be used multiple times on the same interface. You must delete an existing association by using the **no** form of this command before you can create a new association on the specified interface.

Activating a LANE configuration server requires the **lane config database** command and one of the following commands: **lane fixed-config-atm-address**, **lane auto-config-atm-address**, or **lane config-atm-address**.

Examples

The following example shows how to associate the LECS with the database named network1 and to specify that the configuration server's ATM address will be assigned by the Cisco automatic method:

```
Router(config)# lane database network1
Router(lane-config-dat)# name eng server-atm-address
39.020304050607080910111213.0800.AA00.1001.02
Router(lane-config-dat)# name mkt server-atm-address
39.020304050607080910111213.0800.AA00.4001.01
Router(config)# interface atm 1/0
Router(config-if)# lane config database network1
Router(config-if)# lane config auto-config-atm-address
```

Related Commands

Command	Description
lane auto-config-atm-address	Specifies that the configuration server ATM address is computed by the Cisco automatic method.
lane config-atm-address	Specifies the ATM address of the configuration server explicitly.
lane database	Creates a named configuration database that can be associated with a configuration server.
lane fixed-config-atm-address	Specifies that the fixed configuration server ATM address assigned by the ATM Forum will be used.

lane config-atm-address

To specify a configuration server's ATM address explicitly, use the **lane config-atm-address** command in interface configuration mode. To remove an assigned ATM address, use the **no** form of this command.

lane [**config**] **config-atm-address** *atm-address-template*

no lane [**config**] **config-atm-address** *atm-address-template*

Syntax Description	config	(Optional) When the config keyword is used, this command applies only to the LANE Configuration Server (LECS). This keyword indicates that the LECS should use the 20-byte address that you explicitly entered.
	<i>atm-address-template</i>	ATM address or a template in which wildcard characters are replaced by any nibble or group of nibbles of the prefix bytes, the end-system identifier (ESI) bytes, or the selector byte of the automatically assigned ATM address.

Command Default	No specific ATM address or method is set.
------------------------	---

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	11.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	If the config keyword is not present, this command causes the LAN Emulation (LANE) server and LANE client on the subinterface to use the specified ATM address for the configuration server.
-------------------------	---

When the **config** keyword is present, this command adds an ATM address to the configuration server configured on the interface. A LECS can listen on multiple ATM addresses. Multiple commands that assign ATM addresses to the LECS can be issued on the same interface to assign different ATM addresses to the LECS.

ATM Addresses

A LANE ATM address has the same syntax as an NSAP (but it is not a network-level address). It consists of the following:

- A 13-byte prefix that includes the following fields defined by the ATM Forum:
 - AFI (Authority and Format Identifier) field (1 byte)
 - DCC (Data Country Code) or ICD (International Code Designator) field (2 bytes)

- DFI field (Domain Specific Part Format Identifier) (1 byte)
- Administrative Authority field (3 bytes)
- Reserved field (2 bytes)
- Routing Domain field (2 bytes)
- Area field (2 bytes)
- A 6-byte ESI
- A 1-byte selector field

Address Templates

LANE ATM address templates can use two types of wildcards: an asterisk (*) to match any single character (nibble), and an ellipsis (...) to match any number of leading, middle, or trailing characters. The values of the characters replaced by wildcards come from the automatically assigned ATM address.

In LANE, a *prefix template* explicitly matches the ATM address prefix but uses wildcards for the ESI and selector fields. An *ESI template* explicitly matches the ESI field but uses wildcards for the prefix and selector.

In our implementation of LANE, the prefix corresponds to the switch prefix, the ESI corresponds to a function of the ATM interface's MAC address, and the selector field corresponds to the specific subinterface of the interface.

For a discussion of the Cisco method of automatically assigning ATM addresses, refer to the “Configuring LAN Emulation” chapter in the *Cisco IOS Switching Services Configuration Guide*.

Examples

The following example shows how to associate the LANE configuration server with the database named network1 and to explicitly specify the configuration server's ATM address:

```
Router(config)# lane database network1
Router(lane-config-dat)# name eng server-atm-address
39.020304050607080910111213.0800.AA00.1001.02
Router(lane-config-dat)# name mkt server-atm-address
39.020304050607080910111213.0800.AA00.4001.01

Router(config)# interface atm 1/0
Router(config-if)# lane config database network1
Router(config-if)# lane config config-atm-address
39.020304050607080910111213.0800.AA00.3000.00
```

The following example shows how to cause the LANE server and LANE client on the subinterface to use the explicitly specified ATM address to communicate with the configuration server:

```
Router(config)# interface atm 2/0.1
Router(config-if)# ip address 172.16.0.4 255.255.255.0
Router(config-if)# lane client ethernet
Router(config-if)# lane server-bus ethernet eng
Router(config-if)# lane config-atm-address 39.020304050607080910111213.0800.AA00.3000.00
```

Related Commands	Command	Description
	lane auto-config-atm-address	Specifies that the configuration server ATM address is computed by the Cisco automatic method.
	lane config database	Associates a named configuration table (database) with the configuration server on the selected ATM interface.
	lane database	Creates a named configuration database that can be associated with a configuration server.
	lane fixed-config-atm-address	Specifies that the fixed configuration server ATM address assigned by the ATM Forum will be used.

lane database

To create a named configuration database that can be associated with a configuration server, use the **lane database** command in global configuration mode. To delete the database, use the **no** form of this command.

lane database *database-name*

no lane database *database-name*

Syntax Description

<i>database-name</i>	Database name (32 characters maximum).
----------------------	--

Command Default

No name is provided.

Command Modes

Global configuration

Command History

Release	Modification
11.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Use of the **lane database** command places you in database configuration mode, in which you can use the **client-atm-address name**, **default name**, **mac-address name**, **name restricted**, **name unrestricted**, **name new-name**, and **name server-atm-address** commands to create entries in the specified database. When you are finished creating entries, type **^Z** or **exit** to return to global configuration mode.

Examples

The following example shows how to create the database named network1 and associates it with the configuration server on interface ATM 1/0:

```
Router(config)# lane database network1
Router(lane-config-dat)# name eng server-atm-address
39.020304050607080910111213.0800.AA00.1001.02
Router(lane-config-dat)# name mkt server-atm-address
39.020304050607080910111213.0800.AA00.4001.01
Router(lane-config-dat)# default-name eng

Router(config)# interface atm 1/0
Router(config-if)# lane config database network1
Router(config-if)# lane config auto-config-atm-address
```

Related Commands	Command	Description
	client-atm-address name	Adds a LANE client address entry to the configuration database of the configuration server.
	default-name	Provides an ELAN name in the database of the configuration server for those client MAC addresses and client ATM addresses that do not have explicit ELAN name bindings.
	lane config database	Associates a named configuration table (database) with the configuration server on the selected ATM interface.
	mac-address	Sets the MAC-layer address of the Cisco Token Ring.
	name	Assigns a name to the internal adapter.
	name server-atm-address	Specifies or replaces the ATM address of the LANE server for the ELAN in the configuration database of the configuration server.

lane fixed-config-atm-address

To specify that the fixed configuration server ATM address assigned by the ATM Forum will be used, use the **lane fixed-config-atm-address** command in interface configuration mode. To specify that the fixed ATM address will not be used, use the **no** form of this command.

lane [config] fixed-config-atm-address

no lane [config] fixed-config-atm-address

Syntax Description

config	(Optional) When the config keyword is used, this command applies only to the LANE Configuration Server (LECS). This keyword indicates that LECS should use the well-known, ATM Forum LEC address.
---------------	--

Command Default

No specific ATM address or method is set.

Command Modes

Interface configuration

Command History

Release	Modification
11.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

When the **config** keyword is not present, this command causes the LAN emulation (LANE) server and LANE client on the subinterface to use that ATM address, rather than the ATM address provided by the ILMI, to locate the configuration server.

When the **config** keyword is present, and the LECS is already up and running, be aware of the following scenarios:

- If you configure the LECS with only the well-known address, the LECS will not participate in the SSRP, will act as a standalone master, and will listen only on the well-known LECS address. This scenario is ideal if you want a standalone LECS that does not participate in SSRP, and you would like to listen to only the well-known address.
- If only the well-known address is already assigned, and you assign at least one other address to the LECS (additional addresses are assigned using the **lane auto-config-atm-address** command or the **lane config-atm-address** command), the LECS will participate in the SSRP and act as the master or slave based on the normal SSRP rules. This scenario is ideal if you would like the LECS to participate in SSRP, and you would like to make the master LECS listen on the well-known address.
- If the LECS is participating in SSRP, has more than one address (one of which is the well-known address), and all the addresses but the well-known address are removed, the LECS will declare itself the master and stop participating in SSRP completely.

- If the LECS is operating as an SSRP slave, and it has the well-known address configured, it will not listen on the well-known address unless it becomes the master.
- If you want the LECS to assume the well-known address only when it becomes the master, configure the LECS with the well-known address and at least one other address.

When you use this command with the **config** keyword, and the LECS is a master, the master will listen on the fixed address. If you use this command when an LECS is not a master, the LECS will listen on this address when it becomes a master. If you do not use this command, the LECS will not listen on the fixed address.

Multiple commands that assign ATM addresses to the LECS can be issued on the same interface in order to assign different ATM addresses to the LECS. Commands that assign ATM addresses to the LECS include **lane auto-config-atm-address**, **lane config-atm-address**, and **lane fixed-config-atm-address**. The **lane config database** command and at least one command that assigns an ATM address to the LECS are required to activate a LECS.

Examples

The following example shows how to associate the LECS with the database named network1 and how to specify that the configuration server's ATM address is the fixed address:

```
Router(config)# lane database network1
Router(lane-config-dat)# name eng server-atm-address
39.020304050607080910111213.0800.AA00.1001.02
Router(lane-config-dat)# name mkt server-atm-address
39.020304050607080910111213.0800.AA00.4001.01

Router(config)# interface atm 1/0
Router(config-if)# lane config database network1
Router(config-if)# lane config fixed-config-atm-address
```

The following example shows how to cause the LANE server and LANE client on the subinterface to use the fixed ATM address to communicate with the configuration server:

```
Router(config)# interface atm 2/0.1
Router(config-if)# ip address 172.16.0.4 255.255.255.0
Router(config-if)# lane client ethernet
Router(config-if)# lane server-bus ethernet eng
Router(config-if)# lane fixed-config-atm-address
```

Related Commands

Command	Description
lane auto-config-atm-address	Specifies that the configuration server ATM address is computed by the Cisco automatic method.
lane config-atm-address	Specifies the ATM address of the configuration server explicitly.
lane config database	Associates a named configuration table (database) with the configuration server on the selected ATM interface.

lane fssrp

To enable the special LANE features such that LANE components (such as the LANE Configuration Server, the LANE client, the LANE server, and the BUS) become aware of the Fast Simple Server Redundancy Protocol (FSSRP), use the **lane fssrp** command in interface configuration mode. To disable the LANE FSSRP configuration, use the **no** form of this command.

lane fssrp

no lane fssrp

Syntax Description

This command contains no arguments or keywords.

Command Default

FSSRP is not enabled by default.

Command Modes

Interface configuration

Command History

Release	Modification
12.0(4c)W5(10a)	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

You must execute this command on all ATM interfaces to enable FSSRP capability for all LANE components on that interface and hence all its subinterfaces.

Examples

The following example shows how to enable FSSRP on an ATM interface:

```
Router(config-if)# lane fssrp
```

Related Commands

Command	Description
lane client	Activates a LANE client on the specified subinterface.
lane server	Activates a LANE server on the specified subinterface.
show lane client	Generates additional FSSRP information about a LANE client.
show lane config	Displays global LANE information for the configuration server configured on an interface.

lane global-lecs-address

To specify a list of LAN Emulation Configuration Server (LECS) addresses to use when the addresses cannot be obtained from the Interim Local Management Interface (ILMI), use the **lane global-lecs-address** command in interface configuration mode. To remove a LECS address from the list, use the **no** form of this command.

lane global-lecs-address *address*

no lane global-lecs-address *address*

Syntax Description	<i>address</i>	Address of the LECS. You cannot use the well-known LECS address.
---------------------------	----------------	--

Command Default	No addresses are configured. The router obtains LECS addresses from the ILMI.
------------------------	---

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	11.2	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	Use this command when your ATM switches do not support the ILMI list of LECS addresses and you want to configure Simple Server Redundancy. This command will simulate the list of LECS addresses, as if they had been obtained from the ILMI. Use this command with a different address for each LECS. The order they are used determines their priority. You should enter the addresses in the same order as you would on the ATM switch.
-------------------------	--

**Note**

You must configure the same list of addresses on each interface that contains a LAN emulation (LANE) entity.

If your switches do support ILMI, this command forces the router to use the addresses specified and will not use the ILMI to obtain the LECS addresses.

Because the well-known LECS address is always used as a last resort LECS address, you cannot use the address in this command.

lane le-arp

To add a static entry to the LAN Emulation Address Resolution Protocol (LE ARP) table of the LANE client configured on the specified subinterface, use the **lane le-arp** command in interface configuration mode. To remove a static entry from the LE ARP table of the LANE client on the specified subinterface, use the **no** form of this command.

lane le-arp {*mac-address* | **route-desc segment** *segment-number* **bridge** *bridge-number*}
atm-address

no lane le-arp {*mac-address* | **route-desc segment** *segment-number* **bridge** *bridge-number*}
atm-address

Syntax Description	<i>mac-address</i>	MAC address to bind to the specified ATM address.
	route-desc segment <i>segment-number</i>	LANE segment number. The segment number ranges from 1 to 4095.
	bridge <i>bridge-number</i>	Bridge number that is contained in the route descriptor. The bridge number ranges from 1 to 15.
	<i>atm-address</i>	ATM address.

Command Default No static address bindings are provided.

Command Modes Interface configuration

Command History	Release	Modification
	11.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines This command adds or removes a static entry binding a MAC address or segment number and bridge number to an ATM address. It does not add or remove dynamic entries. Removing the static entry for a specified ATM address from a LE ARP table does not release data direct VCCs established to that ATM address. However, clearing a static entry clears any fast-cache entries that were created from the MAC address-to-ATM address binding.

Static LE ARP entries are neither aged nor removed automatically.

To remove dynamic entries from the LE ARP table of the LANE client on the specified subinterface, use the **clear lane le-arp** command.

Examples

The following example shows how to add a static entry to the LE ARP table:

```
Router(config-if)# lane le-arp 0800.aa00.0101 47.000014155551212f.00.00.0800.200c.1001.01
```

The following example shows how to add a static entry to the LE ARP table binding segment number 1, bridge number 1 to the ATM address:

```
Router(config-if)# lane le-arp route-desc segment 1 bridge 1  
39.020304050607080910111213.00000CA05B41.01
```

Related Commands

Command	Description
clear lane le-arp	Forces a LANE server to drop a client and allow the LANE configuration server to assign the client to another ELAN.

lane server-atm-address

To specify an ATM address—and thus override the automatic ATM address assignment—for the LAN emulation (LANE) server on the specified subinterface, use the **lane server-atm-address** command in interface configuration mode. To remove the ATM address previously specified for the LANE server on the specified subinterface and thus revert to the automatic address assignment, use the **no** form of this command.

lane server-atm-address *atm-address-template*

no lane server-atm-address [*atm-address-template*]

Syntax Description

<i>atm-address-template</i>	ATM address or a template in which wildcard characters are replaced by any nibble or group of nibbles of the prefix bytes, the end-system identifier (ESI) bytes, or the selector byte of the automatically assigned ATM address.
-----------------------------	---

Defaults

For the LANE server, the default is automatic address assignment; the LANE client finds the LANE server by consulting the configuration server.

Command Modes

Interface configuration

Command History

Release	Modification
11.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command also instructs the LANE client configured on this subinterface to reach the LANE server by using the specified ATM address instead of the ATM address provided by the configuration server.

When used on a selected subinterface, but with a different ATM address than was used previously, this command replaces the ATM address of the LANE server.

ATM Addresses

A LANE ATM address has the same syntax as an network service access point (NSAP) (but it is not a network-level address). It consists of the following:

- A 13-byte prefix that includes the following fields defined by the ATM Forum:
 - AFI (Authority and Format Identifier) field (1 byte)
 - DCC (Data Country Code) or ICD (International Code Designator) field (2 bytes)
 - DFI field (Domain Specific Part Format Identifier) (1 byte)

- Administrative Authority field (3 bytes)
- Reserved field (2 bytes)
- Routing Domain field (2 bytes)
- Area field (2 bytes)
- A 6-byte ESI
- A 1-byte selector field

Address Templates

LANE ATM address templates can use two types of wildcards: an asterisk (*) to match any single character (nibble), and an ellipsis (...) to match any number of leading, middle, or trailing characters. The values of the characters replaced by wildcards come from the automatically assigned ATM address.

In LANE, a *prefix template* explicitly matches the prefix, but uses wildcards for the ESI and selector fields. An *ESI template* explicitly matches the ESI field, but uses wildcards for the prefix and selector.

In the Cisco implementation of LANE, the prefix corresponds to the switch, the ESI corresponds to the ATM interface, and the selector field corresponds to the specific subinterface of the interface.

For a discussion of the Cisco method of automatically assigning ATM addresses, refer to the “Configuring LAN Emulation” chapter of the *Cisco IOS Switching Services Configuration Guide*.

Examples

The following example shows how to use an ESI template to specify the part of the ATM address corresponding to the interface; the remaining parts of the ATM address come from automatic assignment:

```
Router(config-if)# lane server-atm-address ...0800.200C.1001.**
```

The following example shows how to use a prefix template to specify the part of the ATM address corresponding to the switch; the remaining part of the ATM address come from automatic assignment:

```
Router(config-if)# lane server-atm-address 45.000014155551212f.00.00...
```

Related Commands

Command	Description
lane server-bus	Enables a LANE server and a BUS on the specified subinterface with the ELAN ID.

lane server-bus

To enable a LAN emulation (LANE) server and a broadcast and unknown server (BUS) on the specified subinterface with the emulated LAN (ELAN) ID, use the **lane server-bus** command in interface configuration mode. To disable a LANE server and BUS on the specified subinterface, use the **no** form of this command.

lane server-bus {**ethernet**} *elan-name* [**elan-id** *id*]

no lane server-bus {**ethernet**} *elan-name* [**elan-id** *id*]

Syntax Description

ethernet	Identifies the ELAN attached to this subinterface as an Ethernet ELAN.
<i>elan-name</i>	Name of the ELAN. The maximum length of the name is 32 characters.
elan-id	(Optional) Identifies the ELAN.
<i>id</i>	(Optional) Specifies the ELAN ID of the LAN emulation client (LEC).

Command Default

No LAN type or ELAN name is provided.

Command Modes

Interface configuration

Command History

Release	Modification
11.0	This command was introduced.
12.0	This command was modified to support the elan-id keyword.
12.3(2)T	The tokenring keyword was removed from this command.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

The LANE server and the BUS are located on the same router.

If a **lane server-bus** command has already been used on the subinterface for a different ELAN, the server initiates termination procedures with all clients and comes up as the server for the new ELAN.

To participate in MPOA, a LEC must have an ELAN ID. This command enables the LEC to get the ELAN ID from the LES when the LEC bypasses the LECS phase.



Caution

If an ELAN ID is supplied, make sure that it corresponds to the same ELAN ID value specified in the LECS for the same ELAN.

The LEC can also obtain the ELAN ID from the LECS by using the **name elan-id** command.

Examples

The following example shows how to enable a LANE server and BUS for an Ethernet ELAN named MYELAN:

```
Router(config-if)# lane server-bus ethernet myelan
```

Related Commands

Command	Description
lane server-atm-address	Specifies an ATM address and thus overrides the automatic ATM address assignment for the LANE server on a specified subinterface.
name elan-id	Configures the ELAN ID of an ELAN in the LECS database to participate in MPOA.

logging event atm pvc state

To enable notification of ATM permanent virtual circuit (PVC) state changes, use the **logging event atm pvc state** command in interface configuration mode. To disable notification, use the **no** form of this command.

logging event atm pvc state

no logging event atm pvc state

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Interface configuration (config-if)
----------------------	-------------------------------------

Command History	Release	Modification
	12.3	This command was introduced.

Usage Guidelines	For monitoring purposes, this command can be used to log the state changes for all PVCs associated with an ATM interface.
-------------------------	---

Examples	The following example shows how to enable notification of ATM PVC state changes:
-----------------	--

```
Router(config-if)# logging event atm pvc state
```

Related Commands	Command	Description
	debug atm state	Displays messages about ATM PVC state changes.

loopback

To loop packets back to the interface for testing, use the **loopback** interface configuration command with or without an optional keyword. To remove the loopback, use the **no** form of this command.

Cisco 2600 and 3600 Series

loopback [**line** | **local** | **payload** | **remote**]

no loopback [**line** | **local** | **payload** | **remote**]

Cisco 7100, 7200, and 7500 Series

For T1 lines:

loopback {**diagnostic** | **local** {**payload** | **line**} | **remote** {**iboc** | **esf** {**payload** | **line**}}}

For E1 lines:

loopback {**diagnostic** | **local** {**payload** | **line**} }

no loopback

Syntax Description

line	(Optional) Places the interface into external loopback mode at the line.
local	(Optional) Places the interface into local loopback mode.
payload	(Optional) Places the interface into external loopback mode at the payload level.
remote	(Optional) Keeps the local end of the connection in remote loopback mode.
diagnostic	(Optional) Loops the outgoing transmit signal back to the receive signal.
iboc	(Optional) Sends an in-band code to the far-end receiver to cause it to go into line loopback.
esf	(Optional) Specifies the FDL loopbacks. FDL should be configured on the link.

Defaults

The interface is placed into external loopback mode at the line, and loopback is disabled.

Command Modes

Interface configuration

Command History

Release	Modification
10.0	This command was introduced.
11.3 MA	This command was modified for the Cisco MC3810.
12.0(5)XK	Support for the Cisco 2600 and 3600 series routers was added.
12.0(5)T	Support for the Cisco 2600 and 3600 series routers was integrated into Cisco IOS Release 12.0(5)T.
12.0(5)XE	Support for the Cisco 720 0 and 7500 series routers was added.
12.0(7)XE1	Support for the Cisco 7100 series routers was added.

Release	Modification
12.1(5)T	Support for Cisco 7100, 7200, and 7500 series routers was integrated into Cisco IOS Release 12.1(5)T.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

You can use a loopback test on lines to detect and distinguish equipment malfunctions caused either by line and channel service unit/digital service unit (CSU/DSU) or by the interface. If correct data transmission is not possible when an interface is in loopback mode, the interface is the source of the problem.

The local loopback does not generate any packets automatically. Instead, the **ping** command is used.

Examples

The following example sets up local loopback diagnostics:

```
interface atm 1/0
 loopback local
```

loopback (ATM)

To configure the ATM interface into loopback mode, use the **loopback** interface configuration command. To remove the loopback, use the **no** form of this command.

loopback [cell | line | payload]

no loopback [cell | line | payload]

Syntax Description	cell	(Optional) Places the interface into external loopback at cell level.
	line	(Optional) Places the interface into external loopback at the line.
	payload	(Optional) Places the interface into external loopback at the payload level.

Defaults	The interface is placed into external loopback at the line.
-----------------	---

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	11.0	This command was introduced.
	11.1	The following keywords were removed: • diagnostic • test
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	This command is useful for testing because it loops all packets from the ATM interface back to the interface as well as directing the packets to the network. Use the loopback line command to check that the PA-A3 port adapter is working by looping the receive data back to the transmit data.
-------------------------	---

Examples	The following example loops all packets back to the ATM interface: <pre>interface atm 4/0 loopback</pre>
-----------------	--

Related Commands	Command	Description
	ces dsx1 loopback	Enables a loopback for the CBR interface.

mac-address (ATM)

To configure the MAC address on ATM permanent virtual circuits (PVCs) in a broadband access (BBA) group to use a different MAC address for PPP over Ethernet over ATM (PPPoEoA), use the **mac-address** command in BBA group configuration mode. To remove a MAC address, use the **no** form of this command.

mac-address { **autoselect** | *mac-address* }

no mac-address { **autoselect** | *mac-address* }

Syntax Description	autoselect	Automatically selects the MAC address based on the ATM interface.
	<i>mac-address</i>	MAC address (MAC value) to be used on ATM interfaces, entered as a series of three hexadecimal numbers presented in dotted notation. Example: 0100.CCCC.CCCD.

Command Default The use of MAC addresses will not change unless this command is configured.

Command Modes BBA group configuration

Command History	Release	Modification
	12.3(11)T	This command was introduced.
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines Use of this command changes the MAC address, but otherwise does not change the way PPPoE works. Use the **mac-address** command to configure the MAC address on ATM PVCs in a BBA group so there will be a different MAC address for PPPoEoA.

If a PPP over Ethernet (PPPoE) profile is not specified with the group option, PPPoE sessions will be established using values from the global PPPoE profile. PPPoE profiles must be configured using the **bba-group pppoe** command.

Examples

The following example configures the MAC address on an ATM PVC in a BBA group using values from the global PPPoE profile by specifying the MAC address:

```
Router(config)# bba-group pppoe global  
Router(config-bba-group)# virtual-template 1  
Router(config-bba-group)# mac-address 1.1.3
```

The following example uses the autoselect option to configure the MAC address automatically on an ATM PVC in a BBA group using a group profile:

```
Router(config)# bba-group pppoe vpn1  
Router(config-bba-group)# virtual-template 1  
Router(config-bba-group)# mac-address autoselect
```

Related Commands

Command	Description
bba-group pppoe	Creates a PPPoE profile on the BBA group.
protocol pppoe	Establishes PPPoE sessions on PVCs.

map-class atm

This command is no longer supported.

mid

To set the range of message identifier (MID) values on a permanent virtual circuit (PVC), use the **mid** interface-ATM-VC configuration command. To remove MID value range settings, use the **no** form of this command.

mid *midlow midhigh*

no mid *midlow midhigh*

Syntax Description

<i>midlow</i>	Starting MID number for this PVC. This can be set between 0 and 1023.
<i>midhigh</i>	Ending MID number for this PVC. This can be set between 0 and 1023.

Defaults

0

Command Modes

Interface-ATM-VC configuration

Command History

Release	Modification
11.3(2)T	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command is only available when SMDS encapsulation is configured on a PVC.
Use this command to assign different ranges of message identifiers to different PVCs.

Examples

In the following example, the **atm mid-per-vc** command limits the maximum number of message identifiers to 32 for each VC on the ATM interface. Using the **mid** command, the selected range of numbers that are available for the message identifiers on PVC 1/40 is 0 to 31. For PVC 2/50, the range is 32 to 63.

```
interface atm 2/0
 atm mid-per-vc 32
 pvc 1/40 smds
 mid 0 31
 pvc 2/50 smds
 mid 32 63
```

mpoa client config name

To define a Multiprotocol over ATM (MPOA) client (MPC) with a specified name, use the **mpoa client config name** command in global configuration mode. To delete the MPC, use the **no** form of this command.

mpoa client config name *mpc-name*

no mpoa client config name *mpc-name*

Syntax Description

<i>mpc-name</i>	Specifies the name of an MPC.
-----------------	-------------------------------

Command Default

No MPC is defined.

Command Modes

Global configuration

Command History

Release	Modification
11.3(3a)WA4(5)	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

When you configure or create an MPC, you automatically enter the MPC configuration mode. From here, you can enter subcommands to define or change MPC variables specific only to this MPC. Note that the MPC is not functional until it is attached to a hardware interface.

Examples

The following example shows how to create or modify the MPC named ip_mpc:

```
Router(config)# mpoa client config name ip_mpc
```

Related Commands

Command	Description
atm-address	Overrides the control ATM address of an MPC or MPS.
shortcut-frame-count	Specifies the maximum number of times a packet can be routed to the default router within shortcut-frame time before an MPOA resolution request is sent.
shortcut-frame-time	Sets the shortcut-setup frame time (in seconds) for the MPC.

mpoa client name

To attach a Multiprotocol over ATM (MPOA) client (MPC) to a major ATM interface, use the **mpoa client name** command in interface configuration mode. To break the attachment, use the **no** form of this command.

mpoa client name *mpc-name*

no mpoa client name *mpc-name*

Syntax Description

<i>mpc-name</i>	Specifies the name of an MPC.
-----------------	-------------------------------

Command Default

No MPC is attached to an ATM interface.

Command Modes

Interface configuration

Command History

Release	Modification
11.3(3a)WA4(5)	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

The **mpoa client name** command provides an interface to the MPC through which the MPC can set up and receive calls.

When you enter this command on a major interface that is up and operational, the named MPC becomes operational. Once the MPC is fully operational, it can register its ATM address.

Examples

The following example shows how to attach the MPC named ip_mpc to an interface:

```
Router(config)# interface atm 1/0  
Router(config-if)# mpoa client name ip_mpc
```

mpoa server config name

To define a Multiprotocol over ATM (MPOA) server (MPS) with the specified name, use the **mpoa server config name** command in global configuration mode. To delete an MPS, use the **no** form of this command.

mpoa server config name *mps-name*

no mpoa server config name *mps-name*

Syntax Description

<i>mps-name</i>	Name of the MPOA server.
-----------------	--------------------------

Command Default

No MPS is defined.

Command Modes

Global configuration

Command History

Release	Modification
11.3(3a)WA4(5)	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command defines an MPS with the specified name. The MPS does not actually start functioning until it is attached to a specific hardware interface. Once that attachment is complete, the MPS starts functioning. When you configure or create an MPS, you automatically enter the MPS configuration mode.

You can define the MPS variables specific to an MPS only after that MPS has been defined with a specified name. After this command is entered, further commands can be used to change MPS variables that are specific only to this MPS.

Examples

The following example shows how to define the MPS named MYMPS:

```
Router(config)# mpoa server config name MYMPS
```

mpoa server name

To attach a Multiprotocol over ATM (MPOA) server (MPS) to a major ATM interface, use the **mpoa server name** command in interface configuration mode. To break the attachment, use the **no** form of this command.

mpoa server name *mps-name*

no mpoa server name *mps-name*

Syntax Description

<i>mps-name</i>	Name of the MPOA server.
-----------------	--------------------------

Command Default

No MPS is attached to an ATM interface.

Command Modes

Interface configuration

Command History

Release	Modification
11.3(3a)WA4(5)	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command attaches an MPS to a specific (major) interface. At this point, the MPS can obtain its autogenerated ATM address and an interface through which it can communicate to the neighboring MPOA devices. Only when an MPS is both defined globally and attached to an interface is it considered to be operational. Although multiple different servers may share the same hardware interface, an MPS can be attached to only a single interface at any one time. The specified MPS must already be defined when this command is entered.

Examples

The following example attaches the MPS named MYMPS to an ATM interface:

```
Router(config)# interface atm 1/0  
Router(config-if)# mpoa server name MYMPS
```

mpoa server name trigger ip-address

To originate a Multiprotocol over ATM (MPOA) trigger for the specified IP address to the specified MPOA client from the specified Multiprotocol over ATM server (MPS), use the **mpoa server name trigger ip-address** command in interface configuration mode.

mpoa server name *mps-name* **trigger ip-address** *ip-address* [**mpc-address** *mpc-address*]

Syntax Description

<i>mps-name</i>	Specifies the name of the MPOA server.
<i>ip-address</i>	Specifies the IP address.
mpc-address <i>mpc-address</i>	(Optional) Specifies the MPOA client (MPC) address to which the trigger should be sent. If the address is not specified, a trigger will be sent to all clients.

Command Modes

Interface configuration

Command History

Release	Modification
11.3(3a)WA4(5)	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command sends an MPOA trigger for the specified IP address to the specified MPOA client from the specified MPOA server. If an MPOA client is not specified, it is triggered to all MPOA clients.

Examples

The following example shows how to send an MPOA trigger for the specified IP address 128.9.0.7 to all known MPOA clients from the MPOA server named MYMPS:

```
Router(config)# interface atm 1/0
Router(config-if)# mpoa server name MYMPS trigger ip-address 128.9.0.7
```

multiqueue

To enable two queues to prioritize multiple classes of packet streams over the same PVC, use the **multiqueue** command in PVC- or VC-class configuration mode. To return to a single-queue approach, use the **no** form of this command.

multiqueue

no multiqueue

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	Only a single queue per PVC is enabled.
------------------------	---

Command Modes	PVC-class configuration VC-class configuration
----------------------	---

Command History	Release	Modification
	12.4(2)XA	This command was introduced.
	12.4(6)T	This command was integrated into Cisco IOS Release 12.4(6)T.

Usage Guidelines	This command enables a priority queue and a regular (nonpriority) queue for traffic streams. When the multiqueue command is enabled and multiple classes of packet streams exist over the same PVC, packets coming from the streams that have priority values configured in a policy map are sent to the high-priority queue. Packets from all other streams are sent to the low-priority queue.
-------------------------	--

This command applies only to DSL ATM interfaces. Multiqueueing is intended for configuring DSL lines and allows configuring one data flow in a priority queue. If you have configured more than one flow in a priority queue, the latency for delay-sensitive traffic flow might not be guaranteed.

Multiqueueing does not work well with applications such as Multilink PPP (MLP) with interleave and Crypto. This is because MLP uses the same sequence numbering scheme for interleaved packets as multiqueueing. For example, if there are a voice packet and two data packets interleaved, the MLP sequence numbers for these packets could be 1 for the first data packet, 2 for the voice packet, and 3 for a second data packet. With multiqueueing, the voice packet with MLP sequence number 2 goes out before the data packet with MLP sequence number 1. This causes out-of-order sequencing of packets as far as MLP is concerned and causes unexpected behavior. The same problems apply to the Crypto application.

Multiqueueing is disabled by default, so that when MLP and the Crypto applications are used with DSL, the network is disrupted by upgrading to an image with multiqueueing support.

Examples

The following example shows how to enter the command from PVC configuration mode:

```
Router(config-if-atm-vc)# multiqueue
```

The following example shows how to enter the command from VC-class configuration mode:

```
Router(config)# vc-class atm x  
Router(config-vc-class)# multiqueue
```

The following example shows how to return the queues to the default state:

```
Router(config-if-atm-vc)# no multiqueue
```

Related Commands

Command	Description
tx-ring-limit	Limits the number of packets that can be used on a transmission ring on the DSL WIC or interface.

name elan-id

To configure the emulated LAN (ELAN) ID of an ELAN in the LAN Emulation Configuration Server (LECS) database to participate in Multiprotocol over ATM (MPOA), use the **name elan-id** command in LANE database configuration mode. To disable the ELAN ID of an ELAN in the LECS database to participate in MPOA, use the **no** form of this command.

name *name* **elan-id** *id*

no name *name* **elan-id** *id*

Syntax Description

<i>name</i>	Specifies the name of the ELAN.
<i>id</i>	Specifies the identification number of the ELAN.

Command Default

No ELAN ID is configured.

Command Modes

LANE database configuration

Command History

Release	Modification
12.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

To participate in MPOA, a LAN Emulation Client (LEC) must have an ELAN ID. The LEC obtains the ELAN ID from the LECS. In case the LEC bypasses the LECS phase, the LEC can get the ELAN ID from the LES when the **name elan-id** command is used.

Examples

The following example shows how to set the ELAN ID to 10 for an ELAN named MYELAN:

```
Router(lane-config-dat)# name MYELAN elan-id 10
```

Related Commands

Command	Description
lane server-bus	Enables a LANE server and a broadcast and unknown server on the specified subinterface with the ELAN ID.

name local-seg-id

To specify or replace the ring number of the emulated LAN (ELAN) in the configuration server's configuration database, use the **name local-seg-id** command in database configuration mode. To remove the ring number from the database, use the **no** form of this command.

name *elan-name* **local-seg-id** *segment-number*

no name *elan-name* **local-seg-id** *segment-number*

Syntax Description

<i>elan-name</i>	Name of the ELAN. The maximum length of the name is 32 characters.
<i>segment-number</i>	Segment number to be assigned to the ELAN. The number ranges from 1 to 4095.

Command Default

No ELAN name or segment number is provided.

Command Modes

LANE database configuration

Command History

Release	Modification
11.3	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command is ordinarily used for Token Ring LANE.

The same LANE ring number cannot be assigned to more than one ELAN.

The **no** form of this command deletes the relationships.

Examples

The following example shows how to specify a ring number of 1024 for the ELAN named red:

```
Router(lane-config-dat)# name red local-seg-id 1024
```

Related Commands

Command	Description
default-name	Provides an ELAN name in the database of the configuration server for those client MAC addresses and client ATM addresses that do not have explicit ELAN name bindings.
lane database	Creates a named configuration database that can be associated with a configuration server.
mac-address	Sets the MAC-layer address of the Cisco Token Ring.

name preempt

To set the emulated LAN (ELAN) preempt, use the **name preempt** command in LANE database configuration mode. To disable preemption, use the **no** form of this command.

name *elan-name* **preempt**

no name *elan-name* **preempt**

Syntax Description

<i>elan-name</i>	Specifies the name of the ELAN.
------------------	---------------------------------

Command Default

Preemption is disabled.

Command Modes

LANE database configuration

Command History

Release	Modification
11.3	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Prior to Cisco IOS Release 11.3, when the primary LAN Emulation Server (LES) failed, the Cisco Simple Server Redundancy Protocol (SSRP) switched over to a secondary LES. But when a LES that is ranked higher in the list came back up, the SSRP protocol switched the active LES to the new LES, which had a higher priority. This forced the network to flap multiple times. We have prevented the network flapping by staying with the currently active master LES regardless of the priority. If a higher priority LES comes back online, SSRP will not switch to that LES.

LES preemption is off by default. The first LES that comes on becomes the master. Users can revert to the old behavior (of switching to the higher-priority LES all the time) by specifying the **name elan-name preempt** command in the LECS database.

Examples

The following example shows how to set the ELAN preempt for the ELAN named MYELAN:

```
Router(lane-config-dat)# name MYELAN preempt
```

name server-atm-address

To specify or replace the ATM address of the LAN Emulation (LANE) server for the emulated LAN (ELAN) in the configuration server's configuration database, use the **name server-atm-address** command in database configuration mode. To remove it from the database, use the **no** form of this command.

name *elan-name* **server-atm-address** *atm-address* [**restricted** | **un-restricted**] [*index number*]

no name *elan-name* **server-atm-address** *atm-address* [**restricted** | **un-restricted**] [*index number*]

Syntax Description	<i>elan-name</i>	Name of the ELAN. Maximum length is 32 characters.
	<i>atm-address</i>	LANE server's ATM address.
	restricted un-restricted	(Optional) Membership in the named ELAN is restricted to the LANE clients explicitly defined to the ELAN in the configuration server's database.
	<i>index number</i>	(Optional) Priority number. When specifying multiple LANE servers for fault tolerance, you can specify a priority for each server. 0 is the highest priority.

Defaults No emulated LAN name or server ATM address is provided.

Command Modes Database configuration

Command History	Release	Modification
	11.0	This command was introduced.
	11.2	The following keywords were added: • un-restricted • index
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines ELAN names must be unique within one named LANE configuration database.

Specifying an existing ELAN name with a new LANE server ATM address adds the LANE server ATM address for that ELAN for redundant server operation or simple LANE service replication. This command can be used multiple times.

The **no** form of this command deletes the relationships.

Examples

The following example shows how to configure the example3 database with two restricted and one unrestricted ELANs. The clients that can be assigned to the eng and mkt ELANs are specified using the **client-atm-address** commands. All other clients are assigned to the man ELAN.

```
Router(config)# lane database example3
Router(lane-config-dat)# name eng server-atm-address
39.000001415555121101020304.0800.200c.1001.02 restricted
Router(lane-config-dat)# name man server-atm-address
39.000001415555121101020304.0800.200c.1001.01
Router(lane-config-dat)# name mkt server-atm-address
39.000001415555121101020304.0800.200c.4001.01 restricted
Router(lane-config-dat)# client-atm-address 39.000001415555121101020304.0800.200c.1000.02
name eng
Router(lane-config-dat)# client-atm-address 39.0000001415555121101020304.0800.200c.2000.02
name eng
Router(lane-config-dat)# client-atm-address 39.000001415555121101020304.0800.200c.3000.02
name mkt
Router(lane-config-dat)# client-atm-address 39.000001415555121101020304.0800.200c.4000.01
name mkt
Router(lane-config-dat)# default-name man
Router(lane-config-dat)# exit
```

Related Commands

Command	Description
client-atm-address name	Adds a LANE client address entry to the configuration database of the configuration server.
default-name	Provides an ELAN name in the database of the configuration server for those client MAC addresses and client ATM addresses that do not have explicit ELAN name bindings.
lane database	Creates a named configuration database that can be associated with a configuration server.
mac-address	Sets the MAC-layer address of the Cisco Token Ring.

network-clock-select (ATM)

To establish the sources and priorities of the requisite clocking signals for an ATM-CES port adapter, use the **network-clock-select** command in global configuration mode. To remove the clock source, use the **no** form of this command.

network-clock-select *priority* { **cbr** | **atm** } *slot/port*

no network-clock-select *priority* { **cbr** | **atm** } *slot/port*

Syntax Description

<i>priority</i>	Priority of the clock source. Values are 1 (high priority) to 4 (low priority).
cbr	Specifies a CBR interface to supply the clock source.
atm	Specifies an ATM interface to supply the clock source.
<i>slot</i>	Backplane slot number.
<i>port</i>	Interface port number.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
11.1	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

To support synchronous or synchronous residual time stamp (SRTS) clocking modes on the CBR interface, you must specify a primary reference source to synchronize the flow of CBR data from its source to its destination.

You can specify up to four clock priorities. The highest priority active interface in the router supplies primary reference source to all other interfaces that require network clock synchronization services. The fifth priority is the local oscillator on the ATM-CES port adapter.

Use the **show network-clocks** command to display currently configured clock priorities on the router.

Examples

The following example defines two clock priorities on the router:

```
network-clock-select 1 cbr 2/0
network-clock-select 2 atm 2/0
```

Related Commands

Command	Description
ces aal1 clock	Configures the AAL1 timing recovery clock for the CBR interface.
ces dsx1 clock source	Configures a transmit clock source for the CBR interface.
show network-clocks	Displays which ports are designated as network clock sources.

network-id

To specify the network ID of a Multiprotocol over ATM (MPOA) server (MPS), use the **network-id** command in MPS configuration mode. To revert to the default value (default value is 1), use the **no** form of this command.

network-id *id*

no network-id

Syntax Description	<i>id</i> Specifies the network ID of the MPOA server.
---------------------------	--

Defaults	The default value for the network ID is 1.
-----------------	--

Command Modes	MPS configuration
----------------------	-------------------

Command History	Release	Modification
	11.3(3a)WA4(5)	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	Specifies the network ID of this MPS. This value is used in a very similar way the NHRP network ID is used. It is for partitioning nonbroadcast multiaccess (NBMA) clouds artificially by administration.
-------------------------	---

Examples	The following example shows how to set the network ID to 5:
-----------------	---

```
Router(mpoa-server-config)# network-id 5
```

oam-ac segment endpoint

To enable Operation, Administration, and Maintenance (OAM) segment cell termination on ATM adaptation layer 5 (AAL5) over Multiprotocol Label Switching (MPLS) or Layer 2 Tunnel Protocol Version 3 (L2TPv3), use the **oam-ac segment endpoint** command in L2transport VC configuration mode or VC-class configuration mode. To disable OAM segment cell termination, use the no form of this command.

oam-ac segment endpoint

no oam-ac segment endpoint

Syntax Description

This command has no arguments or keywords.

Command Default

OAM segment cell termination is disabled.

Command Modes

L2transport VC configuration mode—for an ATM PVC (cfg-if-atm-l2trans-pvc)
VC-class configuration mode—for a VC class (config-vc-class)

Command History

Release	Modification
12.0(30)S	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.

Examples

The following examples show how to configure the **oam-ac segment endpoint** command in the L2transport VC configuration mode and VC-class configuration mode:

VC Layer 2 Transport

```
Router(config)# interface atm1/1
Router(config-if)# pvc 0/100 l2transport
Router(cfg-if-atm-l2trans-pvc)# oam-ac segment endpoint
Router(cfg-if-atm-l2trans-pvc)# end
```

VC-Class Configuration

```
Router(config)# vc-class atm test
Router(config-vc-class)# oam-ac segment endpoint
Router(config-vc-class)# end
```

Related Commands

Command	Description
oam-ac emulation-enable	Enables OAM cell emulation on ATM adaptation layer 5 (AAL5) over Multiprotocol Label Switching (MPLS) or Layer 2 Tunnel Protocol Version 3 (L2TPv3).

oam ais-rdi

To configure an ATM permanent virtual circuit (PVC) to be brought down after a specified number of Operation, Administration, and Maintenance (OAM) alarm indication signal/remote defect indication (AIS/RDI) cells have been received on the PVC or brought up if no OAM AIS/RDI cells have been received in a specified interval, use the **oam ais-rdi** command in ATM VC configuration mode or VC class configuration mode. To return OAM AIS/RDI behavior to the default, use the **no** form of this command.

oam ais-rdi [*down-count* [*up-count*]]

no oam ais-rdi [*down-count* [*up-count*]]

Syntax Description	<i>down-count</i>	(Optional) Number of consecutive OAM AIS/RDI cells received before the PVC is brought down. The range is from 1 to 60.
	<i>up-count</i>	(Optional) Number of seconds after which a PVC will be brought up if no OAM AIS/RDI cells are received. The range is from 3 to 60.

Command Default	The down count is set to 1 and the up count is set to 3.
------------------------	--

Command Modes	ATM VC configuration (config-if-atm-vc) VC class configuration (config-vc-class)
----------------------	---

Command History	Release	Modification
	12.1(2)T	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	The default values for the OAM AIS/RDI down count and up count are used in the following situations: • If the oam ais-rdi command has not been entered • If the oam ais-rdi command is entered without the <i>up-count</i> or <i>down-count</i> argument • If the no oam ais-rdi command is entered If the oam ais-rdi command is entered without the <i>up-count</i> or <i>down-count</i> argument, the command will not appear in the show running-config command output.
-------------------------	--

Examples

In the following example, PVC 0/400 will be brought down after 25 consecutive OAM AIS/RDI cells have been received on the PVC. The PVC will be brought up when no OAM AIS/RDI cells have been received for 5 seconds.

```
Router> enable
Router# configure terminal
Router(config)# interface ATM2/0/0
Router(config-if)# pvc 0/400
Router(config-if-atm-vc)# oam ais-rdi 25 5
```

Related Commands

Command	Description
pvc	Creates or assigns a name to an ATM PVC and specifies the encapsulation type on an ATM PVC.
snmp-server enable traps atm pvc extension	Enables the sending of extended ATM PVC SNMP notifications and SNMP notifications for ATM OAM F5 CC, ATM OAM F5 AIS/RDI, and loopback failures.

oam retry

To configure parameters related to Operation, Administration, and Maintenance (OAM) management for an ATM permanent virtual circuit (PVC), switched virtual circuit (SVC), VC class, or VC bundle, or label-controlled ATM (LC-ATM) VC, use the **oam retry** command in the appropriate command mode. To remove OAM management parameters, use the **no** form of this command.

oam retry *up-count down-count retry-frequency*

no oam retry

Syntax Description	<i>up-count</i>	Number of consecutive end-to-end F5 OAM loopback cell responses that must be received in order to change a connection state to up. This argument does not apply to SVCs.
	<i>down-count</i>	Number of consecutive end-to-end F5 OAM loopback cell responses that are not received in order to change the state to down or tear down an SVC connection.
	<i>retry-frequency</i>	The frequency (in seconds) at which end-to-end F5 OAM loopback cells are transmitted when a change in the up/down state is being verified. For example, if a PVC is up and a loopback cell response is not received after the <i>retry-frequency</i> (in seconds) argument is specified using the oam-pvc command, loopback cells are sent at the <i>retry-frequency</i> to verify whether the PVC is down.

Defaults

ATM PVCs and SVCs

up-count: 3
down-count: 5
retry-frequency: 1 second

LC-ATM VCs

up-count: 2
down-count: 2
retry-frequency: 2 seconds

Command Modes

Bundle configuration mode (for a VC bundle)
Control-VC configuration (for an LC-ATM VC)
Interface-ATM-VC configuration (for an ATM PVC or SVC)
PVC range configuration (for an ATM PVC range)
PVC-in-range configuration (for an individual PVC within a PVC range)
VC-class configuration (for a VC class)

Command History

Release	Modification
11.3T	This command was introduced.
12.0(3)T	This command was modified to allow configuration parameters related to OAM management for ATM VC bundles.

Release	Modification
12.1(5)T	This command was implemented in PVC range and PVC-in-range configuration modes.
12.3(2)T	This command was implemented in control-VC configuration mode.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

The following guidelines apply to PVCs, SVCs, and VC classes. They do not apply to LC-ATM VCs.

- For ATM PVCs, SVCs, or VC bundles, if the **oam retry** command is not explicitly configured, the VC inherits the following default configuration (listed in order of precedence):
 - Configuration of the **oam retry** command in a VC class assigned to the PVC or SVC itself.
 - Configuration of the **oam retry** command in a VC class assigned to the PVC's or SVC's ATM subinterface.
 - Configuration of the **oam retry** command in a VC class assigned to the PVC's or SVC's ATM main interface.
 - Global default: *up-count* = 3, *down-count* = 5, *retry-frequency* = 1 second. This set of defaults assumes that OAM management is enabled using the **oam-pvc** or **oam-svc** command. The *up-count* and *retry-frequency* arguments do not apply to SVCs.
- To use this command in bundle configuration mode, enter the bundle command to create the bundle or to specify an existing bundle before you enter this command.
- If you use the **oam retry** command to configure a VC bundle, you configure all VC members of that bundle. VCs in a VC bundle are further subject to the following inheritance rules (listed in order of precedence):
 - VC configuration in bundle-vc mode
 - Bundle configuration in bundle mode (with the effect of assigned VC-class configuration)
 - Subinterface configuration in subinterface mode

Examples

The following example shows how to configure the OAM management parameters with an up count of 3, a down-count of 3, and the retry frequency set at 10 seconds:

```
Router(cfg-mpls-atm-cvc) # oam retry 3 3 10
```

Related Commands	Command	Description
	broadcast	Configures broadcast packet duplication and transmission for an ATM VC class, PVC, SVC, or VC bundle.
	class-int	Assigns a VC class to an ATM main interface or subinterface.
	class-vc	Assigns a VC class to an ATM PVC, SVC, or VC bundle member.
	encapsulation	Sets the encapsulation method used by the interface.
	inarp	Configures the Inverse ARP time period for an ATM PVC, VC class, or VC bundle.
	oam-bundle	Enables end-to-end F5 OAM loopback cell generation and OAM management for a virtual circuit class that can be applied to a virtual circuit bundle.
	oam-pvc	Enables end-to-end F5 OAM loopback cell generation and OAM management for an ATM PVC or virtual circuit class.
	oam-svc	Enables end-to-end F5 OAM loopback cell generation and OAM management for an ATM SVC or virtual circuit class.
	protocol (ATM)	Configures a static map for an ATM PVC, SVC, VC class, or VC bundle. Enables Inverse ARP or Inverse ARP broadcasts on an ATM PVC by either configuring Inverse ARP directly on the PVC, on the VC bundle, or in a VC class (applies to IP and IPX protocols only).
	ubr	Configures UBR QoS and specifies the output peak cell rate for an ATM PVC, SVC, VC class, or VC bundle member.
	ubr+	Configures UBR QoS and specifies the output peak cell rate and output minimum guaranteed cell rate for an ATM PVC, SVC, VC class, or VC bundle member.
	vbr-nrt	Configures the VBR-NRT QoS and specifies output peak cell rate, output sustainable cell rate, and output maximum burst cell size for an ATM PVC, SVC, VC class, or VC bundle member.

oam retry cc

To set the frequency with which ATM Operation, Administration, and Maintenance (OAM) F5 continuity check (CC) activation and deactivation requests are sent to a device at the other end of a segment or permanent virtual circuit (PVC), use the **oam retry cc** command in ATM virtual circuit configuration mode. To remove the retry settings, use the **no** form of this command.

oam retry cc {*end* | *segment*} [*activation-count* [*deactivation-count* [*retry-frequency*]]]

no oam retry cc {*end* | *segment*} [*activation-count* [*deactivation-count* [*retry-frequency*]]]

Syntax Description

end	End-to-end continuity check.
segment	Segment continuity check.
<i>activation-count</i>	(Optional) Maximum number of times the activation request will be sent before the receipt of an acknowledgment. The range is from 3 to 600. The default is 3.
<i>deactivation-count</i>	(Optional) Maximum number of times the deactivation request will be sent before the receipt of an acknowledgment. The range is from 3 to 600. The default is 3.
<i>retry-frequency</i>	(Optional) Interval between retries, in seconds. The default is 30.

Command Default

F5 segment and end-to-end continuity check cells are disabled.

Command Modes

ATM virtual circuit configuration

Command History

Release	Modification
12.2(13)T	This command was introduced.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following example shows how to configure ATM OAM F5 CC support over the segment and configure the router to function as the source. The frequency with which CC activation and deactivation requests will be sent over the segment is also configured.

```
interface atm 0
 ip address 10.0.0.3 255.255.255.0
 pvc 0/40
  oam-pvc manage cc segment direction source
  oam retry cc segment 10 10 30
```


Related Commands	Command	Description
	oam-pvc manage cc deny	Configures ATM OAM F5 CC management.
	oam-pvc manage cc deny	Disables ATM OAM F5 CC support and configures the PVC to deny CC activation requests.

oam-bundle

To enable end-to-end F5 Operation, Administration, and Maintenance (OAM) loopback cell generation and OAM management for all virtual circuit (VC) members of a bundle or a VC class that can be applied to a VC bundle, use the **oam-bundle** command in SVC-bundle configuration mode or VC-class configuration mode. To remove OAM management from the bundle or class configuration, use the **no** form of this command.

To enable end-to-end F5 OAM loopback cell generation and OAM management for all VC members of a bundle, use the **oam-bundle** command in bundle configuration mode. To remove OAM management from the bundle, use the **no** form of this command.

oam-bundle [**manage**] [*frequency*]

no oam-bundle [**manage**] [*frequency*]

Syntax Description

manage	(Optional) Enables OAM management. If this keyword is omitted, loopback cells are sent, but the bundle is not managed.
<i>frequency</i>	(Optional) Number of seconds between transmitted OAM loopback cells. Values range from 0 to 600 seconds. The default value for the <i>frequency</i> argument is 10 seconds.

Command Default

End-to-end F5 OAM loopback cell generation and OAM management are disabled, but if OAM cells are received, they are looped back.

Command Modes

SVC-bundle configuration (for an SVC bundle)
 VC-class configuration (for a VC class)
 Bundle configuration (for an ATM VC bundle)

Command History

Release	Modification
12.0(3)T	This command was introduced.
12.0(26)S	This command was introduced on the Cisco 10000 series router.
12.2(16)BX	This command was implemented on the ESR-PRE2.
12.2(4)T	This command was made available in SVC-bundle configuration mode.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(31)SB	This command was integrated into Cisco IOS Release 12.2(31)SB.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command defines whether a VC bundle is OAM managed. If this command is configured for a bundle, every VC member of the bundle is OAM managed. If OAM management is enabled, further control of OAM management is configured using the **oam retry** command.

This command has no effect if the VC class that contains the command is attached to a standalone VC; that is, if the VC is not a bundle member. In this case, the attributes are ignored by the VC.

To use this command in VC-class configuration mode, first enter the **vc-class atm** global configuration command.

To use this command in bundle configuration mode, first enter the **bundle** subinterface configuration command to create the bundle or to specify an existing bundle.

VCs in a VC bundle are subject to the following configuration inheritance rules (listed in order of next-highest precedence):

- VC configuration in bundle-VC mode
- Bundle configuration in bundle mode (with the effect of assigned VC-class configuration)

Examples

The following example enables OAM management for a bundle called “bundle 1”:

```
bundle bundle1
 oam-bundle manage
```

Related Commands

Command	Description
broadcast	Configures broadcast packet duplication and transmission for an ATM VC class, PVC, SVC, or VC bundle.
bundle	Enters bundle configuration mode to create a bundle or modify an existing bundle.
class-bundle	Configures a VC bundle with the bundle-level commands contained in the specified VC class.
encapsulation	Sets the encapsulation method used by the interface.
inarp	Configures the Inverse ARP time period for an ATM PVC, VC class, or VC bundle.
oam retry	Configures parameters related to OAM management for an ATM PVC, SVC, VC class, or VC bundle.
protocol (ATM)	Configures a static map for an ATM PVC, SVC, VC class, or VC bundle, and enables Inverse ARP or Inverse ARP broadcasts on an ATM PVC by configuring Inverse ARP either directly on the PVC, on the VC bundle, or in a VC class (applies to IP and IPX protocols only).
vc-class atm	Creates a virtual circuit (VC) class for an ATM permanent virtual circuit (PVC), switched virtual circuit (SVC), or ATM interface.

oam-pvc

To enable end-to-end F5 Operation, Administration, and Maintenance (OAM) loopback cell generation and OAM management for an ATM permanent virtual circuit (PVC), virtual circuit (VC) class, or label-controlled ATM (LC-ATM) VC, use the **oam-pvc** command in the appropriate command mode. To disable generation of OAM loopback cells and OAM management, use the **no** form of this command.

ATM VC or VC Class

oam-pvc [**manage**] [*frequency*]

no oam-pvc [**manage**]

LC-ATM VC

oam-pvc manage [*frequency*]

no oam-pvc manage

Loopback Mode Detection

oam-pvc manage [*frequency*] **loop-detection**

no oam-pvc manage loop-detection

Cisco 10000 Series Router

oam-pvc manage [*frequency*] [**auto-detect** [**optimum**]] [**keep-vc-up** [**seg aisrdi failure**]]

no oam-pvc manage [*frequency*] [**auto-detect** [**optimum**]] [**keep-vc-up** [**seg aisrdi failure**]]

Syntax Description

manage	(Optional for ATM VCs or VC classes; required for LC-ATM VCs) Enables OAM management. The default is disabled.
<i>frequency</i>	(Optional) Specifies the time delay between transmitting OAM loopback cells, in seconds. For ATM VCs or VC classes and loopback mode detection, the range is from 0 to 600, and the default is 10. For LC-ATM VCs, the range is from 0 to 255, and the default is 5.
loop-detection	Enables automatic detection of whether the physically connected ATM switch is in loopback mode. The default is disabled.
auto-detect	(Optional) Enables auto-detection of peer OAM command cells.
optimum	(Optional) Configures an optimum mode so that when the traffic-monitoring timer expires, the PVC sends an OAM command cell at the locally configured frequency instead of going into Retry mode immediately. If there is no response, the PVC goes into Retry mode.
keep-vc-up	(Optional) Specifies that the VC will be kept in the UP state when continuity check (CC) cells detect connectivity failure.
seg aisrdi failure	(Optional) Specifies that if segment alarm indication signal/remote defect indication (AIS/RDI) cells are received, the VC will not be brought down because of end CC failure or loopback failure.

Command Default OAM management and loop detection are disabled.

Command Modes

- ATM VC class configuration (config-vc-class)
- ATM VC configuration (config-if-atm-vc)
- Control-VC configuration (cfg-mpls-atm-cvc)
- PVC-in-range configuration (cfg-if-atm-range-pvc)

Command History	Release	Modification
	11.3	This command was introduced.
	12.1(5)T	This command was implemented in PVC-in-range configuration mode.
	12.3(2)T	This command was implemented for LC-ATM VCs.
	12.0(30)S	This command was integrated into Cisco IOS Release 12.0(30)S, and the loop-detection keyword was added.
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
	12.2(31)SB10	The loop-detection keyword was added.
	Cisco IOS XE Release 2.3	This command was integrated into Cisco IOS XE Software Release 2.3 and implemented on the Cisco ASR 1000 series routers.

Usage Guidelines If OAM management is enabled, further control of OAM management is configured by using the **oam retry** command.

ATM VC or VC Classes

If the **oam-pvc** command is not explicitly configured on an ATM PVC, the PVC inherits the following default configuration (in order of precedence):

- Configuration from the **oam-pvc** command in a VC class assigned to the PVC itself.
- Configuration from the **oam-pvc** command in a VC class assigned to the ATM subinterface of the PVC.
- Configuration from the **oam-pvc** command in a VC class assigned to the ATM main interface of the PVC.
- Global default: End-to-end F5 OAM loopback cell generation and OAM management are disabled, but if OAM cells are received, they are looped back. The default value for the *frequency* argument is 10 seconds.

Specifying the ATM VC or VC Classes

You can select the VCs or VC classes to which to apply OAM management and loop detection by using the **oam-pvc** command in any of the following command modes:

- ATM VC class configuration—for a VC class
- ATM VC configuration mode—for an ATM PVC or loopback mode detection
- Control-VC configuration mode—for enabling OAM management on an LC-ATM VC

- PVC-in-range configuration—for an individual PVC within a PVC range

Loopback Mode Detection

When a PVC traverses an ATM cloud and OAM is enabled, the router sends a loopback cell to the other end and waits for a response to determine whether the circuit is up. However, if an intervening router within the ATM cloud is in loopback mode, the router considers the circuit to be up, when in fact the other end is not reachable.

When enabled, the Loopback Mode Detection Through OAM feature detects when an intervening router is in loopback mode, in which case it sets the OAM state to NOT_VERIFIED. This prevents traffic from being routed on the PVC for as long as any intervening router is detected as being in loopback mode.

Examples

The following example shows how to enable end-to-end F5 OAM loopback cell transmission and OAM management on an ATM PVC with a transmission frequency of 3 seconds:

```
Router(cfg-mpls-atm-cvc) # oam-pvc manage 3
```

The following example shows how to enable end-to-end F5 OAM loopback cell transmission and OAM management on an LC-ATM interface with a transmission frequency of 2 seconds:

```
Router(config)# interface Switch1.10 mpls
Router(config-subif)# ip unnumbered Loopback0
Router(config-subif)# mpls atm control-vc 0 32
Router(cfg-mpls-atm-cvc) # oam-pvc manage 2
```

The following example shows how to create a PVC and enable loopback detection:

```
Router(config)# interface ATM1/0
Router(config-if)# pvc 4/100
Router(config-if-atm-vc) # oam-pvc manage loop-detection
```

Related Commands

Command	Description
ilmi manage	Enables ILMI management on an ATM PVC.
oam retry	Configures parameters related to OAM management for an ATM PVC, SVC, VC class, or LC-ATM VC.
show atm pvc	Displays all ATM PVCs and traffic information.

oam-pvc manage cc

To configure ATM Operation, Administration, and Maintenance (OAM) F5 continuity check (CC) management, use the **oam-pvc manage cc** command in ATM virtual circuit configuration mode. To disable OAM F5 continuity checking, use the **no** form of this command.

```
oam-pvc manage cc {end | segment} [direction {both | sink | source}] [keep-vc-up [end aisrdi failure | seg aisrdi failure]]
```

```
no oam-pvc manage cc {end | segment} [deactivate-down-vc] [direction {both | sink | source}] [keep-vc-up [end aisrdi failure | seg aisrdi failure]]
```

Syntax Description

end	End-to-end continuity checking. Monitoring occurs on the entire VC between two ATM end stations.
segment	Segment continuity checking. Monitoring occurs on a VC segment between a router and a first-hop ATM switch.
direction	(Optional) Direction of CC cell transmission.
both	(Optional) Specifies that CC cells transmit toward and away from the activator.
sink	(Optional) Specifies that CC cells transmit toward the activator. This is the default direction.
source	(Optional) Specifies that CC cells transmit away from the activator.
keep-vc-up	(Optional) Specifies that VC will be kept in the UP state when CC cells detect connectivity failure.
end aisrdi failure	(Optional) Specifies that if end alarm indication signals/remote defect indications (AIS/RDI) cells are received, the VC will not be brought down because of segment CC failure.
seg aisrdi failure	(Optional) Specifies that if segment AIS/RDI cells are received, the VC will not be brought down because of end CC failure or loopback failure.
deactivate-down-vc	(Optional) Specifies that an OAM F5 CC deactivation message will be sent when the VC is operationally down and in the CC active state. This keyword is available only when the no form of this command is used.

Command Default

CC cells transmit toward the activator.

Command Modes

ATM virtual circuit configuration

Command History

Release	Modification
12.2(13)T	This command was introduced.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.

Release	Modification
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

ATM OAM F5 continuity checking enables OAM to support the use of F5 segment and end-to-end CC cells to detect connectivity failures.

It is not necessary to enter a CC configuration on the router at the other end of a segment. The router on which CC management has been configured sends a CC activation request to the router at the other end of the segment, directing it to act as either a source or a sink.

Use the **oam-pvc manage cc deny** command to configure a permanent virtual circuit (PVC) to respond to activation requests from a peer device with “activation denied” messages. The **oam-pvc manage cc deny** command prevents ATM OAM F5 CC management from being activated on the PVC.

Use the **no oam-pvc manage cc** command to send a deactivation request to the peer device. The **no oam-pvc manage cc** command will disable ATM OAM F5 CC management on the PVC until the PVC receives an activation request. When the PVC receives an activation request, ATM OAM F5 CC management will be reenabled.

The **no oam-pvc manage cc {end | segment} deactivate-down-vc** command does not disable ATM OAM F5 CC support. This command causes OAM F5 CC deactivation messages to be sent over the VC when the VC goes down.

To enable the SNMP notifications that support ATM OAM F5 continuity checking, use the **snmp-server enable traps atm pvc extension** command.

Examples

ATM OAM F5 CC Support on a PVC Configuration Example

The following example shows how to configure ATM OAM F5 CC support over the segment and configure the router to function as the source. The frequency at which CC activation and deactivation requests will be sent over the segment is also configured.

```
interface atm 0
 ip address 10.0.0.3 255.255.255.0
 pvc 0/40
  oam-pvc manage cc segment direction source
  oam retry cc segment 10 10 30
```

Deactivation of ATM OAM F5 CC upon VC Failure Example

The following example shows how to configure OAM to send a CC deactivation request across the segment when PVC 0/1 goes down:

```
interface atm 0
 ip address 10.0.0.3 255.255.255.0
 pvc 0/40
  no oam-pvc manage cc segment deactivate-down-vc
```


Related Commands

Command	Description
debug atm oam cc	Displays ATM OAM F5 CC management activity.
oam-pvc manage cc deny	Disables ATM OAM F5 CC support and configures the PVC to deny CC activation requests.
oam retry cc	Sets the frequency at which ATM OAM F5 CC activation and deactivation requests are sent to the device at the other end of a segment or PVC.
show atm pvc	Displays all ATM PVCs and traffic information.
vpn service	Enables the sending of extended ATM PVC SNMP notifications and SNMP notifications for ATM OAM F5 CC, ATM OAM F5 AIS/RDI, and loopback failures.
snmp-server enable traps atm pvc extension mibversion	Specifies the MIB that supports extended ATM PVC SNMP notifications or the MIB that supports SNMP notifications for ATM OAM F5 CC management, ATM OAM F5 AIS/RDI management, and F5 loopback failure management.

oam-pvc manage cc deny

To disable ATM Operation, Administration, and Maintenance (OAM) F5 continuity check (CC) support and configure a permanent virtual circuit (PVC) to deny CC activation requests, use the **oam-pvc manage cc deny** command in ATM virtual circuit configuration mode. To reen able OAM F5 CC support and allow CC activation requests, use the **no** form of this command.

oam-pvc manage cc {end | segment} deny

no oam-pvc manage cc {end | segment} deny

Syntax Description

end	End-to-end continuity checking.
segment	Segment continuity checking.

Command Default

If the peer device sends the activation message, F5 CC management will be enabled on the PVC.

Command Modes

ATM virtual circuit configuration

Command History

Release	Modification
12.2(13)T	This command was introduced.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Use the **oam-pvc manage cc deny** command to configure a permanent virtual circuit (PVC) to respond to activation requests from a peer device with “activation denied” messages. The **oam-pvc manage cc deny** command prevents ATM OAM F5 CC management from being activated on the PVC.

Use the **no oam-pvc manage cc** command to send a deactivation request to the peer device. The **no oam-pvc manage cc** command will disable ATM OAM F5 CC management on the PVC until the PVC receives an activation request. When the PVC receives an activation request, ATM OAM F5 CC management will be reenabled.

Examples

The following example shows how to disable ATM OAM F5 CC support and configure the VC to deny CC activation requests:

```
interface atm 0
 ip address 10.0.0.3 255.255.255.0
 pvc 0/40
  oam-pvc manage cc segment deny
```

Related Commands	Command	Description
	oam-pvc manage cc deny	Configures ATM OAM F5 CC management.
	oam retry cc	Sets the frequency at which ATM OAM F5 CC activation and deactivation requests are sent to the device at the other end of a segment or PVC.

oam queue

To configure the global ATM Operations, Administration, and Maintenance (OAM) queue, use the **oam queue** command in global configuration mode. To disable this configuration, use the **no** form of this command.

oam queue *queue-size*

no oam queue *queue-size*

Syntax Description

<i>queue-size</i>	Size of the OAM queue, in packets. The range of the queue size is from 40 to 32000.
-------------------	---

Command Default

The global ATM OAM queue is not configured.

Command Modes

Global configuration (config)

Command History

Release	Modification
15.0(1)M	This command was introduced in a release earlier than Cisco IOS Release 15.0(1)M.

Examples

The following example shows how to configure the global ATM OAM queue to a size of 100:

```
Router(config)# oam queue 100
```

Related Commands

Command	Description
show atm interface atm	Displays ATM-specific information about an ATM interface.

oam-range

To enable end-to-end F5 Operation, Administration, and Maintenance (OAM) loopback cell generation and OAM management for an ATM permanent virtual circuit (PVC) range, use the **oam-range** command in PVC range configuration mode. To disable generation of OAM loopback cells and OAM management, use the **no** form of this command.

oam-range [**manage**] [*frequency*]

no oam-range [**manage**] [*frequency*]

Syntax Description	manage	(Optional) Enables OAM management.
	<i>frequency</i>	(Optional) Time delay (0 to 600 seconds) between transmissions of OAM loopback cells.

Defaults	10 seconds
----------	------------

Command Modes	PVC range configuration
---------------	-------------------------

Command History	Release	Modification
	12.1(5)T	This command was introduced.
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	If OAM management is enabled, further control of OAM management is configured using the oam retry command.
------------------	---

If the **oam-range** command is not explicitly configured for an ATM PVC range, the range inherits the following default configuration (listed in order of precedence):

- Configuration of the **oam-range** command in a VC class assigned to the range.
- Configuration of the **oam-range** command in a VC class assigned to the ATM subinterface for the range.
- Configuration of the **oam-range** command in a VC class assigned to the ATM main interface for the range.
- Global default: End-to-end F5 OAM loopback cell generation and OAM management are disabled, but if OAM cells are received, they are looped back. The default value for the *frequency* argument is 10 seconds.

Examples

The following example enables end-to-end F5 OAM loopback cell transmission and OAM management on an ATM PVC range called “range1” with a transmission frequency of 11 seconds:

```
interface atm 6/0.1
 range range1 pvc 7/101 7/103
  oam-range manage 11
  oam retry 8 9 10
```

Related Commands

Command	Description
ilmi manage	Enables ILMI management on an ATM PVC.
oam-pvc	Enables end-to-end F5 OAM loopback cell generation and OAM management for an ATM PVC or VC class.
oam retry	Configures parameters related to OAM management for ATM PVC, SVC, or VC class.

oam-svc

To enable end-to-end F5 Operation, Administration, and Maintenance (OAM) loopback cell generation and OAM management for an ATM switched virtual circuit (SVC) or virtual circuit (VC) class, use the **oam-svc** command in the appropriate command mode. To disable generation of OAM loopback cells and OAM management, use the **no** form of this command.

oam-svc [**manage**] [*frequency*]

no oam-svc [**manage**] [*frequency*]

Syntax Description

manage	(Optional) Enable OAM management.
<i>frequency</i>	(Optional) Time delay (0 to 600 seconds) between transmitting OAM loopback cells.

Defaults

10 seconds

Command Modes

Interface-ATM-VC configuration (for an ATM SVC)
VC-class configuration (for a VC class)

Command History

Release	Modification
11.3	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

If OAM management is enabled, further control of OAM management is configured using the **oam retry** command.



Note

Generally, ATM signalling manages ATM SVCs. Configuring the **oam-svc** command on an SVC verifies the inband integrity of the SVC.

If the **oam-svc** command is not explicitly configured on an ATM SVC, the SVC inherits the following default configuration (listed in order of precedence):

- Configuration of the **oam-svc** command in a VC class assigned to the SVC itself.
- Configuration of the **oam-svc** command in a VC class assigned to the SVC's ATM subinterface.
- Configuration of the **oam-svc** command in a VC class assigned to the SVC's ATM main interface.
- Global default: End-to-end F5 OAM loopback cell generation and OAM management are disabled, but if OAM cells are received, they are looped back. The default value for *frequency* is 10 seconds.

Examples

The following example enables end-to-end F5 OAM loopback cell transmission and OAM management on an ATM SVC with a transmission frequency of 3 seconds:

```
oam-svc manage 3
```

Related Commands

Command	Description
oam retry	Configures parameters related to OAM management for an ATM PVC, SVC, or VC class.

partial-fill

To configure the number of AAL1 user octets per cell for the ATM circuit emulation service (CES) on the OC-3/STM-1 Circuit Emulation Service network module, use the **partial-fill** command in interface-CES-VC mode. To delete the CES partial-fill value, use the **no** form of this command.

partial-fill *octet*

no partial-fill *octet*

Syntax Description

<i>octet</i>	Number of user octets per cell for the CES. Possible values of octet range from 1 to 47.
--------------	--

Command Default

No partial-fill

Command Modes

Interface-CES-VC configuration

Command History

Release	Modification
12.1(2)T	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

The **partial-fill** command applies to CES switched virtual circuits (SVCs) and permanent virtual circuits (PVCs) configured on Cisco 2600 series and Cisco 3600 series routers that have OC-3/STM-1 ATM CES network modules.

Examples

The following example sets the CES partial cell fill to 50 octets per cell for SVC “ces1”:

```
interface atm 1/0
  svc ces1 nsap 47.00.00.....01.01.00 ces
  partial fill 40
```

Related Commands

Command	Description
svc	Creates an ATM SVC and specifies the destination NSAP address on a main interface or subinterface.

ping atm interface atm

To perform an ATM Operation, Administration, and Maintenance (OAM) ping on a specific permanent virtual circuit (PVC), use the **ping atm interface atm** command in privileged EXEC mode.

Cisco 7200 and 7500 Series, Catalyst 6500 and 7600 Series

```
ping atm interface atm interface-number vpi-value [vci-value [end-loopback | seg-loopback]
[repeat [timeout]]]
```

Cisco ASR 1000 Series

```
ping atm interface atm interface-number vpi-value vci-value [end-loopback [ignore-loop] |
seg-loopback] [repeat] [timeout]
```

Syntax Description

atm interface_number	ATM interface name.
vpi-value	Virtual path identifier. Range: 0 to 255.
vci-value	(Optional) Virtual channel identifier. Range: 0 to 65535.
end-loopback	(Optional) Send ATM end loopback cells. This is the default.
seg-loopback	(Optional) Send ATM segment loopback cells.
repeat	(Optional) Number of ping packets that are sent to the destination address. Range: 1 to 1000. Default: 5.
timeout	(Optional) Timeout interval, in seconds. Range: 1 to 30. Default: 2.
ignore-loop	(Optional) Displays a successful response when the peer ATM interface is in a loopback mode. If ignore-loop is not set, the ping fails, with a message (without timestamp) stating that the circuit is looped.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
11.4	This command was introduced on the LightStream 1010.
12.0(21)S	This command was integrated into Cisco IOS Release 12.0(21)S.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE.
12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.
Cisco IOS XE Release 2.3	This command was integrated into Cisco IOS XE Release 2.3.

Usage Guidelines

The **ping atm interface atm** command sends an OAM packet and indicates when a response is received. It can be used either in normal mode or in interactive mode.

The **ping atm interface atm** command provides two ATM OAM ping options:

- End loopback—Verifies end-to-end PVC integrity.
- Segment loopback—Verifies PVC integrity to the neighboring ATM device.

Examples

In the following example, an ATM OAM ping with a 15-second timeout verifies end-to-end connectivity for PVC 0/500 in the normal mode:

```
Router# ping atm interface atm 1/1.1 0 500 end-loopback 30 15

Type escape sequence to abort.
Sending 30, 53-byte end-to-end OAM echoes, timeout is 15 seconds:
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
Success rate is 100 percent (30/30), round-trip min/avg/max = 1/1/4 ms
```

In the following example, an ATM OAM ping verifies connectivity to the first-hop ATM switch on PVC 1/100 in the normal mode:

```
Router# ping atm interface atm 1/1.1 0 500 seg-loopback 30 10

Type escape sequence to abort.
Sending 30, 53-byte segment OAM echoes, timeout is 10 seconds:
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
Success rate is 100 percent (30/30), round-trip min/avg/max = 1/1/4 ms
```

Table 11 describes the significant fields shown in the display.

Table 11 *ping atm Field Descriptions*

Field	Description
Success rate is 100 percent	Percentage of packets successfully echoed back to the router. Anything less than 80 percent indicates problems in the system.
!!!!!!	Each exclamation point (!) indicates receipt of a reply. A period (.) indicates that an OAM response cell was not received within the timeout interval.
round-trip min/avg/max = 1/1/4 ms	Round-trip travel time intervals for the OAM loopback cells, including minimum, average, and maximum (in milliseconds).

The following example verifies connectivity to the neighboring ATM device for the ATM PVC with the virtual path identifier (VPI)/virtual channel identifier (VCI) value 0/500 in the interactive mode:

```
Router# ping

Protocol [ip]:atm

ATM Interface:atm1/1.1

VPI value [0]:0

VCI value [1]:500

Loopback - End(0), Segment(1) [0]:1

Repeat Count [5]:
```

Timeout [2]:

Type escape sequence to abort.

Sending 5, 53-byte segment OAM echoes, timeout is 2 seconds:
!!!!!!

Success rate is 100 percent (5/5), round-trip min/avg/max = 1/1/1 ms

Table 12 describes the **ping** fields shown in the display.

Table 12 *ping Field Descriptions for ATM*

Field	Description
Protocol [ip]:	Prompt for a supported protocol.
ATM Interface:	Prompt for the ATM interface.
VPI value [0]:	Prompt for the virtual path identifier. Default: 0.
VCI value [1]:	Prompt for the virtual channel identifier. Default: 1.
Loopback - End(0), Segment(1) [0]:	Prompt to specify end loopback, which verifies end-to-end PVC integrity, or segment loopback, which verifies PVC integrity to the neighboring ATM device. Default: end loopback.
Repeat Count [5]:	Number of ping packets that will be sent to the destination. Default: 5.
Timeout [2]:	Timeout interval, in seconds. Default: 2.

Related Commands

Command	Description
debug atm oam	Displays information about ATM OAM events.
show atm oam auto-detect	Displays ATM OAM autodetect statistics.
show atm pvc	Displays the OAM status information.

pos flag s1-byte rx-communicate

To direct the router to switch to internal clocking when it receives an S1 SONET overhead byte with a value of 0xF, use the **pos flag s1-byte rx-communicate** command in interface configuration mode. To disable this capability, use the **no** form of this command.

pos flag s1-byte rx-communicate

no pos flag s1-byte rx-communicate

Command Default	Disabled
-----------------	----------

Command Modes	Interface configuration
---------------	-------------------------

Command History	Release	Modification
	12.2(28)SB	This command was introduced on the Cisco 10000 series router.

Usage Guidelines	The pos flag s1-byte rx-communicate command directs the router to switch the clock source to internal when it receives an S1 SONET overhead byte with a value of 0xF. When the S1 SONET overhead byte changes from 0xF to any other value, the clock source reverts back to the clock source specified in the user configuration. The S1 SONET overhead byte is ignored by the receiving router unless the pos flag s1-byte rx-communicate command is issued.
------------------	---

Examples	The following example directs the router to switch to internal clocking when it receives an S1 SONET overhead byte with a value of 0xF: <pre>pos flag s1-byte rx-communicate</pre>
----------	---

Related Commands	Command	Description
	pos flag	Assigns values for specific elements of the frame header. This command is typically used to meet a standards requirement or to ensure interoperability with another vendor's equipment.
	pos flag s1-byte tx	Controls the transmission of the S1 SONET overhead byte.

pos flag s1-byte tx

To control the transmission of the S1 SONET overhead byte, use the **pos flag s1-byte tx** command in interface configuration mode.

pos flag s1-byte tx *value*

Syntax Description	<i>value</i>	Set the S1 SONET overhead byte to a value in the range of 0x0 to 0xF.
---------------------------	--------------	---

Defaults	The default is 0x0.
-----------------	---------------------

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	12.2(28)SB	This command was introduced on the Cisco 10000 series router.

Usage Guidelines	In most situations, the default value for the S1 SONET overhead byte does not need to be changed. Refer to the SONET standards for information about the possible values for the S1 SONET overhead byte and the definition of each value.
-------------------------	---

Examples	The following example sets the S1 SONET overhead byte to 0xF: pos flag s1-byte tx 0xF
-----------------	--

Related Commands	Command	Description
	pos flag	Assigns values for specific elements of the frame header. This command is typically used to meet a standards requirement or to ensure interoperability with another vendor's equipment.
	pos flag s1-byte rx-communicate	Directs the router to switch to internal clocking when it receives an S1 SONET overhead byte with a value of 0xF.

protect

To configure a virtual circuit (VC) class with protected group or protected VC status for application to a VC bundle member, use the **protect** command in ATM VC class configuration mode. To remove the protected status from a VC class, use the **no** form of this command.

To configure a specific VC or permanent virtual circuit (PVC) as part of a protected group of the bundle or to configure it as an individually protected VC or PVC bundle member, use the **protect** command in ATM VC bundle-member configuration mode. To remove the protected status from a VC or PVC, use the **no** form of this command.

protect {group | vc}

no protect {group | vc}

Syntax Description

group	Configures the VC or PVC bundle member as part of the protected group of the bundle.
vc	Configures the VC or PVC member as individually protected.

Defaults

The VC or PVC does not belong to the protected group and is also not individually protected.

Command Modes

ATM VC class configuration (for a VC class)
ATM VC bundle-member configuration (for ATM VC bundle members)

Command History

Release	Modification
12.0(3)T	This command was introduced.
12.0(23)S	This command was made available in ATM VC class configuration and ATM VC bundle-member configuration modes on the 8-port OC-3 STM-1 ATM line card for Cisco 12000 series Internet routers.
12.2(16)BX	This command was integrated into Cisco IOS Release 12.2(16)BX.
12.0(26)S	This command was integrated into Cisco IOS Release 12.0(26)S.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(31)SB	This command was integrated into Cisco IOS Release 12.2(31)SB.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Use the **protect** command in ATM VC class configuration mode to assign a VC class to have protected group or individually protected VC status. When the class is applied to the VC bundle member, that VC is characterized by the protected status. You can also apply this command directly to a VC in ATM VC bundle-member configuration mode.

When a protected VC fails, it causes the bundle to fail. When all members of a protected group fail, the bundle fails.

You must enter the **vc-class atm** global configuration command before you can use the **protect** command in ATM VC class configuration mode.

The **protect** command has no effect if the VC class that contains the command is attached to a standalone VC, that is, if the VC is not a bundle member.

You must enter the **bundle** command to enter bundle configuration mode for the bundle containing the VC member to be configured before you can use the **protect** command in ATM VC bundle-member configuration mode. Then enter the **pvc-bundle** configuration command to add the VC to the bundle as a member of it.

VCs in a VC bundle have the following configuration inheritance guidelines (in order of next-highest precedence):

- VC configuration in ATM VC bundle-member configuration mode
- Configuration in the VC class attached to the ATM VC bundle member in ATM VC bundle-member configuration mode
- Configuration in the VC class attached to the bundle in ATM VC bundle configuration mode
- Configuration in the VC class attached to the subinterface associated with the bundle in subinterface configuration mode
- Configuration in the VC class attached to the main interface associated with the bundle in interface configuration mode

Examples

The following example shows how to configure a class named control-class to include a **protect** command, which, when applied to a VC bundle member, configures the VC as an individually protected VC bundle member. When this protected VC goes down, it takes the bundle down:

```
vc-class atm control-class
protect vc
```

Related Commands

Command	Description
bump	Configures the bumping rules for a VC class that can be assigned to a VC bundle.
bundle	Creates a bundle or modifies an existing bundle to enter bundle configuration mode.
class-vc	Assigns a VC class to an ATM PVC, SVC, or VC bundle member.
precedence	Configures precedence levels for a VC class that can be assigned to a VC bundle and thus applied to all VC members of that bundle and configures precedence levels for an individual VC or PVC bundle member.
pvc	Creates or assigns a name to an ATM PVC, specifies the encapsulation type on an ATM PVC, and enters ATM permanent virtual circuit configuration mode.
pvc-bundle	Adds a PVC to a bundle as a member of the bundle and enters ATM VC bundle-member configuration mode in order to configure that PVC bundle member.
ubr	Configures UBR QoS and specifies the output peak cell rate for an ATM PVC, SVC, VC class, or VC bundle member.

Command	Description
ubr+	Configures UBR QoS and specifies the output peak cell rate and output minimum guaranteed cell rate for an ATM PVC, SVC, VC class, or VC bundle member.
vbr-nrt	Configures VBR-NRT QoS and specifies output peak cell rate, output sustainable cell rate, and output maximum burst cell size for an ATM PVC, SVC, VC class, or VC bundle member.
vc-class atm	Configures a VC class for an ATM VC or interface.

protocol (ATM)

To configure a static map for an ATM permanent virtual circuit (PVC), switched virtual circuit (SVC), or virtual circuit (VC) class or to enable Inverse Address Resolution Protocol (ARP) or Inverse ARP broadcasts on an ATM PVC, use the **protocol** command in the appropriate mode. To remove a static map or disable Inverse ARP, use the **no** form of this command.

protocol *protocol* [*protocol-address* [**virtual-template**] | **inarp**] [[**no**] **broadcast** | **disable-check-subnet** | [**no**] **enable-check-subnet**]

no protocol *protocol* [*protocol-address* [**virtual-template**] | **inarp**] [[**no**] **broadcast** | **disable-check-subnet** | [**no**] **enable-check-subnet**]

Syntax Description

<i>protocol</i>	Choose one of the following values:
	• aarp—AppleTalk ARP • appletalk—AppleTalk • arp—IP ARP • bridge—bridging • bstun—block serial tunnel • cdp—Cisco Discovery Protocol • clns—ISO Connectionless Network Service (CLNS) • clns_es—ISO CLNS end system • clns_is—ISO CLNS intermediate system • cmns—ISO CMNS • compressedtcp—Compressed TCP • decnet—DECnet

	• decnet_node—DECnet node • decnet_prime_router—DECnet prime router • decnet_router-l1—DECnet router L1 • decnet_router-l2—DECnet router L2 • dls—data link switching • ip—IP • ipx—Novell IPX • llc2—llc2 • pad—packet assembler/disassembler (PAD) links • ppp—Point-to-Point Protocol carried on the VC • pppoe—PPP over Ethernet • qlc—Qualified Logical Link Control protocol • rsrb—remote source-route bridging • snapshot—snapshot routing support • stun—serial tunnel
<i>protocol-address</i>	Destination address that is being mapped to a PVC.
virtual-template	(Optional) Specifies parameters that the point-to-point protocol over ATM (PPPoA) sessions will use. Note This keyword is valid only for the PPP protocol.
inarp	(Valid only for IP and IPX protocols on PVCs) Enables Inverse ARP on an ATM PVC. If you specify a protocol address instead of inarp , Inverse ARP is automatically disabled for that protocol.
[no] broadcast	(Optional) Indicates that this map entry is used when the corresponding protocol sends broadcast packets to the interface. Pseudobroadcasting is supported. The broadcast keyword of the protocol command takes precedence if you previously configured the broadcast command on the ATM PVC or SVC.
disable-check-subnet	(Optional) Disables subnet checking for InARP.
enable-check-subnet	(Optional) Enables subnet checking for InARP.

Inverse ARP is enabled for IP and IPX if the protocol is running on the interface and no static map is configured. Subnet checking for InARP is disabled by default.

Command Modes

Interface-ATM-VC configuration (for an ATM PVC or SVC)
 PVC-in-range configuration (for an individual PVC within a PVC range)
 PVC range configuration (for an ATM PVC range)
 VC-class configuration (for a VC class)

Command History

Release	Modification
11.3	This command was introduced.
12.1	The ppp and virtual-template keywords were added.

Release	Modification
12.1(5)T	The ip and ipx options were made available in PVC range and PVC-in-range configuration modes.
12.2(13)T	The apollo , vines , and xns keywords were removed because Apollo Domain, Banyan VINES, and Xerox Network Systems are no longer supported in the Cisco IOS software.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
12.2SRE	The disable-check-subnet and enable-check-subnet keywords were added.

Usage Guidelines

Command Application

Use this command to perform either of the following tasks:

- Configure a static map for an ATM PVC, SVC, or VC class.
- Enable Inverse ARP or Inverse ARP broadcasts on an ATM PVC or PVC range by configuring Inverse ARP directly on the PVC, in the PVC range, or in a VC class (applies to IP and IPX protocols only).
- Enable the router to respond to an InARP request when the source IP address contained in the request is not in the subnet as the receiving sub-interface on which PVC is configured.
- Enable the router to accept InARP reply when the peer router's IP address is not in the same subnet as the receiving sub-interface on which the PVC is configured.
- Does not provide support for SVC, PVC, and SVC bundles.

PVC range and PVC-in-range configuration modes support only the protocols that do not require static map configuration. Those protocol options are **ip** and **ipx**.

Default Configurations

If the **protocol** command is not explicitly configured on an ATM PVC or SVC, the VC inherits the following default configuration (listed in order of precedence):

- Configuration of the **protocol ip inarp** or **protocol ipx inarp** command in a VC class assigned to the PVC or SVC itself.
- Configuration of the **protocol ip inarp** or **protocol ipx inarp** command in a VC class assigned to the ATM subinterface of the PVC or SVC.
- Configuration of the **protocol ip inarp** or **protocol ipx inarp** command in a VC class assigned to the ATM main interface of the PVC or SVC.
- Global default: Inverse ARP is enabled for IP and IPX if the protocol is running on the interface and no static map is configured.

Examples

In the following example, the router creates a static map on a VC, indicates that 10.68.34.237 is connected to this VC, and sends ATM pseudobroadcasts:

```
protocol ip 10.68.34.237 broadcast
```

In the following example, the router enables Inverse ARP for IPX and does not send ATM pseudobroadcasts:

```
protocol ipx inarp no broadcast
```

In the following example, the router removes a static map from a VC and restores the default behavior for Inverse ARP (refer to the “Defaults” section):

```
no protocol ip 10.68.34.237
```

In the following example, the VC carries PPP traffic and its associated parameters:

```
protocol ppp 10.68.34.237 virtual-template
```

pvc

To create or assign a name to an ATM permanent virtual circuit (PVC), to specify the encapsulation type on an ATM PVC, and to enter ATM virtual circuit configuration mode, use the **pvc** command in interface configuration mode or subinterface configuration mode. To remove an ATM PVC from an interface, use the **no** form of this command.

pvc [*name*] *vpi/vci* [**ces** | **ilmi** | **qsaal** | **smds** | **l2transport**]

no pvc [*name*] *vpi/vci* [**ces** | **ilmi** | **qsaal** | **smds** | **l2transport**]

Cisco 10000 Series Router

pvc [*name*] *vpi/vci* [**ilmi** | **l2transport**]

no pvc [*name*] *vpi/vci* [**ilmi** | **l2transport**]

Cisco 800, Cisco 1800, Cisco 2800, Cisco 3600, and Cisco 3800 Series Routers

pvc [*name*] *vpi/vci* [**ces** | **ilmi** | **qsaal** | **smds**]

no pvc [*name*] *vpi/vci* [**ces** | **ilmi** | **qsaal** | **smds**]

Syntax Description

<i>name</i>	(Optional) The name of the PVC or map. The name can be up to 15 characters long.
<i>vpi/</i>	ATM network virtual path identifier (VPI) for this PVC. The slash is required. This value defaults to 0 if no value is given for <i>vpi/</i>. Valid value ranges are as follows: • Cisco 7200, 7500, and 10000 series routers: 0 to 255. • Cisco 4500 and 4700 routers: 0 to 1 less than the quotient of 8192 divided by the value set by the atm vc-per-vp command. • Cisco 2600 and 3600 series routers using Inverse Multiplexing for ATM (IMA): 0 to 15, 64 to 79, 128 to 143, and 192 to 207. A value that is out of range is interpreted as a string and is used as the connection ID. The arguments <i>vpi</i> and <i>vci</i> cannot both be set to 0; if one is 0, the other cannot be 0.

<i>vci</i>	ATM network virtual channel identifier (VCI) for this PVC. The range of valid values is 0 to 1 less than the maximum value set for this interface by the atm vc-per-vp command. Lower values from 0 to 31 are usually reserved for specific traffic (F4 Operation Administration and Maintenance (OAM), SSL VPN Client (SVC) signaling, Interim Local Management Interface (ILMI), and so on) and should not be used. The VCI value is a 16-bit field in the header of the ATM cell. The VCI value is unique only on a single link, not throughout the ATM network, because it has local significance only. A value that is out of range causes an “unrecognized command” error message. The arguments <i>vpi</i> and <i>vci</i> cannot both be set to 0; if one is 0, the other cannot be 0.
ces	(Optional) Circuit Emulation Service (CES) encapsulation. This keyword is available on the OC-3/STM-1 ATM Circuit Emulation Service network module and on AIM-ATM and AIM-ATM-VOICE-30 network modules only.
ilmi	(Optional) Sets up communication with the ILMI; the associated <i>vpi</i> and <i>vci</i> values are usually 0 and 16, respectively.
qsaal	(Optional) A signaling-type PVC used for setting up or tearing down SVCs; the associated <i>vpi</i> and <i>vci</i> values are usually 0 and 5, respectively.
smds	(Optional) Encapsulation for Switched Multimegabit Data Service (SMDS) networks. If you are configuring an ATM PVC on the ATM Interface Processor (AIP), you must configure AAL3/4SMDS by using the atm aal aal3/4 command before specifying smds encapsulation. If you are configuring an ATM network processor module (NPM), the atm aal aal3/4 command is not required. SMDS encapsulation is not supported on the ATM port adapter.
l2transport	(Optional) Specifies that the PVC is switched and not terminated.

Command Default

No PVC is defined.

Command Modes

Interface configuration (config-if)
 Subinterface configuration (config-subif)

Command History

Release	Modification
11.3T	This command was introduced.
12.1(2)T	The ranges for the VPI were increased for Cisco 2600 series and Cisco 3600 series routers that use Inverse Multiplexing for ATM (IMA). The ces keyword was added for configuring CES encapsulation when using the OC-3/STM-1 ATM Circuit Emulation Service network module on Cisco 2600 series and Cisco 3600 series routers.
12.1(5)XM	This command was integrated into Cisco IOS Release 12.1(5)XM and was extended to the merged Simple Gateway Control Protocol (SGCP)/Media Gateway Control Protocol (MGCP) software. This command replaces the atm pvc command.

Release	Modification
12.0(17)SL	This command was integrated into Cisco IOS Release 12.0(17)SL.
12.0(23)S	This command was integrated into Cisco IOS Release 12.0(23)S, and the l2transport keyword was added.
12.3(8)T	The ces keyword was added to AIM-ATM and AIM-ATM-VOICE-30 network modules.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(31)SB	The command was integrated into Cisco IOS Release 12.2(31)SB.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Cisco IOS XE Release 2.5	This command was implemented on Cisco ASR 1000 Series Aggregation Service Routers.

Usage Guidelines

When a PVC is defined, the global default of the **encapsulation** command applies (**aal5snap**).

Creating and Configuring PVCs

The **pvc** command replaces the **atm pvc** command. Use the **pvc** command to configure a single ATM VC only, not a VC that is a bundle member. You should use the **pvc** command in conjunction with the **encapsulation** and **random-detect attach** commands instead of the **atm pvc** command.

When configuring an SVC, use the **pvc** command to configure the PVC that handles SVC call setup and termination. In this case, specify the **qsaal** keyword.



Note

When an unsupported service-policy is attached to a PVC in a PVC range, an error message is displayed.

ATM PVC Names

Once you specify a name for a PVC, you can reenter ATM virtual circuit configuration mode by entering the **pvc name** command. You can remove a PVC and any associated parameters by entering the **no pvc name** or **no pvc vpi/vci** command.



Note

After configuring the parameters for an ATM PVC, you must exit the ATM virtual circuit configuration mode in order to create the PVC and enable the settings.

Encapsulation Types on ATM PVCs

Specify CES, ILMI, QSAAL, SMDS, or l2transport as the encapsulation type on an ATM PVC. (To configure other encapsulations types, see the **encapsulation** command.)

Configuring CES encapsulation on a PVC is equivalent to creating a constant bit rate (CBR) class of service.

Rate Queues

The Cisco IOS software dynamically creates rate queues as necessary to satisfy the requests of the **pvc** commands.

Default Configurations

If **ilmi**, **qsaal**, or **smds** encapsulation is not explicitly configured on the ATM PVC, the PVC inherits the following default configuration (listed in order of precedence):

- Configuration of the **encapsulation** command in a VC class assigned to the PVC itself.
- Configuration of the **encapsulation** command in a VC class assigned to the ATM subinterface of the PVC.
- Configuration of the **encapsulation** command in a VC class assigned to the ATM main interface of the PVC.
- Global default: The global default value of the **encapsulation** command applies (**aal5snap**).

Examples

The following example creates a PVC with VPI 0 and VCI 16 and sets up communication with the ILMI:

```
pvc cisco 0/16 ilmi
exit
```

The following example creates a PVC used for ATM signaling for an SVC. It specifies VPI 0 and VCI 5:

```
pvc cisco 0/5 qsaal
exit
```

The following example configures a PVC named cisco to use class-based weighted fair queueing (CBWFQ). It attaches a policy map named policy1 to the PVC. The classes that comprise policy1 determine the service policy for the PVC:

```
pvc cisco 0/5
 service-policy output policy1
 vbr-nrt 2000 2000
 encaps aal5snap
```

Related Commands

Command	Description
atm vc-per-vp	Sets the maximum number of VCI to support per VPI.
encapsulation	Configures the AAL and encapsulation type for an ATM VC, VC class, VC, bundle, or PVC range.
pvc-bundle	Adds a PVC to a bundle as a member of the bundle.
random-detect	Enables per-VC WRED or per-VC VIP-DWRED.

pvc-bundle

To add a virtual circuit (VC) to a bundle as a member of the bundle and enter bundle-vc configuration mode in order to configure that VC bundle member, use the **pvc-bundle** command in bundle configuration mode. To remove the VC from the bundle, use the **no** form of this command.

pvc-bundle *pvc-name* [*vpi*/] [*vci*]

no pvc-bundle *pvc-name* [*vpi*/] [*vci*]

Syntax Description

<i>pvc-name</i>	The name of the permanent virtual circuit (PVC) bundle.
<i>vpi</i>	(Optional) ATM network virtual path identifier (VPI) for this PVC. The absence of the / and a <i>vpi</i> value defaults the <i>vpi</i> value to 0. On the Cisco 7200 and 7500 series routers, the value range is from 0 to 255; on the Cisco 4500 and 4700 routers, the value range is from 0 to 1 less than the quotient of 8192 divided by the value set by the atm vc-per-vp command. The <i>vpi</i> and <i>vci</i> arguments cannot both be set to 0; if one is 0, the other cannot be 0.
<i>vci</i>	(Optional) ATM network virtual channel identifier (VCI) for this PVC. The value range is from 0 to 1 less than the maximum value set for this interface by the atm vc-per-vp command. Typically, lower values 0 to 31 are reserved for specific traffic (F4 Operation, Administration, and Maintenance (OAM), switched virtual circuit (SVC) signaling Integrated Local Management Interface (ILMI), and so on) and should not be used. The VCI is a 16-bit field in the header of the ATM cell. The VCI value is unique only on a single link, not throughout the ATM network, because it has local significance only. The <i>vpi</i> and <i>vci</i> arguments cannot both be set to 0; if one is 0, the other cannot be 0.

Command Default

None

Command Modes

Bundle configuration

Command History

Release	Modification
12.0(3)T	This command was introduced.
12.0(26)S	This command was implemented on the Cisco 10000 series router.
12.2(16)BX	This command was implemented on the ESR-PRE2.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.

Release	Modification
12.2(31)SB	This command was integrated into Cisco IOS Release 12.2(31)SB.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Each bundle can contain multiple VCs having different quality of service (QoS) attributes. This command associates a VC with a bundle, making it a member of that bundle. Before you can add a VC to a bundle, the bundle must exist. Use the **bundle** command to create a bundle. You can also use this command to configure a VC that already belongs to a bundle. You enter the command in the same way, giving the name of the VC bundle member.

The **pvc-bundle** command enters bundle-vc configuration mode, in which you can specify VC-specific and VC class attributes for the VC.

Examples

The following example specifies an existing bundle called bundle1 and enters bundle configuration mode. Then it adds two VCs to the bundle. For each added VC, bundle-vc mode is entered and a VC class is attached to the VC to configure it.

```
bundle bundle1
pvc-bundle bundle1-control 207
class control-class
pvc-bundle bundle1-premium 206
class premium-class
```

The following example configures the PVC called bundle1-control, an existing member of the bundle called bundle1, to use class-based weighted fair queueing (CBWFQ). The example configuration attaches the policy map called policy1 to the PVC. Once the policy map is attached, the classes comprising policy1 determine the service policy for the PVC bundle1-control.

```
bundle bundle1
pvc-bundle bundle1-control 207
class control-class
service-policy output policy1
```

Related Commands

Command	Description
atm vc-per-vp	Sets the maximum number of VCs to support per VPI.
bump	Configures the bumping rules for a VC class that can be assigned to a VC bundle.
class-bundle	Configures a VC bundle with the bundle-level commands contained in the specified VC class.
class-vc	Assigns a VC class to an ATM PVC, SVC, or VC bundle member.
precedence	Configures precedence levels for a VC member of a bundle, or for a VC class that can be assigned to a VC bundle.
protect	Configures a VC class with protected group or protected VC status for application to a VC bundle member.
pvc	Creates or assigns a name to an ATM PVC, specifies the encapsulation type on an ATM PVC, and enters interface-ATM-VC configuration mode.

Command	Description
ubr	Configures UBR QoS and specifies the output peak cell rate for an ATM PVC, SVC, VC class, or VC bundle member.
ubr+	Configures UBR QoS and specifies the output peak cell rate and output minimum guaranteed cell rate for an ATM PVC, SVC, VC class, or VC bundle member.
vbr-nrt	Configures the VBR-NRT QoS and specifies output peak cell rate, output sustainable cell rate, and output maximum burst cell size for an ATM PVC, SVC, VC class, or VC bundle member.

qos-group (ATM VC bundle member)

To associate a quality of service (QoS) group or groups with a permanent virtual circuit (PVC) bundle member, use the **qos-group** command in ATM VC bundle-member configuration mode. To disassociate a QoS group or groups from a PVC bundle member, use the **no** form of this command.

qos-group *qos-groups*

no qos-group *qos-groups*

Syntax Description

<i>qos-groups</i>	QoS group or groups. You can specify a QoS group, a range of QoS groups, or any combination of QoS groups and ranges of QoS groups separated by commas. Specify a range by entering the starting and ending QoS group numbers separated by a hyphen (-).
-------------------	--

Command Default

No QoS groups are associated with the PVC bundle member.

Command Modes

ATM VC bundle-member configuration

Command History

Release	Modification
12.4(4)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.

Examples

The following example associates a single QoS group with a PVC bundle member:

```
Router> enable
Password:
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# interface atm 2/0
Router(config-subif)# bundle cisco
Router(config-if-atm-bundle)# selection-method qos-group
Router(config-if-atm-bundle)# pvc 1/32
Router(config-if-atm-member)# qos-group 1
Router(config-if-atm-member)# end
```

The following example associates a range of QoS groups from 1 to 5 with a PVC bundle member:

```
Router> enable
Password:
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# interface atm 2/0
Router(config-subif)# bundle cisco
Router(config-if-atm-bundle)# selection-method qos-group
Router(config-if-atm-bundle)# pvc 1/32
Router(config-if-atm-member)# qos-group 1-5
Router(config-if-atm-member)# end
```

The following example associates QoS groups 1 and 7 with a PVC bundle member:

```
Router> enable
Password:
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# interface atm 2/0
Router(config-subif)# bundle cisco
Router(config-if-atm-bundle)# selection-method qos-group
Router(config-if-atm-bundle)# pvc 1/32
Router(config-if-atm-member)# qos-group 1,7
Router(config-if-atm-member)# end
```

The following example associates a range of QoS groups 1 to 5 and a range of QoS groups 7-10 with a PVC bundle member:

```
Router> enable
Password:
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# interface atm 2/0
Router(config-subif)# bundle cisco
Router(config-if-atm-bundle)# selection-method qos-group
Router(config-if-atm-bundle)# pvc 1/32
Router(config-if-atm-member)# qos-group 1-5,7-10
Router(config-if-atm-member)# end
```

Related Commands

Command	Description
inarp-vc	Enables InARP for a PVC bundle member.
selection-method	Specifies the method for selection of the PVC bundle member.

retry (SVC)

To configure a router to periodically attempt to bring up an active switched virtual circuit (SVC) connection after the initial call setup failed, use the **retry** command in interface-CES-VC configuration mode. To disable the retry mechanism, use the **no** form of this command.

retry *timeout-value* [*retry-limit*] [*first-retry-interval*]

no **retry**

Syntax Description	<i>timeout-value</i>	Number of seconds between attempts to bring up the connection. The range is from 1 to 86400 seconds.
	<i>retry-limit</i>	(Optional) Number of attempts the router will make to bring up the connection. The range is from 0 to 65535. The default value of 0 indicates no limit.
	<i>first-retry-interval</i>	(Optional) Number of seconds the router will wait after the first call attempt failed before trying the call again. The default is 10 seconds.

Defaults	There is no default <i>timeout-value</i> . <i>retry-limit</i> : 0 <i>first-retry-interval</i> : 10 seconds
-----------------	--

Command Modes	Interface-CES-VC configuration
----------------------	--------------------------------

Command History	Release	Modification
	12.1(2)T	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	This command is used on Cisco 2600 series and 3600 series routers that have OC-3/STM-1 ATM CES network modules. The retry command applies only to active SVCs.
-------------------------	--

Examples	In the following example, the router is configured to make up to 20 attempts to bring up a connection on SVC “ces1”. The interval between attempts is set at 10 seconds. <pre>interface atm 1/0 svc ces1 nsap 47.0091.81.000000.0040.0B0A.2501.ABC1.3333.3333.05 ces retry 10 20</pre>
-----------------	---

Related Commands

Command	Description
ces	Configures CES on a router port and enters CES configuration mode.
svc	Creates an ATM SVC and specifies the destination NSAP address on a main interface or subinterface.

scrambling cell-payload

To improve data reliability by randomizing the ATM cell payload frames on Cisco 7100, 7200, or 7500 series routers, use the **scrambling cell-payload** command in interface configuration mode. To disable scrambling, use the **no** form of this command.x

scrambling cell-payload

no scrambling cell-payload

Syntax Description This command has no arguments or keywords.

Command Default Scrambling is disabled.

Command Modes Interface configuration

Command History	Release	Modification
	12.0(5)XE	This command was introduced.
	12.0(7)XE1	Support for Cisco 7100 series routers added.
	12.1(5)T	This command was integrated into Cisco IOS Release 12.1(5)T.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines Normally, you do not issue the **scrambling cell-payload** command explicitly, because the default value is sufficient. On T1 links, the default b8zs line encoding normally assures sufficient reliability. The default for E1 is hdb3.

The scrambling setting must match that of the far-end receiver.

Examples On Cisco 7100 or 7200 series routers, the following example sets the link on interface 1 on the port adapter in slot 0 to no scrambling:

```
interface atm0/1
 no scrambling cell-payload
```

Related Commands	Command	Description
	scrambling-payload	Improves data reliability by randomizing the ATM cell payload frames on Cisco 2600 and 3600 series routers.

scrambling-payload

To improve data reliability by randomizing the ATM cell payload frames on Cisco 2600 or 3600 series routers, use the **scrambling-payload** command in interface configuration mode. To disable scrambling, use the **no** form of this command.

scrambling-payload

no scrambling-payload

Syntax Description

This command has no arguments or keywords.

Command Default

Payload scrambling is on for E1 links and off for T1 links.

Command Modes

Interface configuration

Command History

Release	Modification
12.0(5)XK	This command was introduced.
12.0(5)T	This command was integrated into Cisco IOS Release 12.0(5)T.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Normally, you do not issue the **scrambling-payload** command explicitly, because the default value is sufficient. On T1 links, the default b8zs line encoding normally assures sufficient reliability.

The scrambling setting must match that of the far end.

Examples

On a Cisco 2600 or 3600 series router, the following example sets the link on interface 1 on the module in slot 0 to no scrambling:

```
interface atm0/1
 no scrambling-payload
```

Related Commands

Command	Description
scrambling cell-payload	Improves data reliability by randomizing the ATM cell payload frames on Cisco 7100, 7200, or 7500 series routers.

selection-method

To specify the method for selection of permanent virtual circuit (PVC) bundle members, use the **selection-method** command in ATM bundle configuration mode. To disable a selection method, use the **no** form of this command.

selection-method { qos-group | tos-exp }

no selection-method { qos-group | tos-exp }

Syntax Description	qos-group	Specifies that the quality of service (QoS) group value associated with each packet for selection of PVC bundle members is used.
	tos-exp	Specifies that the type of service (ToS) bit settings of each packet (for IP packets) or Experimental (EXP) bit settings of each packet (for Multiprotocol Label Switching (MPLS) packets) for selection of PVC bundle members is used.

Command Default No selection method is set.

Command Modes ATM bundle configuration (config-if-atm-bundle)

Command History	Release	Modification
	12.4(4)T	This command was introduced.
	12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
	12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.

Usage Guidelines You can change the selection method from QoS groups to ToS or EXP only if none of the PVC bundle members have QoS groups or Inverse Address Resolution Protocol (Inverse ARP) configured.

You can change the selection method from ToS or EXP to QoS groups only if none of the PVC bundle members have precedence, protection, or bumping configured.

Examples The following example shows how to use the QoS groups selection method on a PVC bundle and associate a QoS group with a member of the PVC bundle:

```
Router> enable
Password:
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# interface atm 2/0
Router(config-subif)# bundle test
Router(config-if-atm-bundle)# selection-method qos-group
Router(config-if-atm-bundle)# pvc 1/32
Router(config-if-atm-member)# qos-group 1
Router(config-if-atm-member)# end
```

The following example shows the ToS or EXP selection method for a PVC bundle:

```
Router> enable
Password:
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# interface atm 2/0
Router(config-subif)# bundle test
Router(config-if-atm-bundle)# selection-method tos-exp
Router(config-if-atm-member)# end
```

Related Commands

Command	Description
inarp-vc	Enables InARP for a PVC bundle member.
qos-group (ATM bundle member)	Associates a QoS group or groups with a PVC bundle member.

shortcut-frame-count

To specify the maximum number of times a packet can be routed to the default router within shortcut-frame time before a Multiprotocol over ATM (MPOA) resolution request is sent, use the **shortcut-frame-count** command in MPC configuration mode. To restore the default shortcut-setup frame count value, use the **no** form of this command.

shortcut-frame-count *count*

no shortcut-frame-count

Syntax Description

<i>count</i>	Shortcut-setup frame count. The default is 10 frames.
--------------	---

Defaults

The default is 10 frames.

Command Modes

MPC configuration

Command History

Release	Modification
11.3(3a)WA4(5)	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following example shows how to set the shortcut-setup frame count to 5 for the MPC:

```
Router(mpoa-client-config)# shortcut-frame-count 5
```

Related Commands

Command	Description
atm-address	Overrides the control ATM address of an MPC or MPS.
mpoa client config name	Defines an MPC with a specified name.
shortcut-frame-time	Sets the shortcut-setup frame time (in seconds) for the MPC.

shortcut-frame-time

To set the shortcut-setup frame time (in seconds) for the Multiprotocol over ATM (MPOA) client (MPC), use the **shortcut-frame-time** command in MPC configuration mode. To restore the default shortcut-setup frame-time value, use the **no** form of this command.

shortcut-frame-time *time*

no shortcut-frame-time

Syntax Description

<i>time</i>	Shortcut-setup frame time (in seconds).
-------------	---

Defaults

The default is 1 second.

Command Modes

MPC configuration

Command History

Release	Modification
11.3(3a)WA4(5)	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following example shows how to set the shortcut-setup frame time to 7 for the MPC:

```
Router(mpoa-client-config)# shortcut-frame-time 7
```

Related Commands

Command	Description
atm-address	Overrides the control ATM address of an MPC or MPS.
mpoa client config name	Defines an MPC with a specified name.
shortcut-frame-count	Specifies the maximum number of times a packet can be routed to the default router within shortcut-frame time before an MPOA resolution request is sent.

show aal2 xgcpspi

To display the ATM adaptation layer 2 (AAL2) External Media Gateway Control Protocols (XGCP) Service Provider Interface, use the **show aal2 xgcpspi** command in privileged EXEC mode.

show aal2 xgcpspi { call | statistics }

Syntax Description

call	Displays the active call details of the AAL2 XGCP Service Provider Interface.
statistics	Displays the call statistics of the AAL2 XGCP Service Provider Interface.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.4(15)T	This command was introduced.

Usage Guidelines

Use this command to display the active call details and call statistics of the AAL2 XGCP Service Provider Interface.

Examples

The following is sample output from the **show aal2 xgcpspi** command. The fields are self-explanatory.

Router# **show aal2 xgcpspi call**

```
C a l l I d
      No.  Srce  Dest  Mode          VPI  VCI  Port
      ==  =====  =====  =====  ==  ==  =====
      1    4     3   Receive         2   40   0
      2    6     5   Receive         2   41   8
```

Related Commands

Command	Description
show aal2 profile	Displays AAL2 profiles configured on the system.

show atm arp-server

To display the ATM Address Resolution Protocol (ARP) server's information about one specific interface or all interfaces, use the **show atm arp-server** user EXEC command.

AIP on Cisco 7500 series with AIP; Cisco 7200 series with ATM, ATM-CES, and enhanced ATM port adapters; Cisco 2600 and 3600 series with 1-port ATM-25 network module

```
show atm arp-server [atm slot/port[.subinterface-number]]
```

Cisco 7500 series with ATM and enhanced ATM port adapters

```
show atm arp-server [atm slot/port-adapter/port[.subinterface-number]]
```

Cisco 4500 and 4700 series with NPM

```
show atm arp-server [atm number[.subinterface-number]]
```

Syntax Description		
atm slot/port	(Optional) ATM slot and port numbers. Use this format for the following platform configurations:	- AIP on Cisco 7500 series routers. - ATM port adapter, ATM-CES port adapter, and enhanced ATM port adapter on Cisco 7200 series routers. 1-port ATM-25 network module on Cisco 2600 and 3600 series routers.
atm slot/port-adapter/port	(Optional) ATM slot, port adapter, and port numbers. Use this format for the ATM port adapter or enhanced ATM port adapter on Cisco 7500 series routers.	
atm number	(Optional) ATM network processor module (NPM) number on Cisco 4500 and 4700 routers.	
.subinterface-number	(Optional) Subinterface number.	

Command Modes	User EXEC
---------------	-----------

Command History	Release	Modification
	11.1	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

The following is sample output from the **show atm arp-server** command when no interface is specified:

Note that a '*' next to an IP address indicates an active call

Note that a '*' next to an IP address indicates an active call

Identifies an ATM ARP server for the IP network or sets TTL values for entries in the ATM ARP table.
--

show atm class-links

To display virtual circuit (VC) parameter configurations and where the parameter values are inherited from, use the **show atm class-links** command in privileged EXEC mode.

show atm class-links { *vpi/vci* | *name* }

Syntax Description

<i>vpi/vci</i>	The ATM VPI and VCI numbers. The absence of the slash character (/) and a <i>vpi</i> value defaults the <i>vpi</i> value to 0.
<i>name</i>	Name of the VC.

Command Modes

Privileged EXEC

Command History

Release	Modification
11.3	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following is sample output from the **show atm class-links** command for VPI 0 and VCI 66:

```
Router# show atm class-links 0/66
```

```
Displaying vc-class inheritance for ATM2/0.3, vc 0/66:
broadcast - VC-class configured on main-interface
encapsulation aal5mux ip - VC-class configured on subinterface
no ilmi manage - Not configured - using default
oam-pvc manage 3 - VC-class configured on vc
oam retry 3 5 1 - Not configured - using default
ubr 10000 - Configured on vc directly
```

show atm ilmi-configuration

To display ILMI configuration information, use the **show atm ilmi-configuration** command in privileged EXEC mode.

show atm ilmi-configuration

Syntax Description This command has no arguments or keywords.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.0	This command was introduced prior to Cisco IOS Release 12.0.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples The following example shows sample output for the **show atm ilmi-configuration** command:

```
Router# show atm ilmi-configuration
```

```
LECS Address(s) :  
1122334455667788990011223344556677889900
```

[Table 13](#) describes the fields shown in the display.

Table 13 *show atm ilmi-configuration Field Descriptions*

Field	Description
LECS Address(s)	Current ATM LAN Emulation Clients (LECs) addresses.

Related Commands	Command	Description
	show atm ilmi-status	Displays ILMI-related status information.

show atm ilmi-status

To display ILMI-related status information, use the **show atm ilmi-status** command in privileged EXEC mode.

show atm ilmi-status [*atm interface-number*]

Syntax Description

atm	(Optional) ATM interface.
<i>interface-number</i>	(Optional) Number of the ATM interface.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.0	This command was introduced in a release prior to Cisco IOS Release 12.0.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Entering the **show atm ilmi-status** command without specifying an interface will display ILMI-related status information for all of the ATM interfaces.

Examples

The following example is sample output for the **show atm ilmi-status** command:

```
Router# show atm ilmi-status

Interface :ATM2/0 Interface Type :Unknown
ILMI VCC :(0, 16) ILMI Keepalive :Disabled
ILMI State:      Restarting

Interface :ATM5/0 Interface Type :Private UNI (User-side)
ILMI VCC :(0, 16) ILMI Keepalive :Disabled
ILMI State:      UpAndNormal
Peer IP Addr:    10.0.52.17      Peer IF Name:    ATM1/1/0
Peer MaxVPIbits: 8              Peer MaxVCIBits: 14
Active Prefix(s) :
47.0091.8100.0000.0040.0b0a.2501
End-System Registered Address(s) :
47.0091.8100.0000.0040.0b0a.2501.bbbb.ccdd.eeff.12(Confirmed)
```

[Table 14](#) describes the fields shown in the display.

Table 14 *show atm ilmi-status Field Descriptions*

Field	Description
interface	ATM interface.
Interface Type	Type of ATM interface.
ILMI VCC	Number of the current ILMI VCC for the interface.
ILMI Keepalive	Status of ILMI keepalive packets.
ILMI State	Status of ILMI for the interface.
Peer IP Addr	IP address of the peer.
Peer IF Name	Name of the peer interface.
Peer Max VPIbits	Maximum number of bits allowed for VPIs on the peer interface.
Peer Max VCIbits	Maximum number of bits allowed for VCIs on the peer interface.
Active Prefix	Network prefix that is registered from the switch side and is active and valid.
End-System Registered Address(s)	Address that the router registers back to the switch. The router combines the network prefix of the switch with the end-system identifier to form the end-system registered address.

Related Commands

Command	Description
show atm ilmi-configuration	Displays ILMI configuration information.

show atm interface atm

To display ATM-specific information about an ATM interface, use the **show atm interface atm** command in privileged EXEC mode.

Cisco 7500 series with AIP; Cisco 7200 series with ATM, ATM-CES, and enhanced ATM port adapters; Cisco 2600 and 3600 series with 1-port ATM-25 network module

```
show atm interface atm slot/port
```

Cisco 7500 series with ATM and enhanced ATM port adapters

```
show atm interface atm slot/port-adapter/port
```

Cisco 4500 and 4700 series with NPM

```
show atm interface atm number
```

Syntax Description		
	<i>slot/port</i>	ATM slot number and port number. Use this format on the following platform configurations: • The AIP on Cisco 7500 series routers. • The ATM port adapter, ATM-CES port adapter, or enhanced ATM port adapter on Cisco 7200 series routers. • The 1-port ATM-25 network module on Cisco 2600 and 3600 series routers.
	<i>slot/port-adapter/port</i>	ATM slot, port adapter, and port number. Use this format on the ATM port adapter or ATM-CES port adapter on Cisco 7500 series routers.
	<i>number</i>	NPM number for Cisco 4500 and 4700 routers.

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	10.0	This command was introduced.
	11.0	The <i>number</i> argument was added.
	11.2	The <i>slot/port-adapter/port</i> arguments were added.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following is sample output for the ATM-CES port adapter to display statistics on slot 4, port 0:

```
Router# show atm interface atm 4/0

ATM interface ATM4/0:
AAL enabled: AAL5, Maximum VCs: 1024, Current VCs: 6
Tx buffers 256, Rx buffers 256, Exception Queue: 32, Raw Queue: 32
VP Filter: 0x7B, VCIs per VPI: 1024, Max Datagram Size:4496, MIDs/VC:16
PLIM Type:4B5B - 100Mbps, No Framing, TX clocking: LINE
4897 input, 2900 output, 0 IN fast, 0 OUT fast
Rate-Queue 1 set to 100Mbps, reg=0x4EA DYNAMIC, 1 VCCs
ATM4/0.1:AAL3/4-SMDS address c111.1111.1111 Multicast e222.2222.222
Config. is ACTIVE
```

The following is sample output for the enhanced ATM port adapter to display statistics on slot 6, port 0:

```
Router# show atm interface atm 6/0

ATM interface ATM6/0
AAL enabled: AAL5, Maximum VCs: 2048, Current VCs: 3
Maximum Transmit Channels: 64
Tx buffers: 256, Rx buffers 256, Exception Queue: 32, Raw Queue: 32
VP Filter: 0x7B, VCIs per VPI: 1024, Max Datagram Size: 4496
PLIM Type: SONET - 155Mbps, TX clocking: INTERNAL
0 input, 59 output, 0 IN fast, 0 OUT fast
ABR parameters, rif: 16 rdf: 16
Config. is ACTIVE
```

Table 15 describes the fields shown in the display.

Table 15 *show atm interface atm Field Descriptions*

Field	Description
ATM interface	Slot and port number of the interface.
AAL enabled	Type of AAL. If both AAL5 and AAL3/4 are enabled on the interface, the output will include both AAL5 and AAL3/4.
Maximum VCs	Maximum number of virtual circuits this interface can support.
Current VCs	Number of active virtual circuits.
Tx buffers, Rx buffers	Number of transmit and receive buffers.
Exception Queue	Number of exception buffers.
Raw Queue	Queue size.
VP Filter	Hexadecimal value of the VP filter.
VCIs per VPI	Maximum number of VCIs to support per VPI.
Max Datagram Size	The configured maximum number of bytes in the largest datagram.
MIDs/VC	The configured maximum number of message identifiers allowed per virtual circuit on this interface.
PLIM Type	Physical Layer Interface Module (PLIM) type (E3, 4B/5B, or SONET).
Framing	For E3, this might be G.804; otherwise, no framing.

Table 15 *show atm interface atm Field Descriptions (continued)*

Field	Description
TX clocking	Clocking on the router. For E3 or SONET, this might be INTERNAL, meaning that the AIP or NPM generates the clock. Otherwise, LINE indicates that the ATM switch provides the clocking.
input	Number of packets received and process-switched.
output	Number of packets sent from process switch.
IN fast	Number of input packets fast-switched.
OUT fast	Number of output packets fast-switched.
ABR parameters, rif rdf	The amount that the cell transmission rate increases or decreases in response to flow control information from the network or destination for available bit rate (ABR) PVCs. The rate increase factor (RIF) and rate decrease factor (RDF) in this example are 16, the default.
Rate-Queue	List of configured rate queues.
reg=	Actual register value passed to the AIP to define a specific rate queue (AIP only).
DYNAMIC	Indicates that the rate queue is dynamic and was created automatically by the software. Dynamic rate queues are created when an atm pvc command specifies a peak or average rate that does not match any user configured rate queue. The value PERMANENT indicates that the rate queue was user-configured.
VCCs	Number of virtual channel connections (VCCs) dynamically attached to this rate queue.
ATM4/0.1	Indicates that the subinterface supports ATM adaptation layer AAL3/4 and displays the SMDS E.164 unicast address and the SMDS E.164 multicast address assigned to the subinterface.
Config. is	ACTIVE or VALID in <i>n</i> SECONDS. ACTIVE indicates that the current AIP or NPM configuration has been loaded into the AIP and is being used. There is a 5-second window when a user changes a configuration and the configuration is sent to the AIP.

Related Commands

Command	Description
pvc	Configures the PVC interface.

show atm map

To display the list of all configured ATM static maps to remote hosts on an ATM network and on ATM bundle maps, use the **show atm map** command in user EXEC or privileged EXEC mode.

show atm map

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Modes	User EXEC Privileged EXEC
----------------------	------------------------------

Command History	Release	Modification
	10.0	This command was introduced.
	11.1CA	This command was modified to include an example for the ATM-CES port adapter (PA).
	12.0(3)T	This command was modified to include display for ATM bundle maps. An ATM bundle map identifies a bundle and all of its related virtual circuits (VCs).
	12.2(2)T	The display output for this command was modified to include the IPv6 address mappings of remote nodes to ATM permanent virtual circuits (PVCs).
	12.0(21)ST	This command was integrated into Cisco IOS Release 12.0(21)ST.
	12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S.
	12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.

Examples	The following is sample output from the show atm map command for a bundle called san-jose (0/122, 0/123, 0/124, and 0/126 are the virtual path and virtual channel identifiers of the bundle members):
-----------------	---

```
Router# show atm map
```

```
Map list san-jose_B_ATM1/0.52 : PERMANENT
ip 10.1.1.1. maps to bundle san-jose, 0/122, 0/123, 0/124, 0/126, ATM1/0.52, broadcast
```

The following is sample output from the **show atm map** command for an ATM-CES PA on the Cisco 7200 series router:

```
Router# show atm map
```

```
Map list alien: PERMANENT
ip 10.1.1.1 maps to VC 6
ip 10.1.1.2 maps to VC 6
```

The following is sample output from the **show atm map** command that displays information for a bundle called new-york:

```
Router# show atm map
```

```
Map list atm:
vines 3004B310:0001 maps to VC 4, broadcast
ip 172.21.168.110 maps to VC 1, broadcast
clns 47.0004.0001.0000.0c00.6e26.00 maps to VC 6, broadcast
appletalk 10.1 maps to VC 7, broadcast
decnet 10.1 maps to VC 2, broadcast
Map list new-york: PERMANENT
ip 10.0.0.2 maps to bundle new-york, 0/200, 0/205, 0/210, ATM1/0.1
```

The following is sample output from the **show atm map** command for a multipoint connection:

```
Router# show atm map
```

```
Map list atm_pri: PERMANENT
ip 10.4.4.4 maps to NSAP CD.CDEF.01.234567.890A.BCDE.F012.3456.7890.1234.12, broadcast,
aal5mux, multipoint connection up, VC 6
ip 10.4.4.6 maps to NSAP DE.CDEF.01.234567.890A.BCDE.F012.3456.7890.1234.12, broadcast,
aal5mux, connection up, VC 15, multipoint connection up, VC 6

Map list atm_ipx: PERMANENT
ipx 1004.dddd.dddd.dddd maps to NSAP DE.CDEF.01.234567.890A.BCDE.F012.3456.7890.1234.12,
broadcast, aal5mux, multipoint connection up, VC 8
ipx 1004.cccc.cccc.cccc maps to NSAP CD.CDEF.01.234567.890A.BCDE.F012.3456.7890.1234.12,
broadcast, aal5mux, multipoint connection up, VC 8

Map list atm_apple: PERMANENT
appletalk 62000.5 maps to NSAP CD.CDEF.01.234567.890A.BCDE.F012.3456.7890.1234.12,
broadcast, aal5mux, multipoint connection up, VC 4
appletalk 62000.6 maps to NSAP DE.CDEF.01.234567.890A.BCDE.F012.3456.7890.1234.12,
broadcast, aal5mux, multipoint connection up, VC 4
```

The following is sample output from the **show atm map** command if you configure an ATM PVC using the **pvc** command:

```
Router# show atm map
```

```
Map list endA: PERMANENT
ip 10.11.11.1 maps to VC 4, VPI 0, VCI 60, ATM0.2
```

The following sample output from the **show atm map** command shows the link-local and global IPv6 addresses (FE80::60:3E47:AC8:C and 2001:0DB8:2222::72, respectively) of a remote node that are explicitly mapped to PVC 1/32 of ATM interface 0;

```
Router# show atm map
```

```
Map list ATM0pvc1 : PERMANENT
ipv6 FE80::60:3E47:AC8:C maps to VC 1, VPI 1, VCI 32, ATM0
, broadcast
ipv6 2001:0DB8:2222::72 maps to VC 1, VPI 1, VCI 32, ATM0
```

Table 16 describes the significant fields shown in the displays.

Table 16 *show atm map Field Descriptions*

Field	Description
Map list	Name of map list.
PERMANENT	This map entry was entered from configuration; it was not entered automatically by a process.
ip 172.21.168.110 maps to VC 1 or ip 10.4.4.6 maps to NSAP DE.CDEF.01.234567.890A.BCDE.F012.345 6.7890.1234.12	Name of protocol, the protocol address, and the virtual circuit descriptor (VCD) or network service access point (NSAP) to which the address is mapped (for ATM VCs configured with the atm pvc command).
broadcast	Indicates pseudobroadcasting.
ip 10.11.11.1 maps to VC 4, VPI 0, VCI 60, ATM0.2 or ip 10.4.4.6 maps to NSAP DE.CDEF.01.234567.890A.BCDE.F012.345 6.7890.1234.12	Name of protocol, the protocol address, the virtual path identifier (VPI) number, the virtual channel identifier (VCI) number, and the ATM interface or subinterface (for ATM PVCs configured using the pvc command). or Name of the protocol, the protocol address, and the NSAP to which the address is mapped (for ATM switched virtual circuits (SVCs) configured using the svc command).
aal5mux	Indicates the encapsulation used, a multipoint or point-to-point VC, and the number of the virtual circuit.
multipoint connection up	Indicates that this is a multipoint VC.
VC 6	Number of the VC.
connection up	Indicates a point-to-point VC.
VPI	VPI for the VC.
VCI	VCI for the VC.
ATM1/0.52	ATM interface or subinterface number.
Map list	Name of the bundle whose mapping information follows.
ip 10.1.1.1 maps to bundle san-jose, 0/122, 0/123, 0/124, 0/126	IP address of the bundle and VC members that belong to the bundle.

Related Commands

Command	Description
protocol (ATM)	Configures a static map for an ATM PVC, SVC, VC class, or VC bundle. Enables Inverse ARP or Inverse ARP broadcasts on an ATM PVC by either configuring Inverse ARP directly on the PVC, on the VC bundle, or in a VC class (applies to IP and IPX protocols only).
protocol ipv6 (ATM)	Maps the IPv6 address of a remote node to the ATM PVC used to reach the address.

Command	Description
pvc	Creates or assigns a name to an ATM PVC, specifies the encapsulation type on an ATM PVC, or enters interface-ATM-VC configuration mode.
show atm bundle	Displays the bundle attributes assigned to each bundle VC member and the current working status of the VC members.
show atm bundle statistics	Displays statistics on the specified bundle.
svc	Creates an ATM SVC and specifies destination NSAP address on an interface or subinterface.

show atm pvc

To display all ATM permanent virtual connections (PVCs) and traffic information, use the **show atm pvc** command in privileged EXEC mode.

show atm pvc [**interface atm** *interface-number* [*.subinterface*] *vpi/vci* **vaccess** [*detail*]]

Syntax Description	
<i>vpi/vci</i>	(Optional) ATM virtual path identifier (VPI) and virtual channel identifier (VCI) numbers. The absence of the slash character (/) and a <i>vpi</i> value causes the <i>vpi</i> value to default to 0.
interface atm <i>interface-number</i>	(Optional) Displays all PVCs on the specified ATM interface. To determine the appropriate form of the <i>interface-number</i> argument, consult your ATM network module, port adapter, or router documentation.
<i>.subinterface-number</i>	(Optional) Subinterface number in the range from 1 to 4294967293. The dot (.) is required as a separator between <i>interface-number</i> and <i>subinterface-number</i> .
<i>vpi/vci</i>	(Optional) Displays the names of all of the virtual access interfaces associated with the PVC <i>vpi/vci</i> on the ATM subinterface you specify.
vaccess <i>detail</i>	Displays information about the virtual access interfaces associated with the PVC <i>vpi/vci</i> on the ATM subinterface you specify.

Command Default All ATM PVCs are displayed.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	11.3T	This command was introduced.
	12.1(1)T	This command was modified to display PPP over Ethernet (PPPoE) status.
	12.2(4)T	This command was modified to display only PVCs that are attached to a virtual access interface. Before this modification, all PVCs that were configured with PPP over ATM (PPPoA) or PPPoE were displayed.
	12.0(23)S	This command was modified to display OAM cell emulation status for Any Transport over MPLS (AToM).
	12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
	12.3(7)T	This command was modified to display information about multilink PPP over ATM link fragmentation and interleaving for ATM PVCs.
	12.0(30)S	This command was modified to display information about OAM loopback detection.
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.

Release	Modification
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
12.2(31)SB10	This command was modified to display information about OAM loopback detection.
Cisco IOS XE Release 2.3	This command was implemented on the Cisco ASR 1000 series routers.
15.0(1)M	This command was integrated into Cisco IOS Release 15.0(1)M.

Usage Guidelines

If you do not specify the *vpilvci* or *name* argument, the output of this command is the same as that of the **show atm vc** command, but only the configured PVCs appear.

If you specify the *vpilvci* or *name* argument, the output of this command is the same as that of the **show atm vc vcd** command, with extra information related to PVC management, including connection name, detailed states, and Operation, Administration, and Maintenance (OAM) counters. Do not attempt to configure virtual circuit numbers 3 and 4 as these virtual circuits are reserved for OAM.

If you include the **interface atm interface-number** argument in the command, the output of this command displays all of the PVCs under that interface or subinterface. If you include the *vpilvci vaccess* argument, the command output displays the names of all of the virtual access interfaces associated with the PVC on the ATM interface. If you include the *vpilvci vaccess detail* argument, the command output displays detailed virtual access interface information.

The functionality and output of the **show atm pvc {interface atm interface-number vpilvci}** command are unchanged.

Examples

The following is sample output from the **show atm pvc** command. The output is the same as that of the **show atm vc** command, but only the configured PVCs appear.

```
Router# show atm pvc
```

Interface	VCD/ Name	VPI	VCI	Type	Encaps	Peak Kbps	Avg/Min Kbps	Burst Cells	Sts
2/0	1	0	5	PVC	SAAL	155000	155000		UP
2/0	2	0	16	PVC	ILMI	155000	155000		UP
2/0.2	101	0	50	PVC	SNAP	155000	155000		UP
2/0.2	102	0	60	PVC	SNAP	155000	155000		DOWN
2/0.2	104	0	80	PVC	SNAP	155000	155000		UP
2/0	hello	0	99	PVC	SNAP	1000			UP

The following is sample output from the **show atm pvc** command with the *vpilvci* argument specified:

```
Router# show atm pvc 0/41
```

```
ATM2/0: VCD: 3, VPI: 0, VCI: 41
UBR, PeakRate: 155000
AAL5-LLC/SNAP, etype:0x0, Flags: 0xC20, VCmode: 0x0
OAM frequency: 0 second(s), OAM retry frequency: 1 second(s), OAM retry frequency: 1
second(s)
OAM up retry count: 3, OAM down retry count: 5
OAM Loopback status: OAM Disabled
OAM VC state: Not Managed
OAM Loop detection: Disabled
ILMI VC state: Not Managed
```

```

InARP frequency: 15 minutes(s)
InPkts: 31759, OutPkts: 26497, InBytes: 2356434, OutBytes: 1589743
InPProc: 15785, OutPProc: 26472, Broadcasts: 0
InFast: 20, OutFast: 20, InAS: 15954, OutAS: 6
OAM cells received: 0
F5 InEndloop: 0, F5 InSegloop: 0, F5 InAIS: 0, F5 InRDI: 0
F4 InEndloop: 0, F4 InSegloop: 0, F4 InAIS: 0, F4 InRDI: 0
OAM cells sent: 0
F5 OutEndloop: 0, F5 OutSegloop: 0, F5 OutRDI: 0
F4 OutEndloop: 0, F4 OutSegloop: 0, F4 OutRDI: 0
OAM cell drops: 0
Status: UP
PPPOE enabled.

```

The following sample output from the **show atm pvc** command displays OAM cell emulation statistics, which are marked in this example by exclamation points:

```

Router# show atm pvc 5/500

ATM4/1/0.200: VCD: 6, VPI: 5, VCI: 500
UBR, PeakRate: 1
AAL5-LLC/SNAP, etype:0x0, Flags: 0x34000C20, VCmode: 0x0
OAM Cell Emulation: enabled, F5 End2end AIS Xmit frequency: 1 second(s) !!!
OAM frequency: 0 second(s), OAM retry frequency: 1 second(s)
OAM up retry count: 3, OAM down retry count: 5
OAM Loopback status: OAM Disabled
OAM VC state: Not ManagedVerified
OAM Loop detection: Disabled
ILMI VC state: Not Managed
InPkts: 564, OutPkts: 560, InBytes: 19792, OutBytes: 19680
InPProc: 0, OutPProc: 0
InFast: 4, OutFast: 0, InAS: 560, OutAS: 560
InPktDrops: 0, OutPktDrops: 0
CrcErrors: 0, SarTimeOuts: 0, OverSizedSDUs: 0
Out CLP=1 Pkts: 0
OAM cells received: 26
F5 InEndloop: 0, F5 InSegloop: 0, F5 InAIS: 0, F5 InRDI: 26
OAM cells sent: 77
F5 OutEndloop: 0, F5 OutSegloop: 0, F5 OutAIS: 77, F5 OutRDI: 0 !!!
OAM cell drops: 0
Status: UP

```

The following is sample output from the **show atm pvc** command with the ATM subinterface specified:

```
Router# show atm pvc interface atm 2/0.2
```

Interface	VCD/ Name	VPI	VCI	Type	Encaps	Peak Kbps	Avg/Min Kbps	Burst Cells	Sts
2/0.2	101	0	50	PVC	SNAP	155000	155000		UP
2/0.2	102	0	60	PVC	SNAP	155000	155000		DOWN
2/0.2	104	0	80	PVC	SNAP	155000	155000		UP

The following is sample output for the **show atm pvc** command for a PVC that is a member of a multilink PPP bundle:

```
Router# show atm pvc 15/200
```

```

ATM4/0.10000:VCD:16, VPI:15, VCI:200
UBR, PeakRate:149760 (353208 cps)
AAL5-LLC/SNAP, etype:0x0, Flags:0xC20, VCmode:0x0, Encaps:12
OAM frequency:0 second(s), OAM retry frequency:1 second(s)
OAM up retry count:3, OAM down retry count:5
OAM Loopback status:OAM Disabled
OAM VC State:Not Managed

```

```

OAM Loop detection: Disabled
ILMI VC status:Not Managed
VC TxRingLimit:40 particles
VC Rx Limit:800 particles
InARP frequency:15 minutes(s)
Transmit priority 6
InPkts:347, OutPkts:399, InBytes:6268, OutBytes:7728
InCells:347, OutCells:399
InPRoc:7, OutPRoc:228
InFast:338, OutFast:169, InAS:0, OutAS:0
InPktDrops:0, OutPktDrops:0/0/0 (holdq/outputq/total)
InCellDrops:0, OutCellDrops:0
InByteDrops:0, OutByteDrops:0
CrcErrors:0, SarTimeOuts:0, OverSizedSDUs:0, LengthViolation:0, CPIErrors:0
Out CLP=1 Pkts:0, Cells:0
OAM cells received:0
F5 InEndloop:0, F5 InSegloop:0, F5 InAIS:0, F5 InRDI:0
F4 InEndloop:0, F4 InSegloop:0, F4 InAIS:0, F4 InRDI:0
OAM cells sent:0
F5 OutEndloop:0, F5 OutSegloop:0, F5 OutRDI:0
F4 OutEndloop:0, F4 OutSegloop:0, F4 OutRDI:0
OAM cell drops:0
Status:UP
PPP:Virtual-Access3 from Virtual-Template1
PPPoA Current State = LOCALLY_TERMINATED
PPPoA Latest Event = Vaccess Up
PPPoA Latest Error = None
PPPoA Session ID = 7
PPPoA Handle = 0x4D000006, SSS Handle = 0x00000000
Switch Handle = 0xB5000006, PPP Handle = 0xD700000A
AAA Unique ID = 0x00000007, AIE Handle = 0xE7000006
PVC belongs to Multilink PPP Bundle Virtual-Access4 as a PPPoA member link
Packets in VC Holdq:0 , Particles in VC Tx Ring:0

```

The following is sample output from the **show atm pvc** command with loopback detection mode through OAM enabled:

```
Router# show atm pvc 4/100
```

```

ATM1/0: VCD: 4, VPI: 4, VCI: 100
UBR, PeakRate: 149760
AAL5-LLC/SNAP, etype:0x0, Flags: 0xC20, VCmode: 0x0
!
OAM frequency: 10 second(s), OAM retry frequency: 1 second(s)
OAM up retry count: 3, OAM down retry count: 5
OAM Loopback status: OAM Received
OAM VC state: Verified
OAM Loop detection: Enabled ! Indicates that loopback mode detection is enabled.
!
ILMI VC state: Not Managed
VC is managed by OAM.
InARP frequency: 15 minutes(s)
Transmit priority 4
InPkts: 0, OutPkts: 0, InBytes: 0, OutBytes: 0
InPRoc: 0, OutPRoc: 0, Broadcasts: 0
InFast: 0, OutFast: 0, InAS: 0, OutAS: 0
InPktDrops: 0, OutPktDrops: 0
CrcErrors: 0, SarTimeOuts: 0, OverSizedSDUs: 0
Out CLP=1 Pkts: 0
OAM cells received: 27
F5 InEndloop: 27, F5 InSegloop: 0, F5 InAIS: 0, F5 InRDI: 0
OAM cells sent: 27
F5 OutEndloop: 27, F5 OutSegloop: 0, F5 OutAIS: 0, F5 OutRDI: 0
OAM cell drops: 3

```


Status: UP

The following is sample output from the **show atm pvc** command when loopback mode is detected:

```
Router# show atm pvc 4/100
```

```
ATM1/0: VCD: 4, VPI: 4, VCI: 100
UBR, PeakRate: 149760
AAL5-LLC/SNAP, etype:0x0, Flags: 0xC20, VCmode: 0x0
!
OAM frequency: 10 second(s), OAM retry frequency: 1 second(s)
OAM up retry count: 3, OAM down retry count: 5
OAM Loopback status: OAM Sent
OAM VC state: Not Verified
OAM Loop detection: Enabled, Detected ! Indicates that loopback mode has been detected on
this interface.
!
ILMI VC state: Not Managed
VC is managed by OAM.
InARP frequency: 15 minutes(s)
Transmit priority 4
InPkts: 0, OutPkts: 0, InBytes: 0, OutBytes: 0
InPRoc: 0, OutPRoc: 0, Broadcasts: 0
InFast: 0, OutFast: 0, InAS: 0, OutAS: 0
InPktDrops: 0, OutPktDrops: 0
CrcErrors: 0, SarTimeOuts: 0, OverSizedSDUs: 0
Out CLP=1 Pkts: 0
OAM cells received: 20
F5 InEndloop: 20, F5 InSegloop: 0, F5 InAIS: 0, F5 InRDI: 0
OAM cells sent: 20
F5 OutEndloop: 20, F5 OutSegloop: 0, F5 OutAIS: 0, F5 OutRDI: 0
OAM cell drops: 1
Status: DOWN, State: NOT_VERIFIED
```

Cisco 10000 Series Router

The following example shows sample output from the **show atm pvc interface atm interface-number vpi/vci vaccess** command. In the output, the *vpi/vci vaccess* option causes the name of all of the virtual access interfaces (VAIs) to appear. These VAIs are associated with PVC 100/1000 on ATM subinterface ATM 3/0/0.6.

```
Router# show atm pvc interface atm3/0/0.6 100/1000 vaccess
          VCD / ProtocolVirtual Access
InterfaceNameVPI VCInterface
ATM3/0/0.63100 1000pppoeVi3.1
```

The following example shows sample output when using the **show atm pvc interface atm interface-number vpi/vci vaccess detail** command. The output is similar to the output that appears when you use the **show interface virtual-access-number** command.

```
Router# show atm pvc interface atm3/0/0.6 100/1000 vaccess detail
ATM3/0/0.6: VCD: 3 VPI: 100 VCI: 1000
Virtual-Access3.1 is up, line protocol is up
Hardware is Virtual Access interface
Internet address will be negotiated using IPCP
MTU 1492 bytes, BW 599040 Kbit, DLY 100000 usec,
reliability 255/255, txload 1/255, rxload 1/255
Encapsulation PPP, LCP Open
Stopped: IPCP
PPPoE vaccess, cloned from Virtual-Template1
Vaccess status 0x0
PPPoE Bound to ATM3/0/0.6 VCD: 3, VPI: 100, VCI: 1000
Keepalive set (10 sec)
```

3 packets input, 50 bytes
 3 packets output, 44 bytes
 Last clearing of "show interface" counters never

Table 17 describes the significant fields shown in the displays.

Table 17 *show atm pvc Field Descriptions*

Field	Description
Interface	Interface and subinterface slot and port.
VCD/Name	Virtual connection descriptor (virtual connection number). The connection name is displayed if a name for the VC was configured using the pvc command.
VPI	Virtual path identifier.
VCI	Virtual channel identifier.
Type	Type of PVC detected from PVC discovery; either PVC-D, PVC-L, or PVC-M: - PVC-D—PVC created as a result of PVC discovery. - PVC-L—The corresponding peer of this PVC could not be found on the switch. - PVC-M—Some or all of the QoS¹ parameters of this PVC fail to match those of the corresponding peer on the switch.
Encaps	Type of ATM adaptation layer (AAL) and encapsulation.
Peak or PeakRate	Kilobits per second sent at the peak rate.
Avg/Min or Average Rate	Kilobits per second sent at the average rate.
Burst Cells	Maximum number of ATM cells that the VC can send at peak rate.
Sts or Status	Status of the VC connection: - UP—The connection is enabled for data traffic. - DOWN—The connection is not ready for data traffic. When the Status field is DOWN, a State field is shown. See a description of the different values for the State field later in this table. - INACTIVE—The interface is down.
Connection Name	Name of the PVC.
UBR, UBR+, or VBR-NRT	- UBR—Unspecified bit rate QoS is specified for this PVC. See the ubr command for further information. - UBR+—Unspecified bit rate QoS is specified for this PVC. See the ubr+ command for further information. - VBR-NRT—Variable bit rate–non-real-time QoS rates are specified for this PVC. See the vbr-nrt command for further information.
etype	Encapsulation type.

Table 17 *show atm pvc Field Descriptions (continued)*

Field	Description
Flags	Bit mask describing VC information. The flag values are summed to result in the displayed value: • 0x40—SVC • 0x20—PVC • 0x10—ACTIVE • 0x0—AAL5-SNAP • 0x1—AAL5-NLPID • 0x2—AAL5-FRNLPID • 0x3—AAL5-MUX • 0x4—AAL3/4-SMDS • 0x5—QSAAL • 0x6—ILMI • 0x7—AAL5-LANE • 0x9—AAL5-CISCOPPP
virtual-access	Virtual-access interface identifier.
virtual-template	Virtual template identifier.
VCmode	AIP-specific or NPM-specific register describing the usage of the VC. This register contains values such as rate queue, peak rate, and AAL mode, which are also displayed in other fields.
OAM Cell emulation	The status of the OAM cell emulation functionality. It is either enabled or disabled.
F5 end2end AIS xmit frequency	Number of seconds between transmissions of AIS cells.
OAM frequency	Number of seconds between transmissions of OAM loopback cells.
OAM retry frequency	Frequency (in seconds) at which end-to-end F5 loopback cells should be sent when a change in state (up or down) is being verified. For example, if a PVC is up and a loopback cell response is not received after the value of the <i>frequency</i> argument (in seconds) specified using the oam-pvc command, loopback cells are sent at the value of the <i>retry-frequency</i> argument to determine whether the PVC is down.
OAM up retry count	Number of consecutive end-to-end F5 OAM loopback cell responses that must be received in order to change a PVC state to up. Does not apply to SVCs.
OAM down retry count	Number of consecutive end-to-end F5 OAM loopback cell responses that if not received, change a PVC state to down or tear down an SVC.

Table 17 *show atm pvc Field Descriptions (continued)*

Field	Description
OAM Loopback status	Status of end-to-end F5 OAM loopback cell generation for this VC. This field will have one of the following values: • OAM Disabled—End-to-end F5 OAM loopback cell generation is disabled. • OAM Sent—OAM cell was sent. • OAM Received—OAM cell was received. • OAM Failed—OAM reply was not received within the frequency period or contained a bad correlation tag.
OAM VC state	This field will have one of the following states for this VC: • AIS²/RDI³—The VC received AIS/RDI cells. End-to-end F5 OAM loopback cells are not sent in this state. • Down Retry—An OAM loopback failed. End-to-end F5 OAM loopback cells are sent at retry frequency to verify that the VC is really down. After down-count unsuccessful retries, the VC goes to the Not Verified state. • Not Managed—VC is not being managed by OAM. • Not Verified—VC has not been verified by end-to-end F5 OAM loopback cells. AIS and RDI conditions are cleared. • Up Retry—An OAM loopback was successful. End-to-end F5 OAM loopback cells are sent at retry frequency to verify that the VC is really up. After up-count successive and successful loopback retries, the VC goes to the Verified state. • Verified—Loopbacks are successful. AIS/RDI cell was not received.
OAM Loop detection	Status of loopback detection mode through OAM: • Disabled—Automatic loopback detection is disabled. • Enabled—Automatic loopback detection is enabled. • Detected—Loopback mode is detected on an ATM interface.
ILMI VC state	This field will have one of the following states for this VC: • Not Managed—VC is not being managed by ILMI⁴. • Not Verified—VC has not been verified by ILMI. • Verified—VC has been verified by ILMI.
VC is managed by OAM/ILMI	VC is managed by OAM or ILMI.
InARP frequency	Number of minutes for the Inverse Address Resolution Protocol time period.
InPkts	Total number of packets received on this VC. This number includes all fast-switched and process-switched packets.
OutPkts	Total number of packets sent on this VC. This number includes all fast-switched and process-switched packets.
InBytes	Total number of bytes received on this VC. This number includes all fast-switched and process-switched bytes.

Table 17 *show atm pvc Field Descriptions (continued)*

Field	Description
OutBytes	Total number of bytes sent on this VC. This number includes all fast-switched and process-switched bytes.
InPRoc	Number of process-switched input packets.
OutPRoc	Number of process-switched output packets.
Broadcasts	Number of process-switched broadcast packets.
InFast	Number of fast-switched input packets.
OutFast	Number of fast-switched output packets.
InAS	Number of autonomous-switched or silicon-switched input packets.
OutAS	Number of autonomous-switched or silicon-switched output packets.
OAM cells received	Total number of OAM cells received on this VC.
F5 InEndloop	Number of end-to-end F5 OAM loopback cells received.
F5 InSegloop	Number of segment F5 OAM loopback cells received.
F5 InAIS	Number of F5 OAM AIS cells received.
F5 InRDI	Number of F5 OAM RDI cells received.
F4 InEndloop	Number of end-to-end F4 OAM loopback cells received.
F4 InSegloop	Number of segment F4 OAM loopback cells received.
F4 InAIS	Number of F4 OAM AIS cells received.
F4 InRDI	Number of F4 OAM RDI cells received.
OAM cells sent	Total number of OAM cells sent on this VC.
F5 OutEndloop	Number of end-to-end F5 OAM loopback cells sent.
F5 OutSegloop	Number of segment F5 OAM loopback cells sent.
F5 OutRDI	Number of F5 OAM RDI cells sent.
OAM cell drops	Number of OAM cells dropped (or flushed).
PVC Discovery	• NOT_VERIFIED—This PVC is manually configured on the router and not yet verified with the attached adjacent switch. • WELL_KNOWN—This PVC has a VCI value of 0 through 31. • DISCOVERED—This PVC is learned from the attached adjacent switch via ILMI. • MIXED—Some of the traffic parameters for this PVC were learned from the switch via ILMI. • MATCHED—This PVC is manually configured on the router, and the local traffic-shaping parameters match the parameters learned from the switch. • MISMATCHED—This PVC is manually configured on the router, and the local traffic-shaping parameters do not match the parameters learned from the switch. • LOCAL_ONLY—This PVC is configured locally on the router and not on the remote switch.

Table 17 *show atm pvc Field Descriptions (continued)*

Field	Description
Status	When the Status field indicates UP, the VC is established. When the Status field indicates DOWN, refer to the State field for further information about the VC state.
State	When the Status field is UP, this field does not appear. When the Status field is DOWN or INACTIVE, the State field will appear with one of the following values: • NOT_VERIFIED—The VC has been established successfully; waiting for OAM (if enabled) and ILMI (if enabled) to verify that the VC is up. • NOT_EXIST—VC has not been created. • HASHING_IN—VC has been hashed into a hash table. • ESTABLISHING—Ready to establish VC connection. • MODIFYING—VC parameters have been modified. • DELETING—VC is being deleted. • DELETED—VC has been deleted. • NOT_IN_SERVICE—ATM interface is shut down.
PPP	For PPP over ATM, indicates the virtual access interface number and virtual template number being used.
PPPoA Current State	State of the PPPoA session associated with the VC.
PPPoA Latest Event	The latest event that occurred on the PPPoA session associated with the VC.
PPPoA Latest Error	The latest error that occurred on the PPPoA session associated with the VC.
PPPoA Session ID	PPPoA session identifier of the PPPoA session associated with the VC.
PPPoA Handle	PPPoA context handle.
SSS Handle	SSS handle for PPPoA session associated with the VC.
Switch Handle	SSS handle for switch management.
PPP Handle	Handle associated with the PPP context.
AAA Unique ID	Unique identifier associated with the AAA session.
AIE Handle	Access IE handle for the PPPoA session.
Packets in VC Holdq	Number of packets in the hold queue of the VC.
Particles in VC Tx Ring	Number of particles in the Tx ring of the VC.

1. QoS = quality of service
2. AIS = alarm indication signal
3. RDI = remote defect identification
4. ILMI = Interim Local Management Interface

Related Commands

Command	Description
show atm svc	Displays all ATM SVCs and traffic information.
show atm vc	Displays all ATM PVCs and SVCs and traffic information.

Related Commands	Command	Description
	show atm svc	Displays all ATM switched virtual circuits (SVCs) and traffic information.
	show atm vc	Displays all ATM permanent virtual circuits (PVCs) and switched virtual circuits (SVCs) and traffic information.

show atm pvc dbs

To display all ATM permanent virtual circuits (PVCs) that have Dynamic Subscriber Bandwidth Selection (DBS) quality of service (QoS) parameters applied, use the **show atm pvc dbs** command in privileged EXEC mode.

show atm pvc dbs

Syntax Description This command has no arguments or keywords.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(4)B	This command was introduced.
	12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines Use the **show atm pvc dbs** command to display information about ATM PVCs that have DBS QoS parameters applied. To view information about all ATM PVCs in your system, use the **show atm pvc** command.

Examples The following example displays information about ATM PVCs that have DBS QoS parameters applied:

```
Router# show atm pvc dbs
```

Interface	VCD / Name	VPI	VCI	Type	Encaps	SC	Peak Kbps	Avg/Min Kbps	Burst Cells	Sts
1/0.7	3	0	95	PVC	MUX	VBR	2000	700	94	UP

Table 18 describes the significant fields shown in the display.

Table 18 *show atm pvc dbs Field Descriptions*

Field	Description
Interface	Identifies the interface and subinterface and the slot number.
VCD/Name	Identifies the Virtual Connection Descriptor (VCD). The connection name is displayed when a name for the virtual circuit was defined using the pvc command.
VPI	Identifies the network virtual path identifier (VPI) name for this PVC.

Table 18 *show atm pvc dbs Field Descriptions (continued)*

Field	Description
VCI	Identifies the ATM network virtual channel identifier (VCI) for the PVC.
Type	Identifies the type of PVC detected from PVC Discovery. - PVC-D—Indicates a PVC created due to PVC Discovery. - PVC-L—Indicates that the corresponding peer of this PVC could not be found on the switch. - PVC-M—Indicates that some or all of the QoS parameters of this PVC do not match the QoS parameters of the corresponding peer.
Encaps	Identifies the ATM encapsulation type of the VC.
SC	Identifies the service category for the VC.
Peak Kbps	Identifies the number of kilobits per second sent at the peak rate.
Avg/Min Kbps	Identifies the number of kilobits per second sent at the average rate.
Burst Cells	Identifies the burst cell size in terms of number of cells. This number is the maximum number of ATM cells the VC can send at the peak rate.
Sts	Identifies the status of the virtual circuit.

Related Commands

Command	Description
dbs enable	Enables DBS.
pvc	Creates or assigns a name to an ATM PVC, specifies the encapsulation type on an ATM PVC, or enters interface-ATM-VC configuration mode.
pvc-in-range	Configures an individual PVC within a PVC range.
range pvc	Defines a range of ATM PVCs.
show atm pvc	Displays all ATM PVCs and traffic information.
vc-class atm	Configures a VC class for an ATM VC or interface.

show atm signalling statistics

To display ATM signaling statistics counters, use the **show atm signalling statistics** command in user EXEC or privileged EXEC mode.

show atm signalling statistics [*interface type number*]

Syntax Description

interface type number (Optional) Specifies the interface type and number.

Command Default

If the interface is not specified, global signalling statistics counters are displayed.

Command Modes

User EXEC (>)
Privileged EXEC (#)

Command History

Release	Modification
12.4(24)T	This command was introduced in a release earlier than Cisco IOS Release 12.4(24)T.
12.2(33)SRC	This command was integrated into a release earlier than Cisco IOS Release 12.2(33)SRC.
12.2(33)SXI	This command was integrated into a release earlier than Cisco IOS Release 12.2(33)SXI.

Examples

The following is sample output from the **show atm signalling statistics** command:

```
Router# show atm signalling statistics interface atm 6/0
```

```
ATM ATM6/0   UP Time 1d16h   # of int resets: 1
```

```
-----
Conn-Pending: 0          Conn-Pending High Water Mark: 0
Calls Throttled: 0      Max-Conn-Pending: 40
```

```

      Messages:   Incoming   Outgoing
      -----
PTP Setup Messages:      0         0
MTP Setup Messages:      0         0
Release Messages:        0         0
Restart Messages:        0         0
Status Enq Messages:     0         0
Status Messages:         0         0
```

```
Message:   Received Transmitted Tx-Reject Rx-Reject
Add Party Messages:      0         0         0         0
```

```

      Failure Cause:   Routing   CAC   Access-list   Addr-Reg   Misc-Failure
Location Local:       0         0         0         0         0
```

```
Location Remote:          0          0          0          0          0
```

Table 19 describes the significant fields shown in the display.

Table 19 *show atm signalling statistics Field Descriptions*

Field	Description
Conn-Pending	Indicates the number of pending connections.
Conn-Pending High Water Mark	Indicates the peak number of connections on the controller.
Calls Throttled	Displays the number of calls throttled.
Max-Conn-Pending	Indicates the maximum number of pending connections the controller can accept.
Messages	Indicates the type of messages.
Incoming	Indicates the number of incoming messages for the specified type.
Outgoing	Indicates the number of outgoing messages for the specified type.
Add Party Messages	Indicates the number of additional third-party messages.
Failure Cause	Indicates the cause for the connection failure. The possible causes are as follows: Issues in routing, problems with call admission control (CAC), errors in access lists, errors in address registry, or miscellaneous types of failures.
Location Local	Indicates if the failure occurred at a local location.
Location Remote	Indicates if the failure occurred at a remote location.

Related Commands

Command	Description
atm sig-traffic-shaping strict	Specifies that an SVC should be established on an ATM interface only if shaping can be done in accordance with the signaled traffic parameters.

show atm svc

To display all ATM switched virtual circuits (SVCs) and traffic information, use the **show atm svc** command in privileged EXEC mode.

show atm svc [*vpilvci* | *name* | **interface atm** *interface-number*]

Syntax Description

<i>vpilvci</i>	(Optional) The ATM VPI and VCI numbers. The absence of the slash character (/) and a <i>vpi</i> value causes the <i>vpi</i> value to default to 0.
<i>name</i>	(Optional) Name of the SVC.
interface atm <i>interface-number</i>	(Optional) Interface number or subinterface number of the SVC. Displays all SVCs on the specified interface or subinterface. The <i>interface-number</i> argument uses one of the following formats, depending on what router platform you are using: - For the AIP on Cisco 7500 series routers; For the ATM port adapter, ATM-CES port adapter, and enhanced ATM port adapter on Cisco 7200 series routers; For the 1-port ATM-25 network module on Cisco 2600 and 3600 series routers: <i>slot</i>/0[.<i>subinterface-number</i> multipoint] - For the ATM port adapter and enhanced ATM port adapter on Cisco 7500 series routers: <i>slot</i>/<i>port-adapter</i>/0[.<i>subinterface-number</i> multipoint] - For the NPM on Cisco 4500 and 4700 routers: <i>number</i>[.<i>subinterface-number</i> multipoint] For a description of these arguments, refer to the interface atm command.

Command Modes

Privileged EXEC

Command History

Release	Modification
11.3	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

If the *vpilvci* or *name* argument is not specified, the output of this command is the same as that of the **show atm vc** command but only the configured SVCs are displayed. See the first sample output below, which uses the **show atm svc** command without any of the optional arguments.

If the *vpi/vci* or *name* argument is specified, the output of this command is the same as the **show atm vc vcd** command, plus extra information related to SVC management including connection name, detailed states, and OAM counters. See the second sample output below, which uses the **show atm svc** command with the *vpi/vci* specified as 0/34.

If the **interface atm interface-number** option is included in the command, all SVCs under that interface or subinterface are displayed. See the third sample output below, which uses the **show atm svc** command with the ATM subinterface specified as 2/0.2.

Examples

The following is sample output from the **show atm svc** command:

```
Router# show atm svc
```

Interface	VCD/ Name	VPI	VCI	Type	Encaps	Peak Kbps	Avg/Min Kbps	Burst Cells	Sts
2/0.2	4	0	32	SVC	SNAP	155000	155000		UP
2/0.2	3	0	33	SVC	SNAP	155000	155000		UP
2/0.1	5	0	34	SVC	SNAP	155000			UP
2/0.2	6	0	35	SVC	SNAP	155000	155000		UP

The following is sample output from the **show atm svc** command with VPI 0 and VCI 34 specified:

```
Router# show atm svc 0/34
```

```
ATM2/0.1: VCD: 5, VPI: 0, VCI: 34
UBR, PeakRate: 155000
AAL5-LLC/SNAP, etype: 0x0, Flags 0x440, VCmode: 0xE000
OAM frequency: 0 second(s), OAM retry frequency: 1 second(s)
OAM up retry count: 3, OAM down retry count: 5
OAM Loopback status: OAM Disabled
OAM VC state: Not Managed
ILMI VC state: Not Managed
InARP DISABLED
InPkts: 4, OutPkts: 4, InBytes: 432, OutBytes: 432
InPRoc: 4, OutPRoc: 4, Broadcasts: 0
InFast: 0, OutFast: 0, InAS: 0, OutAS: 0
OAM cells received: 0
F5 InEndloop: 0, F5 InSegloop: 0, F5 InAIS: 0, F5 InRDI:0
F4 InEndloop: 0, F4 InSegloop: 0, F4 InAIS: 0, F4 InRDI:0
OAM cells sent: 0
F5 OutEndloop: 0, F5 OutSegloop: 0, F5 OutRDI: 0
OAM cell drops: 0
Status: UP
TTL: 3
interface = ATM2/0.2, call locally initiated, call reference = 8388610
vcnum = 5, vpi = 0, vci = 34, state = Active(U10), point-to-point call
Retry count: Current = 0
timer currently inactive, timer value = 00:00:00
Remote Atm Nsap address:47.00918100000000400B0A2501.0060837B4743.00, VCowner:Static Map
```

The following is sample output from the **show atm svc interface atm interface-number** command:

```
Router# show atm svc interface atm 2/0.2
```

Interface	VCD/ Name	VPI	VCI	Type	Encaps	Peak Kbps	Avg/Min Kbps	Burst Cells	Sts
2/0.2	4	0	32	SVC	SNAP	155000	155000		UP
2/0.2	3	0	33	SVC	SNAP	155000	155000		UP
2/0.2	6	0	35	SVC	SNAP	155000	155000		UP

Table 20 describes significant fields shown in the displays.

Table 20 *show atm svc Field Descriptions*

Field	Description
Interface	Interface and subinterface slot and port.
VCD/Name	Virtual circuit descriptor (virtual circuit number). The connection name is displayed if a name for the VC was configured using the svc command.
VPI	Virtual path identifier.
VCI	Virtual channel identifier.
Type	Type of virtual circuit, either SVC or MSVC (multipoint SVC). - MSVC (with no -x) indicates that VCD is a leaf of some other router's multipoint VC. - MSVC-x indicates there are x leaf routers for that multipoint VC opened by the root.
Encaps	Type of ATM adaptation layer (AAL) and encapsulation.
Peak or PeakRate	Kilobits per second transmitted at the peak rate.
Avg/Min or Average Rate	Kilobits per second transmitted at the average rate.
Burst Cells	Value that equals the maximum number of ATM cells the virtual circuit can transmit at peak rate.
Sts or Status	Status of the VC connection. - UP indicates that the connection is enabled for data traffic. - DN indicates that the connection is down (not ready for data traffic). When the Status field is DN (down), a State field is shown. See a description of the different values for this field listed later in this table. - IN indicates that the interface is down (inactive).
Connection Name	The name of the SVC.
UBR, UBR+, or VBR-NRT	UBR—Unspecified Bit Rate QoS is specified for this SVC. See the ubr command for further information. UBR+—Unspecified Bit Rate QoS is specified for this SVC. See the ubr+ command for further information. VBR-NRT—Variable Bit Rate–Non Real Time QoS rates are specified for this SVC. See the vbr-nrt command for further information.
etype	Encapsulation type.

Table 20 *show atm svc Field Descriptions (continued)*

Field	Description
Flags	Bit mask describing virtual circuit information. The flag values are summed to result in the displayed value. 0x40—SVC 0x20—PVC 0x10—ACTIVE 0x0—AAL5-SNAP 0x1—AAL5-NLPID 0x2—AAL5-FRNLPID 0x3—AAL5-MUX 0x4—AAL3/4-SMDS 0x5—QSAAL 0x6—ILMI 0x7—AAL5-LANE 0x9—AAL5-CISCOPPP
VCmode	AIP-specific or NPM-specific register describing the usage of the virtual circuit. This register contains values such as rate queue, peak rate, and AAL mode, which are also displayed in other fields.
OAM frequency	Number of seconds between sending OAM loopback cells.
OAM retry frequency	The frequency (in seconds) that end-to-end F5 loopback cells should be transmitted when a change in UP/DN (up/down) state is being verified. For example, if an SVC is up and a loopback cell response is not received after the <i>frequency</i> (in seconds) specified using the oam-svc command, then loopback cells are sent at the <i>retry-frequency</i> to verify whether the SVC is down.
OAM up retry count	Number of consecutive end-to-end F5 OAM loopback cell responses that must be received in order to change a PVC state to up. Does not apply to SVCs.
OAM down retry count	Number of consecutive end-to-end F5 OAM loopback cell responses that are not received in order to change a PVC state to down or tear down an SVC.
OAM Loopback status	Status of end-to-end F5 OAM loopback cell generation for this VC. This field will have one of the following values: • OAM Disabled—End-to-End F5 OAM loopback cell generation is disabled. • OAM Sent—OAM cell was sent. • OAM Received—OAM cell was received. • OAM Failed—OAM reply was not received within the frequency period or contained bad correlation tag.ssss.

Table 20 *show atm svc Field Descriptions (continued)*

Field	Description
OAM VC state	This field will have one of the following states for this VC: • AIS/RDI—The VC received AIS/RDI cells. End-to-end F5 OAM loopback cells are not sent in this state. • Down Retry—An OAM loopback failed. End-to-end F5 OAM loopback cells are sent at retry frequency to verify the VC is really down. After down-count unsuccessful retries, the VC goes to the Not Verified state. • Not Managed—VC is not being managed by OAM. • Not Verified—VC has not been verified by end-to-end F5 OAM loopback cells. AIS and RDI conditions are cleared. • Up Retry—An OAM loopback was successful. End-to-end F5 OAM loopback cells are sent at retry frequency to verify the VC is really up. After up-count successive and successful loopback retries, the VC goes to the Verified state. • Verified—Loopbacks are successful. AIS/RDI cell was not received.
ILMI VC state	This field will have one of the following states for this VC: • Not Managed—VC is not being managed by ILMI. • Not Verified—VC has not been verified by ILMI. • Verified—VC has been verified by ILMI.
VC is managed by OAM/ILMI	VC is managed by OAM and/or ILMI.
InARP frequency	Number of minutes for the Inverse ARP time period.
InPkts	Total number of packets received on this virtual circuit. This number includes all fast-switched and process-switched packets.
OutPkts	Total number of packets sent on this virtual circuit. This number includes all fast-switched and process-switched packets.
InBytes	Total number of bytes received on this virtual circuit. This number includes all fast-switched and process-switched bytes.
OutBytes	Total number of bytes sent on this virtual circuit. This number includes all fast-switched and process-switched bytes.
InPRoc	Number of process-switched input packets.
OutPRoc	Number of process-switched output packets.
Broadcasts	Number of process-switched broadcast packets.
InFast	Number of fast-switched input packets.
OutFast	Number of fast-switched output packets.
InAS	Number of autonomous-switched or silicon-switched input packets.
OutAS	Number of autonomous-switched or silicon-switched output packets.
OAM cells received	Total number of OAM cells received on this virtual circuit.
F5 InEndloop	Number of end-to-end F5 OAM loopback cells received.
F5 InSegloop	Number of segment F5 OAM loopback cells received.

Table 20 *show atm svc Field Descriptions (continued)*

Field	Description
F5 InAIS	Number of F5 OAM AIS cells received.
F5 InRDI	Number of F5 OAM RDI cells received.
F4 InEndloop	Number of end-to-end F4 OAM loopback cells received.
F4 InSegloop	Number of segment F4 OAM loopback cells received.
F4 InAIS	Number of F4 OAM AIS cells received.
F4 InRDI	Number of F4 OAM RDI cells received.
OAM cells sent	Total number of OAM cells sent on this virtual circuit.
F5 OutEndloop	Number of end-to-end F5 OAM loopback cells sent.
F5 OutSegloop	Number of segment F5 OAM loopback cells sent.
F5 OutRDI	Number of F5 OAM RDI cells sent.
OAM cell drops	Number of OAM cells dropped (or flushed).
State	When the Status field is DN (down) or IN (inactive), the State field will appear with one of the following values: NOT_VERIFIED—The VC has been established successfully; Waiting for OAM (if enabled) and ILMI (if enabled) to verify that the VC is up. NOT_EXIST—VC has not been created. HASHING_IN—VC has been hashed into a hash table. ESTABLISHING—Ready to establish VC connection. MODIFYING—VC parameters have been modified. DELETING—VC is being deleted. DELETED—VC has been deleted. NOT_IN_SERVICE—ATM interface is shut down.
TTL	Time-to-live in ATM hops across the VC.
VC owner	IP Multicast address of group.

show atm traffic

To display current, global ATM traffic information to and from all ATM networks connected to the router, use the **show atm traffic** command in privileged EXEC mode.

show atm traffic

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC

Command History

Release	Modification
10.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following is sample output from the **show atm traffic** command for the ATM-CES port adapter on a Cisco 7200 series router:

```
Router# show atm traffic

0 Input packets
1044 Output packets
1021 Broadcast packets
0 Packets received on non-existent VC
0 Packets attempted to send on non-existent VC
0 OAM cells received
0 OAM cells sent
```

The following is sample output from the **show atm traffic** command for the AIP on a Cisco 7500 series router:

```
Router# show atm traffic

276875 Input packets
272965 Output packets
2 Broadcast packets
0 Packets received on non-existent VC
6 Packets attempted to send on non-existent VC
272523 OAM cells received
F5 InEndloop: 272523, F5 InSegloop: 0, F5 InAIS: 0, F5 InRDI: 0
F4 InEndloop: 0, F4 InSegloop: 0, F4 InAIS: 0, F4 InRDI: 0
272963 OAM cells sent
F5 OutEndloop: 272963, F5 OutSegloop: 0, F5 OutRDI: 0
0 OAM cell drops
```

[Table 21](#) describes the fields shown in the display.

Table 21 *show atm traffic Field Descriptions*

Field	Description
Input packets	Total packets input.
Output packets	Total packets output (nonbroadcast).
Broadcast packets	Total broadcast packets output.
Packets received on nonexistent VC	Number of packets sent to virtual circuits not configured.
Packets attempted to send on non-existent VC	Number of packets attempted to be sent on a virtual circuit that were not configured.
OAM cells received	Total Operation, Administration, and Maintenance (OAM) cells received.
F5 InEndloop	Number of end-to-end F5 OAM loopback cells received.
F5 InSegloop	Number of segment F5 OAM loopback cells received.
F5 InAIS	Number of F5 OAM AIS cells received.
F5 InRDI	Number of F5 OAM RDI cells received.
F4 InEndloop	Number of end-to-end F4 OAM loopback cells received.
F4 InSegloop	Number of segment F4 OAM loopback cells received.
F4 InAIS	Number of F4 OAM AIS cells received.
F4 InRDI	Number of F4 OAM RDI cells received.
OAM cells sent	Total number of OAM cells sent on this VC.
F5 OutEndloop	Number of end-to-end F5 OAM loopback cells sent.
F5OutSegloop	Number of segment F5 OAM loopback cells sent.
F5 OutRDI	Number of F5 OAM RDI cells sent.
OAM cell drops	Number of OAM cells dropped (or flushed).

Related Commands

Command	Description
pvc	Configures the PVC interface.
svc	Creates an ATM SVC and specifies the destination NSAP address on a main interface or subinterface.

show atm vc

To display all ATM permanent virtual circuits (PVCs), switched virtual circuits (SVCs), and traffic information, use the **show atm vc** command in privileged EXEC mode.

```
show atm vc [vcd-number] [range lower-limit-vcd upper-limit-vcd] [interface atm
interface-number] [detail [prefix {vpi/vci | vcd | interface | vc_name}] ] [connection-name] |
signalling [freed-svcs] [cast-type {p2mp | p2p}] [detail] [interface atm interface-number]
| summary atm interface-number
```

Syntax Description

<i>vcd-number</i>	(Optional) Specifies a unique virtual circuit descriptor (VCD) number that identifies PVCs within one ATM interface.
range <i>lower-limit-vcd upper-limit-vcd</i>	(Optional) Specifies the range of VCs. Displays all the VC information for the specified range of VCDs. The <i>lower-limit-vcd</i> argument specifies the lower limit of the VCD range. The <i>upper-limit-vcd</i> argument specifies the upper limit of the VCD range.
interface atm <i>interface-number</i>	(Optional) Interface number or subinterface number of the PVC or SVC. Displays all PVCs and SVCs on the specified interface or subinterface. The <i>interface-number</i> uses one of the following formats, depending on the router platform you use: - For the ATM Interface Processor (AIP) on Cisco 7500 series routers; for the ATM port adapter, ATM-CES port adapter, and enhanced ATM port adapter on Cisco 7200 series routers; for the 1-port ATM-25 network module on Cisco 2600 and 3600 series routers: <i>slot/0[.subinterface-number multipoint]</i> - For the ATM port adapter and enhanced ATM port adapter on Cisco 7500 series routers: <i>slot/port-adapter/0[.subinterface-number multipoint]</i> - For the network processing module (NPM) on Cisco 4500 and Cisco 4700 routers: <i>number[.subinterface-number multipoint]</i> - For a description of these arguments, refer to the interface atm command.
detail	(Optional) Displays the detailed information about the VCs.
prefix	(Optional) Displays detailed information about the selected VC category. You must specify one of the following VC categories: vpi/vci—Virtual path identifier and virtual channel identifier. vcd—Virtual circuit descriptor. interface—Interface in which the VCD is configured. vc_name—Name of the PVC or SVC.
<i>connection-name</i>	(Optional) Connection name of the PVC or SVC.
signalling	(Optional) Displays the ATM interface signaling information for all the interfaces.
freed-svcs	(Optional) Displays the details of the last few freed SVCs.

cast-type	(Optional) SVC cast type. You must specify one of the following connections: • p2mp—Point to multipoint connection. • p2p—Point to point connection.
summary atm interface-number	(Optional) Displays a summary of VCs.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
10.0	This command was introduced.
11.1CA	This command was modified. Information about VCs on an ATM-CES port adapter was added to the command output.
12.0(5)T	This command was modified. Information about VCs on an extended Multiprotocol Label Switching (MPLS) ATM interface was added to the command output.
12.2(25)S	This command was modified. Information about packet drops and errors was added to the command output.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB and implemented on the Cisco 10000 series routers.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SRB	This command was integrated into Cisco IOS Release 12.2(33)SRB and the signalling keyword was added.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.
Cisco IOS XE 2.3	This command was implemented on the Cisco ASR 1000 series routers.

Usage Guidelines

If no value is specified for the *vcd* argument, the command displays information for all PVCs and SVCs. The output is in summary form (one line per virtual circuit).

VCs on the extended MPLS ATM interfaces do not appear in the **show atm vc** command output. Instead, the **show xtagatm vc** command provides a similar output that shows information only on extended MPLS ATM VCs.



Note The SVCs and the **signalling** keyword are not supported on the Cisco ASR 1000 series routers.

Examples

The following is sample output from the **show atm vc** command when no value for the *vcd* argument is specified. The status field is either ACTIVE or IN (inactive).

Router# **show atm vc**

Interface	VCD	VPI	VCI	Type	AAL/Encaps	Peak	Avg.	Burst	Status
ATM2/0	1	0	5	PVC	AAL5-SAAL	155000	155000	93	ACTIVE
ATM2/0.4	3	0	32	SVC	AAL5-SNAP	155000	155000	93	ACTIVE
ATM2/0.65432	10	10	10	PVC	AAL5-SNAP	100000	40000	10	ACTIVE

ATM2/0	99	0	16	PVC	AAL5-ILMI	155000	155000	93	ACTIVE
ATM2/0.105	250	33	44	PVC	AAL5-SNAP	155000	155000	93	ACTIVE
ATM2/0.100	300	22	33	PVC	AAL5-SNAP	155000	155000	93	ACTIVE
ATM2/0.12345	2047	255	65535	PVC	AAL5-SNAP	56	28	2047	ACTIVE

The following is sample output from the **show atm vc** command when a *vcd* value is specified for a circuit emulation service (CES) circuit:

```
Router# show atm vc 2
```

```
ATM6/0: VCD: 2, VPI: 10, VCI: 10
PeakRate: 2310, Average Rate: 2310, Burst Cells: 94
CES-AAL1, etype:0x0, Flags: 0x20138, VCmode: 0x0
OAM DISABLED
InARP DISABLED
OAM cells received: 0
OAM cells sent: 334272
Status: ACTIVE
```

The following is sample output from the **show atm vc** command when a *vcd* value is specified, displaying statistics for that virtual circuit only:

```
Router# show atm vc 8
```

```
ATM4/0: VCD: 8, VPI: 8, VCI: 8
PeakRate: 155000, Average Rate: 155000, Burst Cells: 0
AAL5-LLC/SNAP, etype:0x0, Flags: 0x30, VCmode: 0xE000
OAM frequency: 0 second(s)
InARP frequency: 1 minute(s)
InPkts: 181061, OutPkts: 570499, InBytes: 757314267, OutBytes: 2137187609
InPRoc: 181011, OutPRoc: 10, Broadcasts: 570459
InFast: 39, OutFast: 36, InAS: 11, OutAS: 6
OAM cells received: 0
OAM cells sent: 0
Status: UP
```

The following is sample output from the **show atm vc** command when a *vcd* value is specified, AAL3/4 is enabled, an ATM Switched Multimegabit Data Service (SMDS) subinterface has been defined, and a range of message identifier numbers (MIDs) has been assigned to the PVC:

```
Router# show atm vc 1
```

```
ATM4/0.1: VCD: 1, VPI: 0, VCI: 1
PeakRate: 0, Average Rate: 0, Burst Cells: 0
AAL3/4-SMDS, etype:0x1, Flags: 0x35, VCmode: 0xE200
MID start: 1, MID end: 16
InPkts: 0, OutPkts: 0, InBytes: 0, OutBytes: 0
InPRoc: 0, OutPRoc: 0, Broadcasts: 0
InFast: 0, OutFast: 0, InAS: 0, OutAS: 0
```

The following is sample output from the **show atm vc** command when a *vcd* value is specified and generation of Operation, Administration, and Maintenance (OAM) F5 loopback cells has been enabled:

```
Router# show atm vc 7
```

```
ATM4/0: VCD: 7, VPI: 7, VCI: 7
PeakRate: 0, Average Rate: 0, Burst Cells: 0
AAL5-LLC/SNAP, etype:0x0, Flags: 0x30, VCmode: 0xE000
OAM frequency: 10 second(s)
InARP DISABLED
InPkts: 0, OutPkts: 0, InBytes: 0, OutBytes: 0
InPRoc: 0, OutPRoc: 0, Broadcasts: 0
InFast:0, OutFast:0, InAS:0, OutAS:0
OAM cells received: 0
```

```
OAM cells sent: 1
Status: UP
```

The following is sample output from the **show atm vc** command when a *vcd* value is specified, and there is an incoming multipoint virtual circuit:

```
Router# show atm vc 3

ATM2/0: VCD: 3, VPI: 0, VCI: 33
PeakRate: 0, Average Rate: 0, Burst Cells: 0
AAL5-MUX, etype:0x809B, Flags: 0x53, VCmode: 0xE000
OAM DISABLED
InARP DISABLED
InPkts: 6646, OutPkts: 0, InBytes: 153078, OutBytes: 0
InPRoc: 6646, OutPRoc: 0, Broadcasts: 0
InFast: 0, OutFast: 0, InAS: 0, OutAS: 0
interface = ATM2/0, call remotely initiated, call reference = 18082
vnum = 3, vpi = 0, vci = 33, state = Active
  aal5mux vc, multipoint call
Retry count: Current = 0, Max = 10
timer currently inactive, timer value = never
Root Atm Nsap address: DE.CDEF.01.234567.890A.BCDE.F012.3456.7890.1234.12
```

The following is sample output from the **show atm vc** command when a *vcd* value is specified, and there is an outgoing multipoint virtual circuit:

```
Router# show atm vc 6

ATM2/0: VCD: 6, VPI: 0, VCI: 35
PeakRate: 0, Average Rate: 0, Burst Cells: 0
AAL5-MUX, etype:0x800, Flags: 0x53, VCmode: 0xE000
OAM DISABLED
InARP DISABLED
InPkts: 0, OutPkts: 818, InBytes: 0, OutBytes: 37628
InPRoc: 0, OutPRoc: 0, Broadcasts: 818
InFast: 0, OutFast: 0, InAS: 0, OutAS: 0
interface = ATM2/0, call locally initiated, call reference = 3
vnum = 6, vpi = 0, vci = 35, state = Active
  aal5mux vc, multipoint call
Retry count: Current = 0, Max = 10
timer currently inactive, timer value = never
Leaf Atm Nsap address: DE.CDEF.01.234567.890A.BCDE.F012.3456.7890.1234.12
Leaf Atm Nsap address: CD.CDEF.01.234567.890A.BCDE.F012.3456.7890.1234.12
```

The following is sample output from the **show atm vc** command when a *vcd* value is specified and there is a PPP-over-ATM connection:

```
Router# show atm vc 1

ATM8/0.1: VCD: 1, VPI: 41, VCI: 41
PeakRate: 155000, Average Rate: 155000, Burst Cells: 96
AAL5-CISCOPPP, etype:0x9, Flags: 0xC38, VCmode: 0xE000
virtual-access: 1, virtual-template: 1
OAM DISABLED
InARP DISABLED
InPkts: 13, OutPkts: 10, InBytes: 198, OutBytes: 156
InPRoc: 13, OutPRoc: 10, Broadcasts: 0
InFast: 0, OutFast: 0, InAS: 0, OutAS: 0
OAM cells received: 0
OAM cells sent: 0
```

The following is sample output from the **show atm vc** command for IP multicast virtual circuits. The display shows the leaf count for multipoint VCs opened by the root. VCD 3 is a root of a multipoint VC with three leaf routers. VCD 4 is a leaf of some other router's multipoint VC. VCD 12 is a root of a multipoint VC with only one leaf router.

Router# **show atm vc**

Interface	VCD/ Name	VPI	VCI	Type	Encaps	Peak Kbps	Avg/Min Kbps	Burst Cells	Sts
0/0	1	0	5	PVC	SAAL	155000	155000	96	UP
0/0	2	0	16	PVC	ILMI	155000	155000	96	UP
0/0	3	0	124	MSVC-3	SNAP	155000	155000	96	UP
0/0	4	0	125	MSVC	SNAP	155000	155000	96	UP
0/0	5	0	126	MSVC	SNAP	155000	155000	96	UP
0/0	6	0	127	MSVC	SNAP	155000	155000	96	UP
0/0	9	0	130	MSVC	SNAP	155000	155000	96	UP
0/0	10	0	131	SVC	SNAP	155000	155000	96	UP
0/0	11	0	132	MSVC-3	SNAP	155000	155000	96	UP
0/0	12	0	133	MSVC-1	SNAP	155000	155000	96	UP
0/0	13	0	134	SVC	SNAP	155000	155000	96	UP
0/0	14	0	135	MSVC-2	SNAP	155000	155000	96	UP
0/0	15	0	136	MSVC-2	SNAP	155000	155000	96	UP

The following is sample output from the **show atm vc** command for an IP multicast virtual circuit. The display shows the owner of the VC and leaves of the multipoint VC. This VC was opened by IP multicast. The three leaf routers' ATM addresses are included in the display. The VC is associated with IP group address 10.1.1.1.

Router# **show atm vc 11**

```

ATM0/0: VCD: 11, VPI: 0, VCI: 132
PeakRate: 155000, Average Rate: 155000, Burst Cells: 96
AAL5-LLC/SNAP, etype:0x0, Flags: 0x650, VCmode: 0xE000
OAM DISABLED
InARP DISABLED
InPkts: 0, OutPkts: 12, InBytes: 0, OutBytes: 496
InPRoc: 0, OutPRoc: 0, Broadcasts: 12
InFast: 0, OutFast: 0, InAS: 0, OutAS: 0
OAM cells received: 0
OAM cells sent: 0
Status: ACTIVE, TTL: 2, VC owner: IP Multicast (10.1.1.1)
interface = ATM0/0, call locally initiated, call reference = 2
vcnum = 11, vpi = 0, vci = 132, state = Active
aal5snap vc, multipoint call
Retry count: Current = 0, Max = 10
timer currently inactive, timer value = 00:00:00
Leaf Atm Nsap address: 47.0091810000000002BA08E101.444444444444.02
Leaf Atm Nsap address: 47.0091810000000002BA08E101.333333333333.02
Leaf Atm Nsap address: 47.0091810000000002BA08E101.222222222222.02

```


The following is sample output from the **show atm vc** command where no VCD is specified and private VCs are present:

```
Router# show atm vc
```

AAL / Interface	Peak VCD	Avg. VPI	Burst VCI	Type	Encapsulation	Kbps	Kbps	Cells	Status
ATM1/0	1	0	40	PVC	AAL5-SNAP	0	0	0	ACTIVE
ATM1/0	2	0	41	PVC	AAL5-SNAP	0	0	0	ACTIVE
ATM1/0	3	0	42	PVC	AAL5-SNAP	0	0	0	ACTIVE
ATM1/0	4	0	43	PVC	AAL5-SNAP	0	0	0	ACTIVE
ATM1/0	5	0	44	PVC	AAL5-SNAP	0	0	0	ACTIVE
ATM1/0	15	1	32	PVC	AAL5-XTAGATM	0	0	0	ACTIVE
ATM1/0	17	1	34	TVC	AAL5-XTAGATM	0	0	0	ACTIVE
ATM1/0	26	1	43	TVC	AAL5-XTAGATM	0	0	0	ACTIVE
ATM1/0	28	1	45	TVC	AAL5-XTAGATM	0	0	0	ACTIVE
ATM1/0	29	1	46	TVC	AAL5-XTAGATM	0	0	0	ACTIVE
ATM1/0	33	1	50	TVC	AAL5-XTAGATM	0	0	0	ACTIVE

When you specify a VCD value and the VCD corresponds to that of a private VC on a control interface, the display output appears as follows:

```
Router# show atm vc 15
```

```
ATM1/0 33      1      50  TVC  AAL5-XTAGATM      0      0      0  ACTIVE
ATM1/0: VCD: 15, VPI: 1, VCI: 32, etype:0x8, AAL5 - XTAGATM, Flags: 0xD38
PeakRate: 0, Average Rate: 0, Burst Cells: 0, VCmode: 0x0
XTagATM1, VCD: 1, VPI: 0, VCI: 32
OAM DISABLED, InARP DISABLED
InPkts: 38811, OutPkts: 38813, InBytes: 2911240, OutBytes: 2968834
InProc: 0, OutProc: 0, Broadcasts: 0
InFast: 0, OutFast: 0, InAS: 0, OutAS: 0
OAM F5 cells sent: 0, OAM cells received: 0
Status: ACTIVE
```

Table 22 describes the fields shown in the displays.

Table 22 *show atm vc Field Descriptions*

Field	Description
Interface	Interface slot and port.
VCD/Name	Virtual circuit descriptor (virtual circuit number). The connection name is displayed if the virtual circuit (VC) was configured using the pvc command and the name was specified.
VPI	Virtual path identifier.
VCI	Virtual channel identifier.

Table 22 *show atm vc Field Descriptions (continued)*

Field	Description
Type	Type of VC, either PVC, SVC, TVC, or multipoint SVC (MSVC). - MSVC (with no -x) indicates that VCD is a leaf of some other router's multipoint VC. - MSVC-x indicates there are x leaf routers for that multipoint VC opened by the root. Type of PVC detected from PVC discovery, either PVC-D, PVC-L, or PVC-M. - PVC-D indicates a PVC created due to PVC discovery. - PVC-L indicates that the corresponding peer of this PVC could not be found on the switch. - PVC-M indicates that some or all of the quality of service (QoS) parameters of this PVC do not match those of the corresponding peer on the switch. - TVC indicates a Tag VC.
Encaps	Type of ATM adaptation layer (AAL) and encapsulation.
PeakRate	Kilobits per second sent at the peak rate.
Average Rate	Kilobits per second sent at the average rate.
Burst Cells	Value that equals the maximum number of ATM cells the VC can send at peak rate.
Status	Status of the VC connection. - UP indicates that the connection is enabled for data traffic. - DN indicates that the connection is down (not ready for data traffic). When the Status field is DN (down), a State field is shown. - IN indicates that the interface is down (inactive). - ACTIVE indicates that the interface is in use and active.
etype	Encapsulation type.

Table 22 *show atm vc Field Descriptions (continued)*

Field	Description
Flags	Bit mask describing VC information. The flag values are summed to result in the displayed value. 0x10000 ABR VC 0x20000 CES VC 0x40000 TVC 0x100 TEMP (automatically created) 0x200 MULTIPOINT 0x400 DEFAULT_RATE 0x800 DEFAULT_BURST 0x10 ACTIVE 0x20 PVC 0x40 SVC 0x0 AAL5-SNAP 0x1 AAL5-NLPID 0x2 AAL5-FRNLPID 0x3 AAL5-MUX 0x4 AAL3/4-SMDS 0x5 QSAAL 0x6 AAL5-ILMI 0x7 AAL5-LANE 0x8 AAL5-XTAGATM 0x9 CES-AAL1 0xA F4-OAM
VCmode	AIP-specific or NPM-specific register describing the usage of the VC. This register contains values such as rate queue, peak rate, and AAL mode, which are also displayed in other fields.
OAM frequency	Seconds between OAM loopback messages, or DISABLED if OAM is not in use on this VC.
InARP frequency	Minutes between Inverse Address Resolution Protocol (InARP) messages, or DISABLED if InARP is not in use on this VC.
virtual-access	Virtual access interface identifier.
virtual-template	Virtual template identifier.
InPkts	Total number of packets received on this VC. This number includes all fast-switched and process-switched packets.
OutPkts	Total number of packets sent on this VC. This number includes all fast-switched and process-switched packets.
InBytes	Total number of bytes received on this VC. This number includes all fast-switched and process-switched packets.
OutBytes	Total number of bytes sent on this VC. This number includes all fast-switched and process-switched packets.
InPRoc	Number of process-switched input packets.
OutPRoc	Number of process-switched output packets.
Broadcasts	Number of process-switched broadcast packets.
InFast	Number of fast-switched input packets.

Table 22 *show atm vc Field Descriptions (continued)*

Field	Description
OutFast	Number of fast-switched output packets.
InAS	Number of autonomous-switched or silicon-switched input packets.
VC TxRingLimit	Transmit Ring Limit for this VC.
VC Rx Limit	Receive Ring Limit for this VC.
Transmit priority	ATM service class transmit priority for this VC.
InCells	Number of incoming cells on this VC.
OutCells	Number of outgoing cells on this VC.
InPktDrops	A non-zero value for the InPktDrops of a VC counter suggests that the ATM interface is running out of packet buffers for an individual VC, or is exceeding the total number of VC buffers that can be shared by the VCs.
OutPktDrops	The PA-A3 driver increments the OutPktDrops counter when a VC fills its individual transmit buffer quota. The purpose of the quota is to prevent a consistently oversubscribed VC from grabbing all of the packet buffer resources and hindering other VCs from transmitting normal traffic within their traffic contracts.
InCellDrops	Number of incoming cells dropped on this VC.
OutCellDrops	Number of outgoing cells dropped on this VC.
InByteDrops	Number of incoming bytes that are dropped on this VC.
OutByteDrops	Number of outgoing bytes that are dropped on this VC.
CrcErrors	Number of cyclic redundancy check (CRC) errors on this VC.
SarTimeOuts	Number of segmentation and reassembly sublayer time-outs on this VC.
OverSizedSDUs	Number of over-sized service data units on this VC
LengthViolation	Number of length violations on this VC. A length violation occurs when a reassembled packet is dropped without checking the CRC.
CPIErrors	The Common Part Indicator error field is a one octet field in the AAL5 encapsulation of an ATM cell and must be set to 0. If it is received with some other value, it is flagged as an error by the interface. For example, this error may indicate data corruption.
Out CLP	Number of packets or cells where the Output Cell Loss Priority bit is set.
OutAS	Number of autonomous-switched or silicon-switched output packets.
OAM cells received	Number of OAM cells received on this VC.
OAM cells sent	Number of OAM cells sent on this VC.
TTL	Time to live in ATM hops across the VC.
VC owner	IP Multicast address of the group.

Related Commands

Command	Description
atm nsap-address	Sets the NSAP address for an ATM interface using SVC mode.
show xtagatm vc	Displays information about the VCs on the extended MPLS ATM interfaces.

show atm vp

To display the statistics for all virtual paths (VPs) on an interface or for a specific VP, use the **show atm vp** command in privileged EXEC mode.

show atm vp [*vpi*]

Syntax Description

vpi (Optional) ATM network virtual path identifier (VPI) of the permanent virtual path. The range is from 0 to 255. The VPI is an 8-bit field in the header of the ATM cell.

Command Modes

Privileged EXEC

Command History

Release	Modification
11.1	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following is sample output from the **show atm vp** command. This output shows the interface name, the status of the interface, the administrative status of the interface, the port type, and the number of channels in use on the interface. The status of the interface can be UP (in operation) or DOWN (not in operation).

Router# **show atm vp 1**

ATM6/0 VPI: 1, PeakRate: 155000, CesRate: 1742, DataVCs: 1, CesVCs:1, Status: ACTIVE

VCD	VCI	Type	InPkts	OutPkts	AAL/Encap	Status
1	100	PVC	n/a	n/a	CES-AAL1	ACTIVE
13	13	PVC	0	0	AAL5-SNAP	ACTIVE
409	3	PVC	0	0	F4 OAM	ACTIVE
410	4	PVC	0	0	F4 OAM	ACTIVE

TotalInPkts: 0, TotalOutPkts: 0, TotalInFast: 0, TotalOutFast: 0, TotalBroadcasts: 0

Table 23 describes the fields shown in the display.

Table 23 *show atm vp Field Descriptions*

Field	Description
ATM6/0	Interface type, slot, and port number of the VP.
VPI	Virtual path identifier of the VP.
PeakRate	Maximum rate, in kbps, at which the VP can send data. Range is 84 kbps to line rate. The default is the line rate.

Table 23 *show atm vp Field Descriptions (continued)*

Field	Description
CesRate	Total circuit emulation service (CES) bandwidth allocated for the VP.
DataVCs	Number of data virtual circuits (VCs) on the VP.
CesVCs	Number of CES VC on the VP.
Status	Current status of the VP. Values are ACTIVE and INACTIVE.
VCD	Virtual circuit descriptor of the VC associated with this VP.
VCI	Virtual channel identifier of the VC associated with this VP.
Type	Type of VC associated with this VP. Values are PVC and SVC.
InPkts	Number of packets received on the VP.
OutPkts	Number of packets transmitted on the VP.
AAL/Encap	Type of encapsulation used on the VC associated with this VP.
Status	Status of the VP (ACTIVE or INACTIVE).
TotalInPkts:	Total number of input packets process-switched and fast-switched on the VP.
TotalOutPkts:	Total number of output packets process-switched and fast-switched on the VP.
TotalInFast	Total number of input packets fast-switched.
TotalOutFast:	Total number of output packets fast-switched.
TotalBroadcasts:	Total number of broadcast packets fast-switched.

Related Commands

Command	Description
atm pvp	Creates a PVP used to multiplex (or bundle) one or more VCs (especially CES and data VCs).

show ces

To display details about a Circuit Emulation Service (CES) connection, use the **show ces** privileged EXEC command.

show ces [*slot/port*]

Syntax Description	<i>slot/port</i> (Optional) Slot and port number of the CES interface.
---------------------------	--

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	12.1(2)T	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	This command is used on Cisco 2600 series and Cisco 3600 series routers that have OC-3/STM-1 ATM CES network modules.
-------------------------	---

Examples	The following is sample output from the show ces command.
-----------------	--

```
Router# show ces 3/0

CURRENT VPD CES CLOCK:Set to ATM
ATM CLOCKING:Clock Source is Line
VPD BASE ADDRESS->(0x3DE00000)
Multi Mode VPD Installed
VIC/WIC PRESENT-> 2 port drop&insert T1 humvee installed
CONTROLLER CLOCKING-> PORT[0]:Clock is Internal
CONTROLLER CLOCKING-> PORT[1]:Clock is Internal
DCU [0]:
  port State:    active          alarm State:normal          Loop Type:    noloop
  Clocking Mode:loopTimed  Data Mode:  crossConnect  Framing Type:  d4
  Line Coding:  ami          t1Cas:    off          tsInUse:      0000001C
  VPI/VCI 6/78 CES AAL1 Input cells 210252 CES AAL1 Output cells 210252
  imRestart 0 xcUndfrmslp 2 overflow 0
DCU [1]:
  port State:    inactive        alarm State:normal          Loop Type:    noloop
  Clocking Mode:synchronous  Data Mode:  clearChannel  Framing Type:none
  Line Coding:  ami          t1Cas:    off          tsInUse:      00000000
DCU [2]:
  port State:    inactive        alarm State:normal          Loop Type:    noloop
  Clocking Mode:synchronous  Data Mode:  clearChannel  Framing Type:none
  Line Coding:  ami          t1Cas:    off          tsInUse:      00000000
DCU [3]:
```

```

port State:    inactive      alarm State:normal      Loop Type:    noloop
Clocking Mode:synchronous  Data Mode:    clearChannel  Framing Type:none
Line Coding:   ami           t1Cas:        off          tsInUse:      00000000

```

Table 24 describes significant fields shown in the display.

Table 24 *show ces Field Descriptions*

Field	Description
CURRENT VPD CES CLOCK	Clock being used by the CES function.
ATM CLOCKING	Clock being used by the ATM interface.
VIC/WIC PRESENT	Type of WIC plugged into the Network Module.
CONTROLLER CLOCKING	Clock being used by the T1 controller.
port State	Current state of port. Values are active or inactive.
alarm State	Current state of the CES port.
Clocking Mode	CES circuit clocking mode.
Data Mode	CES circuit data mode.
Framing Type	CES port framing type. Values are d4 and esf.
Line Coding	CES port line code type. Values are ami and b8zs.
t1Cas	Current state of T1 Channel Associated Signalling on CES port. Values are on and off.
tsInUse	Bit mask of timeslots in use.
VPI/VCI	VPI/VCI used by CES circuit.
CES AAL1 Input cells	Number of CES cells received.
CES AAL1 Output cells	Number of CES cells transmitted.
xcUndfrmslp	Structured CES circuit Under Frame Slips.
overflow	CES circuit overflows.

Related Commands

Command	Description
ces	Configures CES on a router port.

show ces circuit

To display detailed circuit information for the constant bit rate (CBR) interface, use the **show ces circuit** command in privileged EXEC mode.

show ces circuit [**interface cbr** *slot/port* [*circuit-number*]]

Syntax Description

interface cbr <i>slot/port</i>	(Optional) Slot and port number of the CBR interface.
<i>circuit-number</i>	(Optional) Circuit identification. For unstructured service, use 0. For T1 structure service, the range is from 1 to 24. For E1 structure service, the range is from 1 to 31.

Command Modes

Privileged EXEC

Command History

Release	Modification
11.1	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following is sample output from the **show ces circuit** command.

Router # **show ces circuit**

Interface	Circuit	Circuit-Type	X-interface	X-vpi	X-vci	Status
CBR6/0	1	HardPVC	ATM6/0	0	34	UP
CBR6/1	1	HardPVC	ATM6/1	0	34	UP

Table 25 describes the fields shown in the display.

Table 25 *show ces circuit Field Descriptions*

Field	Description
Interface	Type, slot, and port number of the interface.
Circuit	Circuit number assigned to the PVC.
Circuit-Type	Type of circuit. Values are HardPVC or SoftPVC. Only HardPVC is supported on the ATM-CES port adapter.
X-interface	Type, slot, and port number of the destination interface.
X-vpi	Virtual path identifier of the destination interface.
X-vci	Virtual channel identifier of the destination interface.
Status	State of the circuit. Values are Up and Down.

The following is sample output from the **show ces circuit** command for a circuit 1 on CBR interface 6/0:

```
Router# show ces circuit interface cbr 6/0 1
```

```
circuit: Name CBR6/0:1, Circuit-state ADMIN_UP / Interface CBR6/0, Circuit_id 1,
Port-Type T1, Port-State UP
Port Clocking network-derived, aal1 Clocking Method CESIWF_AAL1_CLOCK_Sync
Channel in use on this port: 1
Channels used by this circuit: 1
Cell-Rate: 171, Bit-Rate 64000
cas OFF, cell-header 0X3E80 (vci = 1000)
Configured CDV 2000 usecs, Measured CDV unavailable
ErrTolerance 8, idleCircuitdetect OFF, onHookIdleCode 0x0
state: VcActive, maxQueueDepth      128, startDequeueDepth      111
Partial Fill:      47, Structured Data Transfer 24
HardPVC
src: CBR6/0 vpi 0, vci 16
Dst: ATM6/0 vpi0, vci 1000
```

Table 26 describes the fields shown in the display.

Table 26 *show ces circuit interface Field Descriptions*

Field	Description
circuit Name	Name of the circuit specified with the ces circuit interface command.
Circuit-state	Current configuration state of the circuit. Values are ADMIN_UP or ADMIN_DOWN.
Interface	Type, slot, and port number of the interface.
Circuit_ID	Circuit identification specified with the ces pvc interface command.
Port-Type	Type of interface on the ATM-CES port adapter. Values are T1 and E1.
Port-State	Current status of the port. Values are Up and Down.
Port Clocking	Clocking mode used by the interface specified with the ces dsx1 clock interface command. Values are Loop-Timed and Network-Derived Adaptive.
aal1 Clocking Method	AAL1 clocking mode used by the interface specified with the ces aal1 clock interface command. Values are Adaptive, Synchronous Residual Time Stamp (SRTS), and Synchronous.
Channel in use on this port	Number of active channels used by this interface.
Channels used by this circuit	Number of channels used by the circuit.
Cell-Rate	Number of cells transmitted or received on the interface per second.
Bit-Rate	Speed at which the cells are transmitted or received.
cas	Indicates whether channel-associated signaling (CAS) is enabled on the interface with the ces circuit interface command.
cell-header	ATM cell header VCI bytes used for debugging only.
Configured CDV	Indicates the peak-to-peak cell delay variation (CDV) requirement (CDV) in milliseconds specified with the ces circuit interface command. The range for CDV is 1 through 65535 milliseconds. The default is 2000 milliseconds.
Measured CDV	Indicates the actual cell delay variation in milliseconds.
ErrTolerance	For internal use only.

Table 26 *show ces circuit interface Field Descriptions (continued)*

Field	Description
idleCircuitdetect	Indicates whether idle circuit detection is enabled (ON) or disabled (OFF).
onHookIdleCode	Indicates that the on-hook detection feature is enabled with the ces circuit interface command and the hex value (0 through F) that indicates a 2 or 4 bit AB[CD] pattern to detect on-hook. The AB[CD] bits are determined by the manufacturer of the voice/video telephony device that is generating the CBR traffic.
state	Current state of the circuit. Values are VcActive, VcInactive, VcLOC (loss of cell), or VcAlarm (alarm condition).
maxQueueDepth	Maximum queue depth in bits.
startDequeueDepth	Start dequeue depth in bits.
Partial Fill	Indicates the partial AAL1 cell fill service for structured service only specified by the ces circuit interface command. The range is 0 through 47. The default is 47.
Structured Data Transfer	Size (in bytes) of the structured data transfer frame.
HardPVC	Only hard PVC are supported by the ATM-CES port adapter.
src	Source interface type, slot, and port number and VPI and VCI for the circuit.
Dst	Destination interface type, slot, and port number and the VPI and VCI for the circuit.

Related Commands

Command	Description
show ces circuit	Displays detailed circuit information for the CBR interface.
show ces status	Displays the status of the ports on the ATM-CES port adapter.

show ces interface cbr

To display detailed constant bit rate (CBR) port information, use the **show ces interface cbr** command in privileged EXEC mode.

show ces interface cbr *slot/port*

Syntax Description

<i>slot/port</i>	Slot and port number of the CES interface.
------------------	--

Command Modes

Privileged EXEC

Command History

Release	Modification
11.1	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following is sample output from the **show ces interface cbr** command for CBR interface 6/0:

Router# **show ces interface cbr 6/0**

```

Interface:      CBR6/0          Port-type:T1-DCU
IF Status:      UP              Admin Status: UP
Channels in use on this port: 1
LineType: ESF          LineCoding: B8ZS  LoopConfig: NoLoop
SignalMode: NoSignalling  XmtClockSrc: network-derived
DataFormat: Structured  AAL1 Clocking Mode: Synchronous  LineLength: 0_110
LineState: LossOfSignal
Errors in the Current Interval:
  PCVs      0  LCVs      0  ESs      0  SESs      0  SEFSS      0
  UASs      0  CSSs      0  LESSs    0  BESSs     0  DMs        0
Errors in the last 24Hrs:
  PCVs     514  LCVs      0  ESs      0  SESs      1  SEFSS      0
  UASs      0  CSSs      0  LESSs    0  BESSs     0  DMs        0
Input  Counters: 0 cells, 0 bytes
Output Counters: 0 cells, 0 bytes

```

Table 27 describes the fields shown in the display.

Table 27 *show ces interface cbr* Field Descriptions

Field	Description
Interface	Type, slot, and port number of the interface.
Port-type	Type of port on the ATM-CES port adapter. Values are T1-DCU and E1-DCU.
IF Status	Status of the interface. Values are Up and Down.

Table 27 *show ces interface cbr Field Descriptions (continued)*

Field	Description
Admin Status	Configured status of the interface. Values are Up and Down (administratively configured down).
Channels in use on this port	Number of active channels used by this interface.
LineType	Framing used on the interface specified with the ces dsx1 framing interface command. Values (for T1) are ESF and SF; (for E1) E1-CRC-MFCASLT, E1-CRC-MFLT, E1-LT, and E1-MFCASLT.
LineCoding	Line coding used on the interface specified with the ces dsx1 linecode interface command. Values (for T1) are AMI and B8ZS; (for E1) HDB3.
LoopConfig	Indicates whether the interface is in a loop state specified by the ces dsx1 loopback interface command. Values are line loopback, payload loopback, and noloop.
SignalMode	For T1 to use robbed-bit signaling or not.
XmitClockSrc	Transmit clock source specified by the ces dsx1 clock interface command. Values are loop-timed or network-derived.
DataFormat	Type of CES services specified by the ces aal1 service interface command. Values are structured or unstructured.
AAL1 Clocking Mode	AAL1 clocking mode used by the interface specified with the ces aal1 clock interface command. Values are adaptive, synchronous residual time stamp (SRTS), or synchronous.
LineLength	Cable length specified by the ces dsx1 lbo interface command. Values are 0-110, 10-200, 220-330, 330-440, 440-550, 550-660, 660-above, and square-pulse.
LineState	Current status of the line. Values are: - Unknown - NoAlarm - RcvFarEndLOF - XmtFarEndLOF - RcvAIS - XmtAIS - LossOfFrame - LossOfSignal - LoopbackState - T16AIS
Errors in the Current Interval	Error statistics received during the current 15-minute interval.
PCVs	Number of Path Code Violations (PCVs). PCVs indicate a frame synchronization bit error in the D4 and E1 no-CRC formats, or a CRC error in the ESF and E1 CRC formats.

Table 27 *show ces interface cbr Field Descriptions (continued)*

Field	Description
LCVs	Number of Line Code Violations (LCVs). LCVs indicate the occurrence of either a Bipolar Violation (BPV) or Excessive Zeros (EXZ) error event.
ESs	Number of errored seconds. In ESF and E1 CRC links, an Errored Second is a second in which one of the following are detected: one or more Path Code Violations, one or more Out of Frame defects, one or more Controlled Slip events, or a detected AIS defect. For SF and E1 no-CRC links, the presence of Bipolar Violations also triggers an Errored Second.
SESSs	Number of Severely Errored Seconds (SESSs). A SESS is a second with 320 or more path code violation errors events, one or more Out of Frame defects, or a detected AIS defect.
SEFSs	Number of Severely Errored Framing Seconds (SEFS). SEFS is a second with one or more Out of Frame defects or a detected incoming AIS.
UASs	Number of Unavailable Seconds (UASs). UAS is a count of the total number of seconds on the interface.
CSSs	Number of Controlled Slip Second (CSS). CSS is a 1-second interval containing one or more controlled slips.
LESs	Number of Line Errored Seconds (LES). LES is a second in which one or more Line Code Violation errors are detected.
BESs	Number of Bursty Errored Seconds (BES). BES is a second with fewer than 320 and more than one Path Coding Violation error, no Severely Errored Frame defects, and no detected incoming AIS defects. Controlled slips are not included in this parameter.
DMs	Number of Degraded Minutes (DMs). A degraded minute is one in which the estimated error rate exceeds 1E-6 but does not exceed 1E-3. For more information, refer to RFC 1406.
Errors in the last 24Hrs	Error statistics received during the during the last 24 hours.
Input Counters	Number of cells and bytes received on the interface.
Output Counters	Number of cells and bytes.

Related Commands

Command	Description
show interface cbr	Displays the information about the CBR interface on the ATM-CES port adapter.

show ces status

To display the status of the ports on the ATM-CES port adapter, use the **show ces status** command in privileged EXEC mode.

show ces status

Syntax Description This command has no arguments or keywords.

Command Modes Privileged EXEC

Command History	Release	Modification
	11.1	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples The following is sample output from the **show ces status** command. This output shows the interface name, the status of the interface, the administrative status of the interface, the port type, and the number of channels in use on the interface. The status of the interface can be UP (in operation) or DOWN (not in operation).

Router# **show ces status**

Interface Name	IF Status	Admin Status	Port Type	Channels in use
-----	-----	-----	-----	-----
CBR0/0/0	UP	UP	T1	1-24
CBR0/0/1	UP	UP	T1	1-24
CBR0/0/2	UP	UP	T1	1-24
CBR0/0/3	UP	UP	T1	

Related Commands	Command	Description
	show ces circuit	Displays detailed circuit information for the CBR interface.

show controllers atm

To display information about an inverse multiplexing over ATM (IMA) group, use the **show controllers atm** privileged EXEC command.

Cisco 2600 and 3600 Series

```
show controllers atm [slot/ima group-number]
```

Cisco 7200 Series

```
show controller atm [slot/port]
```

or

```
show controllers atm [slot/imagroup-number]
```

Cisco 7500 Series (physical port hardware information)

```
show controllers atm [slot/port-adapter/port]
```

Cisco 7500 Series (IMA group hardware information)

```
show controllers atm [slot/port-adapter/imagroup-number]
```

Syntax Description

<i>slot/</i>	(Optional) ATM slot number.
ima	(Optional) This keyword indicates an IMA group specification rather than a port value for a UNI interface.
<i>group-number</i>	(Optional) Enter an IMA group number from 0 to 3. If you specify the group number, do not insert a space between ima and the number.
<i>port</i>	(Optional) ATM port number.
<i>port-adapter/</i>	(Optional) ATM port adapter.

Command Modes

Privileged EXEC

Command History

Release	Modification
11.2 GS	This command was introduced.
12.0(5)XK	This command was modified to support IMA groups on Cisco 2600 and 3600 series routers.
12.0(5)T	This command was modified to support IMA groups on Cisco 2600 and 3600 series routers.
12.0(5)XE	Support for Cisco 7200 and 7500 series routers was added.
12.0(7)XE1	Support for Cisco 7100 series routers was added.
12.1(5)T	Support for Cisco 7100, 7200, and 7500 series routers was added.

Release	Modification
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Use this command to monitor and diagnose ATM IMA links and groups.

Examples

Cisco 7100 or 7200 Series Example

On Cisco 7100 series or 7200 series routers, the following example displays detailed information about IMA group hardware related information. It includes the configuration of IMA hardware and IMA alarms.

```
Router# show controllers atm 1/ima0
```

```
Interface ATM1/ima0 is up
Hardware is IMA PA - DS1 (1Mbps)
Framer is PMC PM7344, SAR is LSI ATMIZER II
Firmware rev:G102, ATMIZER II rev:3
  idb=0x61DE9F10, ds=0x6185C0A0, vc=0x6187D3C0, pa=0x6184AF40
  slot 1, unit 9, subunit 0, fci_type 0x00BA, ticks 701720
  400 rx buffers:size=512, encap=64, trailer=28, magic=4
Curr Stats:
  rx_cell_lost=0, rx_no_buffer=0, rx_crc_10=0
  rx_cell_len=0, rx_no_vcd=0, rx_cell_throttle=0, tx_aci_err=0
Rx Free Ring status:
  base=0x3CFF0040, size=1024, write=320
Rx Compl Ring status:
  base=0x338DCE40, size=2048, read=1275
Tx Ring status:
  base=0x3CFE8040, size=8192, write=700
Tx Compl Ring status:
  base=0x338E0E80, size=2048, read=344
BFD Cache status:
  base=0x61878340, size=5120, read=5107
Rx Cache status:
  base=0x61863D80, size=16, write=11
Tx Shadow status:
  base=0x618641C0, size=8192, read=687, write=700
Control data:
  rx_max_spins=12, max_tx_count=25, tx_count=13
  rx_threshold=267, rx_count=11, tx_threshold=3840
  tx bfd write indx=0x27, rx_pool_info=0x61863E20
Control data base address:
  rx_buf_base = 0x038A15A0      rx_p_base = 0x6185CB40
  rx_pak = 0x61863AF0          cmd = 0x6185C320
  device_base = 0x3C800000      ima_pa_stats = 0x038E2FA0
  sdram_base = 0x3CE00000       pa_cmd_buf = 0x3CFFFC00
  vcd_base[0] = 0x3CE3C100      vcd_base[1] = 0x3CE1C000
  chip_dump = 0x038E3D7C        dpram_base = 0x3CD80000
  sar_buf_base[0] = 0x3CE4C000   sar_buf_base[1] = 0x3CF22000
  bfd_base[0] = 0x3CFD4000      bfd_base[1] = 0x3CFC0000
  acd_base[0] = 0x3CE88360      acd_base[1] = 0x3CE5C200
  pci_atm_stats = 0x038E2EC0
ATM1/ima0 is up
  hwgrp number = 1
grp tx up reg= 0x5, grp rx up reg= 0x3, rx dcb reg= 0xD4 0x4, tx links grp reg=
```

```
0x3, scci reg= 0x3C, ima id reg= 0x0, group status reg= 0xA2, tx timing reg= 0x
20, tx test reg= 0x21, tx test pattern reg= 0x41, rx test pattern reg= 0x42, icp
cell link info reg= 0xFC, icp cell link info reg= 0xFC, icp cell link info r
eg= 0x0, icp cell link info reg= 0x0, icp cell link info reg= 0x0, icp cell li
nk info reg= 0x0, icp cell link info reg= 0x0, icp cell link info reg= 0x0
```

Cisco 2600 or 3600 Series Example

On a Cisco 2600 or 3600 series router, the following example displays detailed information about IMA group 0 on ATM interface 2:

```
router# show controller atm 0/ima3
```

```
Interface ATM0/IMA3 is up
Hardware is ATM IMA
LANE client MAC address is 0050.0f0c.148b
hwidb=0x61C2E990, ds=0x617D498C
slot 0, unit 3, subunit 3
rs8234 base 0x3C000000, slave base 0x3C000000
rs8234 ds 0x617D498C
SBDs - avail 2048, guaranteed 3, unguaranteed 2045, starved 0
Seg VCC table 3C00B800, Shadow Seg VCC Table 617EF76C, VCD Table 61805798
Schedule table 3C016800, Shadow Schedule table 618087C4, Size 63D
RSM VCC Table 3C02ED80, Shadow RSM VCC Table 6180C994
VPI Index Table 3C02C300, VCI Index Table 3C02E980
Bucket2 Table 3C01E500, Shadow Bucket2 Table 6180A0E4
MCR Limit Table 3C01E900, Shadow MCR Table 617D2160
ABR template 3C01EB00, Shadow template 614DEEAC
RM Cell RS Queue 3C02C980
Queue          TXQ Addr  Pos  StQ Addr  Pos
0  UBR CHN0     3C028B00  0    03118540  0
1  UBR CHN1     3C028F00  0    03118D40  0
2  UBR CHN2     3C029300  0    03119540  0
3  UBR CHN3     3C029700  0    03119D40  0
4  VBR/ABR CHN0 3C029B00  0    0311A540  0
5  VBR/ABR CHN1 3C029F00  0    0311AD40  0
6  VBR/ABR CHN2 3C02A300  0    0311B540  0
7  VBR/ABR CHN3 3C02A700  0    0311BD40  0
8  VBR-RT CHN0  3C02AB00  0    0311C540  0
9  VBR-RT CHN1  3C02AF00  0    0311CD40  0
10 VBR-RT CHN2  3C02B300  0    0311D540  0
11 VBR-RT CHN3  3C02B700  0    0311DD40  0
12 SIG          3C02BB00  0    0311E540  0
13 VPD          3C02BF00  0    0311ED40  0

Queue          FBQ Addr  Pos  RSQ Addr  Pos
0  OAM          3C0EED80  255  0311F600  0
1  UBR CHN0     3C0EFD80  0    03120600  0
2  UBR CHN1     3C0F0D80  0    03121600  0
3  UBR CHN2     3C0F1D80  0    03122600  0
4  UBR CHN3     3C0F2D80  0    03123600  0
5  VBR/ABR CHN0 3C0F3D80  0    03124600  0
6  VBR/ABR CHN1 3C0F4D80  0    03125600  0
7  VBR/ABR CHN2 3C0F5D80  0    03126600  0
8  VBR/ABR CHN3 3C0F6D80  0    03127600  0
9  VBR-RT CHN0  3C0F7D80  0    03128600  0
10 VBR-RT CHN1  3C0F8D80  255  03129600  0
11 VBR-RT CHN2  3C0F9D80  0    0312A600  0
12 VBR-RT CHN3  3C0FAD80  0    0312B600  0
13 SIG          3C0FBD80  255  0312C600  0
SAR Scheduling channels: -1 -1 -1 -1 -1 -1 -1 -1
ATM channel number is 1
link members are 0x7, active links are 0x0
Group status is blockedNe, 3 links configured,
```

```
Group Info: Configured links bitmap 0x7, Active links bitmap 0x0,
            Tx/Rx IMA_id 0x3/0x63,
            NE Group status is startUp,
            frame length 0x80, Max Diff Delay 0,
            1 min links, clock mode ctc, symmetry symmetricOperation, trl 0,
            Group Failure status is startUpNe.
            Test pattern procedure is disabled
SAR counter totals across all links and groups:
0 cells output, 0 cells stripped
0 cells input, 0 cells discarded, 0 AAL5 frames discarded
0 pci bus err, 0 dma fifo full err, 0 rsm parity err
0 rsm syn err, 0 rsm/seg q full err, 0 rsm overflow err
0 hs q full err, 0 no free buff q err, 0 seg underflow err
0 host seg stat q full err
```

Related Commands

Command	Description
show controllers atm	Displays information about an IMA group.
show ima interface atm	Provides information about all configured IMA groups or a specific IMA group.

show dxi map

To display all the protocol addresses mapped to a serial interface, use the **show dxi map** EXEC command.

show dxi map

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	10.3	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples The following is sample output from the **show dxi map** command. It displays output for several previously defined ATM-DXI maps that defined Apollo, IP, DECnet, CLNS, and AppleTalk protocol addresses, various encapsulations, and broadcast traffic.

```
Router# show dxi map
```

```
Serial0 (administratively down): ipx 123.0000.1234.1234
    DFA 69(0x45,0x1050), static, vpi = 4, vci = 5,
    encapsulation: SNAP
Serial0 (administratively down): appletalk 2000.5
    DFA 52(0x34,0xC40), static, vpi = 3, vci = 4,
    encapsulation: NLPID
Serial0 (administratively down): ip 172.21.177.1
    DFA 35(0x23,0x830), static,
    broadcast, vpi = 2, vci = 3,
    encapsulation: VC based MUX,
    Linktype IP
```

Table 28 explains significant fields shown in the display.

Table 28 *show dxi map Field Descriptions*

Field	Description
DFA	Data Exchange Interface (DXI) Frame Address, similar to a data-link connection identifier (DLCI) for Frame Relay. The DFA is shown in decimal, hexadecimal, and DXI header format. The router computes this address value from the virtual path identifier (VPI) and virtual channel identifier (VCI) values.

Table 28 ***show dxi map Field Descriptions***

Field	Description
encapsulation	Encapsulation type selected by the dxi pvc command. Displayed values can be <i>SNAP</i> , <i>NLPID</i> , or <i>VC based MUX</i> .
Linktype	Value used only with MUX encapsulation and therefore with only a single network protocol defined for the permanent virtual circuit (PVC). Maps configured on a PVC with MUX encapsulation must have the same link type.

show dxi pvc

To display the permanent virtual circuit (PVC) statistics for a serial interface, use the **show dxi pvc EXEC** command.

show dxi pvc

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	10.3	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples The following is sample output from the **show dxi pvc** command. It displays output for ATM-DXI PVCs previously defined for serial interface 0.

```
Router# show dxi pvc

PVC Statistics for interface Serial0 (ATM DXI)

DFA = 17, VPI = 1, VCI = 1, PVC STATUS = STATIC, INTERFACE = Serial0

    input pkts 0          output pkts 0          in bytes 0
    out bytes 0          dropped pkts 0

DFA = 34, VPI = 2, VCI = 2, PVC STATUS = STATIC, INTERFACE = Serial0

    input pkts 0          output pkts 0          in bytes 0
    out bytes 0          dropped pkts 0

DFA = 35, VPI = 2, VCI = 3, PVC STATUS = STATIC, INTERFACE = Serial0

    input pkts 0          output pkts 0          in bytes 0
    out bytes 0          dropped pkts 0
```

[Table 29](#) describes significant fields shown in the display.

Table 29 *show dxi pvc Field Descriptions*

Field	Description
DFA	Data Exchange Interface (DXI) Frame Address, similar to a data-link connection identifier (DLCI) for Frame Relay. The DFA is shown in decimal, hexadecimal, and DXI header format. The router computes this address value from the virtual path identifier (VPI) and virtual channel identifier (VCI) values.
PVC STATUS = STATIC	Only static maps are supported. Maps are not created dynamically.
input pkts	Number of packets received.
output pkts	Number of packets transmitted.
in bytes	Number of bytes in all packets received.
out bytes	Number of bytes in all packets transmitted.
dropped pkts	Should display a zero (0) value. A nonzero value indicates a configuration problem, specifically that a PVC does not exist.

show dxi pvc interface

To display the ATM Data Exchange Interface (DXI) Protocol Version Independent (PVI) interface information, use the **show dxi pvc interface** command in user EXEC or privileged EXEC mode.

show dxi pvc interface { *interface-type interface-number* [*vpi-number vci-number*] | *vpi-number vci-number* }

Syntax Description	<i>interface-type</i>	Specifies the interface type.
	<i>interface-number</i>	Specifies the interface number.
	<i>vpi-number</i>	Specifies the virtual path identifier number.
	<i>vci-number</i>	Specifies the virtual circuit interface number.

Command Modes	User EXEC (>)
	Privileged EXEC (#)

Command History	Release	Modification
	12.2(33)SRB	This command was introduced.
	12.2(33)SXI	This command was integrated into Cisco IOS Release 12.2(33)SXI.
	12.4(22)T	This command was integrated into Cisco IOS Release 12.4(22)T.
	Cisco IOS XE 2.3	This command was integrated into Cisco IOS XE Release 2.3.

Usage Guidelines	Use this command to display ATM DXI PVI interface information using the available keywords and arguments. More than one interface type and interface number can be specified. The interface keyword with the interface type and interface number can be specified again optionally after the first instance of the interface keyword, interface type and interface number.
-------------------------	--

Examples	The following is sample output from the show dxi pvc interface command. The fields are self-explanatory.
-----------------	---

```
Router# show dxi pvc interface serial 2/0
```

```
PVC Statistics for interface Serial2/0 (ATM DXI)
DFA = 170, VPI = 10, VCI = 10, PVC STATUS = STATIC, INTERFACE = Serial2/0
input pkts 5 output pkts 5 in bytes 510
out bytes 510 dropped pkts 0
```


show ima interface atm

To display information about all configured inverse multiplexing over ATM (IMA) groups or a specific group, use the **show ima interface atm** command in privileged EXEC mode.

Cisco 2600 and 3600 Series

```
show ima interface atm [slot/imagroup-number] [detail]
```

Cisco 7200 Series

```
show ima interface atm [slot/port] [detail]
```

or

```
show ima interface atm [slot/port-adapter/imagroup-number] [detail]
```

Cisco 7500 Series

```
show ima interface atm [slot/port-adapter/slot] [detail]
```

or

```
show ima interface atm [slot/port-adapter/imagroup-number] [detail]
```

Syntax Description	
<i>slot/</i>	(Optional) ATM slot number.
ima	(Optional) This keyword indicates an IMA group specification rather than a port value for a UNI interface.
<i>group-number</i>	(Optional) Enter an IMA group number from 0 to 3. If you specify the group number, do not insert a space between ima and the number.
<i>port</i>	(Optional) ATM port number.
<i>port-adapter/</i>	(Optional) ATM port adapter.
detail	(Optional) To obtain detailed information, use this keyword.

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	12.0(5)XK	This command was introduced.
	12.0(5)XE	Support for Cisco 7200 and 7500 series routers was added.
	12.0(7)XE1	Support for Cisco 7100 series routers was added.
	12.1(5)T	Support for Cisco 7100, 7200, and 7500 series routers was integrated in Cisco IOS Release 12.1(5)T.

Release	Modification
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Use this command to monitor the status of IMA group links.

Examples

On Cisco 7100 or 7200 series routers, the following example displays detailed information about IMA group 0 on ATM interface 2. If you do not enter the **detail** keyword, you do not see the IMA MIB information or the “Detailed Link Information” output.

```
Router# show ima interface atm 5/ima0 detail
```

```
ATM5/ima0 is up
  ImaGroupState:NearEnd = operational, FarEnd = operational
  ImaGroupFailureStatus = noFailure
IMA Group Current Configuration:
  ImaGroupMinNumTxLinks = 2      ImaGroupMinNumRxLinks = 2
  ImaGroupDiffDelayMax  = 250    ImaGroupNeTxClkMode  = common(ctc)
  ImaGroupFrameLength   = 128    ImaTestProcStatus    = disabled
  ImaGroupTestLink      = 0      ImaGroupTestPattern   = 0xFF
IMA MIB Information:
  ImaGroupSymmetry      = symmetricOperation
  ImaGroupFeTxClkMode   = common(ctc)
  ImaGroupRxFrameLength = 128
  ImaGroupTxTimingRefLink = 0      ImaGroupRxTimingRefLink = 0
  ImaGroupTxImaId       = 0      ImaGroupRxImaId       = 0
  ImaGroupNumTxCfgLinks = 2      ImaGroupNumRxCfgLinks = 2
  ImaGroupNumTxActLinks = 2      ImaGroupNumRxActLinks = 2
  ImaGroupLeastDelayLink = 0      ImaGroupDiffDelayMaxObs = 0
IMA group counters:
  ImaGroupNeNumFailures = 1      ImaGroupFeNumFailures = 2
  ImaGroupUnAvailSecs   = 18     ImaGroupRunningSecs   = 241
IMA Detailed Link Information:

ATM5/0 is up
  ImaLinkRowStatus = active
  ImaLinkIfIndex   = 1          ImaLinkGroupIndex = 47
  ImaLinkState:
    NeTx = active
    NeRx = active
    FeTx = active
    FeRx = active
  ImaLinkFailureStatus:
    NeRx = noFailure
    FeRx = noFailure
  ImaLinkTxLid      = 0          ImaLinkRxLid      = 0
  ImaLinkRxTestPattern = 64      ImaLinkTestProcStatus = disabled
  ImaLinkRelDelay    = 0
IMA Link counters :
  ImaLinkImaViolations = 1
  ImaLinkNeSevErroredSec = 10    ImaLinkFeSevErroredSec = 10
  ImaLinkNeUnavailSec   = 7      ImaLinkFeUnavailSec   = 8
  ImaLinkNeTxUnusableSec = 17    ImaLinkNeRxUnusableSec = 16
  ImaLinkFeTxUnusableSec = 17    ImaLinkFeRxUnusableSec = 16
  ImaLinkNeTxNumFailures = 0      ImaLinkNeRxNumFailures = 2
```

```

        ImaLinkFeTxNumFailures = 1          ImaLinkFeRxNumFailures = 1

ATM5/1 is up
  ImaLinkRowStatus = active
  ImaLinkIfIndex   = 2                    ImaLinkGroupIndex = 47
  ImaLinkState:
    NeTx = active
    NeRx = active
    FeTx = active
    FeRx = active
  ImaLinkFailureStatus:
    NeRx = noFailure
    FeRx = noFailure
  ImaLinkTxLid      = 1                    ImaLinkRxLid      = 1
  ImaLinkRxTestPattern = 64                ImaLinkTestProcStatus = disabled
  ImaLinkRelDelay    = 0

IMA Link counters :
  ImaLinkImaViolations = 1
  ImaLinkNeSevErroredSec = 10              ImaLinkFeSevErroredSec = 10
  ImaLinkNeUnavailSec    = 7                ImaLinkFeUnavailSec    = 8
  ImaLinkNeTxUnusableSec = 16              ImaLinkNeRxUnusableSec = 16
  ImaLinkFeTxUnusableSec = 16              ImaLinkFeRxUnusableSec = 16
  ImaLinkNeTxNumFailures = 0                ImaLinkNeRxNumFailures = 2
  ImaLinkFeTxNumFailures = 1                ImaLinkFeRxNumFailures = 1

```

On a Cisco 2600 or 3600 series router, the following example displays detailed information about IMA group 0 on ATM interface 2. Without the **detail** keyword, only the information up to “Detailed group Information:” appears.

```
Router# show ima interface atm 4/ima0 detail
```

```

Interface ATM2/IMA2 is up
  Group index is 2
  Ne state is operational, failure status is noFailure
  active links bitmap 0x30
  IMA Group Current Configuration:
    Tx/Rx configured links bitmap 0x30/0x30
    Tx/Rx minimum required links 1/1
    Maximum allowed diff delay is 25ms, Tx frame length 128
    Ne Tx clock mode CTC, configured timing reference link ATM2/4
    Test pattern procedure is disabled
  Detailed group Information:
    Tx/Rx Ima_id 0x22/0x40, symmetry symmetricOperation
    Number of Tx/Rx configured links 2/2
    Number of Tx/Rx active links 2/2
    Fe Tx clock mode ctc, Rx frame length 128
    Tx/Rx timing reference link 4/4
    Maximum observed diff delay 0ms, least delayed link 5
    Running seconds 32
    GTSM last changed 10:14:41 UTC Wed Jun 16 1999
  IMA Group Current Counters (time elapsed 33 seconds):
    3 Ne Failures, 3 Fe Failures, 4 Unavail Secs
  IMA Group Total Counters (last 0 15 minute intervals):
    0 Ne Failures, 0 Fe Failures, 0 Unavail Secs
  Detailed IMA link Information:

Interface ATM2/4 is up
  ifIndex 13, Group Index 2, Row Status is active
  Tx/Rx Lid 4/4, relative delay 0ms
  Ne Tx/Rx state active/active
  Fe Tx/Rx state active/active
  Ne Rx failure status is noFailure
  Fe Rx failure status is noFailure
  Rx test pattern 0x41, test procedure disabled

```

```
show ima interface atm
```

```
IMA Link Current Counters (time elapsed 35 seconds):
  1 Ima Violations, 0 Oif Anomalies
  1 Ne Severely Err Secs, 2 Fe Severely Err Secs
  0 Ne Unavail Secs, 0 Fe Unavail Secs
  2 Ne Tx Unusable Secs, 2 Ne Rx Unusable Secs
  0 Fe Tx Unusable Secs, 2 Fe Rx Unusable Secs
  0 Ne Tx Failures, 0 Ne Rx Failures
  0 Fe Tx Failures, 0 Fe Rx Failures
IMA Link Total Counters (last 0 15 minute intervals):
  0 Ima Violations, 0 Oif Anomalies
  0 Ne Severely Err Secs, 0 Fe Severely Err Secs
  0 Ne Unavail Secs, 0 Fe Unavail Secs
  0 Ne Tx Unusable Secs, 0 Ne Rx Unusable Secs
  0 Fe Tx Unusable Secs, 0 Fe Rx Unusable Secs
  0 Ne Tx Failures, 0 Ne Rx Failures
  0 Fe Tx Failures, 0 Fe Rx Failures
```

```
Interface ATM2/5 is up
  ifIndex 14, Group Index 2, Row Status is active
  Tx/Rx Lid 5/5, relative delay 0ms
  Ne Tx/Rx state active/active
  Fe Tx/Rx state active/active
  Ne Rx failure status is noFailure
  Fe Rx failure status is noFailure
  Rx test pattern 0x41, test procedure disabled
IMA Link Current Counters (time elapsed 46 seconds):
  1 Ima Violations, 0 Oif Anomalies
  1 Ne Severely Err Secs, 2 Fe Severely Err Secs
  0 Ne Unavail Secs, 0 Fe Unavail Secs
  2 Ne Tx Unusable Secs, 2 Ne Rx Unusable Secs
  0 Fe Tx Unusable Secs, 2 Fe Rx Unusable Secs
  0 Ne Tx Failures, 0 Ne Rx Failures
  0 Fe Tx Failures, 0 Fe Rx Failures
IMA Link Total Counters (last 0 15 minute intervals):
  0 Ima Violations, 0 Oif Anomalies
  0 Ne Severely Err Secs, 0 Fe Severely Err Secs
  0 Ne Unavail Secs, 0 Fe Unavail Secs
  0 Ne Tx Unusable Secs, 0 Ne Rx Unusable Secs
  0 Fe Tx Unusable Secs, 0 Fe Rx Unusable Secs
  0 Ne Tx Failures, 0 Ne Rx Failures
  0 Fe Tx Failures, 0 Fe Rx Failures
```

Related Commands

Command	Description
show controllers atm	Displays information about an IMA group.

show interface cbr

To display information about the constant bit rate (CBR) interface on the ATM-CES port adapter, use the **show interface cbr** command in privileged EXEC mode.

show interface cbr *slot/port*

Syntax Description	<i>slot/port</i>	Interface slot and port.
---------------------------	------------------	--------------------------

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	11.1	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following is sample output from the **show interface cbr** command.

```
Router# show interface cbr 6/0
```

```
CBR6/0 is up, line protocol is up
  Hardware is DCU
  MTU 0 bytes, BW 1544 Kbit, DLY 0 usec, rely 255/255, load 248/255
  Encapsulation ET_ATMCES_T1, loopback not set
  Last input 00:00:00, output 00:00:00, output hang never
  Last clearing of "show interface" counters never
  Queueing strategy: fifo
  Output queue 0/0, 0 drops; input queue 0/75, 0 drops
  5 minute input rate 1507000 bits/sec, 3957 packets/sec
  5 minute output rate 1507000 bits/sec, 3955 packets/sec
    3025960 packets input, 142220120 bytes, 0 no buffer
    Received 0 broadcasts, 0 runts, 0 giants
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
    3030067 packets output, 142413149 bytes, 0 underruns
    0 output errors, 0 collisions, 0 interface resets
    0 output buffer failures, 0 output buffers swapped out
```

[Table 30](#) describes the fields shown in the display.

Table 30 *show interface cbr Field Descriptions*

Field	Description
CBR6/0 is...	Type, slot, and port number of the interface and indicates whether the interface hardware is currently active (whether carrier detect is present), down, or if it has been taken down by an administrator.
line protocol is...	Indicates whether the software processes that handle the line protocol think the line is usable (that is, whether keepalives are successful). Values are up, down, and administratively down.
Hardware is...	Hardware type.
MTU	Maximum transmission unit of the interface.
BW	Bandwidth of the interface in kilobits per second.
DLY	Delay of the interface, in microseconds.
rely	Reliability of the interface as a fraction of 255 (255/255 is 100% reliability), calculated as an exponential average over 5 minutes.
load	Load on the interface as a fraction of 255 (255/255 is completely saturated), calculated as an exponential average over 5 minutes. The calculation uses the value from the bandwidth interface configuration command.
Encapsulation	Encapsulation method assigned to interface.
loopback not set	Indicates whether or not loopback is set.
Last input	Number of hours, minutes, and seconds since the last packet was successfully received by an interface. Useful for knowing when a dead interface failed.
Last output	Number of hours, minutes, and seconds since the last packet was successfully transmitted by an interface.
output hang	Number of hours, minutes, and seconds (or never) since the interface was last reset because of a transmission that took too long. When the number of hours in any of the “last” fields exceeds 24 hours, the number of days and hours is printed. If that field overflows, asterisks are printed.
Last clearing	The time at which the counters that measure cumulative statistics (such as number of bytes transmitted and received) shown in this report were last reset to zero. Note that variables that might affect routing (for example, load and reliability) are not cleared when the counters are cleared. *** indicates that the elapsed time is too large to be displayed. 0:00:00 indicates that the counters were cleared more than 2^{31} ms (and less than 2^{32} ms) ago.
Queueing strategy	First-in, first-out queueing strategy (other queueing strategies you might see are priority-list, custom-list, and weighted fair).
Output queue, drops input queue, drops	Number of packets in output and input queues. Each number is followed by a slash, the maximum size of the queue, and the number of packets dropped due to a full queue.
5 minute input rate, 5 minute output rate	Average number of bits and packets transmitted per second in the last 5 minutes.
packets input	Total number of error-free packets received by the system.

Table 30 *show interface cbr Field Descriptions (continued)*

Field	Description
bytes input	Total number of bytes, including data and MAC encapsulation, in the error-free packets received by the system.
no buffer	Number of received packets discarded because there was no buffer space in the main system. Compare with ignored count. Broadcast storms on Ethernets and bursts of noise on serial lines are often responsible for no input buffer events.
broadcasts	Total number of broadcast or multicast packets received by the interface.
runts	Number of packets that are discarded because they are smaller than the medium's minimum packet size.
giants	Number of packets that are discarded because they exceed the medium's maximum packet size.
input errors	Total number of no buffer, runts, giants, CRCs, frame, overrun, ignored, and abort counts. Other input-related errors can also increment the count, so that this sum may not balance with the other counts.
CRC	Cyclic redundancy checksum generated by the originating LAN station or far end device does not match the checksum calculated from the data received. On a LAN, this usually indicates noise or transmission problems on the LAN interface or the LAN bus itself. A high number of CRCs is usually the result of collisions or a station transmitting bad data. On a serial link, CRCs usually indicate noise, gain hits or other transmission problems on the data link.
frame	Number of packets received incorrectly having a CRC error and a noninteger number of octets.
overrun	Number of times the serial receiver hardware was unable to hand received data to a hardware buffer because the input rate exceeded the receiver's ability to handle the data.
ignored	Number of received packets ignored by the interface because the interface hardware ran low on internal buffers. These buffers are different than the system buffers mentioned previously in the buffer description. Broadcast storms and bursts of noise can cause the ignored count to be incremented.
abort	Illegal sequence of one bits on the interface. This usually indicates a clocking problem between the interface and the data link equipment.
packets output	Total number of messages transmitted by the system.
bytes	Total number of bytes, including data and MAC encapsulation, transmitted by the system.
underruns	Number of times that the transmitter has been running faster than the router can handle. This may never be reported on some interfaces.
output errors	Sum of all errors that prevented the final transmission of datagrams out of the interface being examined. Note that this may not balance with the sum of the enumerated output errors, as some datagrams may have more than one error, and others may have errors that do not fall into any of the specifically tabulated categories.
collisions	Because collisions do not occur on CBR interfaces, this statistic is always zero.

Table 30 *show interface cbr Field Descriptions (continued)*

Field	Description
interface resets	Number of times an interface has been reset. The interface may be reset by the administrator or automatically when an internal error occurs.
output buffer failures	Number of no resource errors received on the output.
output buffers swapped out	Number of packets swapped to DRAM.

Related Commands

Command	Description
show ces interface cbr	Displays detailed CBR port information.

show interfaces atm

To display information about the ATM interface, use the **show interfaces atm** command in privileged EXEC mode.

Cisco 7500 series with AIP; Cisco 7200 series with ATM, ATM-CES, and enhanced ATM port adapter; Cisco 2600 and 3600 series with 1-port ATM-25 network module

show interfaces atm [*slot/port*]

Cisco 7500 series routers with the ATM port adapter and enhanced ATM port adapter

show interfaces atm [*slot/port-adapter/port*]

Syntax Description	
<i>slot/port</i>	(Optional) ATM slot number and port number. Use this format for the following platform configurations: • The AIP on Cisco 7500 series routers. • The ATM port adapter, ATM-CES port adapter, or enhanced ATM port adapter on Cisco 7200 series routers. • The 1-port ATM-25 network module on Cisco 2600 and 3600 series routers.
<i>slot/port-adapter/port</i>	(Optional) ATM slot, port adapter, and port numbers. Use this format for the ATM port adapter or enhanced ATM port adapter on Cisco 2600 and 3600 series routers.

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	10.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples The following is sample output from the **show interfaces atm** command:

```
Router# show interfaces atm 4/0
```

```
ATM4/0 is up, line protocol is up
Hardware is cxBus ATM
Internet address is 10.108.97.165, subnet mask is 255.255.255.0
MTU 4470 bytes, BW 100000 Kbit, DLY 100 usec, rely 255/255, load 1/255
ATM E164 Auto Conversion Interface
Encapsulation ATM, loopback not set, keepalive set (10 sec)
Encapsulation(s): AAL5, PVC mode
256 TX buffers, 256 RX buffers, 1024 Maximum VCs, 1 Current VCs
```

```

Signalling vc = 1, vpi = 0, vci = 5
ATM NSAP address: BC.CDEF.01.234567.890A.BCDE.F012.3456.7890.1234.13
Last input 0:00:05, output 0:00:05, output hang never
Last clearing of "show interface" counters never
Output queue 0/40, 0 drops; input queue 0/75, 0 drops
Five minute input rate 0 bits/sec, 0 packets/sec
Five minute output rate 0 bits/sec, 0 packets/sec
    144 packets input, 3148 bytes, 0 no buffer
    Received 0 broadcasts, 0 runts, 0 giants
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
    154 packets output, 4228 bytes, 0 underruns
    0 output errors, 0 collisions, 1 interface resets, 0 restarts

```

The following is sample output from the **show interfaces atm** command for the ATM port adapter on a Cisco 7500 series router:

Router# **show interfaces atm 0/0/0**

```

ATM0/0/0 is up, line protocol is up
Hardware is cyBus ATM
Internet address is 10.1.1.1/24
MTU 4470 bytes, sub MTU 4470, BW 156250 Kbit, DLY 80 usec, rely 255/255, load 1/255
Encapsulation ATM, loopback not set, keepalive set (10 sec)
Encapsulation(s): AAL5, PVC mode
256 TX buffers, 256 RX buffers,
2048 maximum active VCs, 1024 VCs per VP, 1 current VCCs
VC idle disconnect time: 300 seconds
Last input never, output 00:00:05, output hang never
Last clearing of "show interface" counters never
Queueing strategy: fifo
Output queue 0/40, 0 drops; input queue 0/75, 0 drops
5 minute input rate 0 bits/sec, 1 packets/sec
5 minute output rate 0 bits/sec, 1 packets/sec
    5 packets input, 560 bytes, 0 no buffer
    Received 0 broadcasts, 0 runts, 0 giants
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
    5 packets output, 560 bytes, 0 underruns
    0 output errors, 0 collisions, 0 interface resets
    0 output buffer failures, 0 output buffers swapped out

```

Table 31 describes the fields shown in both the displays.

Table 31 *show interfaces atm Field Descriptions*

Field	Description
ATM... is {up down administratively down}	Indicates whether the interface hardware is currently active (whether carrier detect is present) and if it has been taken down by an administrator.
line protocol is {up down administratively down}	Indicates whether the software processes that handle the line protocol think the line is usable (that is, whether keepalives are successful).
Hardware is	Hardware type.
Internet address is	Internet address and subnet mask.
MTU	Maximum Transmission Unit of the interface.
sub MTU	Maximum Transmission Unit of the subinterface.
BW	Bandwidth of the interface in kilobits per second.
DLY	Delay of the interface in microseconds.

Table 31 *show interfaces atm Field Descriptions (continued)*

Field	Description
rely	Reliability of the interface as a fraction of 255 (255/255 is 100% reliability), calculated as an exponential average over 5 minutes.
load	Load on the interface as a fraction of 255 (255/255 is completely saturated), calculated as an exponential average over 5 minutes. The calculation uses the value from the bandwidth interface configuration command.
ATM E164 Auto Conversion Interface	Indicates that ATM E164 auto conversion is enabled. When this field is not present, ATM E164 auto conversion is disabled.
Encapsulation	Encapsulation method assigned to interface.
loopback	Indicates whether the interface is configured for loopback testing.
keepalive	Indicates whether keepalives are set or not.
Encapsulation(s)	Type of encapsulation used on the interface (for example, AAL5, and either PVC or SVC mode).
TX buffers	Number of buffers configured with the atm txbuff command.
RX buffers	Number of buffers configured with the atm rxbuff command.
Maximum active VCs	Maximum number of virtual circuits.
VCs per VP	Number of virtual circuits per virtual path (the default is 1024).
Current VCs	Number of virtual circuit connections currently open.
VC idle disconnect time	Number of seconds the SVC must be idle before the SVC is disconnected.
Signalling vc	Number of the signaling PVC.
vpi	Virtual path identifier number.
vci	Virtual channel identifier number.
ATM NSAP address	NSAP address of the ATM interface.
Last input	Number of hours, minutes, and seconds since the last packet was successfully received by an interface. Useful for knowing when a dead interface failed.
Last output	Number of hours, minutes, and seconds since the last packet was successfully transmitted by an interface.
output hang	Number of hours, minutes, and seconds (or never) since the interface was last reset because of a transmission that took too long. When the number of hours in any of the “last” fields exceeds 24 hours, the number of days and hours is printed. If that field overflows, asterisks are printed.
Last clearing	The time at which the counters that measure cumulative statistics (such as number of bytes transmitted and received) shown in this report were last reset to zero. Note that variables that might affect routing (for example, load and reliability) are not cleared when the counters are cleared. *** indicates that the elapsed time is too large to be displayed. 0:00:00 indicates that the counters were cleared more than 2³¹ms (and less than 2³²ms) ago.
Queueing strategy	First-in, first-out queueing strategy (other queueing strategies you might see are priority-list, custom-list, and weighted fair).

Table 31 *show interfaces atm Field Descriptions (continued)*

Field	Description
Output queue, drops input queue, drops	Number of packets in output and input queues. Each number is followed by a slash, the maximum size of the queue, and the number of packets dropped due to a full queue.
5 minute input rate, 5 minute output rate	Average number of bits and packets transmitted per second in the last 5 minutes.
packets input	Total number of error-free packets received by the system.
bytes input	Total number of bytes, including data and MAC encapsulation, in the error free packets received by the system.
no buffer	Number of received packets discarded because there was no buffer space in the main system. Compare with ignored count. Broadcast storms on Ethernets and bursts of noise on serial lines are often responsible for no input buffer events.
Received broadcasts	Total number of broadcast or multicast packets received by the interface.
runts	Number of packets that are discarded because they are smaller than the medium's minimum packet size.
giants	Number of packets that are discarded because they exceed the medium's maximum packet size.
input errors	Total number of no buffer, runts, giants, CRCs, frame, overrun, ignored, and abort counts. Other input-related errors can also increment the count, so that this sum may not balance with the other counts.
CRC	Cyclic redundancy checksum generated by the originating LAN station or far-end device does not match the checksum calculated from the data received. On a LAN, this usually indicates noise or transmission problems on the LAN interface or the LAN bus itself. A high number of CRCs is usually the result of collisions or a station transmitting bad data. On a serial link, CRCs usually indicate noise, gain hits or other transmission problems on the data link.
frame	Number of packets received incorrectly having a CRC error and a noninteger number of octets.
overrun	Number of times the serial receiver hardware was unable to hand received data to a hardware buffer because the input rate exceeded the receiver's ability to handle the data.
ignored	Number of received packets ignored by the interface because the interface hardware ran low on internal buffers. These buffers are different than the system buffers mentioned previously in the buffer description. Broadcast storms and bursts of noise can cause the ignored count to be incremented.
abort	Illegal sequence of one bits the interface. This usually indicates a clocking problem between the interface and the data link equipment.
packets output	Total number of messages transmitted by the system.
bytes	Total number of bytes, including data and MAC encapsulation, transmitted by the system.
underruns	Number of times that the transmitter has been running faster than the router can handle. This may never be reported on some interfaces.

Table 31 *show interfaces atm Field Descriptions (continued)*

Field	Description
output errors	Sum of all errors that prevented the final transmission of datagrams out of the interface being examined. Note that this may not balance with the sum of the enumerated output errors, as some datagrams may have more than one error, and others may have errors that do not fall into any of the specifically tabulated categories.
collisions	This feature is not applicable for ATM interfaces.
interface resets	Number of times an interface has been completely reset. This can happen if packets queued for transmission were not sent within several seconds. On a serial line, this can be caused by a malfunctioning modem that is not supplying the transmit clock signal, or by a cable problem. If the system notices that the carrier detect line of a serial interface is up, but the line protocol is down, it periodically resets the interface in an effort to restart it. Interface resets can also occur when an interface is looped back or shut down.
output buffer failures	Number of times that a packet was not output from the output hold queue because of a shortage of MEMD shared memory.
output buffers swapped out	Number of packets stored in main memory when the output queue is full; swapping buffers to main memory prevents packets from being dropped when output is congested. The number is high when traffic is bursty.
restarts	Number of times the controller was restarted because of errors.

show lane

To display detailed information for all the LAN Emulation (LANE) components configured on an interface or any of its subinterfaces, on a specified subinterface, or on an emulated LAN (ELAN), use the **show lane** command in user EXEC or privileged EXEC mode.

AIP on the Cisco 7500 Series Routers; ATM Port Adapter on the Cisco 7200 Series

```
show lane [interface atm slot/port[.subinterface-number] | name elan-name] [brief]
```

ATM Port Adapter on the Cisco 7500 Series Routers

```
show lane [interface atm slot/port-adapter/port[.subinterface-number] | name elan-name] [brief]
```

Cisco 4500 and 4700 Routers

```
show lane [interface atm number[.subinterface-number] | name elan-name] [brief]
```

Syntax Description		
interface atm <i>slot/port</i>		(Optional) ATM interface slot and port for the following: - AIP on the Cisco 7500 series routers. - ATM port adapter on the Cisco 7200 series routers.
interface atm <i>slot/port-adapter/port</i>		(Optional) ATM interface slot, port adapter, and port number for the ATM port adapter on the Cisco 7500 series routers.
interface atm <i>number</i>		(Optional) ATM interface number for the NPM on the Cisco 4500 or 4700 routers.
<i>.subinterface-number</i>		(Optional) Subinterface number.
name <i>elan-name</i>		(Optional) Name of the ELAN. The maximum length of the name is 32 characters.
brief		(Optional) Keyword used to display the brief subset of available information.

Command Modes	User EXEC Privileged EXEC
---------------	------------------------------

Command History	Release	Modification
	11.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Using the **show lane** command is equivalent to using the **show lane config**, **show lane server**, **show lane bus**, and **show lane client** commands. The **show lane** command shows all LANE-related information except the **show lane database** command information.

Examples

The following is sample output from the **show lane** command for an Ethernet ELAN:

```
Router# show lane
```

```
LE Config Server ATM2/0 config table: cisco_eng
Admin: up State: operational
LECS Mastership State: active master
list of global LECS addresses (30 seconds to update):
39.020304050607080910111213.00000CA05B43.00 <----- me
ATM Address of this LECS: 39.020304050607080910111213.00000CA05B43.00 (auto)
vcd rxCnt txCnt callingParty
  50      2      2 39.020304050607080910111213.00000CA05B41.02 LES elan2 0 active
cumulative total number of unrecognized packets received so far: 0
cumulative total number of config requests received so far: 30
cumulative total number of config failures so far: 12
cause of last failure: no configuration
culprit for the last failure: 39.020304050607080910111213.00602F557940.01
```

```
LE Server ATM2/0.2 ELAN name: elan2 Admin: up State: operational
type: ethernet Max Frame Size: 1516
ATM address: 39.020304050607080910111213.00000CA05B41.02
LECS used: 39.020304050607080910111213.00000CA05B43.00 connected, vcd 51
control distribute: vcd 57, 2 members, 2 packets
```

```
proxy/ (ST: Init, Conn, Waiting, Adding, Joined, Operational, Reject, Term)
lecid ST vcd pkts Hardware Addr ATM Address
  1  O  54      2 0000.0ca0.5b40 39.020304050607080910111213.00000CA05B40.02
  2  O  81      2 0060.2f55.7940 39.020304050607080910111213.00602F557940.02
```

```
LE BUS ATM2/0.2 ELAN name: elan2 Admin: up State: operational
type: ethernet Max Frame Size: 1516
ATM address: 39.020304050607080910111213.00000CA05B42.02
data forward: vcd 61, 2 members, 0 packets, 0 unicasts
```

```
lecid vcd pkts ATM Address
  1  58      0 39.020304050607080910111213.00000CA05B40.02
  2  82      0 39.020304050607080910111213.00602F557940.02
```

```
LE Client ATM2/0.2 ELAN name: elan2 Admin: up State: operational
Client ID: 1 LEC up for 11 minutes 49 seconds
Join Attempt: 1
HW Address: 0000.0ca0.5b40 Type: ethernet Max Frame Size: 1516
```

```
ATM Address: 39.020304050607080910111213.00000CA05B40.02
```

VCD	rxFrames	txFrames	Type	ATM Address
0	0	0	configure	39.020304050607080910111213.00000CA05B43.00
55	1	4	direct	39.020304050607080910111213.00000CA05B41.02
56	6	0	distribute	39.020304050607080910111213.00000CA05B41.02
59	0	1	send	39.020304050607080910111213.00000CA05B42.02
60	3	0	forward	39.020304050607080910111213.00000CA05B42.02
84	3	5	data	39.020304050607080910111213.00602F557940.02

The following is sample output from the **show lane** command for a Token Ring LANE network:

Router# **show lane**

```
LE Config Server ATM4/0 config table: eng
Admin: up State: operational
LECS Mastership State: active master
list of global LECS addresses (35 seconds to update):
39.020304050607080910111213.006047704183.00
ATM Address of this LECS: 39.020304050607080910111213.006047704183.00 (auto)
vcd rxCnt txCnt callingParty
  7      1      1 39.020304050607080910111213.006047704181.01 LES elan1 0 active
cumulative total number of unrecognized packets received so far: 0
cumulative total number of config requests received so far: 2
cumulative total number of config failures so far: 0
```

```
LE Server ATM4/0.1 ELAN name: elan1 Admin: up State: operational
type: token ring Max Frame Size: 4544 Segment ID: 2048
ATM address: 39.020304050607080910111213.006047704181.01
LECS used: 39.020304050607080910111213.006047704183.00 connected, vcd 9
control distribute: vcd 12, 1 members, 2 packets
```

```
proxy/ (ST: Init, Conn, Waiting, Adding, Joined, Operational, Reject, Term)
lecid ST vcd pkts Hardware Addr ATM Address
  1  0   8      3 100.2          39.020304050607080910111213.006047704180.01
                                0060.4770.4180 39.020304050607080910111213.006047704180.01
```

```
LE BUS ATM4/0.1 ELAN name: elan1 Admin: up State: operational
type: token ring Max Frame Size: 4544 Segment ID: 2048
ATM address: 39.020304050607080910111213.006047704182.01
data forward: vcd 16, 1 members, 0 packets, 0 unicasts
```

```
lecid vcd pkts ATM Address
  1  13      0 39.020304050607080910111213.006047704180.01
```

```
LE Client ATM4/0.1 ELAN name: elan1 Admin: up State: operational
Client ID: 1 LEC up for 2 hours 25 minutes 39 seconds
Join Attempt: 3
HW Address: 0060.4770.4180 Type: token ring Max Frame Size: 4544
Ring:100 Bridge:2 ELAN Segment ID: 2048
ATM Address: 39.020304050607080910111213.006047704180.01
```

VCD	rxFrames	txFrames	Type	ATM Address
0	0	0	configure	39.020304050607080910111213.006047704183.00
10	1	3	direct	39.020304050607080910111213.006047704181.01
11	2	0	distribute	39.020304050607080910111213.006047704181.01
14	0	0	send	39.020304050607080910111213.006047704182.01
15	0	0	forward	39.020304050607080910111213.006047704182.01

Table 32 describes significant fields shown in the display.

Table 32 *show lane Field Descriptions*

Field	Description
LE Config Server	Identifies the following lines as applying to the LANE configuration server. These lines are also displayed in output from the show lane config command. See the show lane config command for explanations of the output.
LE Server	Identifies the following lines as applying to the LANE server. These lines are also displayed in output from the show lane server command. See the show lane server command for explanations of the output.
LE BUS	Identifies the following lines as applying to the LANE broadcast and unknown server. These lines are also displayed in output from the show lane bus command. See the show lane bus command for explanations of the output.
LE Client	Identifies the following lines as applying to a LANE client. These lines are also displayed in output from the show lane client command. See the show lane bus command for explanations of the output.

show lane bus

To display detailed LAN Emulation (LANE) information for the broadcast and unknown server (BUS) configured on an interface or any of its subinterfaces, on a specified subinterface, or on an emulated LAN (ELAN), use the **show lane bus** command in user EXEC or privileged EXEC mode.

AIP on the Cisco 7500 Series Routers; ATM Port Adapter on the Cisco 7200 Series

```
show lane bus [interface atm slot/port[.subinterface-number] | name elan-name] [brief]
```

ATM Port Adapter on the Cisco 7500 Series Routers

```
show lane bus [interface atm slot/port-adapter/port[.subinterface-number] | name elan-name] [brief]
```

Cisco 4500 and 4700 Routers

```
show lane bus [interface atm number[.subinterface-number] | name elan-name] [brief]
```

Syntax Description		
interface atm <i>slot/port</i>	(Optional) ATM interface slot and port for the following:	- AIP on the Cisco 7500 series routers. - ATM port adapter on the Cisco 7200 series routers.
interface atm <i>slot/port-adapter/port</i>	(Optional) ATM interface slot, port adapter, and port number for the ATM port adapter on the Cisco 7500 series routers.	
interface atm <i>number</i>	(Optional) ATM interface number for the NPM on the Cisco 4500 or 4700 routers.	
<i>.subinterface-number</i>	(Optional) Subinterface number.	
name <i>elan-name</i>	(Optional) Name of the ELAN. The maximum length of the name is 32 characters.	
brief	(Optional) Displays the brief subset of available information.	

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
11.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following is sample output from the **show lane bus** command for an Ethernet ELAN:

```
Router# show lane bus

LE BUS ATM2/0.2  ELAN name: elan2  Admin: up  State: operational
type: ethernet           Max Frame Size: 1516
ATM address: 39.020304050607080910111213.00000CA05B42.02
data forward: vcd 61, 2 members, 0 packets, 0 unicasts

lecid  vcd      pkts   ATM Address
  1    58        0  39.020304050607080910111213.00000CA05B40.02
  2    82        0  39.020304050607080910111213.00602F557940.02
```

The following is sample output from the **show lane bus** command for a Token Ring LANE:

```
show lane bus

LE BUS ATM3/0.1  ELAN name: anubis  Admin: up  State: operational
type: token ring           Max Frame Size: 4544      Segment ID: 2500
ATM address: 47.00918100000000000000000000.00000CA01662.01
data forward: vcd 14, 2 members, 0 packets, 0 unicasts

lecid  vcd      pkts   ATM Address
  1    11        0  47.00918100000000000000000000.00000CA01660.01
  2    17        0  47.00918100000000000000000000.00000CA04960.01
```

Table 33 describes significant fields shown in the display.

Table 33 *show lane bus Field Descriptions*

Field	Description
LE BUS ATM2/0.2	Interface and subinterface for which information is displayed.
ELAN name	Name of the ELAN for this BUS.
Admin	Administrative state, either up or down.
State	Status of this LANE BUS. Possible states include down and operational.
type	Type of ELAN.
Max Frame Size	Maximum frame size (in bytes) on the ELAN.
Segment ID	The ring number of the ELAN. This field appears only for Token Ring LANE.
ATM address	ATM address of this LANE BUS.
data forward	Virtual channel descriptor of the Data Forward VCC, the number of LANE clients attached to the VCC, and the number of packets sent on the VCC.
lecid	Identifier assigned to each LANE client on the Data Forward VCC.
vcd	Virtual channel descriptor used to reach the LANE client.
pkts	Number of packets sent by the BUS to the LANE client.
ATM Address	ATM address of the LANE client.

show ima interface atm

To display information about all configured inverse multiplexing over ATM (IMA) groups or a specific group, use the **show ima interface atm** command in privileged EXEC mode.

Cisco 2600 and 3600 Series

```
show ima interface atm [slot/imagroup-number] [detail]
```

Cisco 7200 Series

```
show ima interface atm [slot/port] [detail]
```

or

```
show ima interface atm [slot/port-adapter/imagroup-number] [detail]
```

Cisco 7500 Series

```
show ima interface atm [slot/port-adapter/slot] [detail]
```

or

```
show ima interface atm [slot/port-adapter/imagroup-number] [detail]
```

Cisco 7600 Series

```
show ima interface atm [slot/subslot/imagroup-number] [detail]
```

Syntax Description

<i>slot/</i>	(Optional) ATM slot number.
ima	(Optional) This keyword indicates an IMA group specification rather than a port value for a UNI interface.
<i>group-number</i>	(Optional) Enter an IMA group number from 0 to 3. If you specify the group number, do not insert a space between ima and the number. For Cisco 7600 series routers, the value of <i>group-number</i> is as follows: 0 to 11 (24-port Channelized T1/E1 CEoP ATM SPA) 0 to 41 (1-port Channelized OC3/STM-1 CEoP ATM SPA)
<i>port</i>	(Optional) ATM port number.
<i>port-adapter/</i>	(Optional) ATM port adapter.
<i>subslot/</i>	(Optional) SIP subslot where CEoP ATM SPA is installed.
detail	(Optional) To obtain detailed information, use this keyword.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.0(5)XK	This command was introduced.
12.0(5)XE	Support for Cisco 7200 and 7500 series routers was added.
12.0(7)XE1	Support for Cisco 7100 series routers was added.
12.1(5)T	Support for Cisco 7100, 7200, and 7500 series routers was integrated in Cisco IOS Release 12.1(5)T.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
12.2(33)SRB2	Support for Cisco 7600 series routers was added for the 24-Port Channelized ATM CEsP SPA and 1-Port Channelized OC-3/STM-1 ATM CEsP SPA.

Usage Guidelines

Use this command to monitor the status of IMA group links.

Examples**Cisco 7100 and 7200 series routers**

The following example displays detailed information about IMA group 0 on ATM interface 2. If you do not enter the **detail** keyword, you do not see the IMA MIB information or the “Detailed Link Information” output.

```
Router# show ima interface atm 5/ima0 detail
```

```
ATM5/ima0 is up
  ImaGroupState:NearEnd = operational, FarEnd = operational
  ImaGroupFailureStatus = noFailure
IMA Group Current Configuration:
  ImaGroupMinNumTxLinks = 2      ImaGroupMinNumRxLinks = 2
  ImaGroupDiffDelayMax   = 250   ImaGroupNeTxClkMode  = common(ctc)
  ImaGroupFrameLength    = 128   ImaTestProcStatus    = disabled
  ImaGroupTestLink       = 0      ImaGroupTestPattern   = 0xFF
IMA MIB Information:
  ImaGroupSymmetry       = symmetricOperation
  ImaGroupFeTxClkMode    = common(ctc)
  ImaGroupRxFrameLength  = 128
  ImaGroupTxTimingRefLink = 0      ImaGroupRxTimingRefLink = 0
  ImaGroupTxImaId        = 0      ImaGroupRxImaId        = 0
  ImaGroupNumTxCfgLinks  = 2      ImaGroupNumRxCfgLinks  = 2
  ImaGroupNumTxActLinks  = 2      ImaGroupNumRxActLinks  = 2
  ImaGroupLeastDelayLink = 0      ImaGroupDiffDelayMaxObs = 0
IMA group counters:
  ImaGroupNeNumFailures  = 1      ImaGroupFeNumFailures  = 2
  ImaGroupUnAvailSecs    = 18     ImaGroupRunningSecs    = 241
IMA Detailed Link Information:

ATM5/0 is up
  ImaLinkRowStatus = active
  ImaLinkIfIndex   = 1           ImaLinkGroupIndex = 47
  ImaLinkState:
    NeTx = active
    NeRx = active
    FeTx = active
    FeRx = active
  ImaLinkFailureStatus:
    NeRx = noFailure
```

show ima interface atm

```

                FeRx = noFailure
                ImaLinkTxLid      = 0          ImaLinkRxLid      = 0
                ImaLinkRxTestPattern = 64      ImaLinkTestProcStatus = disabled
                ImaLinkRelDelay    = 0

IMA Link counters :
                ImaLinkImaViolations = 1
                ImaLinkNeSevErroredSec = 10      ImaLinkFeSevErroredSec = 10
                ImaLinkNeUnavailSec    = 7          ImaLinkFeUnAvailSec    = 8
                ImaLinkNeTxUnusableSec = 17      ImaLinkNeRxUnUsableSec = 16
                ImaLinkFeTxUnusableSec = 17      ImaLinkFeRxUnusableSec = 16
                ImaLinkNeTxNumFailures = 0          ImaLinkNeRxNumFailures = 2
                ImaLinkFeTxNumFailures = 1          ImaLinkFeRxNumFailures = 1

ATM5/1 is up
                ImaLinkRowStatus = active
                ImaLinkIfIndex    = 2          ImaLinkGroupIndex = 47
                ImaLinkState:
                    NeTx = active
                    NeRx = active
                    FeTx = active
                    FeRx = active
                ImaLinkFailureStatus:
                    NeRx = noFailure
                    FeRx = noFailure
                ImaLinkTxLid      = 1          ImaLinkRxLid      = 1
                ImaLinkRxTestPattern = 64      ImaLinkTestProcStatus = disabled
                ImaLinkRelDelay    = 0

IMA Link counters :
                ImaLinkImaViolations = 1
                ImaLinkNeSevErroredSec = 10      ImaLinkFeSevErroredSec = 10
                ImaLinkNeUnavailSec    = 7          ImaLinkFeUnAvailSec    = 8
                ImaLinkNeTxUnusableSec = 16      ImaLinkNeRxUnUsableSec = 16
                ImaLinkFeTxUnusableSec = 16      ImaLinkFeRxUnusableSec = 16
                ImaLinkNeTxNumFailures = 0          ImaLinkNeRxNumFailures = 2
                ImaLinkFeTxNumFailures = 1          ImaLinkFeRxNumFailures = 1

```

Cisco 7600 series routers

The following example displays information for IMA group 1 on the SPA in chassis slot 5, SIP subslot 0:

```

Router# show ima interface atm5/0/ima1
ATM5/0/ima1 is up, ACTIVATION COMPLETE
Slot 5 Slot Unit 0 unit 257, CTRL VC 257, Vir 0, VC -1
IMA Configured BW 12186, Active BW 3046
IMA version 1.0, Frame length 128
Link Test: Disabled
Auto-Restart: Disabled
                ImaGroupState: NearEnd = operational, FarEnd = operational
                ImaGroupFailureStatus = noFailure
IMA Group Current Configuration:
                ImaGroupMinNumTxLinks = 1      ImaGroupMinNumRxLinks = 1
                ImaGroupDiffDelayMax  = 25      ImaGroupNeTxClkMode  = common(ctc)
                ImaGroupFrameLength    = 128      ImaTestProcStatus    = disabled
                ImaGroupTestLink        = None      ImaGroupTestPattern   = 0x0
                ImaGroupConfLink        = 8          ImaGroupActiveLink    = 2

IMA Link Information:

```

ID	Link	Link Status	Test Status
0	T1 5/0/0	Up - controller Up	disabled
1	T1 5/0/1	Up - controller Up	disabled
2	T1 5/0/2	Down - controller Up	disabled
3	T1 5/0/3	Down - controller Up	disabled
4	T1 5/0/4	Down - controller Up	disabled
5	T1 5/0/5	Down - controller Up	disabled

```

6      T1 5/0/6          Down - controller Up          disabled
7      T1 5/0/7          Down - controller Up          disabled

```

Cisco 2600 and 3600 series routers

The following example displays detailed information about IMA group 0 on ATM interface 2. Without the **detail** keyword, only the information up to “Detailed group Information” appears.

Router# **show ima interface atm 4/ima0 detail**

```

Interface ATM2/IMA2 is up
  Group index is 2
  Ne state is operational, failure status is noFailure
  active links bitmap 0x30
  IMA Group Current Configuration:
    Tx/Rx configured links bitmap 0x30/0x30
    Tx/Rx minimum required links 1/1
    Maximum allowed diff delay is 25ms, Tx frame length 128
    Ne Tx clock mode CTC, configured timing reference link ATM2/4
    Test pattern procedure is disabled
  Detailed group Information:
    Tx/Rx Ima_id 0x22/0x40, symmetry symmetricOperation
    Number of Tx/Rx configured links 2/2
    Number of Tx/Rx active links 2/2
    Fe Tx clock mode ctc, Rx frame length 128
    Tx/Rx timing reference link 4/4
    Maximum observed diff delay 0ms, least delayed link 5
    Running seconds 32
    GTSM last changed 10:14:41 UTC Wed Jun 16 1999
  IMA Group Current Counters (time elapsed 33 seconds):
    3 Ne Failures, 3 Fe Failures, 4 Unavail Secs
  IMA Group Total Counters (last 0 15 minute intervals):
    0 Ne Failures, 0 Fe Failures, 0 Unavail Secs
  Detailed IMA link Information:

Interface ATM2/4 is up
  ifIndex 13, Group Index 2, Row Status is active
  Tx/Rx Lid 4/4, relative delay 0ms
  Ne Tx/Rx state active/active
  Fe Tx/Rx state active/active
  Ne Rx failure status is noFailure
  Fe Rx failure status is noFailure
  Rx test pattern 0x41, test procedure disabled
  IMA Link Current Counters (time elapsed 35 seconds):
    1 Ima Violations, 0 Oif Anomalies
    1 Ne Severely Err Secs, 2 Fe Severely Err Secs
    0 Ne Unavail Secs, 0 Fe Unavail Secs
    2 Ne Tx Unusable Secs, 2 Ne Rx Unusable Secs
    0 Fe Tx Unusable Secs, 2 Fe Rx Unusable Secs
    0 Ne Tx Failures, 0 Ne Rx Failures
    0 Fe Tx Failures, 0 Fe Rx Failures
  IMA Link Total Counters (last 0 15 minute intervals):
    0 Ima Violations, 0 Oif Anomalies
    0 Ne Severely Err Secs, 0 Fe Severely Err Secs
    0 Ne Unavail Secs, 0 Fe Unavail Secs
    0 Ne Tx Unusable Secs, 0 Ne Rx Unusable Secs
    0 Fe Tx Unusable Secs, 0 Fe Rx Unusable Secs
    0 Ne Tx Failures, 0 Ne Rx Failures
    0 Fe Tx Failures, 0 Fe Rx Failures

Interface ATM2/5 is up
  ifIndex 14, Group Index 2, Row Status is active
  Tx/Rx Lid 5/5, relative delay 0ms
  Ne Tx/Rx state active/active

```

■ show ima interface atm

```

Fe Tx/Rx state active/active
Ne Rx failure status is noFailure
Fe Rx failure status is noFailure
Rx test pattern 0x41, test procedure disabled
IMA Link Current Counters (time elapsed 46 seconds):
  1 Ima Violations, 0 Oif Anomalies
  1 Ne Severely Err Secs, 2 Fe Severely Err Secs
  0 Ne Unavail Secs, 0 Fe Unavail Secs
  2 Ne Tx Unusable Secs, 2 Ne Rx Unusable Secs
  0 Fe Tx Unusable Secs, 2 Fe Rx Unusable Secs
  0 Ne Tx Failures, 0 Ne Rx Failures
  0 Fe Tx Failures, 0 Fe Rx Failures
IMA Link Total Counters (last 0 15 minute intervals):
  0 Ima Violations, 0 Oif Anomalies
  0 Ne Severely Err Secs, 0 Fe Severely Err Secs
  0 Ne Unavail Secs, 0 Fe Unavail Secs
  0 Ne Tx Unusable Secs, 0 Ne Rx Unusable Secs
  0 Fe Tx Unusable Secs, 0 Fe Rx Unusable Secs
  0 Ne Tx Failures, 0 Ne Rx Failures
  0 Fe Tx Failures, 0 Fe Rx Failures

```

Related Commands

Command	Description
show controllers atm	Displays information about an IMA group.

show lane client

To display detailed LAN Emulation (LANE) information for all the LANE clients configured on an interface or any of its subinterfaces, on a specified subinterface, or on an emulated LAN (ELAN), use the **show lane client** command in user EXEC or privileged EXEC mode.

AIP on the Cisco 7500 Series Routers; ATM Port Adapter on the Cisco 7200 Series

```
show lane client detail [interface atm slot/port[.subinterface-number] | name elan-name] [brief]
```

ATM Port Adapter on the Cisco 7500 Series Routers

```
show lane client detail [interface atm slot/port-adapter/port[.subinterface-number] | name elan-name] [brief]
```

Cisco 4500 and 4700 Routers

```
show lane client detail [interface atm number[.subinterface-number] | name elan-name] [brief]
```

Syntax Description		
detail		Displays additional FSSRP information.
interface atm <i>slot/port</i>		(Optional) ATM interface slot and port for the following: • AIP on the Cisco 7500 series routers. • ATM port adapter on the Cisco 7200 series routers.
interface atm <i>slot/port-adapter/port</i>		(Optional) ATM interface slot, port adapter, and port number for the ATM port adapter on the Cisco 7500 series routers.
interface atm <i>number</i>		(Optional) ATM interface number for the NPM on the Cisco 4500 or 4700 routers.
<i>.subinterface-number</i>		(Optional) Subinterface number.
name <i>elan-name</i>		(Optional) Name of ELAN. The maximum length of the name is 32 characters.
brief		(Optional) Displays the brief subset of available information.

Command Modes	User EXEC Privileged EXEC
---------------	------------------------------

Command History	Release	Modification
	11.0	This command was introduced.
	12.0(5)T	The detail option and command output line “This client is running in FSSRP mode” were added.

Release	Modification
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following is sample output from the **show lane client** command for an Ethernet ELAN:

```
Router# show lane client

LE Client ATM2/0.2  ELAN name: elan2  Admin: up  State: operational
Client ID: 1          LEC up for 11 minutes 49 seconds
Join Attempt: 1
HW Address: 0000.0ca0.5b40  Type: ethernet          Max Frame Size: 1516

ATM Address: 39.020304050607080910111213.00000CA05B40.02

VCD  rxFrames  txFrames  Type      ATM Address
  0         0         0  configure 39.020304050607080910111213.00000CA05B43.00
 55         1         4  direct   39.020304050607080910111213.00000CA05B41.02
 56         6         0  distribute 39.020304050607080910111213.00000CA05B41.02
 59         0         1  send     39.020304050607080910111213.00000CA05B42.02
 60         3         0  forward  39.020304050607080910111213.00000CA05B42.02
 84         3         5  data     39.020304050607080910111213.00602F557940.02
```

The following is sample output from the **show lane client** command for a Token Ring LANE:

```
Router# show lane client

LE Client ATM4/0.1  ELAN name: elan1  Admin: up  State: operational
Client ID: 1          LEC up for 2 hours 26 minutes 3 seconds
Join Attempt: 3
HW Address: 0060.4770.4180  Type: token ring          Max Frame Size: 4544
Ring:100  Bridge:2          ELAN Segment ID: 2048
ATM Address: 39.020304050607080910111213.006047704180.01

VCD  rxFrames  txFrames  Type      ATM Address
  0         0         0  configure 39.020304050607080910111213.006047704183.00
 10         1         3  direct   39.020304050607080910111213.006047704181.01
 11         2         0  distribute 39.020304050607080910111213.006047704181.01
 14         0         0  send     39.020304050607080910111213.006047704182.01
 15         0         0  forward  39.020304050607080910111213.006047704182.01
```

The following is sample output from the **show lane client detail** command.

```
Router# show lane client detail

LE Client ATM1/0.1 ELAN name:xxx Admin:up State:operational
Client ID:2 LEC up for 5 days 40 minutes 45 seconds
ELAN ID:0
This client is running in FSSRP mode.
Join Attempt:14
Known LE Servers:1
Configured Idle Time:5 seconds
Last Fail Reason:Config VC being released
HW Address:00e0.8fcf.d820  Type:ethernet          Max Frame Size:1516

ATM Address:47.0091810000000061705B0C01.00E08FCFD820.01
VCD rxFramestxFramesTypeATM Address
  0  0  0  configure 47.00918100000000613E5A2F01.006070174823.00
```

LEC ID:2, State:LESBUS_ACTIVE

```

52 17783556direct47.00918100000000613E5A2F01.00000C5A0C59.01
53 17780  distribute47.00918100000000613E5A2F01.00000C5A0C59.01
54 0 0  send47.00918100000000613E5A2F01.00000C5A0C5A.01
55 0 0  forward47.00918100000000613E5A2F01.00000C5A0C5A.01

```

LEC ID:3, State:LESBUS_ACTIVE

```

93 122 234 direct47.00918100000000613E5A2F01.00000ABCD001.09
94 122 0  distribute47.00918100000000613E5A2F01.00000ABCD001.09
97 0 0  send47.00918100000000613E5A2F01.00000ABCD002.09
08 0 0  forward47.00918100000000613E5A2F01.00000ABCD002.09

```

Table 34 describes significant fields shown in the display.

Table 34 *show lane client Field Descriptions*

Field	Description
LE Client ATM2/0.2	Interface and subinterface of this client.
ELAN name	Name of the ELAN.
Admin	Administrative state, either up or down.
State	Status of this LANE client. Possible states include initialState, lecsConnect, configure, join, busConnect, and operational.
Client ID	The LANE 2-byte client ID assigned by the LANE server.
Join Attempt	The number of attempts made before successfully joining the ELAN.
HW Address	MAC address of this LANE client.
Type	Type of ELAN.
Max Frame Size	Maximum frame size (in bytes) on the ELAN.
Ring	The ring number for the client. This field appears only for Token Ring LANE.
Bridge	The bridge number for the client. This field appears only for Token Ring LANE.
ELAN Segment ID	The ring number for the ELAN. This field appears only for Token Ring LANE.
ATM Address	ATM address of this LANE client.
VCD	Virtual channel descriptor for each of the VCCs established for this LANE client.
rxFrames	Number of frames received.
txFrames	Number of frames sent.
Type	Type of VCC. The Configure Direct VCC is shown in this display as <i>configure</i> . The Control Direct VCC is shown as <i>direct</i> ; the Control Distribute VCC is shown as <i>distribute</i> . The Multicast Send VCC and Multicast Forward VC are shown as <i>send</i> and <i>forward</i> , respectively. The Data Direct VCC is shown as <i>data</i> .
ATM Address	ATM address of the LANE component at the other end of this VCC.

Related Commands

Command	Description
lane client	Activates a LANE client on the specified subinterface.
lane fssrp	Enables the special LANE features so that LANE components (such as the LANE configuration server, the LANE client, the LANE server, and the BUS) become aware of FSSRP.
lane server	Activates a LANE server on the specified subinterface.
show lane config	Displays global LANE information for the configuration server configured on an interface.

show lane config

To display global LAN Emulation (LANE) information for the configuration server configured on an interface, use the **show lane config** command in user EXEC or privileged EXEC mode.

AIP on the Cisco 7500 Series Routers; ATM Port Adapter on the Cisco 7200 Series

```
show lane config [interface atm slot/0]
```

ATM Port Adapter on the Cisco 7500 Series Routers

```
show lane config [interface atm slot/port-adapter/0]
```

Cisco 4500 and 4700 Routers

```
show lane config [interface atm number]
```

Syntax Description	
interface atm slot/0	(Optional) ATM interface slot and port for the following: - AIP on the Cisco 7500 series routers. - ATM port adapter on the Cisco 7200 series routers.
interface atm slot/port-adapter/0	(Optional) ATM interface slot, port adapter, and port number for the ATM port adapter on the Cisco 7500 series routers.
interface atm number	(Optional) ATM interface number for the NPM on the Cisco 4500 or 4700 routers.

Command Modes	User EXEC Privileged EXEC
---------------	------------------------------

Command History	Release	Modification
	11.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following is sample **show lane config** output for an Ethernet ELAN:

```
Router# show lane config
```

```
LE Config Server ATM2/0 config table: cisco_eng
Admin: up State: operational
LECS Mastership State: active master
list of global LECS addresses (30 seconds to update):
39.020304050607080910111213.00000CA05B43.00
ATM Address of this LECS: 39.020304050607080910111213.00000CA05B43.00 (auto)
```

```

vcd rxCnt txCnt callingParty
50      2      2 39.020304050607080910111213.00000CA05B41.02 LES elan2 0 active
cumulative total number of unrecognized packets received so far: 0
cumulative total number of config requests received so far: 30
cumulative total number of config failures so far: 12
cause of last failure: no configuration
culprit for the last failure: 39.020304050607080910111213.00602F557940.01

```

The following example shows sample **show lane config** output for TR-LANE:

Router# **show lane config**

```

LE Config Server ATM4/0 config table: eng
Admin: up State: operational
LECS Mastership State: active master
list of global LECS addresses (40 seconds to update):
39.020304050607080910111213.006047704183.00
ATM Address of this LECS: 39.020304050607080910111213.006047704183.00 (auto)
vcd rxCnt txCnt callingParty
7      1      1 39.020304050607080910111213.006047704181.01 LES elan1 0 active
cumulative total number of unrecognized packets received so far: 0
cumulative total number of config requests received so far: 2
cumulative total number of config failures so far: 0

```

Table 35 describes significant fields shown in the display.

Table 35 *show lane config Field Descriptions*

Field	Description
LE Config Server	Major interface on which the LAN emulated Configuration Server (LECS) is configured.
config table	Name of the database associated with the LECS.
Admin	Administrative state, either up or down.
State	State of the configuration server: down or operational. If down, the reasons field indicates why it is down. The reasons include the following: NO-config-table, NO-nsap-address, and NO-interface-up.
LECS Mastership State	Mastership state of the configuration server. If you have configured simple server redundancy, the configuration server with the lowest index is the active LECS.
list of global LECS addresses	List of LECS addresses.
40 seconds to update	Amount of time until the next update.
39.020304050607080910111213.00000CA05B43.00	ATM address of the configuration server.
ATM Address of this LECS	ATM address of the active configuration server.
auto	Method of ATM address assignment for the configuration server. In this example, the address is assigned by the automatic method.
vcd	Virtual circuit descriptor that uniquely identifies the configure VCC.
rxCnt	Number of packets received.
txCnt	Number of packets sent.
callingParty	ATM NSAP address of the LANE component that is connected to the LECS. "elan1" indicates the ELAN name, "0" indicates the priority number, and "active" indicates that the server is active.

show lane database

To display the database of the configuration server, use the **show lane database** command in user EXEC or privileged EXEC mode.

show lane database [*database-name*]

Syntax Description	<i>database-name</i> (Optional) Specific database name.
---------------------------	---

Command Modes	User EXEC Privileged EXEC
----------------------	------------------------------

Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>11.0</td><td>This command was introduced.</td></tr><tr><td>12.2(33)SRA</td><td>This command was integrated into Cisco IOS Release 12.2(33)SRA.</td></tr><tr><td>12.2SX</td><td>This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.</td></tr></table>	Release	Modification	11.0	This command was introduced.	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Release	Modification								
11.0	This command was introduced.								
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.								
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.								

Usage Guidelines	By default, this command displays the LAN Emulated Configuration Server information displayed by the show lane config command. If no database name is specified, this command shows all databases.
-------------------------	--

Examples	The following is sample output of the show lane database command for an Ethernet LANE:
-----------------	---

```
Router# show lane database

LANE Config Server database table 'engandmkt' bound to interface/s: ATM1/0
default elan: none
elan 'eng': restricted
  server 45.000001415555121f.yyyy.zzzz.0800.200c.1001.01 (prio 0) active
  LEC MAC 0800.200c.1100
  LEC NSAP 45.000001415555121f.yyyy.zzzz.0800.200c.1000.01
  LEC NSAP 45.000001415555124f.yyyy.zzzz.0800.200c.1300.01
elan 'mkt':
  server 45.000001415555121f.yyyy.zzzz.0800.200c.1001.02 (prio 0) active
  LEC MAC 0800.200c.1200
  LEC NSAP 45.000001415555121f.yyyy.zzzz.0800.200c.1000.02
  LEC NSAP 45.000001415555124f.yyyy.zzzz.0800.200c.1300.02
```

The following is sample output of the **show lane database** command for a Token Ring LANE:

```
Router# show lane database

LANE Config Server database table 'eng' bound to interface/s: ATM4/0
default elan: elan1
elan 'elan1': un-restricted, local-segment-id 2048
  server 39.020304050607080910111213.006047704181.01 (prio 0) active
```

Table 36 describes significant fields shown in the display.

Table 36 *show lane database Field Descriptions*

Field	Description
LANE Config Server database	Name of this database and interfaces bound to it.
default elan	Default name, if one is established.
elan	Name of the ELAN whose data is reported in this line and the following indented lines.
un-restricted	Indicates whether this ELAN is restricted or unrestricted.
local-segment-id 2048	Ring number of the ELAN.
server	ATM address of the configuration server.
(prio 0) active	Priority level and simple server redundancy state of this configuration server. If you have configured simple server redundancy, the configuration server with the lowest priority will be active.
LEC MAC	MAC addresses of an individual LANE client in this ELAN. This display includes a separate line for every LANE client in this ELAN.
LEC NSAP	ATM addresses of all LANE clients in this ELAN.

show lane default-atm-addresses

To display the automatically assigned ATM address of each LANE component in a router or on a specified interface or subinterface, use the **show lane default-atm-addresses** command in user EXEC or privileged EXEC mode.

AIP on the Cisco 7500 series routers; ATM port adapter on the Cisco 7200 series

```
show lane default-atm-addresses [interface atm slot/port.subinterface-number]
```

ATM Port Adapter on the Cisco 7500 Series Routers

```
show lane default-atm-addresses [interface atm slot/port-adapter/port.subinterface-number]
```

Cisco 4500 and 4700 Routers

```
show lane default-atm-addresses [interface atm number.subinterface-number]
```

Syntax Description	interface atm <i>slot/port</i>	(Optional) ATM interface slot and port for the following: • AIP on the Cisco 7500 series routers. • ATM port adapter on the Cisco 7200 series routers.
	interface atm <i>slot/port-adapter/port</i>	(Optional) ATM interface slot, port adapter, and port number for the ATM port adapter on the Cisco 7500 series routers.
	interface atm <i>number</i>	(Optional) ATM interface number for the NPM on the Cisco 4500 or 4700 routers.
	<i>.subinterface-number</i>	(Optional) Subinterface number.

Command Modes	User EXEC
	Privileged EXEC

Command History	Release	Modification
	11.0	This command was introduced.
	11.1	The <i>number.subinterface-number</i> argument was added.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	It is not necessary to have any of the LANE components running on this router before you use this command.
------------------	--

Examples

The following is sample output of the **show lane default-atm-addresses** command for the ATM interface 1/0 when all the major LANE components are located on that interface:

```
Router# show lane default-atm-addresses interface atm1/0
```

```
interface ATM1/0:
LANE Client:      47.0000000000000000000000000000.00000C304A98.**
LANE Server:      47.0000000000000000000000000000.00000C304A99.**
LANE Bus:         47.0000000000000000000000000000.00000C304A9A.**
LANE Config Server: 47.0000000000000000000000000000.00000C304A9B.00
note: ** is the subinterface number byte in hex
```

Table 37 describes the significant fields shown in the display.

Table 37 *show lane default-atm-addresses Field Descriptions*

Field	Description
interface ATM1/0:	Specified interface.
LANE Client:	ATM address of the LANE client on the interface.
LANE Server:	ATM address of the LANE server on the interface.
LANE Bus:	ATM address of the LANE broadcast and unknown server on the interface.
LANE Config Server:	ATM address of the LAN Emulated Configuration Server on the interface.

show lane le-arp

To display the LANE ARP table of the LANE client configured on an interface or any of its subinterfaces, on a specified subinterface, or on an emulated LAN (ELAN), use the **show lane le-arp** command in user EXEC or privileged EXEC mode.

AIP on the Cisco 7500 series routers; ATM Port Adapter on the Cisco 7200 series

```
show lane le-arp [interface atm slot/port[.subinterface-number] | name elan-name]
```

ATM Port Adapter on the Cisco 7500 Series Routers

```
show lane le-arp [interface atm slot/port-adapter/port[.subinterface-number] | name elan-name]
```

Cisco 4500 and 4700 Routers

```
show lane le-arp [interface atm number[.subinterface-number] | name elan-name]
```

Syntax Description	interface atm <i>slot/port</i>	(Optional) ATM interface slot and port for the following: - AIP on the Cisco 7500 series routers. - ATM port adapter on the Cisco 7200 series routers.
	interface atm <i>slot/port-adapter/port</i>	(Optional) ATM interface slot, port adapter, and port number for the ATM port adapter on the Cisco 7500 series routers.
	interface atm <i>number</i>	(Optional) ATM interface number for the NPM on the Cisco 4500 or 4700 routers.
	<i>.subinterface-number</i>	(Optional) Subinterface number.
	name <i>elan-name</i>	(Optional) Name of the ELAN. The maximum length of the name is 32 characters.

Command Modes	User EXEC
	Privileged EXEC

Command History	Release	Modification
	11.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following is sample output of the **show lane le-arp** command for an Ethernet LANE client:

```
Router# show lane le-arp
```

```
Hardware Addr   ATM Address                               VCD   Interface
0000.0c15.a2b5  39.000000000000000000000000000000.00000C15A2B5.01  39   ATM1/0.1
0000.0c15.f3e5  39.000000000000000000000000000000.00000C15F3E5.01  25*  ATM1/0.1
```

The following is sample output of the **show lane le-arp** command for a Token Ring LANE client:

```
Router# show lane le-arp
```

```
Ring Bridge     ATM Address                               VCD   Interface
512   6             39.020304050607080910111213.00602F557940.01  47   ATM2/0.1
```

Table 38 describes the significant fields shown in the display.

Table 38 *show lane le-arp Field Descriptions*

Field	Description
Hardware Addr	MAC address, in dotted hexadecimal notation, assigned to the LANE component at the other end of this VCD.
Ring	Route descriptor segment number for the LANE component.
Bridge	Bridge number for the LANE component.
ATM Address	ATM address of the LANE component at the other end of this VCD.
VCD	Virtual circuit descriptor.
Interface	Interface or subinterface used to reach the specified component.

show lane neighbor

To display information about all LAN Emulation (LANE) clients that are directly connected to a device, use the **show lane neighbor** command in user EXEC or privileged EXEC mode.

show lane neighbor

Syntax Description This command has no arguments or keywords.

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	12.2(25)S	This command was introduced.
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.

Usage Guidelines Enter this command on any device using an image that supports LANE.

Use this command to display the IP address of the LANE clients directly connected to the device and the numbers of the virtual channel descriptors (VCDs) that connect the LANE clients and the device.

- If the device is using a Cisco IOS image that supports LANE quality of service (QoS), the command displays the IP address of the LANE client, the unspecified bit rate (UBR) service category for the VCD, the UBR+ service category for the VCD, and the IP class of service (CoS) for the connection.
- If the Cisco IOS image on the device does not support LANE QoS, the command displays 0 for the UBR+ VCD and the IP CoS values.

Examples The following is sample output from the **show lane neighbor** command entered on a device using a Cisco IOS Release 12.2S or 12.2SB image that does not support LANE CoS:

```
Router# show lane neighbor
```

```
Lane Neighbor Group List
```

IP Address	UBRVCD	UBRPLUS	VCD	IP cos
10.11.0.11	143	0		0
10.13.0.11	148	0		0

Table 39 describes the significant fields shown in the display.

Table 39 show lane neighbor Field Descriptions

Field	Description
IP Address	Identifies the IP address of the directly connected LANE client.
UBRVCD	Identifies the VCD number for a connection with unspecified bit rate QoS.

Table 39 *show lane neighbor Field Descriptions (continued)*

Field	Description
UBRPLUS VCD	Identifies the VCD number for a connection with unspecified bit rate QoS that has a minimum cell rate (MCR) configuration.
IP cos	Identifies an IP CoS value.

Related Commands

Command	Description
show lane client	Displays detailed LANE information for all the LANE clients configured on an interface or any of its subinterfaces, on a specified subinterface, or on an emulated LAN.

show lane server

To display global information for the LANE server configured on an interface, on any of its subinterfaces, on a specified subinterface, or on an emulated LAN (ELAN), use the **show lane server** command in user EXEC or privileged EXEC mode.

AIP on the Cisco 7500 Series Routers; ATM Port Adapter on the Cisco 7200 Series

```
show lane server [interface atm slot/port[.subinterface-number] | name elan-name] [brief]
```

ATM Port Adapter on the Cisco 7500 Series Routers

```
show lane server [interface atm slot/port-adapter/port[.subinterface-number] | name elan-name] [brief]
```

Cisco 4500 and 4700 Routers

```
show lane server [interface atm number[.subinterface-number] | name elan-name] [brief]
```

Syntax Description	
interface atm <i>slot/port</i>	(Optional) ATM interface slot and port for the following: - AIP on the Cisco 7500 series routers. - ATM port adapter on the Cisco 7200 series routers.
interface atm <i>slot/port-adapter/port</i>	(Optional) ATM interface slot, port adapter, and port number for the ATM port adapter on the Cisco 7500 series routers.
interface atm <i>number</i>	(Optional) ATM interface number for the NPM on the Cisco 4500 or 4700 routers.
<i>.subinterface-number</i>	(Optional) Subinterface number.
name <i>elan-name</i>	(Optional) Name of the ELAN. The maximum length of the name is 32 characters.
brief	(Optional) Keyword used to display the brief subset of available information.

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	11.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following is sample output from the **show lane server** command for an Ethernet ELAN:

```
Router# show lane server

LE Server ATM2/0.2  ELAN name: elan2  Admin: up  State: operational
type: ethernet      Max Frame Size: 1516
ATM address: 39.020304050607080910111213.00000CA05B41.02
LECS used: 39.020304050607080910111213.00000CA05B43.00 connected, vcd 51
control distribute: vcd 57, 2 members, 2 packets

proxy/ (ST: Init, Conn, Waiting, Adding, Joined, Operational, Reject, Term)
lecid ST vcd      pkts Hardware Addr  ATM Address
  1  O   54        2 0000.0ca0.5b40 39.020304050607080910111213.00000CA05B40.02
  2  O   81        2 0060.2f55.7940 39.020304050607080910111213.00602F557940.02
```

The following is sample output from the **show lane server** command for a Token Ring ELAN:

```
Router# show lane server

LE Server ATM3/0.1  ELAN name: anubis  Admin: up  State: operational
type: token ring    Max Frame Size: 4544      Segment ID: 2500
ATM address: 47.009181000000000000000000.00000CA01661.01
LECS used: 47.009181000000000000000000.00000CA01663.00 connected, vcd 6
control distribute: vcd 10, 2 members, 4 packets
proxy/ (ST: Init, Conn, Waiting, Adding, Joined, Operational, Reject, Term)
lecid ST vcd      pkts Hardware Addr  ATM Address
  1  O    7        3 400.1          47.009181000000000000000000.00000CA01660.01
                        0000.0ca0.1660 47.009181000000000000000000.00000CA01660.01
  2  O   16        3 300.1          47.009181000000000000000000.00000CA04960.01
                        0000.0ca0.4960 47.009181000000000000000000.00000CA04960.01
```

Table 40 describes the significant fields shown in the display.

Table 40 *show lane server Field Descriptions*

Field	Description
LE Server ATM2/0.2	Interface and subinterface of this server.
ELAN name	Name of the ELAN.
Admin	Administrative state, either up or down.
State	Status of this LANE server. Possible states for a LANE server include down, waiting_ILMI, waiting_listen, up_not_registered, operational, and terminating.
type	Type of ELAN.
Max Frame Size	Maximum frame size (in bytes) of this type of emulated LAN.
Segment ID	The ring number of the ELAN. This field appears only for Token Ring LANE.
ATM address	ATM address of this LANE server.
LECS used	ATM address of the LANE configuration server being used. This line also shows the current state of the connection between the LANE server and the LAN Emulated Configuration Server (LECS), and the virtual circuit descriptor (VCD) of the circuit connecting them.
control distribute	VCD of the Control Distribute VCC.

Table 40 *show lane server Field Descriptions (continued)*

Field	Description
proxy	Status of the LANE client at the other end of the Control Distribute VCC.
lecid	Identifier for the LANE client at the other end of the Control Distribute VCC.
ST	Status of the LANE client at the other end of the Control Distribute VCC. Possible states are Init, Conn, Waiting, Adding, Joined, Operational, Reject, and Term.
vcd	Virtual channel descriptor used to reach the LANE client.
pkts	Number of packets sent by the LANE server on the Control Distribute VCC to the LANE client.
Hardware Addr	The top number in this column is the router descriptor, and the second number is the MAC-layer address of the LANE client.
ATM Address	ATM address of the LANE client.

show mpoa client

To display a summary of information regarding one or all Multiprotocol over ATM (MPOA) clients (MPCs), use the **show mpoa client** command in user EXEC or privileged EXEC mode.

show mpoa client [*name mpc-name*] [*brief*]

Syntax Description

name <i>mpc-name</i>	(Optional) Name of the MPC with the specified name.
brief	(Optional) Output limit of the command.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
11.3(3a)WA4(5)	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

If you omit the **name** keyword, the command displays information for all MPCs.

Examples

The following is sample output from the **show mpoa client** command:

```
Router# show mpoa client name ip_mpc brief
```

```
MPC Name: ip_mpc, Interface: ATM1/0, State: Up
MPC actual operating address: 47.00918100000000613E5A2F01.0010A6943825.00
Shortcut-Setup Count: 1, Shortcut-Setup Time: 1
Lane clients bound to MPC ip_mpc: ATM1/0.1
Discovered MPS neighbors      kp-alv  vcd      rxPkts    txPkts
47.00918100000000613E5A2F01.006070174824.00    59      30         28         2
Remote Devices known          vcd      rxPkts    txPkts
47.00918100000000613E5A2F01.00000C5A0C5D.00      35         0        10
```

[Table 41](#) describes the significant fields shown in the display.

Table 41 *show mpoa client* Field Descriptions

Field	Description
MPC Name	Name specified for the MPC.
Interface	Interface to which the MPC is attached.
State	Current state of the MPC.
MPC actual operating address	ATM address of the MPC.

Table 41 *show mpoa client Field Descriptions (continued)*

Field	Description
Shortcut-Setup Count	Current number specified by the shortcut-frame-count command.
Shortcut-Setup Time	Current value specified by the shortcut-frame-time command.
Lane clients bound to MPC ip_mpc	List of LANE clients currently bound to MPC ip_mpc.
Discovered MPS neighbours	List of learned MPS addresses.
kp-alv	Number of seconds until the next keepalive message should be received.
vcd	Number that identifies the virtual circuit.
rxPkts	Number of packets received from the learned MPS.
txPkts	Number of packets sent to the learned MPS.
Remote Devices known	List of other devices (typically other MPCs) not in this ELAN.
vcd	Number that identifies the virtual circuit to that MPC.
rxPkts	Number of packets received from the learned remote device.
txPkts	Number of packets sent to the learned remote device.

Related Commands

Command	Description
clear mpoa client name	Clears the ingress and egress cache entries.

show mpoa client cache

To display the ingress or egress cache entries matching the IP addresses for the Multiprotocol over ATM (MPOA) clients (MPCs), use the **show mpoa client cache** command in user EXEC or privileged EXEC mode.

show mpoa client [*name mpc-name*] **cache** [*ingress | egress*] [*ip-address ip-address*]

Syntax Description

name <i>mpc-name</i>	(Optional) Name of the MPC with the specified name.
ingress	(Optional) Displays ingress cache entries associated with an MPC.
egress	(Optional) Displays egress cache entries associated with an MPC.
ip-address <i>ip-address</i>	(Optional) Displays cache entries that match the specified IP address.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
11.3(3a)WA4(5)	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following is sample output from the **show mpoa client cache** command for a specific MPC:

```
Router# show mpoa client ip_mpc cache
```

```
MPC Name: ip-mpc, Interface: ATM1/0, State: Up
MPC actual operating address: 47.00918100000000613E5A2F01.0010A6943825.00
Shortcut-Setup Count: 1, Shortcut-Setup Time: 1
Number of Ingress cache entries: 1
MPC Ingress Cache Information:
Dst IP addr      State   vcd Expires Egress MPC Atm address
20.20.20.1       RSVLD   35   11:38 47.00918100000000613E5A2F01.00000C5A0C5D.00
Number of Egress cache entries: 1
MPC Egress Cache Information:
Dst IP addr      Dst MAC      Src MAC      MPSid  Elan Expires  CacheId  Tag
10.10.10.1       0000.0c5a.0c58 0060.7017.4820 9      2    11:55      1      1
```

Table 42 describes the significant fields shown in the display.

Table 42 *show mpoa client cache Field Descriptions*

Field	Description
MPC Name	Name specified for the MPC.
Interface	Interface to which the MPC is attached.

Table 42 *show mpoa client cache Field Descriptions (continued)*

Field	Description
State	Current state of the MPC (up or down).
MPC actual operating address	ATM address of the MPC.
Shortcut-Setup Count	Current number specified by the shortcut-frame-count command.
Number of Ingress cache entries	Number of entries in the ingress cache.
MPC Ingress Cache Information	
Dst IP addr	IP address of the destination.
State	State of the ingress cache entry. (Valid states are initialized, trigger, refresh, hold-down, resolved, and suspended.)
vcd	Number that identifies the virtual circuit.
Expires	Time in minutes or seconds until the ingress cache entry expires.
Egress MPC Atm address	ATM address of the egress MPC.
Number of Egress cache entries	Number of entries in the egress cache.
MPC Egress Cache Information	
Dst IP addr	IP address of the destination.
Dst MAC	MAC address of the destination.
Src MAC	MAC address of the source.
MPSid	Unique number representing the egress MPS.
Elan	ELAN identifier of the ELAN serving this destination IP address.
Expires	Time in minutes or seconds until the egress cache entry expires.
CacheID	Cache identifier.
Tag	Label (tag) identifier.

show mpoa client statistics

To display all the statistics collected by a Multiprotocol over ATM (MPOA) client (MPC), use the **show mpoa client statistics** command in user EXEC or privileged EXEC mode.

show mpoa client [*name mpc-name*] **statistics**

Syntax Description

name *mpc-name* (Optional) Specifies the name of the MPC.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
11.3(3a)WA4(5)	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command displays all the statistics collected by an MPC.

Examples

The following is sample output from the **show mpoa client statistics** command for the MPC named ip_mpc:

```
Router# show mpoa client name ip_mpc statistics
```

```
MPC Name: ip_mpc, Interface: ATM1/0, State: Up
MPC actual operating address: 47.00918100000000613E5A2F01.0010A6943825.00
Shortcut-Setup Count: 1, Shortcut-Setup Time: 1
```

	Transmitted	Received
MPOA Resolution Requests	2	0
MPOA Resolution Replies	0	2
MPOA Cache Imposition Requests	0	0
MPOA Cache Imposition Replies	0	0
MPOA Cache Purge Requests	0	0
MPOA Cache Purge Replies	0	0
MPOA Trigger Request	0	0
NHRP Purge Requests	0	0

```
Invalid MPOA Data Packets Received: 0
```

show mpoa default-atm-addresses

To display the default ATM addresses for the Multiprotocol over ATM (MPOA) client (MPC), use the **show mpoa default-atm-addresses** command in user EXEC or privileged EXEC mode.

show mpoa default-atm-addresses

Syntax Description This command has no arguments or keywords.

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	11.3(3a)WA4(5)	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples The following is sample output from the **show mpoa default-atm-addresses** command when the switch prefix is not available:

```
Router# show mpoa default-atm-addresses

interface ATM1/0:
MPOA Server: ...006070174824.**
MPOA Client: ...006070174825.**
note: ** is the MPS/MPC instance number in hex

interface ATM2/0:
MPOA Server: ...006070174844.**
MPOA Client: ...006070174845.**
note: ** is the MPS/MPC instance number in hex
```

The following is sample output from the **show mpoa default-atm-addresses** command when the switch prefix is available:

```
Router# show mpoa default-atm-addresses

interface ATM1/0:
MPOA Server: 47.009181000000000613E5A2F01.006070174824.**
MPOA Client: 47.009181000000000613E5A2F01.006070174825.**
note: ** is the MPS/MPC instance number in hex

interface ATM2/0:
MPOA Server: 47.100000000000000000000000000000.006070174844.**
MPOA Client: 47.100000000000000000000000000000.006070174845.**
note: ** is the MPS/MPC instance number in hex
```

Table 43 describes the significant fields shown in the display.

Table 43 *show mpoa default-atm-addresses Field Descriptions*

Field	Description
interface ATM1/0	Specified interface.
MPOA Server	ATM address of the MPOA server on the interface.
MPOA Client	ATM address of the MPOA client on the interface.

show mpoa server

To display information about any specified Multiprotocol over ATM (MPOA) server (MPS) or all MPSs in the system, depending on whether the name of the required MPS is specified, use the **show mpoa server** command in user EXEC or privileged EXEC mode.

show mpoa server [*name mps-name*]

Syntax Description	name <i>mps-name</i> (Optional) Specifies the name of the MPS.
---------------------------	---

Command Modes	User EXEC Privileged EXEC
----------------------	------------------------------

Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>11.3(3a)WA4(5)</td><td>This command was introduced.</td></tr><tr><td>12.2(33)SRA</td><td>This command was integrated into Cisco IOS Release 12.2(33)SRA.</td></tr><tr><td>12.2SX</td><td>This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.</td></tr></table>	Release	Modification	11.3(3a)WA4(5)	This command was introduced.	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Release	Modification								
11.3(3a)WA4(5)	This command was introduced.								
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.								
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.								

Usage Guidelines	The command displays information about server configuration parameters. It also displays information about LAN Emulated Clients (LECs) that are bound to the MPOA server neighbors (both MPC and MPS).
-------------------------	--

Examples	The following is sample output from the show mpoa server command, with a specified name:
-----------------	---

```
Router# show mpoa server name ip_mps

MPS Name: ip_mps, MPS id: 0, Interface: ATM1/0, State: up
network-id: 1, Keepalive: 25 secs, Holding time: 1200 secs
Keepalive lifetime: 75 secs, Giveup time: 40 secs
MPS actual operating address: 47.00918100000000613E5A2F01.006070174824.00
Lane clients bound to MPS ip_mps: ATM1/0.1 ATM1/0.2
Discovered neighbours:
MPC 47.00918100000000613E5A2F01.00000C5A0C5D.00 vcds: 39(R,A)
MPC 47.00918100000000613E5A2F01.0010A6943825.00 vcds: 40(R,A)
```

Table 44 describes the significant fields shown in the display.

Table 44 *show mpoa server Field Descriptions*

Field	Description
MPS Name	Name of the MPOA server.
MPS id	ID of the MPOA server.
Interface	Interface to which the MPS is attached.

Table 44 *show mpoa server Field Descriptions (continued)*

Field	Description
State	State of the MPOA server: up or down.
network-id	Network ID used for partitioning.
Keepalive	Keepalive time value.
Holding time	Holding time value.
Keepalive lifetime	Keepalive lifetime value.
Giveup time	Minimum time to wait before giving up on a pending resolution request.
MPS actual operating address	Actual control address of this MPS.
Lane clients bound to MPS ip_mps	List of LANE clients served by the MPS.
Discovered neighbours	MPOA devices discovered by the clients bound to this MPS.

Related Commands

Command	Description
clear mpoa server name	Clears the ingress and egress cache entries of one or all MPCs.

show mpoa server cache

To display ingress and egress cache entries associated with an Multiprotocol over ATM (MPOA) server (MPS), use the **show mpoa server cache** command in user EXEC or privileged EXEC mode.

show mpoa server [*name mps-name*] **cache** [**ingress** | **egress**] [**ip-address** *ip-address*]

Syntax Description	name <i>mps-name</i>	(Optional) Specifies the name of an MPS.
	ingress	(Optional) Displays ingress cache entries associated with a server.
	egress	(Optional) Displays egress cache entries associated with a server.
	ip-address <i>ip-address</i>	(Optional) Displays the entries that match the specified IP address.

Command Modes	User EXEC
	Privileged EXEC

Command History	Release	Modification
	12.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	This command displays ingress and egress cache entries associated with an MPS.
-------------------------	--

Examples The following is sample output from the **show mpoa server cache** command, with a name specified:

```
Router# show mpoa server name ip_mps cache
```

```
MPS Name: ip_mps, MPS id: 0, Interface: ATM1/0, State: up
network-id: 1, Keepalive: 25 secs, Holding time: 1200 secs
Keepalive lifetime: 75 secs, Giveup time: 40 secs
MPS actual operating address: 47.00918100000000613E5A2F01.006070174824.00
Number of Ingress cache entries: 1
Ingress Cache information:
  IP address      Ingress MPC ATM Address      Remaining Time
  20.20.20.1      47.00918100000000613E5A2F01.0010A6943825.00  19:07
Number of Egress cache entries: 1
Egress Cache information:
  Dst IP address  Ingress MPC ATM Address      Remaining Time
  20.20.20.1      47.00918100000000613E5A2F01.0010A6943825.00  19:06
src IP 20.20.20.2, cache Id 1
```

Table 45 describes the significant fields shown in the display.

Table 45 *show mpoa server cache Field Descriptions*

Field	Description
MPS Name	Name of the MPOA server.
MPS id	ID of the MPOA server.
Interface	Interface to which the MPS is attached.
State	State of the MPOA server: up or down.
network-id	Network ID used for partitioning.
Keepalive	Keepalive time value.
Holding time	Holding time value.
Keepalive lifetime	Keepalive lifetime value.
Giveup time	Minimum time to wait before giving up on a pending resolution request.
MPS actual operating address	Actual control address of this MPS.
Number of Ingress cache entries	Number of entries in the ingress cache.
Ingress Cache information	Information of ingress cache.
IP address	IP address of the MPC.
Ingress MPC ATM Address	ATM address of the ingress MPC.
Remaining Time	Time for which the cache entry is valid.
Number of Egress cache entries	Number of entries in the egress cache.
Egress Cache information	Information of egress cache.
Dst IP address	IP address of the destination.
src IP	IP address of the source MPS that originated the NHRP resolution request.
cache Id	Cache identifier.

show mpoa server statistics

To display all the statistics collected by an Multiprotocol over ATM (MPOA) server (MPS), use the **show mpoa server statistics** command in user EXEC or privileged EXEC mode.

show mpoa server [*name mps-name*] **statistics**

Syntax Description	name <i>mps-name</i> (Optional) Specifies the name of an MPS.
---------------------------	--

Command Modes	User EXEC Privileged EXEC
----------------------	------------------------------

Command History	Release	Modification
	12.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	This command will display all the statistics collected by an MPS. The statistics pertain to the ingress or egress cache entry creation, deletion, and failures.
-------------------------	---

Examples	The following is a sample output from the show mpoa server statistics command, with a name specified:
-----------------	--

```
Router# show mpoa server name ip_mps statistics
```

```
MPS Name: ip_mps, MPS id: 0, Interface: ATM1/0, State: up
network-id: 1, Keepalive: 25 secs, Holding time: 1200 secs
Keepalive lifetime: 75 secs, Giveup time: 40 secs
MPS actual operating address: 47.00918100000000613E5A2F01.006070174824.00
Opcode                               Transmitted    Received
-----
MPOA Resolution Requests              2
MPOA Resolution Replies                1
MPOA Cache Imposition Requests        1
MPOA Cache Imposition Replies         0
MPOA Egress Cache Purge Requests      0
MPOA Egress Cache Purge Replies       0
NHRP Resolution Requests              0
NHRP Resolution Replies               0
NHRP Purge Requests                   0
```

Table 46 describes the significant fields shown in the display.

Table 46 *show mpoa server statistics Field Descriptions*

Field	Description
MPS Name	Name of the MPOA server.
MPS id	ID of the MPOA server.
Interface	Specified interface.
State	State of the MPOA server: up or down.
network-id	Network ID used for partitioning.
Keepalive	Keepalive time value.
Holding time	Holding time value.
Keepalive lifetime	Keepalive lifetime value.
Giveup time	Minimum time to wait before giving up on a pending resolution request.
MPS actual operating address	Actual control address of this MPS.

show network-clocks

To display the current configured and active network clock sources, use the **show network-clocks** command in privileged EXEC mode.

show network-clocks

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	11.1	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	This command applies to Voice over Frame Relay, Voice over ATM, and Voice over HDLC on the Cisco MC3810. The Cisco MC3810 has a background task that verifies whether a valid clocking configuration exists every 120 seconds. If this task detects an error, you will be reminded every 120 seconds until the error is corrected. A clocking configuration error may be generated for various reasons. Using the show network-clocks command, you can display the clocking configuration status.
-------------------------	--

Examples	The following is sample output from the show network-clocks EXEC command:
-----------------	--

```
Router# show network-clocks

Priority 1 clock source: ATM3/0/0
Priority 2 clock source: System clock
Priority 3 clock source: System clock
Priority 4 clock source: System clock

Current clock source:ATM3/0/0, priority:1
```

The following is sample output from the **show network-clocks** command on the Cisco MC3810:

```
Router# show network-clocks

Priority 1 clock source(inactive config): T1 0
Priority 1 clock source(active config) : T1 0
Clock switch delay: 10
Clock restore delay: 10
T1 0 is clocking system bus for 9319 seconds.
Run Priority Queue: controller0
```

In this display, inactive configuration is the new configuration that has been established. Active configuration is the run-time configuration. Should an error be made in the new configuration, the inactive and active configurations will be different. In the previous example, the clock priority configuration is valid, and the system is being clocked as indicated.

The following is another sample output from the **show network-clocks** command:

```
Router# show network-clocks

Priority 1 clock source(inactive config) : T1 0
Priority 2 clock source(inactive config) : T1 1
Priority 1 clock source(active config) : T1 0
Clock switch delay: 10
Clock restore delay: 10
T1 0 is clocking system bus for 9319 seconds.
Run Priority Queue: controller0
```

In this display, the new clocking configuration has an error for controller T1 1. This is indicated by checking differences between the last valid configuration (active) and the new proposed configuration (inactive). The error may result from hardware (the system controller board or MFT) unable to support this mode, or controller T1 1 is currently configured as “clock source internal.”

Since the active and inactive configurations are different, the system will periodically display the warning message about the wrong configuration.

Related Commands

Command	Description
network-clock-select (ATM)	Establishes the sources and priorities of the requisite clocking signals for an ATM-CES port adapter.

show sscop

To show Service-Specific Connection-Oriented Protocol (SSCOP) details for all ATM interfaces, use the **show sscop** command in privileged EXEC mode.

show sscop

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	10.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples	The following is sample output from the show sscop command:
-----------------	--

```
Router# show sscop

SSCOP details for interface ATM4/0
  Current State = Data Transfer Ready
  Send Sequence Number: Current = 2, Maximum = 9
  Send Sequence Number Acked = 3
  Rcv Sequence Number: Lower Edge = 2, Upper Edge = 2, Max = 9
  Poll Sequence Number = 1876, Poll Ack Sequence Number = 2
  Vt(Pd) = 0
  Connection Control: timer = 1000
  Timer currently Inactive
  Keep Alive Timer = 30000
  Current Retry Count = 0, Maximum Retry Count = 10
  Statistics -
    Pdu's Sent = 0, Pdu's Received = 0, Pdu's Ignored = 0
    Begin = 0/1, Begin Ack = 1/0, Begin Reject = 0/0
    End = 0/0, End Ack = 0/0
    Resync = 0/0, Resync Ack = 0/0
    Sequenced Data = 2/0, Sequenced Poll Data = 0/0
    Poll = 1591/1876, Stat = 0/1591, Unsolicited Stat = 0/0
    Unassured Data = 0/0, Mgmt Data = 0/0, Unknown Pdu's = 0
```

[Table 47](#) describes the fields shown in the display. Interpreting this output requires a good understanding of the SSCOP; it is usually displayed by our technicians to help diagnose network problems.

Table 47 *show ssccop Field Descriptions*

Field	Description
SSCOP details for interface	Interface slot and port.
Current State	SSCOP state for the interface.
Send Sequence Number	Current and maximum send sequence number.
Send Sequence Number Acked	Sequence number of packets already acknowledged.
Rcv Sequence Number	Sequence number of packets received.
Poll Sequence Number	Current poll sequence number.
Poll Ack Sequence Number	Poll sequence number already acknowledged.
Vt(Pd)	Number of sequenced data (SD) frames sent, which triggers a sending of a Poll frame.
Connection Control	Timer used for establishing and terminating SSCOP.
Keep Alive Timer	Timer used to send keepalives on an idle link.
Current Retry Count	Current count of the retry counter.
Maximum Retry Count	Maximum value the retry counter can take.
Pdu's Sent	Total number of SSCOP frames sent.
Pdu's Received	Total number of SSCOP frames received.
Pdu's Ignored	Number of invalid SSCOP frames ignored.
Begin	Number of Begin frames sent/received.
Begin Ack	Number of Begin Ack frames sent/received.
Begin Reject	Number of Begin Reject frames sent/received.
End	Number of End frames sent/received.
End Ack	Number of End Ack frames sent/received.
Resync	Number of Resync frames sent/received.
Resync Ack	Number of Resync Ack frames sent/received.
Sequenced Data	Number of Sequenced Data frames sent/received.
Sequenced Poll Data	Number of Sequenced Poll Data frames sent/received.
Poll	Number of Poll frames sent/received.
Stat	Number of Stat frames sent/received.
Unsolicited Stat	Number of Unsolicited Stat frames sent/received.
Unassured Data	Number of Unassured Data frames sent/received.
Mgmt Data	Number of Mgmt Data frames sent/received.
Unknown Pdu's	Number of Unknown Pdu's frames sent/received.

show svc

To display the Switched Virtual Circuits (SVC) information, use the **show svc** command in user EXEC or privileged EXEC mode.

show svc [**ppp** | **interface** | *vpi/vci-value* | *vci-value* | *connection-name*]

Syntax Description

ppp	(Optional) Specifies the Point-to-Point Protocol (PPP) ATM SVC interface information.
interface	(Optional) Specifies the interface for the SVC.
<i>vpi/vci-value</i>	(Optional) The Virtual Path Identifier or Virtual Channel Identifier (VPI/VCI) value. The forward slash is required.
<i>vci-value</i>	(Optional) The virtual circuit interface value.
<i>connection-name</i>	(Optional) The connection name.

Command Modes

User EXEC (>)
Privileged EXEC (#)

Command History

Release	Modification
12.4(24)T	This command was introduced in a release earlier than Cisco IOS Release 12.4(24)T.

Usage Guidelines

Use this command to display the SVC information using the available keywords and arguments.

Examples

The following is sample output from the **show svc** command.

Router# **show svc interface atm1/0**

	VCD /						Peak	Av/Min	Burst	
Interface	Name	VPI	VCI	Type	Encaps	SC	Kbps	Kbps	Cells	St
1/0	1138	0		125	SVC	SNAP	UBR	149760		UP

Table 48 describes the significant fields shown in the display.

Table 48 *show svc Field Description*

Field	Description
Interface	Interface and subinterface slot and port.
VCD/Name	Virtual connection descriptor (virtual connection number). The connection name is displayed if a name for the VC was configured using the pvc command.
VPI	Virtual path identifier.
VCI	Virtual channel identifier.

Table 48 *show svc Field Description (continued)*

Field	Description
Type	Type of PVC detected from PVC discovery; either PVC-D, PVC-L, or PVC-M: - PVC-D—PVC created as a result of PVC discovery. - PVC-L—The corresponding peer of this PVC could not be found on the switch. - PVC-M—Some or all of the quality of service (QOS) parameters of this PVC fail to match those of the corresponding peer on the switch.
Encaps	Type of ATM adaptation layer (AAL) and encapsulation.
Peak Kbps	Kilobits per second sent at the peak rate.
Avg/Min Kbps	Kilobits per second sent at the average rate.
Burst Cells	Maximum number of ATM cells that the VC can send at peak rate.
Sts	Status of the VC connection: - UP—The connection is enabled for data traffic. - DOWN—The connection is not ready for data traffic. When the Status field is DOWN, a State field is shown. See a description of the different values for the State field provided below. - INACTIVE—The interface is down.
State	When the Status field is UP, this field does not appear. When the Status field is DOWN or INACTIVE, the State field will appear with one of the following values: - NOT_VERIFIED—The VC has been established successfully; waiting for OAM (if enabled) and ILMI (if enabled) to verify that the VC is up. - NOT_EXIST—VC has not been created. - HASHING_IN—VC has been hashed into a hash table. - ESTABLISHING—Ready to establish VC connection. - MODIFYING—VC parameters have been modified. - DELETING—VC is being deleted. - DELETED—VC has been deleted. - NOT_IN_SERVICE—ATM interface is shut down.

snmp-server enable traps atm pvc

To enable the sending of ATM permanent virtual circuit (PVC) Simple Network Management Protocol (SNMP) notifications, use the **snmp-server enable traps atm pvc** command in global configuration mode. To disable ATM PVC-specific SNMP notifications, use the **no** form of this command.

snmp-server enable traps atm pvc [*interval seconds*] [*fail-interval seconds*]

no snmp-server enable traps atm pvc [*interval seconds*] [*fail-interval seconds*]

Syntax Description

interval <i>seconds</i>	(Optional) Specifies a minimum period between successive traps. Generation of PVC traps is dampened by the notification interval to prevent trap storms. No traps are sent until the interval lapses. The <i>seconds</i> argument is an integer in the range from 1 to 3600. The default is 30.
fail-interval <i>seconds</i>	(Optional) Specifies a minimum period for storing the failed time stamp. The <i>seconds</i> argument is an integer in the range from 0 to 3600. The default is 0.

Command Default

SNMP notifications are disabled.

Command Modes

Global configuration

Command History

Release	Modification
12.0(1)T	This command was introduced for the platforms that support ATM PVC Management.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Cisco IOS XE Release 2.3	This command was integrated into Cisco IOS XE Software Release 2.3 and implemented on the Cisco ASR 1000 series routers.

Usage Guidelines

SNMP notifications can be sent as traps or inform requests. This command enables both traps and inform requests for the specified notification types. ATM notifications are defined in the CISCO-IETF-ATM2-PVCTRAP-MIB.my file, available from the Cisco FTP site at <ftp://ftp.cisco.com/pub/mibs/v2/>.

ATM PVC failure notifications are sent when a PVC on an ATM interface fails or leaves the UP operational state. Only one trap is generated per hardware interface, within the specified interval defined by the **interval** keyword (stored as the atmIntPvcNotificationInterval in the MIB). If other PVCs on the same interface go DOWN during this interval, traps are generated and held until the fail interval has elapsed. When the interval has elapsed, the traps are sent if the PVCs are still DOWN.

No notifications are generated when a PVC returns to the UP state after having been in the DOWN state. If you need to detect the recovery of PVCs, you must use the SNMP management application to regularly poll your router.

The **snmp-server enable traps atm pvc** command is used in conjunction with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications. To send notifications, you must configure at least one **snmp-server host** command.

Examples

The following example shows the enabling of ATM PVC traps on a router, so that if PVC 0/1 goes down, host 172.16.61.90 will receive the notifications:

```
!For ATM PVC Trap Support to work on your router, you must first have SNMP support and
!an IP routing protocol configured on your router:
Router(config)# snmp-server community public ro
Router(config)# snmp-server host 172.16.61.90 public
Router(config)# ip routing
Router(config)# router igrp 109
Router(config-router)# network 172.16.0.0
!
!Enable ATM PVC Trap Support and OAM management:
Router(config)# snmp-server enable traps atm pvc interval 40 fail-interval 10
Router(config)# interface atm 1/0.1
Router(config-if)# pvc 0/1
Router(config-if-atm-vc)# oam-pvc manage
```

Related Commands

Command	Description
show atm pvc	Displays all ATM PVCs and traffic information.
snmp-server enable traps	Enables all available SNMP notifications on your system.
snmp-server host	Specifies the recipient of an SNMP notification operation.
snmp-server trap-source	Specifies the interface from which an SNMP trap should originate.

snmp-server enable traps atm pvc extension

To enable the sending of extended ATM permanent virtual circuit (PVC) SNMP notifications and SNMP notifications for ATM Operation, Administration, and Maintenance (OAM) F5 continuity check (CC), ATM OAM F5 alarm indication signals/remote defect indications (AIS/RDI), and loopback failures, use the **snmp-server enable traps atm pvc extension** command in global configuration mode. To disable these SNMP notifications, use the **no** form of this command.

snmp-server enable traps atm pvc extension {up | down | oam failure [aisrdi | endCC | loopback | segmentCC]}

no snmp-server enable traps atm pvc extension {up | down | oam failure [aisrdi | endCC | loopback | segmentCC]}

Syntax Description		
up		Enables ATM PVC up traps. These notifications are generated when a PVC changes from the DOWN to the UP state.
down		Enables ATM PVC failure traps. These notifications are generated when a PVC changes from the UP to the DOWN state.
oam failure		Enables ATM PVC OAM failure traps. These notifications are generated when any type of OAM failure occurs on the PVC.
aisrdi		(Optional) Enables AIS/RDI OAM failure traps. These notifications are generated when AIS/RDI OAM failure occurs on the PVC.
endCC		(Optional) Enables end-to-end OAM CC failure traps. These notifications are generated when end-to-end CC failures occur on the PVC.
loopback		(Optional) Enables OAM failure loopback traps. These notifications are generated when OAM loopback failure occurs on the PVC.
segmentCC		(Optional) Enables segment OAM CC failure traps. These notifications are generated when segment CC failures occur on the PVC.

Command Default

SNMP notifications are disabled.
The interval between successive traps is 30 seconds.

Command Modes

Global configuration (config)

Command History	Release	Modification
	12.2(4)T	This command was introduced for those platforms that support ATM PVC management.
	12.2(13)T	This command was modified to configure SNMP notification support for ATM OAM F5 CC and ATM OAM F5 AIS/RDI failures.
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
	Cisco IOS XE Release 2.3	This command was integrated into Cisco IOS XE Software Release 2.3 and implemented on the Cisco ASR 1000 series routers.
	12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.

Usage Guidelines

For PVCs that are not part of a range, extended ATM PVC traps include virtual path identifier/virtual channel identifier (VPI/ VCI) information, the number of state transitions a PVC goes through in an interval, and the timestamp for the start and end of the transitions. For PVCs that are part of a range, extended ATM PVC traps include the first and last VPI/VCI of the range and the timestamp for the first failure and the last failure within the same range.

Extended ATM PVC and ATM OAM F5 CC traps cannot be used at the same time as the legacy ATM PVC trap. The legacy ATM PVC trap must be disabled by using the **no snmp-server enable traps atm pvc** command before extended ATM PVC traps can be configured.

The extended ATM PVC failure trap (which is enabled by the **snmp-server enable traps atm pvc extension down** command) is the same trap as the legacy ATM PVC failure trap (which is enabled by the **snmp-server enable traps atm pvc** command), but with the following differences:

- The extended ATM PVC failure trap contains information in the form of VPI/VCI ranges.
- The extended ATM PVC failure trap contains timestamps for when PVCs go down.
- The legacy ATM PVC failure trap contains only one VPI/VCI per trap.



Note

You must configure the **snmp-server enable traps atm pvc extension mibversion 2** command before you can enable the ATM OAM F5 AIS/RDI failure traps, the end-to-end ATM OAM F5 CC failure traps, the OAM failure loopback traps, and the segment ATM OAM F5 CC failure traps. This command enables the MIB that supports these traps.

OAM management must be enabled on the PVC before you can use ATM PVC traps. To generate F5 loopback failure traps, enable OAM management using the **oam-pvc manage** command. To generate segment F5 CC failure traps, enable segment OAM CC management by using the **oam-pvc manage cc segment** command. To generate end-to-end F5 CC failure traps, enable end-to-end OAM CC management by using the **oam-pvc manage cc end** command. To generate ATM OAM F5 AIS/RDI failure traps, enable any of the three types of OAM management listed above.

SNMP notifications can be sent as traps or inform requests. This command enables both traps and inform requests for the specified notification types. The interval between successive traps is 30 seconds.

The extended ATM PVC notifications for MIB version 1 are defined in the CISCO-IETF-ATM2-PVCTRAP-MIB.my file. The extended ATM PVC notifications for MIB version 2 are defined in the CISCO-ATM-PVCTRAP-EXTN-MIB.my file. Both of these MIB files are available from the Cisco FTP site at <ftp://ftp.cisco.com/pub/mibs/v2/>.

ATM PVC traps are generated at the end of the notification interval. It is possible to generate all three types of ATM PVC traps (the ATM PVC failure trap, ATM PVC up trap, and ATM PVC OAM failure trap) at the end of the same notification interval; however, only one type of trap will be generated for each PVC.

The **snmp-server enable traps atm pvc extension** command is used in conjunction with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications. In order to send notifications, you must configure at least one **snmp-server host** command.

When the ATM OAM F5 loopback, AIS/RDI, or CC failure trap is enabled, the PVC remains in the UP state when an OAM loopback, AIS/RDI, or CC failure is detected, so that the flow of data will still be possible. If one of these traps is not enabled, the PVC will be placed in the DOWN state when an OAM loopback, AIS/RDI, or CC failure is detected.

Examples

Extended ATM PVC Notifications

The following example shows all three of the extended ATM PVC traps enabled on a router. If PVC 0/1 leaves the UP state, leaves the DOWN state, or has an OAM loopback failure, host 172.16.61.90 will receive the SNMP notifications:

```
! Configure SNMP support and an IP routing protocol on your router:
Router(config)# snmp-server community public ro
Router(config)# snmp-server host 172.16.61.90 public
Router(config)# ip routing
Router(config)# router igrp 109
Router(config-router)# network 172.16.0.0
!
! Enable extended ATM PVC trap support and OAM management:
Router(config)# snmp-server enable traps atm pvc extension down
Router(config)# snmp-server enable traps atm pvc extension up
Router(config)# snmp-server enable traps atm pvc extension oam failure loopback
Router(config)# interface atm 1/0.1
Router(config-if)# pvc 0/1
Router(config-if-atm-vc)# oam-pvc manage
```

Extended ATM PVC Failure Trap Output

The following example shows output for extended ATM PVC failure trap for PVCs 1/100, 1/102, and 1/103. Note that only one trap is generated for all the PVCs associated with the same interface or subinterface (in contrast to the legacy ATM PVC failure trap, which generates a separate trap for each PVC). The VPI/VCI information and timing information are located in the objects associated with the trap.

```
00:23:56:SNMP:Queuing packet to 10.1.1.1
00:23:56:SNMP:V2 Trap, reqid 2, errstat 0, erridx 0
sysUpTime.0 = 143636
snmpTrapOID.0 = atmIntfPvcFailuresTrap
ifEntry.1.19 = 19
atmIntfPvcFailures.2 = 7
atmIntfCurrentlyFailingPVcls.2 = 3
atmPVclLowerRangeValue.19.1.2 = 102
atmPVclHigherRangeValue.19.1.2 = 103
atmPVclRangeStatusChangeStart.19.1.2 = 140643
atmPVclRangeStatusChangeEnd.19.1.2 = 140698
atmPVclStatusTransition.19.1.100 = 1
atmPVclStatusChangeStart.19.1.100 = 140636
atmPVclStatusChangeEnd.19.1.100 = 140636
00:23:56:SNMP:Packet sent via UDP to 10.1.1.1
```

Extended ATM PVC Up Trap Output

The following example shows output for the extended ATM PVC up trap for PVCs 1/100, 1/102, and 1/103:

```
00:31:29:SNMP:Queuing packet to 10.1.1.1
00:31:29:SNMP:V2 Trap, reqid 2, errstat 0, erridx 0
sysUpTime.0 = 188990
snmpTrapOID.0 = atmIntfPvcUpTrap
ifEntry.1.19 = 19
atmIntfCurrentlyDownToUpPVcls.2 = 3
atmPVclLowerRangeValue.19.1.2 = 102
atmPVclHigherRangeValue.19.1.2 = 103
atmPVclRangeStatusChangeStart.19.1.2 = 186005
atmPVclRangeStatusChangeEnd.19.1.2 = 186053
atmPVclStatusTransition.19.1.100 = 1
atmPVclStatusChangeStart.19.1.100 = 185990
atmPVclStatusChangeEnd.19.1.100 = 185990
00:31:30:SNMP:Packet sent via UDP to 10.1.1.1
```

ATM OAM F5 CC Notifications

In the following example, the ATM OAM CC notifications and an extended ATM PVC notification are enabled. If connectivity failures are detected on PVC 0/1, host 172.16.61.90 will receive the SNMP notifications:

```
! Configure SNMP support and an IP routing protocol on your router:
Router(config)# snmp-server community public ro
Router(config)# snmp-server host 172.16.61.90 public
Router(config)# ip routing
Router(config)# router igrp 109
Router(config-router)# network 172.16.0.0
!
! Enable extended ATM PVC trap support and OAM management:
Router(config)# snmp-server enable traps atm pvc extension mibversion 2
Router(config)# snmp-server enable traps atm pvc extension oam failure aisrdi
Router(config)# snmp-server enable traps atm pvc extension oam failure endcc
Router(config)# snmp-server enable traps atm pvc extension oam failure segmentcc
Router(config)# snmp-server enable traps atm pvc extension oam failure loopback
Router(config)# snmp-server enable traps atm pvc extension up
Router(config)# interface atm 0
Router(config-if)# pvc 0/1
Router(config-if-atm-vc)# oam-pvc manage cc end
```

Related Commands

Command	Description
oam-pvc manage	Enables end-to-end F5 OAM loopback cell generation and OAM management.
oam-pvc manage cc	Configures ATM OAM F5 CC management.
show atm pvc	Displays all ATM PVCs and traffic information.
snmp-server enable traps	Enables all available SNMP notifications on your system.
snmp-server enable traps atm pvc	Enables the sending of legacy ATM PVC failure traps.
snmp-server enable traps atm pvc extension mibversion	Specifies the MIB that supports extended ATM PVC SNMP notifications or the MIB that supports SNMP notifications for ATM OAM F5 CC, F5 AIS/RDI, and F5 loopback failures.
snmp-server host	Specifies the recipient of an SNMP notification operation.
snmp-server trap-source	Specifies the interface from which an SNMP trap should originate.

snmp-server enable traps atm pvc extension mibversion

To specify the MIB that supports extended ATM permanent virtual circuit (PVC) Simple Network Management Protocol (SNMP) notifications or the MIB that supports SNMP notifications for ATM Operation, Administration, and Maintenance (OAM) F5 continuity check (CC) management, ATM OAM F5 AIS/RDI management, and F5 loopback failure management, use the **snmp-server enable traps atm pvc extension mibversion** command in global configuration mode. To remove the MIB specification, use the **no** form of this command.

snmp-server enable traps atm pvc extension mibversion {1 | 2}

no snmp-server enable traps atm pvc extension mibversion {1 | 2}

Syntax Description	1	Specifies the MIB that supports the extended ATM permanent virtual circuit (PVC) SNMP notifications. This is the default.
	2	Specifies the MIB that supports ATM OAM F5 CC and ATM OAM F5 AIS/RDI SNMP notifications, in addition to the notifications supported by MIB version 1.

Command Default	SNMP notifications are disabled.
------------------------	----------------------------------

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	12.2(15)T	This command was introduced.
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.

Usage Guidelines

MIB version 1 specifies the MIB that supports legacy extended ATM PVC traps and is defined in the file CISCO-IETF-ATM2-PVCTRAP-MIB-EXTN.my. MIB version 1 is implemented by default. Use the **snmp-server enable traps atm pvc extension mibversion 1** command or the **no snmp-server enable traps atm pvc extension mibversion 2** command to reenabling this MIB if it was previously disabled with the **snmp-server enable traps atm pvc extension mibversion 2** command.

Use the **snmp-server enable traps atm pvc extension mibversion 2** command to specify the MIB that supports ATM OAM F5 CC and ATM OAM AID/RDI failure notifications. This MIB is defined in the file CISCO-ATM-PVCTRAP-EXTN-MIB.my.

To enable the SNMP notifications that support ATM OAM F5 continuity checking, use the **snmp-server enable traps atm pvc extension** command in global configuration mode. These SNMP notifications are defined in the file CISCO-ATM-PVCTRAP-EXTN-MIB.my, available from the Cisco FTP site at <ftp://ftp.cisco.com/pub/mibs/v2/>.

OAM management and support for OAM F5 continuity checking must be enabled on the PVC by using the **oam-pvc manage cc** command before you can use the ATM OAM continuity check SNMP notifications.

Examples

In the following example, the MIB that supports the SNMP notifications for ATM OAM continuity checking is implemented, and the ATM OAM continuity checking notifications are enabled. Support for end-to-end OAM F5 continuity checking is enabled on PVC 0/1:

```
Router(config)# snmp-server enable traps atm pvc extension mibversion 2
Router(config)# snmp-server enable traps atm pvc extension oam failure aisrdi
Router(config)# snmp-server enable traps atm pvc extension oam failure endcc
Router(config)# snmp-server enable traps atm pvc extension oam failure segmentcc
Router(config)# snmp-server enable traps atm pvc extension oam failure loopback
Router(config)# snmp-server enable traps atm pvc extension up
Router(config)# interface atm 0
Router(config-if)# pvc 0/40
Router(config-if-atm-vc)# oam-pvc manage cc end
```

Related Commands

Command	Description
debug atm oam cc	Displays ATM OAM F5 CC management activity.
oam-pvc manage cc	Configures ATM OAM F5 CC management.
snmp-server enable traps	Enables all available SNMP notifications on your system.
snmp-server enable traps atm pvc	Enables the sending of legacy ATM PVC DOWN traps.
snmp-server enable traps atm pvc extension	Enables the sending of extended ATM PVC SNMP notifications and SNMP notifications for ATM OAM F5 CC, ATM OAM F5 AIS/RDI, and loopback failures.

sscop cc-timer

To change the connection control timer, use the **sscop cc-timer** interface configuration command. To restore the default value, use the **no** form of this command.

sscop cc-timer *seconds*

no sscop cc-timer

Syntax Description	<i>seconds</i> Number of seconds between Begin messages.	
Defaults	1 second	
Command Modes	Interface configuration	
Command History	Release	Modification
	10.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Usage Guidelines	The connection control timer determines the time between transmission of BGN (establishment), END (release), or RS (resynchronization) protocol data units (PDUs) as long as an acknowledgment has not been received.	
Examples	The following example sets the connection control timer 15 seconds: sscop cc-timer 15	
Related Commands	Command	Description
	sscop max-cc	Changes the SSCOP retry count of connection control.

sscop keepalive-timer

To change the keepalive timer, use the **sscop keepalive-timer** interface configuration command. To restore the default value, use the **no** form of this command.

sscop keepalive-timer *seconds*

no sscop keepalive-timer *seconds*

Syntax Description

<i>seconds</i>	Number of seconds the router waits between transmission of POLL PDUs when no sequential data (SD) or SDP PDUs are queued for transmission or are outstanding pending acknowledgments.
----------------	---

Defaults

5 seconds

Command Modes

Interface configuration

Command History

Release	Modification
10.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following example sets the keepalive timer to 15 seconds:

```
sscop keepalive-timer 15
```

sscop max-cc

To change the retry count of connection control, use the **sscop max-cc** interface configuration command. To restore the default value, use the **no** form of this command.

sscop max-cc *retries*

no sscop max-cc

Syntax Description	<i>retries</i>	Number of times that SSCOP will retry to transmit BGN (establishment), END (release), or RS (resynchronization) PDUs as long as an acknowledgment has not been received. Valid range is from 1 to 6000.
---------------------------	----------------	---

Defaults	10 retries
-----------------	------------

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	10.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples	The following example sets the retry count of the connection control to 20: sscop max-cc 20
-----------------	--

Related Commands	Command	Description
	sscop cc-timer	Changes the SSCOP connection control timer.

sscop poll-timer

To change the poll timer, use the **sscop poll-timer** interface configuration command. To restore the default value, use the **no** form of this command.

sscop poll-timer *seconds*

no sscop poll-timer

Syntax Description	<i>seconds</i>	Number of seconds that the router waits between transmission of POLL PDUs.
--------------------	----------------	--

Defaults	100 seconds
----------	-------------

Command Modes	Interface configuration
---------------	-------------------------

Command History	Release	Modification
	10.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	The poll timer controls the maximum time between transmission of POLL PDUs when SD or SDP PDUs are queued for transmission or are outstanding pending acknowledgments.
------------------	--

Examples	The following example sets the poll timer to 15 seconds:
----------	--

```
sscop poll-timer 15
```


sscop receive-window

To change the receiver window, use the **sscop receive-window** interface configuration command. To restore the default value, use the **no** form of this command.

sscop receive-window *packets*

no sscop receive-window

Syntax Description	packets	Number of packets the interface can receive before it must send an acknowledgment to the ATM switch. Valid range is from 1 to 6000.
Defaults	7 packets	
Command Modes	Interface configuration	
Command History	Release	Modification
	10.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Examples	The following example sets the receiver’s window to 10 packets: sscop rcv-window 10	

sscop send-window

To change the transmitter window, use the **sscop send-window** interface configuration command. To restore the default value, use the **no** form of this command.

sscop send-window *packets*

no sscop send-window

Syntax Description

<i>packets</i>	Number of packets the interface can send before it must receive an acknowledgment from the ATM switch. Valid range is from 1 to 6000.
----------------	---

Defaults

7 packets

Command Modes

Interface configuration

Command History

Release	Modification
10.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following example sets the transmitter's window to 10 packets:

```
sscop send-window 10
```

SVC

To create an ATM switched virtual circuit (SVC) and specify the destination network service access point (NSAP) address on a main interface or subinterface, use the **svc** interface configuration command. To disable the SVC, use the **no** form of this command.

svc [*name*] [**nsap** *address*] [**ces**]

no svc [*name*] [**nsap** *address*] [**ces**]

Syntax Description

<i>name</i>	(Optional) The name of the SVC and map. The name can be up to 16 characters long. A name is required when creating passive a CES SVC.
nsap <i>address</i>	(Optional) The destination ATM NSAP address. Must be exactly 40 hexadecimal digits long and in the correct format. See the “Usage Guidelines” section. An NSAP address is required when creating an active CES SVC.
ces	(Optional) Circuit Emulation Service encapsulation. This keyword is available on the OC-3/STM-1 ATM Circuit Emulation Service network module only.

Command Default

No NSAP address is defined.

Command Modes

Interface configuration

Command History

Release	Modification
11.3	This command was introduced.
12.1(2)T	The ces keyword was added to configure CES encapsulation when using the OC-3/STM-1 ATM Circuit Emulation Service network module on Cisco 2600 and Cisco 3600 series platform.
12.1(3)T	This command was modified to allow an SVC to be created without having a specific NSAP address associated with it.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Cisco IOS XE Release 2.3	This command was integrated into Cisco IOS XE Release 2.3.

Usage Guidelines

After configuring the parameters for an ATM SVC, you must exit the interface-ATM-VC or interface-CES-VC configuration mode in order to enable the SVC settings.

Once you specify a *name* for an SVC, you can reenter the interface-ATM-VC or interface-CES-VC configuration mode by simply entering **svc** *name*.

You can remove an NSAP address and any associated parameters by entering **no svc name** or **no svc nsap address**.

Creating an SVC without a specific NSAP address will allow a router to accept calls from any ATM address, and allow multiple VCs to be set up using the same configuration.

Use the **ces** keyword to configure an active or passive CES SVC. An active CES SVC can originate and terminate SVC calls. A passive CES SVC can only terminate calls.

**Note**

Cisco IOS does not support creation of SVCs on a point-to-point interface.

Examples**SVC Example**

The following example creates an SVC called “chicago” on ATM interface 2/0/0:

```
interface atm 2/0/0
  svc chicago
```

SVC with NSAP Address Example

The following example creates an SVC with the name “lion” and specifies the 40-digit hexadecimal destination ATM NSAP address:

```
svc lion nsap 47.0091.81.000000.0040.0B0A.2501.ABC1.3333.3333.05
```

Active CES SVC Example

The following example creates an active CES SVC named “ces1”:

```
interface atm 1/0
  svc ces1 nsap 47.00.00.000000.0040.0B0A.2501.ABC1.01.01.00 ces
```

Passive CES SVC Example

The following example creates a passive CES SVC named “ces2”:

```
interface atm 1/0
  svc ces2 ces
```

transmit-priority

To configure the transmit priority for a virtual circuit (VC), use the **transmit-priority** command in VC configuration mode. To configure the VC or PVC for its default transmit priority, use the **no** form of this command.

transmit-priority *level*

no transmit-priority

Syntax Description	<i>level</i>	Configures the PVC for the specified transmit priority level. The valid range is from 1 to 6. The default value is determined by the VC's configured quality of service (QoS) class, which in turn is determined by the specified ATM interface.
---------------------------	--------------	--

Defaults	Each VC is configured with the default transmit priority for its configured QoS class (see Table 49).
-----------------	--

Command Modes	VC configuration mode
----------------------	-----------------------

Command History	Release	Modification
	11.1(22)CC	This command was introduced for the PA-A3 ATM port adapters.
	12.(0)4	Support was added for the PA-A3 ATM port adapters on Catalyst 5000 family switches with Catalyst RSM/VIP processor card.
	12.0(7)XR	Support was added for the PA-A3 ATM port adapters on Cisco uBR7200 series routers.
	12.1(1)EX	Support was added for the PA-A3 ATM port adapters on Catalyst 6000 family switches with Catalyst 6000 family FlexWAN module.
	12.2(2)T	Support was added for the PA-A3 ATM port adapters on Cisco 7000 and Cisco 7500 series routers using a VIP2-40 or greater processor card.
	12.2(4)	The maximum priority level for the PA-A3 port adapters was increased from 4 to 6, so that the valid range is now 1 to 6.
	12.2(11)YZ	Support was added for the PA-A3 ATM port adapters on Cisco 7300 series routers.
	12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE to support the 2-Port and 4-Port OC-3c/STM-1 ATM SPA and the 1-Port OC-12c/STM-4 ATM SPA shared port adapters on the Cisco 7600 series routers and Catalyst 6500 series switches.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.

Usage Guidelines

By default, permanent virtual circuits (PVC) and switch virtual circuits (SVCs) that are created on PA-A3 ATM port adapters and ATM shared port adapters (SPA) use a default transmit priority level that depends on the VC's or PVC's configured quality of service (QoS) class. [Table 49](#) lists the default transmit priority levels for each type of service class.

Table 49 *Default Transmit Priorities for Each ATM Service Class*

Transmit Priority	Service Category	
	PA-A3-OC3, PA-A3-DS3 Port Adapters	ATM Shared Port Adapter (SPA)
0 (highest)	CBR ¹ , OAM ² cells, and Signaling	Signaling, and OAM and other control cells
1	AAL5 ³ or AAL2 ⁴ VoATM ⁵ (any service category)	CBR when greater than half of the line rate
2	VBR-rt ⁶	CBR when less than half of the line rate
3	VBR-nrt ⁷	Voice traffic
4	ABR ⁸	VBR-rt
5	UBR ⁹	VBR-nrt
6	Not Supported	UBR
7 (lowest)	Not Supported	Unused

1. CBR=Constant Bit Rate
2. OAM=Operation, Administration, and Maintenance
3. AAL5=Asynchronous Transfer Mode Adaption Layer 5
4. AAL2=Asynchronous Transfer Mode Adaption Layer 2
5. VoATM=Voice over ATM
6. VBR-rt=Variable Bit Rate-Real Time
7. VBR-nrt=Variable Bit Rate-Non-Real Time
8. ABR=Available Bit Rate
9. UBR=Unspecified Bit Rate

To change these default transmit priority levels for a particular VC or PVC, use the **transmit-priority** command.

The **transmit-priority** command is not supported in the following cases:

- The PA-A3 ATM port adapters reserve priority 0 (the highest) for CBR traffic and for OAM and other control cells. You cannot change the transmit priority for this traffic. You also cannot configure other service classes for priority 0.
- You cannot use the **transmit-priority** command for VCs on a shaped virtual path (VP) on an ATM SPA
- The PA-A3-OC12 port adapter does not support the **transmit-priority** command.

**Tip**

Use the **show atm pvc** and **show atm svc** commands to display the current transmit priority for a PVC or SVC.

Examples

The following example shows the **transmit-priority** command being used to change the priority for a PVC on a PA-A3 ATM port adapter. The PVC is configured for the VBR-rt service class, which has a default transmit priority level of 2, but the **transmit-priority** command changes the priority level to 3:

```
Router# configure terminal
Router(config)# interface atm 3/0.10
Router(config)# pvc 10/1
Router(config-if-atm-vc)# vbr-rt 48 48
Router(config-if-atm-vc)# transmit-priority 3
Router(config-if-atm-vc)# end
Router#
```

The following example shows the **transmit-priority** command being used to change the priority for a PVC on an ATM SPA. Because the PVC defaults to the UBR service class, its default transmit priority is configured to 6, but the **transmit-priority** command changes the priority level to 4:

```
Router# configure terminal
Router(config)# interface atm 4/1/3
Router(config-if)# pvc 1/100
Router(config-if-atm-vc)# transmit-priority 4
Router(config-if-atm-vc)# end
Router#
```



Note

The maximum configurable transmit priority through VC class is 6, but only on an IMA interface the maximum applicable transmit priority level is 4. If you configure more than the applicable transmit priority, the priority level falls back to the maximum applicable transmit priority.

Related Commands

Command	Description
show atm pvc	Displays the configuration of a particular permanent virtual circuit (PVC).
show atm svc	Displays the configuration of a particular switched virtual circuit (SVC).

tx-limit

To specify the number of transmit buffers for an ATM virtual circuit (VC), use the **tx-limit** command in ATM VC, VC-bundle, VC-class, or VC-range configuration mode. To reset the number of transmit buffers for a particular VC to the default value, use the **no** form of this command.

tx-limit *buffers*

no tx-limit

Syntax Description

<i>buffers</i>	Specifies the number of buffers to be used for this VC. The valid range is 1 to 57343, with a default value that is based on the current VC line rate.
----------------	--

Defaults

Automatically computed from the VC line rate to produce a default latency of 100 milliseconds (or whatever value is specified by the **atm tx-latency** command).

Command Modes

Interface-ATM-VC configuration (for an ATM VC)
 VC-bundle configuration
 VC-class configuration
 VC-range configuration

Command History

Release	Modification
12.2(18)SXE	This command was introduced for the ATM Shared Port Adapters (SPA) on Catalyst 6500 series switches and Cisco 7600 series routers.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.

Usage Guidelines

When you configure a VC on an ATM SPA interface, the Cisco IOS software automatically determines the maximum number of transmit buffers that are needed by the VC for its outgoing traffic. The Cisco IOS software uses both the configured VC line rate and latency value to calculate the number of buffers. Each transmit buffer can contain an ATM cell (53 bytes).

By default, each VC uses the latency value that is specified by the **atm tx-latency** command, which defaults to 100 milliseconds. The maximum number of transmit buffers is then calculated, so that traffic at the maximum VC line rate can still be transmitted within this latency value.

If a particular VC's traffic flow requires a different latency value, use the **tx-limit** command to manually configure the number of transmit buffers for that VC. This allows you to fine-tune the latency value on a per-VC basis, without affecting the other VCs on the interface.



Tip

Use the **atm tx-latency** command to specify the default latency value for all VCs on the interface, and then use the **tx-limit** command to fine-tune the configuration for a particular VC, as needed.

**Note**

The number of buffers can also be affected by the packet size, because each VC is always allowed to transmit at least one packet, regardless of the number of buffers configured with the **tx-limit** command. If the number of buffers specified by the **tx-limit** command is very small, and the VC must transmit a very large packet, the interface can increase the number of buffers for the VC to whatever number can accommodate the packet's size. This means that occasionally, the number of buffers can grow to whatever number can accommodate a packet up to the maximum MTU size.

**Note**

Other ATM interfaces have used the **tx-ring-limit** command to achieve a similar result, but this command is not supported on ATM SPA interfaces, because it does not apply to the SPA architecture.

Examples

The following example shows an ATM VC being configured for a maximum of 500 buffers:

```
Router# configure terminal
Router(config)# interface atm 4/0/0.10 point-to-point
Router(config-subif)# pvc 10/101
Router(config-if-atm-vc)# tx-limit 500
Router(config-if-atm-vc)#
```

The following example shows an ATM VC being reset for its default buffer value, which will be whatever buffer size is needed, at the VC line rate, to produce a default latency of 100 milliseconds (or whatever value is specified by the **atm tx-latency** command):

```
Router# configure terminal
Router(config)# interface atm 3/0/1.10 point-to-point
Router(config-subif)# pvc 10/20
Router(config-if-atm-vc)# no tx-limit
Router(config-if-atm-vc)#
```

Related Commands

Command	Description
atm tx-latency	Specifies the default transmit latency for an ATM Shared Port Adapter (SPA) interface.

ubr

To configure unspecified bit rate (UBR) quality of service (QoS) and specify the output peak cell rate (PCR) for an ATM permanent virtual circuit (PVC), PVC range, switched virtual circuit (SVC), virtual circuit (VC) class, or VC bundle member, use the **ubr** command in the appropriate command mode. To remove the UBR parameter, use the **no** form of this command.

ubr *output-pcr* [*input-pcr*]

no ubr *output-pcr* [*input-pcr*]

Syntax Description

<i>output-pcr</i>	The output peak cell rate (PCR) in kilobytes per second (kbps).
<i>input-pcr</i>	(Optional for SVCs only) The input PCR in kbps. If this value is omitted, the value of <i>input-pcr</i> argument will equal the value of <i>output-pcr</i> argument.

Command Default

UBR QoS at the maximum line rate of the physical interface.

Command Modes

ATM PVC-in-range configuration (for an individual PVC within a PVC range)
 ATM PVP configuration
 ATM PVC range configuration (for an ATM PVC range)
 Bundle-vc configuration (for ATM VC bundle members)
 Interface-ATM-VC configuration (for an ATM PVC or SVC)
 VC-class configuration (for a VC class)

Command History

Release	Modification
11.3T	This command was introduced.
12.0(3)T	This command was enhanced to support selection of UBR QoS and configuration of output PCR for ATM VC bundles and ATM VC bundle members.
12.1(5)T	This command was made available in PVC range and PVC-in-range configuration modes.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Cisco IOS XE Release 2.3	This command was made available in ATM PVP configuration mode.

Usage Guidelines

To configure ATM SVCs with an output PCR and an input PCR that differ from each other, you must expressly configure an output value and an input value using the *output-pcr* and *input-pcr* arguments, respectively.

Configure QoS parameters using the **ubr**, **ubr+**, or **vbr-nrt** command. The last command you enter will apply to the PVC or SVC you are configuring.

If the **ubr** command is not explicitly configured on an ATM PVC, SVC, or VC bundle member, the VC inherits the following default configuration (listed in order of next highest precedence):

- Configuration of any QoS command (**ubr**, **ubr+**, or **vbr-nrt**) in a VC class assigned to the PVC or SVC itself.
- Configuration of any QoS command (**ubr**, **ubr+**, or **vbr-nrt**) in a VC class assigned to the PVC's or SVC's ATM subinterface.
- Configuration of any QoS command (**ubr**, **ubr+**, or **vbr-nrt**) in a VC class assigned to the PVC's or SVC's ATM main interface.
- Global default: UBR QoS at the maximum line rate of the PVC or SVC.

To use this command in VC-class configuration mode, enter the **vc-class atm** global configuration command. This command has no effect if the VC class that contains the command is attached to a standalone VC, that is, if the VC is not a bundle member.

To use this command in bundle-vc configuration mode, first enter the **bundle** command to specify the bundle, then enter bundle configuration mode. Then enter the **pvc-bundle** configuration command to add the VC to the bundle as a member of it and enter bundle-vc configuration mode.

VCs in a VC bundle are subject to the following configuration inheritance rules (listed in order of next highest precedence):

- VC configuration in bundle-vc mode
- Bundle configuration in bundle mode (with the effect of assigned VC-class configuration)
- Subinterface configuration in subinterface mode

Examples

The following example specifies the *output-pcr* argument for an ATM PVC to be 100,000 kbps:

```
pvc 1/32
ubr 100000
```

The following example specifies the *output-pcr* and *input-pcr* arguments for an ATM SVC to be 10,000 kbps and 9000 kbps, respectively:

```
svc lion nsap 47.0091.81.000000.0040.0B0A.2501.ABC1.3333.3333.05
ubr 10000 9000
```

Related Commands

Command	Description
abr	Selects ABR QoS and configures output peak cell rate and output minimum guaranteed cell rate for an ATM PVC or virtual circuit class.
broadcast	Configures broadcast packet duplication and transmission for an ATM VC class, PVC, SVC, or VC bundle.
bump	Configures the bumping rules for a virtual circuit class that can be assigned to a virtual circuit bundle.
bundle	Creates a bundle or modifies an existing bundle to enter bundle configuration mode.
class-int	Assigns a VC class to an ATM main interface or subinterface.
class-vc	Assigns a VC class to an ATM PVC, SVC, or VC bundle member.

Command	Description
encapsulation	Sets the encapsulation method used by the interface.
inarp	Configures the Inverse ARP time period for an ATM PVC, VC class, or VC bundle.
oam-bundle	Enables end-to-end F5 OAM loopback cell generation and OAM management for a virtual circuit class that can be applied to a virtual circuit bundle.
oam retry	Configures parameters related to OAM management for an ATM PVC, SVC, VC class, or VC bundle.
precedence	Configures precedence levels for a virtual circuit class that can be assigned to a virtual circuit bundle and thus applied to all virtual circuit members of that bundle.
protect	Configures a virtual circuit class with protected group or protected virtual circuit status for application to a virtual circuit bundle member.
protocol (ATM)	Configures a static map for an ATM PVC, SVC, VC class, or VC bundle and enables Inverse ARP or Inverse ARP broadcasts on an ATM PVC by either configuring Inverse ARP directly on the PVC, on the VC bundle, or in a VC class (applies to IP and IPX protocols only).
pvc-bundle	Adds a PVC to a bundle as a member of the bundle and enters bundle-vc configuration mode in order to configure that PVC bundle member.
ubr+	Configures UBR QoS and specifies the output peak cell rate and output minimum guaranteed cell rate for an ATM PVC, SVC, VC class, or VC bundle member.
vbr-nrt	Configures the VBR-NRT QoS and specifies output peak cell rate, output sustainable cell rate, and output maximum burst cell size for an ATM PVC, SVC, VC class, or VC bundle member.

ubr+

To configure unspecified bit rate (UBR) quality of service (QoS) and specify the output peak cell rate and output minimum guaranteed cell rate for an ATM permanent virtual circuit (PVC), PVC range, switched virtual circuit (SVC), virtual circuit (VC) class, or VC bundle member, use the **ubr+** command in the appropriate command mode. To remove the UBR+ parameters, use the **no** form of this command.

ubr+ *output-pcr output-mcr [input-pcr] [input-mcr]*

no ubr+ *output-pcr output-mcr [input-pcr] [input-mcr]*

Syntax Description

<i>output-pcr</i>	The output peak cell rate (PCR) in kbps.
<i>output-mcr</i>	The output minimum guaranteed cell rate in kbps.
<i>input-pcr</i>	(Optional for SVCs only) The input PCR in kbps. If this value is omitted, the <i>input-pcr</i> equals the <i>output-pcr</i> .
<i>input-mcr</i>	(Optional for SVCs only) The input minimum guaranteed cell rate in kbps. If this value is omitted, the <i>input-mcr</i> equals the <i>output-mcr</i> .

Defaults

UBR QoS is at the maximum line rate of the physical interface.

Command Modes

Interface-ATM-VC configuration (for an ATM PVC on non-DSL interfaces only or an ATM SVC on non-DSL interfaces only)
 VC-class configuration (for a VC class)
 Bundle-VC configuration (for ATM VC bundle members)
 PVC range configuration (for an ATM PVC range)
 PVC-in-range configuration (for an individual PVC within a PVC range)

Command History

Release	Modification
11.3 T	This command was introduced.
12.0(3)T	This command was enhanced to support selection of UBR+ QoS and configuration of output PCR and output minimum guaranteed cell rate for ATM VC bundles and VC bundle members.
12.1(5)T	This command was made available in PVC range and PVC-in-range configuration modes.
12.4(2)XA	This command was enabled on DSL ATM interfaces.
12.4(6)T	This command was enabled on DSL ATM interfaces.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

To configure ATM SVCs with an output PCR and an input PCR that differ from each other, you must expressly configure an output value and an input value using the *output-pcr*, *output-mcr*, *input-pcr*, and *input-mcr* arguments.

Configure QoS parameters using the **ubr**, **ubr+**, or **vbr-nrt** command. The last command that you enter will apply to the PVC or SVC that you are configuring.

If the **ubr+** command is not explicitly configured on an ATM PVC or SVC, the VC inherits the following default configuration (in order of precedence):

- Configuration of any QoS command (**ubr**, **ubr+**, or **vbr-nrt**) in a VC class assigned to the PVC or SVC itself
- Configuration of any QoS command (**ubr**, **ubr+**, or **vbr-nrt**) in a VC class assigned to the PVC ATM subinterface or SVC ATM subinterface
- Configuration of any QoS command (**ubr**, **ubr+**, or **vbr-nrt**) in a VC class assigned to the PVC main interface or SVC ATM main interface
- Global default: UBR QoS at the maximum line rate of the PVC or SVC

To use this command in VC-class configuration mode, enter the **vc-class atm** global configuration command before you enter the **ubr+** command. This command has no effect if the VC class that contains the command is attached to a standalone VC (meaning a VC that is not a bundle member).

To use this command in bundle-VC configuration mode, enter the **bundle** command to specify the bundle to which the VC member belongs, then enter bundle configuration mode. Finally, enter the **pvc-bundle** bundle configuration command to add the VC to the bundle as a member.

VCs in a VC bundle use the following configuration inheritance rules (in order of next-highest precedence):

- VC configuration in bundle-VC mode
- Bundle configuration in bundle mode (with effect of assigned VC-class configuration)
- Subinterface configuration in subinterface mode

DSL ATM interfaces do not support switched virtual circuits (SVCs).

Examples

The following example configures UBR+ PVC on a DSL line:

```
interface atm 0/0
 pvc 4/100
  ubr+ 2304 2304
```

The following example specifies the *output-pcr* argument for an ATM PVC to be 100000 kbps and the *output-mcr* to be 3000 kbps:

```
pvc 1/32
 ubr+ 100000 3000
```

The following example specifies the *output-pcr*, *output-mcr*, *input-pcr*, and *input-mcr* arguments for an ATM SVC to be 10000 kbps, 3000 kbps, 9000 kbps, and 1000 kbps, respectively:

```
svc lion nsap 47.0091.81.000000.0040.0B0A.2501.ABC1.3333.3333.05
 ubr+ 10000 3000 9000 1000
```

Related Commands	Command	Description
	abr	Selects ABR QoS and configures the output peak cell rate and the output minimum guaranteed cell rate for an ATM PVC or VC class.
	broadcast	Configures broadcast packet duplication and transmission for an ATM VC class, PVC, SVC, or VC bundle.
	bump	Configures the bumping rules for a VC class that can be assigned to a VC bundle.
	bundle	Creates a bundle or enters bundle configuration mode to modify an existing bundle.
	class	Assigns a VC class to an ATM main interface, subinterface, PVC, SVC, VC bundle, or VC bundle member.
	encapsulation	Sets the encapsulation method used by the interface.
	inarp	Configures the InARP time period for an ATM PVC, VC class, or VC bundle.
	oam-bundle	Enables end-to-end F5 OAM loopback cell generation and OAM management for a VC class that can be applied to a VC bundle.
	oam retry	Configures parameters related to OAM management for an ATM PVC, SVC, VC class, or VC bundle.
	precedence	Configures precedence levels for a VC class that can be assigned to a VC bundle and thus applied to all VC members of that bundle.
	protect	Configures a VC class with protected group or protected VC status for application to a VC bundle member.
	protocol (ATM)	Configures a static map for an ATM PVC, SVC, VC class, or VC bundle.
	pvc-bundle	Adds a PVC to a bundle as a member of the bundle and enters bundle-VC configuration mode to configure that PVC bundle member.
	ubr	Configures UBR QoS and specifies the output peak cell rate for an ATM PVC, SVC, VC class, or VC bundle member.
	vbr-nrt	Configures the VBR-NRT QoS and specifies output peak cell rate, output sustainable cell rate, and output maximum burst cell size for an ATM PVC, SVC, VC class, or VC bundle member.
	vbr-rt	Configures variable bit rate real-time for VoATM voice connections.

ubr+ cos

To map the class of service (CoS) value or range of values to an unspecified bit rate plus (UBR+) virtual channel connection (VCC), use the **ubr+ cos** command in LANE QoS database configuration mode. To revert to the default value or range, use the **no** form of this command.

ubr+ cos {*value* | *range*}

no ubr+ cos {*value* | *range*}

Syntax Description

<i>value</i>	A single CoS value.
<i>range</i>	A range of CoS values.

Defaults

The default CoS range for a UBR+ VCC is 4 to 7.

Command Modes

LANE QoS database configuration

Command History

Release	Modification
12.1(2)E	This command was introduced.
12.1(4)E2	This command was modified to include support for the Catalyst 6000 family ATM module and the Catalyst 5000 family ATM module operating in trusted mode.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.

Usage Guidelines

This command is supported only on the router platforms until Cisco IOS Release 12.1(4)E1. In Cisco IOS Release 12.1(4)E1, this command is supported on all platforms running the QoS over LANE feature, with the lone exception of the Catalyst 5000 family ATM module operating in untrusted mode.

All packets matching the specified CoS values are sent on the UBR+ VCC. A single **ubr+ cos** command can be entered in a database. All network services access point (NSAP) addresses in that database use the same mapping. If a different mapping is required, a separate database needs to be created.

You can configure multiple CoS values by entering individual CoS values separated by commas, or by entering a range of CoS values, separated by a hyphen.

Examples

In the following example, the CoS value is mapped to 1 and 3 to 5:

```
Router(lane-qos) # ubr+ cos 1,3-5
```


Related Commands

Command	Description
atm-address	Specifies the QoS parameters associated with a particular ATM address.
lane client qos	Applies a QoS over LANE database to an interface.
lane qos database	Begins the process of building a QoS over LANE database.
show lane qos database	Displays the contents of a specific QoS over LANE database.

vbr-nrt

To configure the variable bit rate-nonreal time (VBR-NRT) quality of service (QoS) and specify output peak cell rate (PCR), output sustainable cell rate (SCR), and output maximum burst cell size for an ATM permanent virtual circuit (PVC), PVC range, switched virtual circuit (SVC), VC class, or VC bundle member, use the **vbr-nrt** command in the appropriate command mode. To remove the VBR-NRT parameters, use the **no** form of this command.

vbr-nrt *output-pcr output-scr output-maxburstsize [input-pcr] [input-scr] [input-maxburstsize]*

no vbr-nrt *output-pcr output-scr output-maxburstsize [input-pcr] [input-scr] [input-maxburstsize]*

Cisco 10000 Series Router

vbr-nrt *output-pcr output-scr output-maxburstsize*

no vbr-nrt *output-pcr output-scr output-maxburstsize*

Syntax Description

<i>output-pcr</i>	The output PCR, in kilobytes per second (kbps).
<i>output-scr</i>	The output SCR, in kbps.
<i>output-maxburstsize</i>	The output maximum burst cell size, expressed in number of cells.
<i>input-pcr</i>	(Optional for SVCs only) The input PCR, in kbps.
<i>input-scr</i>	(Optional for SVCs only) The input SCR, in kbps.
<i>input-maxburstsize</i>	(Optional for SVCs only) The input maximum burst cell size, expressed in number of cells.

Command Default

Unspecified bit rate (UBR) QoS at the maximum line rate of the physical interface is the default.

Command Modes

ATM PVC-in-range configuration (for an individual PVC within a PVC range)
 ATM PVC range configuration (for an ATM PVC range)
 ATM PVP configuration
 Bundle-vc configuration (for ATM VC bundle members)
 Interface-ATM-VC configuration (for an ATM PVC or SVC)
 VC-class configuration (for a VC class)

Command History

Release	Modification
11.3T	This command was introduced.
12.0(3)T	This command was enhanced to support configuration of VBR-NRT QoS and specification of output PCR, output SCR, and output maximum burst cell size for ATM bundles and VC bundle members.
12.0(25)SX	This command was integrated into Cisco IOS Release 12.0(25)SX and implemented on the Cisco 10000 series router.
12.1(5)T	This command was made available in PVC range and PVC-in-range configuration modes.

Release	Modification
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Cisco IOS XE Release 2.3	This command was made available in ATM PVP configuration mode.

Usage Guidelines

Configure QoS parameters using the **ubr**, **ubr+**, or **vbr-nrt** command. The last command you enter will apply to the PVC or SVC you are configuring.

If the **vbr-nrt** command is not explicitly configured on an ATM PVC or SVC, the VC inherits the following default configuration (listed in order of precedence):

- Configuration of any QoS command (**ubr**, **ubr+**, or **vbr-nrt**) in a VC class assigned to the PVC or SVC itself.
- Configuration of any QoS command (**ubr**, **ubr+**, or **vbr-nrt**) in a VC class assigned to the PVC's or SVC's ATM subinterface.
- Configuration of any QoS command (**ubr**, **ubr+**, or **vbr-nrt**) in a VC class assigned to the PVC's or SVC's ATM main interface.
- Global default: UBR QoS at the maximum line rate of the PVC or SVC.

To use this command in VC-class configuration mode, enter the **vc-class atm** global configuration command before you enter the **vbr-nrt** command. This command has no effect if the VC class that contains the command is attached to a standalone VC, that is, if the VC is not a bundle member.

To use this command in bundle-vc configuration mode, enter the **pvc-bundle** configuration command and add the VC as a bundle member.

VCs in a VC bundle are subject to the following configuration inheritance rules (listed in order of precedence):

- VC configuration in bundle-vc mode
- Bundle configuration in bundle mode (with the effect of assigned VC-class configuration)
- Subinterface configuration in subinterface mode

Cisco 10000 Series Router

Input PCR, input SCR, and input maximum burst size (MBS) are not supported.

For Cisco IOS Release 12.2(31)SB2 and later releases, if you set the output PCR and SCR to the same value, the Cisco IOS software allows a maximum burst cell size of 1. For example:

Prior to Cisco IOS Release 12.2(31)SB2

```
interface ATM2/0/0.81801 point-to-point
bandwidth 11760
pvc 81/801
  vbr-nrt 11760 11760 32
  encapsulation aal5snap
  protocol pppoe
```

Cisco IOS Release 12.2(31)SB2 and Later Releases

```
interface ATM2/0/0.81801 point-to-point
bandwidth 11760
pvc 81/801
  vbr-nrt 11760 11760 1
  encapsulation aal5snap
  protocol pppoe
```

Examples

The following example specifies the output PCR for an ATM PVC to be 100,000 kbps, the output SCR to be 50,000 kbps, and the output MBS to be 64:

```
pvc 1/32
  vbr-nrt 100000 50000 64
```

The following example specifies the VBR-NRT output and input parameters for an ATM SVC:

```
svc atm-svc1 nsap 47.0091.81.000000.0040.0B0A.2501.ABC1.3333.3333.05
  vbr-nrt 10000 5000 32 20000 10000 64
```

Related Commands

Command	Description
abr	Selects ABR QoS and configures output peak cell rate and output minimum guaranteed cell rate for an ATM PVC or virtual circuit class.
broadcast	Configures broadcast packet duplication and transmission for an ATM VC class, PVC, SVC, or VC bundle.
bump	Configures the bumping rules for a virtual circuit class that can be assigned to a virtual circuit bundle.
bundle	Creates a bundle or modifies an existing bundle to enter bundle configuration mode.
class-int	Assigns a VC class to an ATM main interface or subinterface.
class-vc	Assigns a VC class to an ATM PVC, SVC, or VC bundle member.
encapsulation	Sets the encapsulation method used by the interface.
inarp	Configures the Inverse ARP time period for an ATM PVC, VC class, or VC bundle.
oam-bundle	Enables end-to-end F5 OAM loopback cell generation and OAM management for a virtual circuit class that can be applied to a virtual circuit bundle.
oam retry	Configures parameters related to OAM management for an ATM PVC, SVC, VC class, or VC bundle.
precedence	Configures precedence levels for a virtual circuit class that can be assigned to a virtual circuit bundle and thus applied to all virtual circuit members of that bundle.
protect	Configures a virtual circuit class with protected group or protected virtual circuit status for application to a virtual circuit bundle member.
protocol (ATM)	Configures a static map for an ATM PVC, SVC, VC class, or VC bundle, and enables Inverse ARP or Inverse ARP broadcasts on an ATM PVC by either configuring Inverse ARP directly on the PVC, on the VC bundle, or in a VC class (applies to IP and IPX protocols only).

Command	Description
pvc-bundle	Adds a PVC to a bundle as a member of the bundle and enters bundle-vc configuration mode in order to configure that PVC bundle member.
ubr	Configures UBR QoS and specifies the output peak cell rate for an ATM PVC, SVC, VC class, or VC bundle member.
ubr+	Configures UBR QoS and specifies the output peak cell rate and output minimum guaranteed cell rate for an ATM PVC, SVC, VC class, or VC bundle member.
vc-class atm	Creates a VC class for an ATM PVC, SVC, or ATM interface, and enters vc-class configuration mode.

vbr-rt

To configure the real-time variable bit rate (VBR) for VoATM voice connections, use the **vbr-rt** command in the appropriate configuration mode. To disable VBR for voice connections, use the **no** form of this command.

vbr-rt *peak-rate average-rate burst*

no vbr-rt

Syntax Description

<i>peak-rate</i>	Peak information rate (PIR) for the voice connection, in kilobytes per second (kbps). If it does not exceed your carrier's line rate, set it to the line rate. Range is from 56 to 10000.
<i>average-rate</i>	Average information rate (AIR) for the voice connection, in kbps.
<i>burst</i>	Burst size, in number of cells. Range is from 0 to 65536.

Command Default

No real-time VBR settings are configured

Command Modes

ATM Bundle-vc configuration for ATM VC bundle members
 ATM PVP configuration for an ATM PVP
 Interface-ATM-VC configuration for an ATM permanent virtual connection (PVC) or switched virtual circuit (SVC)
 VC-class configuration for a virtual circuit (VC) class

Command History

Release	Modification
12.0	This command was introduced on the Cisco MC3810.
12.1(5)XM	This command was implemented on Cisco 3600 series routers and modified to support Simple Gateway Control Protocol (SGCP) and Media Gateway Control Protocol (MGCP).
12.2(2)T	This command was integrated into Cisco IOS Release 12.2(2)T.
12.2(11)T	This command was implemented on the Cisco AS5300 and Cisco AS5850.
Cisco IOS XE Release 2.3	This command was made available in ATM PVP configuration mode.

Usage Guidelines

This command configures traffic shaping between voice and data PVCs. Traffic shaping is required so that the carrier does not discard calls. To configure voice and data traffic shaping, you must configure the peak, average, and burst options for voice traffic. Configure the burst value if the PVC will carry bursty traffic. Peak, average, and burst values are needed so that the PVC can effectively handle the bandwidth for the number of voice calls.

Calculate the minimum peak, average, and burst values for the number of voice calls as follows:

Peak Value

Peak value = (2 x the maximum number of calls) x 16K = _____

Average Value

Calculate according to the maximum number of calls that the PVC will carry times the bandwidth per call. The following formulas give you the average rate in kbps:

- For VoIP:
 - G.711 with 40- or 80-byte sample size:
Average value = max calls x 128K = _____
 - G.726 with 40-byte sample size:
Average value = max calls x 85K = _____
 - G.729a with 10-byte sample size:
Average value = max calls x 85K = _____
- For VoATM adaptation layer 2 (VoAAL2):
 - G.711 with 40-byte sample size:
Average value = max calls x 85K = _____
 - G.726 with 40-byte sample size:
Average value = max calls x 43K = _____
 - G.729a with 10-byte sample size:
Average value = max calls x 43K = _____

If voice activity detection (VAD) is enabled, bandwidth usage is reduced by as much as 12 percent with the maximum number of calls in progress. With fewer calls in progress, bandwidth savings are less.

Burst Value

Set the burst size as large as possible, and never less than the minimum burst size. Guidelines are as follows:

- Minimum burst size = 4 x number of voice calls = _____
- Maximum burst size = maximum allowed by the carrier = _____

When you configure data PVCs that will be traffic shaped with voice PVCs, use AAL5snap encapsulation and calculate the overhead as 1.13 times the voice rate.

Examples

The following example configures the traffic-shaping rate for ATM PVC 20. Peak, average, and burst rates are calculated based on a maximum of 20 calls on the PVC.

```
pvc 20
 encapsulation aal5mux voice
 vbr-rt 640 320 80
```

Related Commands

Command	Description
encapsulation aal5	Configures the AAL and encapsulation type for an ATM PVC, SVC, or VC class.

vc-class atm

To create a virtual circuit (VC) class for an ATM permanent virtual circuit (PVC), switched virtual circuit (SVC), or ATM interface and enter **vc-class** configuration mode, use the **vc-class atm** global configuration command. To remove a VC class, use the **no** form of this command.

vc-class atm *name*

no vc-class atm *name*

Syntax Description

<i>name</i>	Name of your VC class.
-------------	------------------------

Command Default

No VC class is defined.

Command Modes

Global configuration

Command History

Release	Modification
11.3 T	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Cisco IOS XE Release 2.3	This command was integrated into Cisco IOS XE Release 2.3.

Usage Guidelines

If an SVC command (for example, the **idle-timeout** or **oam-svc** command) is applied on a PVC, the command is ignored. This is also true if a PVC command is applied to an SVC.

Examples

The following example creates a VC class named “pvc-qos”.

```
vc-class atm pvc-qos
```